



PowerWedge[®] 20



User's Guide

PSC Inc

959 Terry Street
Eugene, Oregon 97402
Telephone: (541) 683-5700
Fax: (541) 345-7140

Copyright ©2002 PSC Inc. An Unpublished Work - All rights reserved. No part of the contents of this documentation or the procedures described therein may be reproduced or transmitted in any form or by any means without prior written permission of PSC Inc. or its wholly owned subsidiaries ("PSC"). Owners of PSC products are hereby granted a non-exclusive, revocable license to reproduce and transmit this documentation for the purchaser's own internal business purposes. Purchaser shall not remove or alter any proprietary notices, including copyright notices, contained in this documentation and shall ensure that all notices appear on any reproductions of the documentation.

Should future revisions of this manual be published, you can acquire printed versions by contacting PSC Customer Administration. Electronic versions will either be downloadable from the PSC web site (www.pscnet.com) or provided on appropriate media. If you visit our web site and would like to make comments or suggestions about this or other PSC publications, please let us know via the "Contact PSC" page.

Disclaimer

Reasonable measures have been taken to ensure that the information included in this manual is complete and accurate. However, PSC reserves the right to change any specification at any time without prior notice.

PSC is a registered trademarks of PSC Inc. The PSC logo is a trademark of PSC. All other trademarks and trade names referred to herein are property of their respective owners.

This product may be covered by one or more of the following patents: 4603262 • 4639606 • 4652750 • 4672215 • 4699447 • 4709195 • 4709369 • 4749879 • 4792666 • 4794240 • 4798943 • 4799164 • 4820911 • 4845349 • 4861972 • 4861973 • 4866257 • 4868836 • 4879456 • 4939355 • 4939356 • 4943127 • 4963719 • 4971176 • 4971177 • 4991692 • 5001406 • 5015831 • 5019697 • 5019698 • 5086879 • 5115120 • 5144118 • 5146463 • 5179270 • 5198649 • 5200597 • 5202784 • 5208449 • 5210397 • 5212371 • 5212372 • 5214270 • 5229590 • 5231293 • 5232185 • 5233169 • 5235168 • 5237161 • 5237162 • 5239165 • 5247161 • 5256864 • 5258604 • 5258699 • 5260554 • 5274219 • 5296689 • 5298728 • 5311000 • 5327451 • 5329103 • 5330370 • 5347113 • 5347121 • 5371361 • 5382783 • 5386105 • 5389917 • 5410108 • 5420410 • 5422472 • 5426507 • 5438187 • 5440110 • 5440111 • 5446271 • 5446749 • 5448050 • 5463211 • 5475206 • 5475207 • 5479011 • 5481098 • 5491328 • 5493108 • 5504350 • 5508505 • 5512740 • 5541397 • 5552593 • 5557095 • 5563402 • 5565668 • 5576531 • 5581707 • 5594231 • 5594441 • 5598070 • 5602376 • 5608201 • 5608399 • 5612529 • 5629510 • 5635699 • 5641958 • 5646391 • 5661435 • 5664231 • 5666045 • 5671374 • 5675138 • 5682028 • 5686716 • 5696370 • 5703347 • 5705802 • 5714750 • 5717194 • 5723852 • 5750976 • 5767502 • 5770847 • 5786581 • 5786585 • 5787103 • 5789732 • 5796222 • 5804809 • 5814803 • 5814804 • 5821721 • 5822343 • 5825009 • 5834708 • 5834750 • 5837983 • 5837988 • 5852286 • 5864129 • 5869827 • 5874722 • 5883370 • 5905249 • 5907147 • 5923023 • 5925868 • 5929421 • 5945670 • 5959284 • 5962838 • 5979769 • 6000619 • 6006991 • 6012639 • 6016135 • 6024284 • 6041374 • 6042012 • 6045044 • 6047889 • 6047894 • 6056198 • 6065676 • 6069696 • 6073849 • 6073851 • 6094288 • 6112993 • 6129279 • 6129282 • 6134039 • 6142376 • 6152368 • 6152372 • 6155488 • 6166375 • 6169614 • 6173894 • 6176429 • 6188500 • 6189784 • 6213397 • 6223986 • 6230975 • 6230976 • 6237852 • 6244510 • 6259545 • 6260763 • 6266175 • 6273336 • 6276605 • 6279829 • 6290134 • 6290135 • 6293467 • 6303927 • 6311895 • 6318634 • 6328216 • 6332576 • 6332577 • 6343741 • AU703547 • D312631 • D313590 • D320011 • D320012 • D323492 • D330707 • D330708 • D349109 • D350127 • D350735 • D351149 • D351150 • D352936 • D352937 • D352938 • D352939 • D358588 • D361565 • D372234 • D374630 • D374869 • D375493 • D376357 • D377345 • D377346 • D377347 • D377348 • D388075 • D446524 • EP0256296 • EP0260155 • EP0260156 • EP0295936 • EP0325469 • EP0349770 • EP0368254 • EP0442215 • EP0498366 • EP0531645 • EP0663643 • EP0698251 • GB2252333 • GB2284086 • GB2301691 • GB2304954 • GB2307093 • GB2308267 • GB2308678 • GB2319103 • GB2333163 • GB2343079 • GB2344486 • GB2345568 • GB2354340 • ISR107546 • ISR118507 • ISR118508 • JP1962823 • JP1971216 • JP2513442 • JP2732459 • JP2829331 • JP2953593 • JP2964278 • MEX185552 • MEX187245 • RE37166 • Other Patents Pending

Table of Contents

About the PowerWedge 20	1
Models	2
PowerWedge 20	2
PowerWedge 20 Dual	2
Bar Code Symbolologies	3
Input Devices and Connectors	4
Laser/Input Modes	5
Normal Mode	5
Autoscan Mode	5
Multiscan Mode	5
Symbol Blinking Mode	5
Installing the PowerWedge 20	7
Keyboard Wedge Installation	8
Serial Installation	10
Installing Bar Code Readers	13
Installing a Magnetic Stripe Reader (MSR)	14
Installing an Auxiliary Serial Device	15
Programming the PowerWedge 20	17
Predefined Defaults	18
Auto-Learn	19
Menu Programming	21
Entering Values	22
Entering Strings	22
Setting an Autoterminator	22
Bar Code Batch Programming	23
Guidelines for Creating Batch Bar Codes	24
On-Screen Programming	25
Displaying and Printing Current Settings	28
Serial Batch Programming	29
Code 39 and ASCII Equivalents for Serial Characters	31
Cloning	32
General Programming Parameters	34

Serial Programming Parameters	36
Data Type (I.D. #C0)	36
Baud Rate (I.D. #C1)	36
Data Bits (I.D. #C2)	37
Parity (I.D. #C3)	37
Stop Bits (I.D. #C4)	37
Xon/Xoff Handshaking (I.D. #C5)	38
Enable Auxiliary Serial Input (I.D. #C7)	38
Protocol (I.D. #CA)	39
Require Host Response (I.D. #CE)	40
Host-Controlled Indicators (I.D. #CF)	41
Magnetic Stripe Programming Parameters	44

Input Editing..... 45

Creating Qualification Definitions	47
Parameters for Input-Editing Definitions	48
Understanding Output Sequences	51
Using Extra Fields	53
Redirecting Output	54
An Input Editing Example	55
Step 1: Create a Qualification Definition	56
Step 2: Program Extra Fields	58
Step 3: Program the Output Sequence	59

Programming Options..... 60

Programming Bar Codes..... 74


Predefined Defaults	75
Auto-Learn	75
Cloning	76
Code 39	76
Interleaved 2 of 5	78
Matrix 2 of 5	81
Standard 2 of 5	83
Code 11	85
Codabar/Ames	87
MSI	89

Code 93	91
Code 128	92
Labelcode 4/5	94
UPC-A	94
UPC-E	95
EAN/JAN	96
UPC/EAN/JAN Extensions	97
Magnetic Stripe Channels	98
Other Controls	100
Host Device	107
Serial Parameters	108
Full Keyboard Support	112
IBM Terminals	123
Connectors	128
Host Interface Connector	128
Input 1 Connector	130
Input 2 Connector	131
Cloning Cable	132
Technical Support	140
PSC Website Technical Support	140
Reseller Technical Support	140
E-Mail Technical Support	140
Telephone Technical Support	140
PSC Solutions Group	140

About the PowerWedge 20

The PowerWedge 20[®] is a small but powerful fixed-station decoder. It accepts input from a variety of devices, and it recognizes and automatically discriminates among many bar code symbologies.

Figure 1. The PowerWedge 20



Models

The PowerWedge 20 is available in two models.

PowerWedge 20



For installation information, see Installing the PowerWedge 20 on page 7.

NOTE

The PowerWedge 20 standard model (FD-000-20) is a “universal” decoder, because you can use it as either a keyboard wedge or a serial device. When installed as a keyboard wedge, the decoder sends scanned bar code data to your computer as if it were typed on the keyboard. In both types of installation, auxiliary serial communication is supported through a dedicated jack.

PowerWedge 20 Dual

The PowerWedge 20 Dual model (FD-000-22) has all the features of the standard PowerWedge 20, but both input connectors accept data from bar code scanners. (In the standard model, the second input connector accepts only magnetic stripe reader input.)

Bar Code Symbolologies

The PowerWedge 20 recognizes and decodes the following symbolologies:

- Codabar/Ames
- Code 11
- Code 128
- Code 39, including:
 - Extended ASCII
 - MIL-STD-1189
- Code 93
- EAN-8/13
- JAN-8/13
- Labelcode 4/5
- Matrix 2 of 5
- MSI
- Standard 2 of 5
- UPC-A
- UPC-E
- UPC/EAN/JAN extensions



NOTE

The symbolologies listed above were supported at the time this user's guide was written. Additional symbolologies may also be supported, while some of the symbolologies listed may be discontinued. Please contact your dealer or Customer Service for current information.

Input Devices and Connectors

The PowerWedge 20 decodes input from any of the following devices on input connector 1:

- Wands (visible light and infrared)



NOTE

For installation information, see Installing the PowerWedge 20 on page 7.

- Handheld laser scanners
- Handheld charge-coupled device scanners (CCDs)
- Magnetic stripe readers (MSRs)
- I.D. badge readers



NOTE

Input connector 1 can also be used for both input and output of cloning data (see page 32).

The second input connector on both models of the PowerWedge 20 accepts input from a magnetic stripe reader. The PowerWedge 20 can read up to three magnetic stripe tracks simultaneously, and it supports the California driver's license magnetic stripe.

On the PowerWedge 20 Dual, input connector 2 also accepts input from any of the other devices listed above. It does not accept cloning data, however.

Both models of the PowerWedge 20 support auxiliary serial input.

Laser/Input Modes

The PowerWedge 20 can operate in any of the following laser/input modes:

Normal Mode



NOTE

Bar codes for setting laser/input modes are on page 105.

In normal mode, the PowerWedge 20 accepts bar code or magnetic stripe input from all supported types of input devices except serial devices. This is the default setting for the PowerWedge 20's laser/input modes.

Autoscan Mode

Use this mode for stand-mounted lasers. This mode returns the laser to the ready-to-read state immediately after each read.

Multiscan Mode

This mode allows you to scan bar codes without pressing and releasing the trigger for each read. In this mode, the laser or CCD remains in the ready-to-read state for as long as the trigger is held down.

Symbol Blinking Mode

Use this mode for automatic scanning with a Symbol laser mounted on the Symbol IntelliStand.

NOTES

Installing the PowerWedge 20

The PowerWedge 20 comes in two models (see page 2). The model number is printed on the label on the bottom of the unit. Follow the installation procedure for your model.

**NOTE**


The interface cable you need to use with the PowerWedge 20 depends on the type of installation (serial or keyboard wedge) and the type of computer or terminal you are connecting it to. Be sure you have the correct cable before beginning the installation. (Contact your dealer or Customer Service for more information about cables.)

Keyboard Wedge Installation

1. Turn your computer or terminal off, and unplug the keyboard.
2. The largest plug on the cable is labeled with the cable number. Attach that plug to the connector labeled HOST INTERFACE on the PowerWedge 20 (see Figure 2).

Figure 2. Connecting the PowerWedge 20 or Dual

(drawing not to scale)



NOTE

Your computer or terminal may require a different cable than the one shown in the Figure.

On Macintosh computers, the keyboard connectors are called Apple Desktop Bus (ADB) ports. They are marked with the following icon:



3. Attach the small male plug of the cable to the keyboard input jack on the computer or terminal. Attach the female plug of the cable to the keyboard cable or port (see Figure 2). (For cables with telephone-style connectors, attach the cable plug to the computer or terminal, and plug the jack from the keyboard into the socket on the cable connector.)
4. Plug your bar code scanner into the connector labeled INPUT 1 on the PowerWedge 20 (see Figure 1).
5. Move the switch on the PowerWedge 20 to the ON position.
6. Turn on the computer or terminal. The decoder should beep, and the green LED (light-emitting diode) should light up.
7. Scan the programming bar code for the type of computer or terminal you are using. (The bar codes for host devices start on page 107.)

You can now begin using the PowerWedge 20.

Serial Installation



1. Turn your computer or terminal off.
2. One plug on the serial cable is labeled with the cable number. Attach that plug to the jack labeled HOST INTERFA  the PowerWedge 20 (see Figure 3).

Figure 3. Connecting the PowerWedge 20 (or dual) to a Standalone PC

Drawing not to scale



NOTE


Your computer or terminal may require a different cable than the one shown in the Figure.

On Macintosh computers, attach the smaller cable connector to the modem port. The modem port is marked with the following icon:

STAND-ALONE CONFIGURATION Attach the other end of the cable to an available serial port on your computer or terminal (see Figure 3).

EAVESDROP CONFIGURATION Locate the cable that connects your computer or terminal to the host. Unplug that cable from the computer or terminal's serial port, and attach it to the connector labeled **COMPUTER** on the PowerWedge 20 interface cable. Then attach the connector labeled **TERMINAL** on the PowerWedge 20 cable to the computer or terminal's serial port (see Figure 4).

Figure 4. Connecting to a Terminal in a Multiuser System



NOTE

Your computer or terminal may require a different cable than the one shown in the Figure.

Use only a power adapter supplied by your Dealer. Using another adapter can damage the decoder or input device.

3. Attach the small, round plug of the 9-volt power adapter to the power input jack on the PowerWedge 20 (see Figure 1). Plug the other end into an outlet or power strip (preferably one that has surge protection).
4. Plug your bar code scanner into the connector labeled INPUT 1 on the front panel of the decoder box (see Figure 1).
5. Move the switch on the PowerWedge 20 to the ON position (see Figure 1). The decoder should beep, and the green LED (light-emitting diode) should light up.
6. Turn on your computer or terminal.
7. Scan the following label to set the decoder for serial operation:



You can now begin using the PowerWedge 20.



The decoder is set at the factory with the following parameter settings for serial communications. For information about these parameters, see Serial Programming Parameters on page 36.


NOTE

CODE PARAMETER	I.D. #	DEFAULT SETTING
Data type	C0	ASCII
Baud rate	C1	9600
Data bits	C2	8
Parity	C3	None
Stop bits	C4	1
Xon/Xoff handshaking	C5	Off

Installing Bar Code Readers

On the PowerWedge 20 standard model (FD-000-20), INPUT 2 is reserved for magnetic stripe input. Connect your bar code reader to INPUT 1 (see Figure 5).


Figure 5. Input Connectors on the PowerWedge 20 Standard Model



Both connectors on the PowerWedge 20 Dual model (FD-000-22) can accept input from bar code readers. However, INPUT 1 is optimized for bar code input, and INPUT 2 is optimized for magnetic stripe input. If you are using two bar code readers, connect the primary one to INPUT 1 and the other one to INPUT 2 (see Figure 6.) Then scan the following bar code with the primary reader to enable the secondary one:



Figure 6. Input connectors on the PowerWedge 20 Dual



Installing a Magnetic Stripe Reader (MSR)

Both connectors on the PowerWedge 20 and PowerWedge 20 Dual can accept input from magnetic stripe readers. However, INPUT 1 can read only two tracks simultaneously, while INPUT 2 can read up to three tracks simultaneously. Attach your magnetic stripe reader to INPUT 2. If you are using two MSRs, connect the primary one to INPUT 2 and the other one to INPUT 1 (see Figure 5 and Figure 6).

For information about programming parameters for magnetic stripe readers, see Magnetic Stripe Programming Parameters on page 44.

Installing an Auxiliary Serial Device

Both models of the PowerWedge 20 accept auxiliary serial input through a dedicated RJ-11 (telephone-style) jack.

To attach an auxiliary serial device . . .



Be sure you have the correct cable before beginning the installation. (Contact your dealer or Customer Service for information about cables.)

NOTE

1. Install the PowerWedge 20 as described earlier in this section.
2. Attach the RJ plug from the serial cable to the jack labeled AUX SERIAL on the PowerWedge 20 (see Figure 1).
3. Attach the other end of the cable to the output connector on the serial device.
4. With a bar code reader attached to the PowerWedge 20, scan the following bar code to enable auxiliary serial input:



You can now begin using the serial device with the PowerWedge 20.



For more information about auxiliary serial input, see page 38.

NOTE

NOTES

Programming the PowerWedge 20



See Programming Options on page 60 **for the default settings for all code parameters.**

NOTE

The PowerWedge 20 is configured with certain default parameter settings before it is shipped from the factory. These predefined defaults will work for most applications. However, you may need to customize your settings for the specific types of bar codes you will be scanning.

The following methods can be used to program the PowerWedge 20:

- Predefined-default programming—*see page 18*
- Auto-Learn—*see page 19*
- Menu programming—*see page 21*
- Bar code batch programming—*see page 23*
- On-screen programming—*see page 25*
- Serial batch programming—*see page 29*
- Cloning—*see page 32*

Predefined Defaults

The PowerWedge 20 has the following three sets of default parameters:

- **Predefined Default 0 (D0)** turns every on/off parameter off and sets all minimum and maximum lengths to zero (00). Menu programming remains enabled. This default set makes it easy for you to start with everything off and then enable only the bar code symbologies and parameters you wish to use. This can prevent unwanted data entry to your applications.




The host device setting (C0) is not affected by the predefined default sets.

NOTE

- **Predefined Default 1 (D1)** turns every on/off parameter on and sets all maximum lengths as high as possible. It also sets bar code and magnetic stripe preambles and postambles. This default set gives you the best chance of reading an unknown bar code symbology, and it also identifies the bar code type for you.
- **Predefined Default 2 (D2)** is the default set that was installed in the decoder at the factory. This default set meets most users' needs.

You can reset your PowerWedge 20 to one of the predefined default sets by scanning one of the following bar codes:



Auto-Learn

Auto-Learn is the simplest method of customizing the PowerWedge 20. With Auto-Learn, you “teach” the decoder to accept the types of bar codes you use.

The current settings for the PowerWedge 20 remain unchanged unless they are explicitly set during Auto-Learn programming. For example, enabling Code 11 does not affect other symbologies. To disable all symbologies except the ones you want to use, program the decoder to use Pre-defined Default 0 (see page 18) before starting Auto-Learn.

To program the PowerWedge 20 using Auto-Learn . . .




NOTE

The Auto-Learn feature does not affect terminators or checksums. To set them, use one of the other programming methods described in this section.

1. Scan the START bar code below. (The bar code also appears on the bottom of the PowerWedge 20.)



2. Scan a sample of each of your bar code labels. Be sure the decoder beeps after each read. It is important that you scan each type of label (e.g., Code 39, UPC) as well as the smallest and largest bar codes (e.g., 6 characters and 10 characters) that you want the decoder to read.



NOTE

To quit Auto-Learn mode without saving the setup, scan the following bar codes (E first, F second):



3. Save the setup by scanning the bar code labeled E below (or on the bottom of the PowerWedge 20) *twice*. After the first scan, the decoder should beep once and the red LED should flash. After the second scan, the decoder should beep five times and the green LED should be lit.



Menu Programming

This programming method makes use of a “menu” of bar codes found on the bottom of the PowerWedge 20. You can use these bar codes to enter the programming I.D. numbers and settings listed in Programming Options on page 60.

To program the PowerWedge 20 using the bar code menu . . .



NOTE

If you make a mistake or “get lost” while in programming mode, scan the ESC bar code. This will reset the decoder to expect a code I.D. number, ignoring any entries you made since you were last at the base level of programming mode. To quit programming mode without saving any changes, scan the E bar code and then the F bar code.

1. Scan the START bar code on the bottom of the PowerWedge 20.
2. Look in Programming Options on page 60 for the identification number (I.D. #) of the parameter you want to change. Scan the bar codes for the digits of that I.D. number. Then scan the bar codes for the setting you want to make or string you want to enter.
3. For example, the I.D. number for enabling Codabar is 20, and the code for On is 1. So to turn on Codabar, you would scan 2 and 0 (for 20) and then scan 1 (for On). (For other examples, see “Entering Values,” “Entering Strings,” and “Setting an Autoterminator,” below.)
4. After making all your changes, save the setup by scanning the bar code labeled E on the bottom of the PowerWedge 20 *twice*. After the first scan, the decoder should beep once and the red LED should flash. After the second scan, the decoder should beep five times and the green LED should be lit.


Entering Values

To enter a value setting, you must scan two bar codes for the I.D. number and two more for the value. For example, to set a minimum length of 6 for Code 128, you would scan 4 and 1 (for I.D. #41, Code 128 minimum length) and then 0 and 6 (for the value 06).

Entering Strings

To enter a string, look in Full Keyboard Support on page 112 for the ASCII values of the characters you want to enter, and then scan the bar codes for those values. End the string by scanning the bar code for //, which is the end-of-string character.

For example, to include a tab at the beginning of every block of data you read, you would set a bar code preamble by scanning the bar codes for the following characters:



Setting an Autoterminator

An *autoterminator* is an ASCII character that the decoder places at the end of each data transmission. You can use autoterminators to separate input with tabs, carriage returns, punctuation, or other ASCII characters.

To set an autoterminator (I.D. #B1), scan the bar codes for the ASCII value of a single ASCII character with no string terminator (//). For example, to set an autoterminator of CR (carriage return), you would enter B10D. To set no autoterminator, you would enter B100.

Bar Code Batch Programming

The bar code batch method uses bar codes that program the PowerWedge 20 with a single scan. Each batch bar code contains commands to place the decoder into programming mode, set one or more parameters, save the settings, and exit programming mode. When you successfully scan a batch bar code, your decoder programs itself to your settings, beeps five times, and automatically returns to read mode, ready to go to work.

To program the PowerWedge 20 using batch programming . . .



NOTE

To accept batch programming, the PowerWedge 20 must be programmed to use the extended (or full ASCII) Code 39 character set. The decoder was shipped from the factory ready to read the extended character set. If you have changed the default, use the bar code menu or on-screen programming to set I.D. #05 to on.

1. Find the batch bar codes you need in Programming Bar Codes on page 74, or create custom bar codes containing the programming I.D. numbers and parameters you want to set. You can create the bar code with a bar code printing program, a word-processing program, a desktop publishing program, or any other program that can use and print a Code 39 font. See the guidelines below.
2. Use a wand, laser, or CCD connected to the PowerWedge 20 to read the bar codes. The decoder beeps five times when programming is successful. If a bar code contains an invalid programming entry, the decoder beeps twice and ignores the programming instructions in the entire bar code.

Guidelines for Creating Batch Bar Codes

Keep the following in mind when creating bar codes for batch programming:

- Create your programming bar codes using the standard Code 39 character set, *not* the full ASCII character set. (You must read the bar codes in full ASCII Code 39 mode, however.)
- The first and last character of each bar code must be an asterisk (*), the start and stop character for Code 39. (Most label-printing software programs automatically place the asterisks in Code 39 bar codes.)
- The first asterisk of each bar code must be followed immediately by the characters \$+\$. This lets the decoder know that it is reading programming information rather than data.
- Each bar code must end with EE and the final asterisk.
- String data must appear in a programming bar code after the I.D. number for the code parameter. Use two slashes (//) to terminate the string. (Parameters that accept string data include preambles and postambles.)
- You must enter control or “action” characters (for example, tabs, line feeds, or function keys) by encoding their Code 39 equivalents (see Full Keyboard Support on page 112). For example, to enter a horizontal tab, you would include the character pair \$I in the bar code.

The following bar code provides an example of batch programming. Scanning it will turn off the autoterminator and set the maximum length for Interleaved 2 of 5 labels to 15.



Like all Code 39 bar codes, this one starts and ends with an asterisk (*). \$+ starts programming mode. B1 specifies the autoterminator parameter, and %U is the Code 39 equivalent of the null character, which turns it off. 0A specifies the Interleaved 2 of 5 maximum-length parameter, and 15 sets it to 15 characters per label. EE saves the new settings and exits programming mode.

On-Screen Programming

This programming method lets you display programming parameters and settings on your screen. You can select parameters and change their settings using the computer's keyboard.



NOTE

For on-screen programming of either model of the PowerWedge 20 installed with a serial cable, you must use a communications program (such as Pro-comm). Be sure the decoder's serial parameters settings (baud rate, parity, etc.) match the settings of the communications program.

For keyboard wedge installation, on-screen programming is available via cable 00-001-00 for AT-compatible computers, or cable 00-061-00 for PS/2 style computers.

To program the PowerWedge 20 on-screen . . .

1. Open a text editor (for example, the DOS EDIT utility), or go to the DOS prompt.
2. If you are using a text editor, use Courier or another monospaced font. If you are programming from the DOS prompt, type copy con nul and press **Enter**.
3. Move the switch on the PowerWedge 20 to the PRGM position (see Figure 1), and then press the **Enter** key on your keyboard. The decoder should beep three times, and the on-screen programming menu should appear on your screen, as shown in Figure 7. The menu is arranged in categories and subcategories identified by numbers and letters. Two or more categories or subcategories can share a single number or letter; for example, Code 39 and Interleaved 2 of 5 both use 0 (zero). The last line of the menu prompts you for input.

Figure 7. Main Menu for On-Screen Programming

```
***** POWERWEDGE 20 VER 1.X MAIN MENU *****  
  
BAR CODEMAG. STRIPECOMMUNICATIONS  
-----  
0 CODE394 CHANNEL 1 & 2C HOST SELECTION  
0 I2of55 CHANNEL 3C SERIAL OPTIONS  
1 M2of55 CA DL CONVERT  
1 S2of5INPUT EDITINGD DEFAULTS  
1 CODE116 EXTRA FIELDSD MORE CONTROLS  
2 CODABAR/AMES7 DEFINITION 1  
2 MSI8 DEFINITION 2E SHOW/EXIT  
3 UPC-A9 DEFINITION 3E CLONING  
3 UPC-EA DEFINITION 4  
3 EAN/JANA ALLOW QUAL ONLY  
4 CODE128B OTHER CONTROLS  
5 LCODE-4/55 SYMBOLOGY IDS  
USE BACKSPACE TO EXIT MODES  
(0-E):
```

4. Type the I.D. of the category or subcategory you want to display or change, and press **Enter**. For example, enter 2 to display the current parameter settings for Codabar bar codes. This will also display the parameters and settings for the other symbologies having 2 as an I.D., as shown in Figure 8.

Figure 8. On-Screen Programming Options

```

CODABAR /Ames
0 ENABLE=1
1 MIN LENGTH=04
2 MAX LENGTH=20
3 TRANSMIT START/STOP=0
4 CODABAR TO CLSI CONVERSION=0
5 INTERCHARACTER GAP CHECK=0
MSI
6 ENABLE=0
7 MIN LENGTH=04
8 MAX LENGTH=10
9 2ND CHECKSUM REQUIRED=0
A 2ND CHECKSUM MOD 11=0
B TRANSMIT CHECKSUM=0
CODE93
C ENABLE=1
D MIN LENGTH=02
E MAX LENGTH=20
(0-B) :

```

Notice that the parameters in this list are also identified by numbers and letters. The value following the equals sign (=) in each line is the current setting for that parameter (0 means off, and 1 means on). The last line is the input prompt.



NOTE

To return to the previous menu level, press the **Backspace** key on your keyboard.

5. Type the I.D. of the parameter whose setting you want to change, and press **Enter**. A prompt will display the valid settings for the parameter in parentheses and separated by a “pipe” character (|), as shown in the following example:

```
ENABLE CODABAR/AMES (0|1):
```

6. Type the setting you want to use, and press **Enter**. The list of options will be redisplayed to verify the change you made.
7. Select another option from the list, or press the **Backspace** key to return to the main menu.



To leave on-screen programming without saving any changes, type **EF** and press **Enter**.

NOTE

8. When you are finished checking or changing parameter settings, type **EE** at the prompt and press **Enter**. This will save your changes and exit on-screen programming.
9. Press **Ctrl+Z** to return to the DOS prompt.

Displaying and Printing Current Settings

While you are in on-screen programming mode, you can display the current settings for all the parameters. At the main menu prompt, type **E** and press **Enter**, and then type **D** and press **Enter** again. At the next prompt (ECHO SETTINGS TO SCREEN), type **1** and press **Enter**. A list of all the parameters will appear on your screen. You can pause the display of the list at any time by pressing the **PAUSE** key on your keyboard; then press any key to continue the display.

If you are using a text editor, you can use commands in the editor's menu to print the list of settings or save it to a file. If you are working from the DOS prompt, you can also save or print the list of settings. To print or save the list, follow steps 1 through 9 above, with the following changes in step 2:

- To print the list, use the following command: `copy con prn`.
- To save the list as a file, use the following command: `copy con filename`.

Serial Batch Programming

The serial batch method of programming involves creating an ASCII file of programming commands and then transmitting the ASCII file to the PowerWedge 20. The decoder's serial parameter settings must match the host's settings, and the setting for start-program enable (I.D. #B0) must be either 01 or 03.

Follow these guidelines when creating ASCII files for serial batch programming:

- The first line of the file must begin with \$+\$. This is the decoder's "trigger" to enter programming mode.
- Valid characters for the first character in a line (except the first line) are programming variables or a semicolon.
- A semicolon as the first character in a line indicates the beginning of a comment. A semicolon anywhere else in a string is treated as a normal character. An end-of-line character (CR or CR/LF) marks the end of the comment. (Comments contain information useful to you or anyone else reading the file. They have no effect on the decoder.)
- Data must appear in a line in a specific order: the programming I.D. number for the parameter followed by a value for the parameter setting. If the parameter type is a string, the string characters must be followed by two slashes (//) to terminate the string. (You can use strings as values for preambles, postambles, and extra fields in input editing.)



NOTE

For Code 39 and ASCII equivalents for serial characters, see Table 1.

- You must enter control or "action" characters (for example, tabs, line feeds, or function keys) as a "mnemonic" word enclosed in parentheses (see Full Keyboard Support on page 112). For example, to enter a horizontal tab, you would type (TABR).

- The file must end with EE followed by an end-of-line character (CR or CR/LF) for the programming changes to be saved and the decoder to exit programming mode.

The following is an example of an ASCII file used for serial batch programming:

```
$+${-
;This is a file example with comments
;The first line started programming mode
;Use predefined default D0
D0
;Enable Code 39--00 is Code 39 enable/dis-
able,
; 1 = enable
001
;Set Code 39 minimum length (01) TO 4 (04)
0104
;Set postamble (B7) to a right tab
B7(TABR)//
;Save changes and exit programming mode
EE
```

The last line of the file is blank, because a carriage return ended the line before it.

The following example would have the same results when used to program the decoder:

```
$+${-D00010104B7(TABR)//EE
```

Code 39 and ASCII Equivalents for Serial Characters

Table 1 provides Code 39 and ASCII equivalents for serial characters. For Code 39, ASCII, and mnemonic equivalents of keyboard keys, See “Full Keyboard Support” on page 112.

Table 1. Code 39 and ASCII Equivalents for Serial Characters

Character	Code 39	ASCII Value	Character	Code 39	ASCII Value	Character	Code 39	ASCII Value
NUL	%U	80	VT	\$K	0B	SYN	\$V	16
SOH	\$A	01	FF	\$L	0C	ETB	\$W	17
STX	\$B	02	CR	\$M	0D	CAN	\$X	18
ETX	\$C	03	SO	\$N	0E	EM	\$Y	19
EOT	\$D	04	SI	\$O	0F	SUB	\$Z	1A
ENQ	\$E	05	DLE	\$P	10	ESC	%A	1B
ACK	\$F	06	DC1	\$Q	11	FS	%B	1C
BEL	\$G	07	DC2	\$R	12	GS	%C	1D
BS	\$H	08	DC3	\$S	13	RS	%D	1E
HT	\$I	09	DC4	\$T	14	US	%E	1F
LF	\$J	0A	NAK	\$U	15	Terminate string: //		

Cloning

Cloning is a way to copy the setup from one PowerWedge 20 to another. Once you have programmed the first PowerWedge 20, you can use it as a master to turn other PowerWedge 20s into clones of the first one.

To program the PowerWedge 20 using cloning . . .



NOTE

If you are using a PowerWedge 20 Dual as the master for cloning, you can connect the bar code reader to INPUT 2. The cloning cable, however, must be connected to INPUT 1.

1. Connect a bar code reader to the connector labeled INPUT 1 on the programmed PowerWedge 20 (the “master”), and set the On/Off/Program switch to the ON position (see Figure 1).
2. Scan the following bar code:



NOTE

Cloning will work only if the master and slave are the same model. For example, you cannot use a PowerWedge 20 Dual as the master and a standard PowerWedge 20 as the slave.

You can also use the bar code menu on the bottom of the PowerWedge 20 to enter cloning mode. Scan the labels for START, E, and C, in that order.

To make your own cloning cable, see the pinout diagram on page 132.

This puts the programmed PowerWedge 20 into cloning mode. While the decoder is in cloning mode, the red and green light-emitting diodes (LEDs) alternate flashing twice (that is, the flashing sequence is green-green-red-red, green-green-red-red, and so on).

3. Remove the bar code reader from the master, and connect the cloning cable (part number 00-874-25) to INPUT **1** on the master.
4. The PowerWedge 20 that you want to program is called the “slave.” Set the On/Off/Program switch on the slave to the OFF position.
5. Connect the free end of the cloning cable to INPUT **1** on the slave.
6. Set the On/Off/Program switch on the slave to the PRGM position.

The parameter settings from the master PowerWedge 20 will immediately be copied into the slave. The slave will indicate successful programming by beeping three times and repeatedly flashing its green LED twice.

7. Turn the slave off and disconnect the cable from it.
8. Repeat steps 4 through 7 to make additional clones.

General Programming Parameters

Table 2 describes some of the general parameters for programming the PowerWedge 20. Page references indicate where to find bar codes for setting the parameters. For descriptions of serial parameters, see page 36. For information about magnetic stripe programming parameters, see page 44. For a complete list of parameters and defaults, see Programming Options on page 60.

Table 2. General programming parameters for the PowerWedge 20

I.D. #	PARAMETER	DESCRIPTION
05	Code 39 full ASCII (page 77)	Supports the Code 39 extended ASCII character set (see Full Keyboard Support on page 112). For example, a character string encoded in Code 39 as +A is transmitted as a lowercase a. This allows every key of the keyboard to be encoded in a Code 39 bar code.
25	Codabar wide intercharacter gaps (page 89)	Allows reading of Codabar bar codes printed with large gaps between characters.
33, 36	UPC conversion (starting on page 95)	Converts UPC-A bar codes to EAN-13 (I.D. #33), and converts UPC-E bar codes to UPC-A (I.D. #36).
3C– 3E	UPC/EAN/JAN extensions (starting on page 97)	Reads two-digit (I.D. #3C) and five-digit (I.D. #3D) extensions if the decoder is programmed to allow them. Doesn't read UPC, EAN, or JAN bar codes if the decoder is programmed to <i>require</i> extensions (I.D. #3E) and no extensions are present.
B1	Autoterminator (page 100)	Appends an ASCII character to each transmission. You can program the ASCII value for any single character (see Full Keyboard Support on page 112). The factory default is a carriage return (the Enter key). Programming a value of 00 disables the autoterminator so that the decoder transmits only the bar-coded data.
B2	ASCII capital to lowercase (page 100)	Changes scanned capital letters to lowercase (or lowercase to uppercase if your caps lock is enabled).

Table 2. General programming parameters for the PowerWedge 20

I.D. #	PARAMETER	DESCRIPTION
B3	Intercharacter delay (page 101)	Adds 1 to 99 milliseconds between transmissions of ASCII characters. Use a larger number if characters are omitted when transmitted to the host.
B4	CCD/laser redundancy (page 101)	Requires charge-coupled devices (CCDs) and lasers to obtain two identical reads in a row before transmitting the decoded data. This is an error-checking feature. Only one read's worth of data is transmitted.
B5	Symbology identifiers (page 101)	Precedes the encoded data with a character identifying the type of bar code (see page 68).
B6, DA B7, DB	Preamble Postamble	Precedes data with a preamble (I.D. #B6 or DA) or appends a postamble (I.D. #B7 or DB). Enter a character string ending with //. (I.D. numbers DA and DB are for the second bar code scanner on the Dual model.)
B8– BC	Beeper (page 102)	Controls the decoder's beeper. You can select one of eight pitches for the decoder's good-read beeps (I.D. #B8) and program the number of beeps (I.D. #B9), the duration of each beep (I.D. #BA), and the beep volume (I.D. #BC). You can enable an end-of-transmission beep (I.D. #BB) to indicate that the decoder is ready to scan again.
BF	Numeric keypad (page 103)	Transmits numeric keypad values instead of the number keys in the top row of the keyboard. (Some applications recognize a difference between a number typed on the top row of the keyboard and the same number typed on the keyboard's numeric keypad.)
C0	Host device (page 107)	Identifies the host computer type. This setting is not affected by the predefined defaults (D0–D2).

Serial Programming Parameters

You can use batch programming to set serial parameters for both models of the PowerWedge 20. This section describes the parameters; bar codes for setting them begin on page 108. (For a complete listing of parameters and defaults, see Programming Options on page 60.)

Data Type (I.D. #C0)



Bar codes for setting data type are on page 108.

NOTE

This parameter determines the data content transmitted to or received from the host. The ASCII setting transmits and receives the standard ASCII character set (with the exception of the null character, ASCII 00h, which is received as 80h). The PC SCAN CODES setting transmits the press-and-release codes for the keys on a PC keyboard.

Baud Rate (I.D. #C1)



Bar codes for setting baud rate are on page 109.

NOTE

This parameter determines the communication speed. The setting you use for the decoder must match the setting that the host uses.

Data Bits (I.D. #C2)



Bar codes for setting data bits are on page 109.

NOTE

This parameter specifies the number of data bits in each character.

Parity (I.D. #C3)



Bar codes for setting parity are on page 110.

NOTE

This parameter specifies the parity of the data characters.

Stop Bits (I.D. #C4)



Bar codes for setting stop bits are on page 110.

NOTE

This parameter selects the minimum space between data characters.

Xon/Xoff Handshaking (I.D. #C5)



Bar codes for setting this parameter are on page 110.

NOTE

This parameter is used for software data-flow control. The host can send the Xon character (ASCII 11h) to allow transmission and send the Xoff character (ASCII 13h) to stop transmission.

Enable Auxiliary Serial Input (I.D. #C7)



Bar codes for setting this parameter are on page 110.

NOTE

This parameter is used to let the decoder know if it is going to send data received at the auxiliary serial input jack to the host. This allows data from a serial ASCII output device (for example, a scale or voice-input device) to pass through the decoder and appear to the host as if it had been typed in at the keyboard.

Each auxiliary serial data record input can be up to 125 characters long (including the end-of-record character). You can edit auxiliary serial data just as if the data came from bar codes or magnetic stripes (see Input Editing on page 45).



The decoder will not accept bar code or magnetic stripe data while it receives data from the auxiliary device.

NOTE

Since host keyboard interfaces are slower than most serial devices, the decoder buffers (stores) the data as much as it can. The decoder will try to stop the auxiliary device's data transmission by signaling on the hardware-handshake-out line (pin 5 of the auxiliary serial interface cable's connector).

It is very important that your auxiliary device support hardware handshaking or ACK/NAK protocol if you plan to transmit large files through the auxiliary port. The decoder will transmit data when the Clear to Send (CTS) signal is high and will not transmit data when the CTS signal is low. Since the CTS input has an internal pullup, no connection is required if transmission does not need to be controlled. The decoder can receive data when the Ready to Send (RTS) signal is high and will not receive data when the signal is low.

Protocol (I.D. #CA)



NOTE

Bar codes for setting protocol are on page 111.

This parameter specifies the format of the data records (groups of data characters) transmitted and received.

In *EOR-only* protocol, a record consists of data characters followed by the end-of-record (EOR) character. (The Xon/Xoff command characters are received with no EOR character appended.) When the protocol parameter is set to 00 (EOR only), the data records are received according to both the EOR-character (I.D. #CC) and timeout (I.D. #CD) settings. Records received with the EOR character appended are processed immediately. If the timeout setting is between 01 and 99 (10 to 990 milliseconds), then the data is processed if either an EOR character is received or a timeout occurs.

In *ACK/NAK* protocol, a record consists of data characters followed by the end-of-record (EOR) character and a check character. This protocol transmits and receives ASCII ACK/NAK (ACK = 06h, NAK = 15h) characters for data integrity control.

A data record must have an EOR character and a check character (mod 256 sum of all data characters and the EOR character) appended to be considered good. (The EOR-character setting, I.D. #CC, cannot be 00.) If the record is good, an ACK character is transmitted to inform the host that the data arrived successfully. If the record is bad, a NAK character is transmitted to the host.

If the NAK character is received or a timeout occurs, the data record is retransmitted. Up to ten attempts will be made. If a communications error occurs, a nine-beep error signal is issued and the decoder is reset.

The interfunction delay setting (I.D. #BE; the default is 00) determines the delay between the receipt of the data record and the transmission of the ACK/NAK response. The length of time the decoder will wait before checking for a valid record after each character is received is determined by the timeout setting. If the timeout setting is between 01 and 99, the delay is between 10 milliseconds and 990 milliseconds; if the timeout setting is 00, the delay is 2.55 seconds.

Require Host Response (I.D. #CE)



NOTE

Bar codes for setting this parameter are on page 111.

Host response records can be either host-controlled indicator records (see below) or serial batch programming records (see page 28). If this parameter is set to on, the decoder will wait after sending a packet of data, and the host must respond with a host-controlled indicator record before the decoder can continue decoding.

Host-Controlled Indicators (I.D. #CF)



Bar codes for enabling and disabling host-controlled indicators are on page 111.

NOTE

Host-controlled indicator (HCI) data consists of special ASCII records either transmitted to the decoder through the serial communications interface or sent to the system through output redirection (see *Redirecting Output* on page 54). Turning this parameter setting to on provides the host with a method to indicate, through the serial port, the status (good or bad) of a read by changing the light-emitting diode (LED), sounding the beeper, or both. You can also use HCI to include delays between LED and beep events. The decoder can receive up to 125 bytes of control data.

The host-controlled data can be sent from the host at any time. After a bar code or magnetic stripe has been read successfully, the red LED on the decoder lights up, the decoder beeps (unless the volume setting is 0), and the data is sent to the host. If the require-host-response parameter is set to on, the decoder will wait for the host to respond with a valid packet of data before returning to reading bar code or magnetic stripe input.

Table 3 lists HCI command assignments. All commands are human-readable ASCII characters. An example of a host-controlled indicator command block appears after the table.

Table 3. Host-Controlled Indicator Commands

TYPE	COMMAND	MEANING
Delay (control character <i>D</i> followed by one to three numeric characters from 0 through 254, representing 10-millisecond increments)	D0	No delay
	D1	10-millisecond delay
	D254	2,540-millisecond delay
Beep volume (control character <i>B</i> followed by one numeric character from 0 through 3)	B0	Off
	B1	Low
	B2	Medium
	B3	Loud
Beep tone (control character <i>T</i> followed by one numeric character from 0 through 7)	T0	2400Hz
	T1	2618Hz
	T2	2880Hz
	T3	3200Hz
	T4	3600Hz
	T5	3840Hz
	T6	4114Hz
	T7	4430Hz
LED (control character <i>L</i> followed by one numeric character from 0 through 2)	L0	Off
	L1	Red
	L2	Green
CTRL high/low for pin 10 on 25-pin connector (control character <i>C</i> followed by 0 or 1)	C0	Low
	C1	High

The following example of a host-controlled indicator command block will set the decoder's tone to 3840Hz, turn the beeper on at full volume, turn the green LED on, wait 50 milliseconds, turn the green LED off, wait 50 milliseconds, turn the green LED on again, wait 50 milliseconds, turn the LED off, wait 50 milliseconds, and turn the beeper off:

```
T5B3L2D5L0D5L2D5L0D5B0
```

Magnetic Stripe Programming Parameters

Table 4 describes the options for programming the magnetic stripe channels for both models of the PowerWedge 20. Each of the options works with any channel. Bar codes for setting these parameters begin on page 98. (For a complete listing of parameters and defaults, see Programming Options on page 60.)

Table 4. Magnetic Stripe Parameters for the PowerWedge 20

I.D. #			PARAMETER	DESCRIPTION
CH. 1	CH. 2	CH. 3		
44	4A	54	Enable	Allows the decoder to accept data on the enabled channel or channels.
45	4B	55	Required	Specifies that the channel must have valid data before <i>any</i> channel's data will be transmitted.
48 49	4E 4F	58 59	Preamble Postamble	Can be used to identify which channel data is entering from. Preambles and postambles assigned to bar code data are ignored when magnetic stripe data is transmitted.
5A	5A	5A	Auxiliary serial and magnetic stripe symbology identifiers	Identifies which track the magnetic stripe data comes from or whether it comes from auxiliary serial input.
5B	5B	5B	Bar code symbology identifiers	Identifies the bar code symbology in which the data is encoded.
5C	5C	5C	California DL/ID alpha conversion	Can be used to convert the seventh and eighth characters of the California driver's license identification to their alphanumeric equivalents.

Input Editing

The PowerWedge 20 gives you the ability to modify input from bar code scanners, magnetic stripe readers, auxiliary serial devices, and keyboards. This feature is known as *input editing*.

With input editing, you program the decoder to change the format of the input data before it sends the data to your computer or terminal. You can program your decoder for input editing using any programming method (see Programming the PowerWedge 20 on page 17).

Table 5 shows just a few of the many uses for input editing.

Table 5. Examples of Input Editing

By programming the decoder to ...	You can change this ...	To this ...
Delete the first three characters of each string	A0037066 A0037067	37066 37067
Separate the input into two fields separated by a space	A0037066 A0037067	A 0037066 A 0037067 <i>or</i> A003 7066 A003 7067
Separate the input into three fields separated by dashes	A0037066 A0037067	A-003-7066 A-003-7067
Rearrange the order of the fields	A0037066 A0037067	0037066A 0037067A
Separate the input into fields separated by commas and rearrange the order of the fields	A0037066 A0037067	7066,A003 7067,A003
Add text to the data	A0037066 A0037067	Ser. #A0037066 Ser. #A0037067 <i>or</i> A0037066 Jan/95 A0037067 Jan/95

Input editing overrides standard preamble and postamble settings. Programmed preambles and postambles will be attached only to data input that doesn't qualify for editing (see the next section).

Creating Qualification Definitions

To qualify for input editing, the data that enters the decoder must meet certain criteria that you define. For example, you may require the data to be Code 39, to have exactly ten numbers or letters, and to end with an X. These criteria make up a *qualification definition*. Any input that meets all the criteria for a definition will be edited according to the parameters that you set for it and output in the format that you specify.

You can create up to four different qualification definitions for input editing. The definitions are numbered 1 through 4, and each definition has its own set of I.D. numbers for programming parameters (see Table 6).

Parameters for each definition include the following:

- **Symbology** This specifies whether the data must be of a particular bar code type or come from a specific magnetic stripe channel, an auxiliary serial device, or keyboard input. Only data of the designated symbology can be considered for qualification. (This parameter can also be set to consider *any* input regardless of symbology or source.)
- **Record length** This specifies what length (from 1 through 99 characters) the data must be. Only data of the designated length will be considered. (This parameter can also be set to consider data of *any* length.)
- **Number of input fields** This specifies into how many fields (from 1 through 8) the input data will be broken down. Each field can then be defined as a specific number of characters (or *any* number of characters) beginning with a specific character (or *any* character).
- **Output sequence** This specifies the order in which to output the defined fields. The output sequence can also include additional information, such as symbology identifiers, preambles, postambles, or up to 16 extra fields that contain text strings. These extra fields are numbered 0 through 9 and A through F; each field has its own programming I.D. number. (For more information about output sequencing, see Understanding Output Sequences on page 51.)

When data is read, the decoder processes the definitions in numerical order. If the input data qualifies under definition 1, the decoder edits and outputs the data; if the data does not qualify under definition 1, the decoder tries definition 2. The process continues in order through all four definitions, and the data is edited according to the first definition under which it qualifies; the other definitions are not used. If the data doesn't qualify under any of the four definitions, then the decoder outputs the data without editing it.



NOTE

If the “allow qualified data only” parameter (I.D. #AD) is enabled, no data will be output unless it qualifies under one of the definitions.

Parameters for Input-Editing Definitions

Table 6 lists I.D. numbers and predefined defaults for parameters for input-editing definitions 1 through 4. You can change your decoder's settings for these parameters using the bar code menu, bar code batch, serial batch, or on-screen method of programming.

Table 6. Input Editing Parameters

PARAMETER	I.D. #	TYPE	PREDEFINED DEFAULTS		
			D0	D1	D2
Definition 1			<i>Enter 1 for On and 0 for Off.</i>		
Enable	70	On/Off	Off	On	Off
Symbology (<i>0 = any; for other values, see I.D. #B5 on page 52</i>)	71	Value	0	C	0
Record length (<i>01–99, or 00 for any</i>)	72	Value	00	00	00

Table 6. Input Editing Parameters (Continued)

PARAMETER	I.D. #	TYPE	PREDEFINED DEFAULTS		
			D0	D1	D2
Number of fields (01–08)	73	Value	01	05	01
Fields 1–8 (length followed by qualifier; 00 = any length; (00) = any qualifier)					
Field 1	74	Field	00(00)	00(00)	00(00)
Field 2	75			01!	
Field 3	76			00(00)	
Field 4	77			01=	
Field 5	78			03(00)	
Field 6	79			00(00)	
Field 7	7A			00(00)	
Field 8	7B			00(00)	
Output sequence (see Table 7)	7C	String	//	*	//
<i>*60610561036201B1// (see Understanding Output Sequences on page 51, for explanation)</i>					
Definition 2			<i>Enter 1 for On and 0 for Off.</i>		
Enable	80	On/Off	Off	Off	Off
Symbology (0 = any; for other values, see I.D. #B5 on page 52)	81	Value	0	0	0
Record length (01–99, or 00 for any)	82	Value	00	00	00
Number of fields (01–08)	83	Value	01	01	01
Fields (length followed by qualifier; 00 = any length; (00) = any qualifier)					
Field 1	84	Field	00(00)	00(00)	00(00)
Field 2	85				
Field 3	86				
Field 4	87				
Field 5	88				
Field 6	89				
Field 7	8A				
Field 8	8B				
Output sequence (see Table 7)	8C	String	//	//	//

Table 6. Input Editing Parameters (Continued)

PARAMETER	I.D. #	TYPE	PREDEFINED DEFAULTS		
			D0	D1	D2
Definition 3					
<i>Enter 1 for On and 0 for Off.</i>					
Enable	90	On/Off	Off	Off	Off
Symbology (0 = any; for other values, see I.D. #B5 on page 52)	91	Value	0	0	0
Record length (01–99, or 00 for any)	92	Value	00	00	00
Number of fields (01–08)	93	Value	01	01	01
Fields (length followed by qualifier; 00 = any length; (00) = any qualifier)					
Field 1	94	Field	00(00)	00(00)	00(00)
Field 2	95				
Field 3	96				
Field 4	97				
Field 5	98				
Field 6	99				
Field 7	9A				
Field 8	9B				
Output sequence (see Table 7)	9C	String	//	//	//

Table 6. Input Editing Parameters (Continued)

PARAMETER	I.D. #	TYPE	PREDEFINED DEFAULTS		
			D0	D1	D2
Definition 4 <i>Enter 1 for On and 0 for Off.</i>					
Enable	A0	On/Off	Off	Off	Off
Symbology (0 = any; for other values, see I.D. #B5 on page 52)	A1	Value	0	0	0
Record length (01–99, or 00 for any)	A2	Value	00	00	00
Number of fields (01–08)	A3	Value	01	01	01
Fields (length followed by qualifier; 00 = any length; (00) = any qualifier)					
Field 1	A4	Field	00(00)	00(00)	00(00)
Field 2	A5				
Field 3	A6				
Field 4	A7				
Field 5	A8				
Field 6	A9				
Field 7	AA				
Field 8	AB				
Output sequence (see Table 7)	AC	String	//	//	//
Allow qualified data only	AD	On/Off	Off	Off	Off

Understanding Output Sequences

An output sequence does not contain any text that will actually be output; it contains pointers to fields, which may contain input data or text strings. For example, you cannot include a comma in an output sequence; instead, you must include the output-sequence value of the field containing a comma.

An output sequence can also contain autoterminators, preambles, and postambles. Each field and other type of information is assigned a specific value (either the field number or letter, or the parameter I.D. number) for inclusion in the output sequence (see Table 7).

Each output sequence must end with an end-of-string character (//).

Each input editing definition has its own output sequence with its own I.D. number. The order of the values in the output sequence determines the order in which the field contents and other information will appear in the output. If a field is not included in the output sequence, its contents will be stripped from the data during input editing.

Table 7. Output Sequence Settings

TYPE OF INFORMATION	VALUE USED IN OUTPUT SEQUENCE	ACTUAL OUTPUT
Fields 01–08	01–08	The contents of each specified field
Magnetic stripe preambles Channel 1 Channel 2 Channel 3	48 4E 58	A text string
Magnetic stripe postambles Channel 1 Channel 2 Channel 3	49 4F 59	A text string
Extra fields	60–6F	The contents of each specified field; see Using Extra Fields on page 53
Redirection commands	90–96	None; see Table 9
Autoterminator	B1	A single ASCII character
Symbology identifier	B5	A code identifying the input form
End-of-string character (//)	Must be used to end each output sequence	

Using Extra Fields

You can define up to 16 extra fields for input editing. Use the extra fields to include text strings or keyboard actions. For example, by defining one field to contain the word *aisle*, another field to contain the word *bin*, a third field to contain a tab, and another field to contain a space, you can change

N21263

to

aisle N21 bin 263

You can include the value for each extra field in the output sequence of any or all of the qualification definitions.

Table lists I.D. numbers and predefined defaults for extra fields. You can change your decoder's settings for these parameters using the bar code menu, bar code batch, serial batch, or on-screen method of programming.

Table 8. Extra-Field Parameters

PARAMETER	I.D. #	TYPE	PREDEFINED DEFAULTS		
			D0	D1	D2
Extra field 0	60	String	//	Acc#//	//
Extra field 1	61	String	//	//*	//
Extra field 2	62	String	//	, //†	//
Extra fields 3–16	63–6F [§]	String	//	//	//
*Two spaces †A comma followed by a space §Extra field 3 = 63 Extra field 8 = 68 Extra field D = 6D Extra field 4 = 64 Extra field 9 = 69 Extra field E = 6E Extra field 5 = 65 Extra field A = 6A Extra field F = 6F Extra field 6 = 66 Extra field B = 6B Extra field 7 = 67 Extra field C = 6C					


Redirecting Output

After input editing, data is normally output to the host computer or terminal. You can include output-redirection commands or system commands in the output sequence to redirect the data output (see Table 9).

Table 9. Output-Redirection Settings

VALUE USED IN OUTPUT SEQUENCE	EFFECT
90	Switches output back to the host after data has been redirected
91	Redirects data as control commands to be sent to the system's host-controlled indicator (HCI) parser (see)
92–95	Redirects data to the serial port's handshake-out line using the following settings:
92	9600 baud, 8 data bits, no parity, 1 stop bit
93	9600 baud, 7 data bits, even parity, 1 stop bit
94	2400 baud, 8 data bits, no parity, 1 stop bit
95	2400 baud, 7 data bits, even parity, 1 stop bit
96	Redirects data to the serial port's Tx line

An Input Editing Example



NOTE

To read the bar codes in this example, your PowerWedge 20 decoder must accept Code 39 bar codes with a maximum length of 26 characters. Scan the following bar code to reset your decoder to predefined default D2 and set the maximum length for Code 39 bar codes to 26:



Let's say you are the head of security for a large manufacturing company. Each employee in your company has an identification badge with a Code 39 bar code containing the employee's first name and last name, a five-digit employee number that begins with 0, and sometimes additional information. Names, numbers, and other information in the bar codes are separated by periods, as in the following example:



To enter certain areas of the building, employees must present their badges to an I.D. badge reader that passes the data through a PowerWedge 20 to a central computer. The information output to the computer also includes the location of the I.D. badge reader. The output is in the following format:

Last name, First nameEmp. #Location

Today you are installing a badge reader and decoder at a new location called Area M, and you need to program the decoder to output the data in the proper format. Using the example above, you want the output to be as follows:

Rogers, Sally1836Area M

To get the results you want, you need to complete three steps.

Step 1: Create a Qualification Definition

The definition will require the input to be Code 39 data of any length and will break that data down into seven fields, including (1) first name, (3) last name, (5) employee number with the leading zero dropped off, and (7) other information, as shown below:



Any input that doesn't meet the definition criteria will not be edited.

Table 10 lists the parameters and values you need to use. If you are using predefined defaults (see page 18), you need to program only the parameters whose values are different from the defaults. For example, the D1 default setting for I.D. #71 (definition 1 symbology) is C (Code 39); so if your decoder is using the D1 settings, you do not need to set I.D. #71.

Table 10. Parameter Settings for the Example

Parameter	I.D. #	Value	Meaning
Enable definition 1	70	1	Use definition 1 to filter incoming data.
Symbology	71	C	Only Code 39 input will be edited.
Record length	72	00	The incoming data can contain any number of characters.
Number of fields	73	07	The incoming data contains seven fields.
Field 1	74	00(00)	The first field can be of any length and can begin with any character.
Field 2	75	01.	The second field is exactly one character long and that character is a period.

Table 10. Parameter Settings for the Example

Parameter	I.D. #	Value	Meaning
Field 3	76	00(00)	The third field can be of any length and can begin with any character.
Field 4	77	02.	The second field is exactly two characters long and the first character is a period.
Field 5	78	04(00)	The fifth field is exactly four characters long and can begin with any character.
Field 6	79	01.	The sixth field is exactly one character long and that character is a period.
Field 7	7A	00(00)	The seventh field can be of any length and can begin with any character.

If you are using the bar code batch programming method and the D2 pre-defined defaults, your bar codes for the definition should look like the following:



Notice that the bar codes do not include settings for record length or for fields 1, 3, and 7. Since these parameters use the defaults, it is not necessary to include them in the bar codes. Also notice the %U in the second bar code. This is the Code 39 equivalent for the null character, which is used in place of 00 in bar code batch programming.

Step 2: Program Extra Fields

Set parameters for three extra fields to contain the following:

- The I.D. badge reader’s location
- A comma and a space to separate the first name from the last name
- A tab to separate columns in the output

Table 11 lists the parameters and data strings you need to use. Each string ends with the end-of-string character (//).

Table 11. Parameter Settings for the Extra Fields

Parameter	I.D. #	String	Contents
Extra field 0	60	Area M//	The location of the I.D. badge reader
Extra field 1	61	, //	A comma followed by a space
Extra field 2	62	(TABR)//	A tab character

Your bar codes for the extra-field settings should look like the following:



Notice the use of the plus symbols (+) before the R, the E, and the second A. These cause the letters to be output as lowercase (*a*, *r*, and *e*). In the second bar code, /L is the Code 39 equivalent for a comma, and \$I is the Code 39 equivalent for a tab character. Also notice that each extra-field setting ends with an end-of-string character (//).

Step 3: Program the Output Sequence

Enter the following codes: 03610162056260B1//

where

- 03 is **field 3** (last name)
- 61 is **extra field 1** (comma and space)
- 01 is **field 1** (first name)
- 62 is **extra field 2** (tab)
- 05 is **field 5** (employee number without the leading 0)
- 62 is **extra field 2** (tab)
- 60 is **extra field 0** ("Area M")
- B1 is the autoterminator (a carriage return)
- // is the end-of-string character

Your bar code for the output sequence should look like the following:



Once you've completed these steps, your new I.D. badge reader should be able to read the bar code on each employee's badge and report that the employee has entered Area M.

Programming Options

Table 12 lists programming I.D. numbers for predefined defaults, which provide a fast and easy way to set all parameters off, on, or to factory settings.

Table 13 lists cloning, display, and save-and-exit settings.

Table 14 provides the following information:



NOTE

For explanations of some general programming parameters, see page 34. For explanations of serial parameters, see page 36. For information about magnetic stripe programming parameters, see page 44. For input-editing parameters, see Input Editing on page 45.

- Code Parameter is the “human” name for programming options.
- I.D. # is the “decoder” name for programming options. For example, if you wanted to set a Code 39 minimum label length, you would enter **01** when programming the decoder. Programming I.D. numbers given in this section can be used with all programming methods.
- Type tells what kind of setting to use for each code parameter:
 - On/Off is a toggle. 1 turns the parameter on, and 0 turns it off.
 - Value requires a two-character entry (e.g., **02** for two beeps after each good read, or **05** for a length of five).
 - String uses one or more ASCII characters, followed by // to indicate the end of the string.
 - Immediate takes effect as soon as the I.D. number is entered.

- Acceptable Input gives the settings or range of settings that you can use for each code parameter.
- Predefined Defaults tells how the parameter is set when you select predefined default D0, D1, or D2 (see page 18).

Table 15 lists parameter settings for serial communications.

Table 12. Predefined Defaults

SETTING	I.D. #	TYPE
Predefined default set 0	D0	Immediate
Predefined default set 1	D1	Immediate
Predefined default set 2	D2	Immediate

Table 13. Cloning, Display, and Save-and-Exit Settings

SETTING	I.D. #	TYPE
Cloning	EC	Immediate
Display settings (on-screen programming only)	ED	Immediate
Save and exit	EE	Immediate
Exit only, no save	EF	Immediate

Table 14. General Programming Parameters

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Code 39 <i>Enter 1 for On and 0 for Off.</i>						
Enable	00	On/Off	On or Off	Off	On	On
Minimum length	01	Value	00–50	00	00	00
Maximum length	02	Value	01–50	01	50	20
Enable checksum	03	On/Off	On or Off	Off	Off	Off
Send checksum	04	On/Off	On or Off	Off	Off	Off
Full ASCII mode	05	On/Off	On or Off	Off	On	On
MIL-STD-1189 support	07	On/Off	On or Off	Off	On	Off
Interleaved 2 of 5 <i>Enter 1 for On and 0 for Off.</i>						
Enable	08	On/Off	On or Off	Off	On	On
Minimum length	09	Value	02–50	02	02	06
Maximum length	0A	Value	02–50	02	50	10
Enable checksum	0B	On/Off	On or Off	Off	Off	Off
Send checksum	0C	On/Off	On or Off	Off	Off	Off
Use lengths 6 and 14 only	0D	On/Off	On or Off	Off	Off	Off
Matrix 2 of 5 <i>Enter 1 for On and 0 for Off.</i>						
Enable	10	On/Off	On or Off	Off	On	Off
Minimum length	11	Value	01–50	01	01	06
Maximum length	12	Value	01–50	01	50	10

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Enable checksum	13	On/Off	On or Off	Off	Off	Off
Send checksum	14	On/Off	On or Off	Off	Off	Off
Standard 2 of 5 <i>Enter 1 for On and 0 for Off.</i>						
Enable	15	On/Off	On or Off	Off	On	Off
Minimum length	16	Value	01–50	01	01	06
Maximum length	17	Value	01–50	01	50	10
Enable checksum	18	On/Off	On or Off	Off	Off	Off
Send checksum	19	On/Off	On or Off	Off	Off	Off
Use 2-bar start/stop	1A	On/Off	On or Off	Off	Off	Off
Code 11 <i>Enter 1 for On and 0 for Off.</i>						
Enable	1B	On/Off	On or Off	Off	On	Off
Minimum length	1C	Value	01–50	01	01	04
Maximum length	1D	Value	01–50	01	50	10
Require 2 check digits	1E	On/Off	On or Off	Off	Off	Off
Send check digit(s)	1F	On/Off	On or Off	Off	On	Off
Codabar/Ames <i>Enter 1 for On and 0 for Off.</i>						
Enable	20	On/Off	On or Off	Off	On	On
Minimum length	21	Value	01–50	01	01	04
Maximum length	22	Value	01–50	01	50	20
Send start/stop	23	On/Off	On or Off	Off	Off	Off

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Codabar-to-CLSI conversion	24	On/Off	On or Off	Off	Off	Off
Wide intercharacter gaps allowed	25	On/Off	On or Off	Off	On	Off
MSI <i>Enter 1 for On and 0 for Off.</i>						
Enable	26	On/Off	On or Off	Off	On	Off
Minimum length	27	Value	01–14	01	01	04
Maximum length	28	Value	01–14	01	14	10
Require 2 check digits	29	On/Off	On or Off	Off	Off	Off
2nd check digit Mod 11	2A	On/Off	On or Off	Off	Off	Off
Send check digit(s)	2B	On/Off	On or Off	Off	On	Off
Code 93 <i>Enter 1 for On and 0 for Off.</i>						
Enable	2C	On/Off	On or Off	Off	On	On
Minimum length	2D	Value	00–50	00	01	02
Maximum length	2E	Value	00–50	00	50	20
Universal Product Code-A (UPC-A) <i>Enter 1 for On and 0 for Off.</i>						
Enable	30	On/Off	On or Off	Off	On	On
Send system digit	31	On/Off	On or Off	Off	On	On
Send check digit	32	On/Off	On or Off	Off	On	Off
Convert UPC-A to EAN-13	33	On/Off	On or Off	Off	On	Off

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Universal Product Code-E (UPC-E)				<i>Enter 1 for On and 0 for Off.</i>		
Use system digit 0	34	On/Off	On or Off	Off	On	On
Use system digit 1	35	On/Off	On or Off	Off	On	On
Convert UPC-E to UPC-A	36	On/Off	On or Off	Off	On	Off
Send system digit	37	On/Off	On or Off	Off	On	Off
Send check digit	38	On/Off	On or Off	Off	On	Off
European Article Numbering (EAN) Japan Article Numbering (JAN)				<i>Enter 1 for On and 0 for Off.</i>		
Enable EAN-8/JAN-8	39	On/Off	On or Off	Off	On	On
Enable EAN-13/JAN-13	3A	On/Off	On or Off	Off	On	On
Convert EAN-13 to ISBN	3B	On/Off	On or Off	Off	Off	Off
Transmit EAN/JAN checksum	3F	On/Off	On or Off	Off	Off	Off
UPC, EAN, JAN EXTENSIONS				<i>Enter 1 for On and 0 for Off.</i>		
Allow 2-digit extensions	3C	On/Off	On or Off	Off	On	On
Allow 5-digit extensions	3D	On/Off	On or Off	Off	On	On
Require extensions	3E	On/Off	On or Off	Off	Off	Off
Code 128				<i>Enter 1 for On and 0 for Off.</i>		
Enable	40	On/Off	On or Off	Off	On	On
Minimum length	41	Value	01–50	01	01	02
Maximum length	42	Value	01–50	01	50	20

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Enable UCC128	43	On/Off	On or Off	Off	Off	Off
Labelcode 4/5 <i>Enter 1 for On and 0 for Off.</i>						
Enable	52	On/Off	On or Off	Off	On	Off
Convert	53	On/Off	On or Off	Off	Off	Off
Magnetic Stripe Channel 1 <i>Enter 1 for On and 0 for Off.</i>						
Enable	44	On/Off	On or Off	Off	On	On
Required	45	On/Off	On or Off	Off	Off	Off
Preamble	48	String	*	//	1 // [†]	//
Postamble	49	String	*	//	1// [§]	//
<p><i>*Any supported keyboard keys, up to the maximum length supported by available total memory (about 130 characters)</i> [†]<i>Includes a space after the 1</i> [§]<i>Includes a space before the 1</i></p>						
Magnetic Stripe Channel 2 <i>Enter 1 for On and 0 for Off.</i>						
Enable	4A	On/Off	On or Off	Off	On	On
Required	4B	On/Off	On or Off	Off	Off	Off
Preamble	4E	String	*	//	2 // [†]	//
Postamble	4F	String	*	//	2// [§]	//
<p><i>*Any supported keyboard keys, up to the maximum length supported by available total memory (about 130 characters)</i> [†]<i>Includes a space after the 2</i> [§]<i>Includes a space before the 2</i></p>						

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS																		
				D0	D1	D2																
Magnetic Stripe Channel 3				<i>Enter 1 for On and 0 for Off.</i>																		
Enable	54	On/Off	On or Off	Off	On	Off																
Required	55	On/Off	On or Off	Off	Off	Off																
Preamble	58	String	*	//	3 // [†]	//																
Postamble	59	String	*	//	3// [‡]	//																
Auxiliary serial and magnetic stripe identifiers	5A	String	**	‡	‡	‡																
Bar code symbology identifiers	5B	String	§§	‡	‡	‡																
California DL/ID alpha conversion	5C	On/Off	On or Off	Off	On	On																
<p><i>*Any supported keyboard keys, up to the maximum length supported by available total memory (about 130 characters)</i></p> <p><i>[†]Includes a space after the 3</i></p> <p><i>[‡]Includes a space before the 3</i></p> <p><i>**0 = Auxiliary serial</i></p> <p><i>1 = Magnetic stripe channel 1</i></p> <p><i>2 = Magnetic stripe channel 2</i></p> <p><i>3 = Magnetic stripe channel 3</i></p> <p><i>[‡]See I.D. #B5 on page 68 for default settings</i></p> <table style="width: 100%; border: none;"> <tr> <td><i>§§0 = UPC-A</i></td> <td><i>5 = S 2 of 5</i></td> <td><i>A = Code 128</i></td> <td rowspan="5" style="vertical-align: top;"><i>Select the I.D. letter for the symbology you want to change, and then enter a string followed by //.</i></td> </tr> <tr> <td><i>1 = I 2 of 5</i></td> <td><i>6 = EAN-8</i></td> <td><i>B = EAN 13</i></td> </tr> <tr> <td><i>2 = Code 39</i></td> <td><i>7 = MSI</i></td> <td><i>C = Labelcode 4/5</i></td> </tr> <tr> <td><i>3 = M 2 of 5</i></td> <td><i>8 = Codabar/Ames</i></td> <td></td> </tr> <tr> <td><i>4 = UPC-E</i></td> <td><i>9 = Code 11</i></td> <td></td> </tr> </table>							<i>§§0 = UPC-A</i>	<i>5 = S 2 of 5</i>	<i>A = Code 128</i>	<i>Select the I.D. letter for the symbology you want to change, and then enter a string followed by //.</i>	<i>1 = I 2 of 5</i>	<i>6 = EAN-8</i>	<i>B = EAN 13</i>	<i>2 = Code 39</i>	<i>7 = MSI</i>	<i>C = Labelcode 4/5</i>	<i>3 = M 2 of 5</i>	<i>8 = Codabar/Ames</i>		<i>4 = UPC-E</i>	<i>9 = Code 11</i>	
<i>§§0 = UPC-A</i>	<i>5 = S 2 of 5</i>	<i>A = Code 128</i>	<i>Select the I.D. letter for the symbology you want to change, and then enter a string followed by //.</i>																			
<i>1 = I 2 of 5</i>	<i>6 = EAN-8</i>	<i>B = EAN 13</i>																				
<i>2 = Code 39</i>	<i>7 = MSI</i>	<i>C = Labelcode 4/5</i>																				
<i>3 = M 2 of 5</i>	<i>8 = Codabar/Ames</i>																					
<i>4 = UPC-E</i>	<i>9 = Code 11</i>																					

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Other Controls				<i>Enter 1 for On and 0 for Off.</i>		
Programming mode	B0	Value	00 = Off 01 = Serial batch 02 = Menu 03 = Both	02	02	02
Autoterminator	B1	Value	Any single ASCII character (00 = Off)	(CR)	(CR)	(CR)
ASCII capital to lowercase	B2	On/Off	On or Off	Off	Off	Off
Intercharacter delay	B3	Value	00–99 (milliseconds)	00	00	00
CCD/laser redundancy	B4	On/Off	On or Off	Off	Off	Off
Send assigned symbology identifiers*	B5	On/Off	On or Off	Off	On	Off
<p><i>*Bar Code</i> A = UPC-A B = 1 2 of 5 C = Code 39 D = M 2 of 5 E = UPC-E F = S 2 of 5 G = EAN-8</p> <p><i>H = MSI</i> I = Codabar/Ames J = Code 11 K = Code 128 M = EAN-13 N = Labelcode 4/5</p> <p><i>Magnetic Stripe</i> 1 = Channel 1 2 = Channel 2 3 = Channel 3</p> <p><i>Other</i> S = Auxiliary serial</p>						
Bar code preamble	B6	String	†	//	§	//
Bar code postamble	B7	String	†	//	**	//
<p>†Any supported keyboard keys, up to the maximum length supported by available total memory (about 130 characters) §CODEID // (includes a space after CODEID)</p>						

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Other Controls (continued)				<i>Enter 1 for On and 0 for Off.</i>		
Good-read tone	B8	Value	00 = 3600 Hz 01 = 3840 Hz 02 = 4114 Hz 03 = 4430 Hz 04 = 2400 Hz 05 = 2618 Hz 06 = 2880 Hz 07 = 3200 Hz	04	04	04
Good-read number of beeps	B9	Value	01–04	01	01	01
Good-read tone duration	BA	Value	00 = 0.07 sec. 01 = 0.13 sec. 02 = 0.18 sec. 03 = 0.36 sec.	00	00	00
End-of-transmission beep	BB	On/Off	On or Off	Off	On	Off
Beeper volume	BC	Value	00 = Off 01 = Low 02 = Medium 03 = High	03	03	03
Laser connected to INPUT 2 (Dual model only)	BD	On/Off	On or Off	Off	Off	Off
Interfunction delay	BE	Value	00–99 (milliseconds)	00	00	00
Use numeric keypad	BF	On/Off	On or Off	Off	Off	Off
Strip Motorola data identifiers	D3	On/Off	On or Off	Off	Off	Off

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Other Controls (continued)				<i>Enter 1 for On and 0 for Off.</i>		
Laser/input modes	D4	Value	00 = Normal 01 = Autoscan 02 = Multiscan 03 = Symbol blinking	00	00	00
Require keyboard	D5	On/Off	On or Off	On	On	On
Autoscan timeout	D6	Value	01-99 (<i>minutes</i>) 00 = 256 minutes	30	30	30
CTRL out at power-up	D7	On/Off	On = High Off = Low	On	On	On
Bar code preamble for INPUT 2 (Dual model only)	DA	String	*	//	†	//
Bar code postamble for INPUT 2 (Dual model only)	DB	String	*	//	§	//
<p>*Any supported keyboard keys, up to the maximum length supported by available total memory (about 130 characters) †INPUT2 // (includes a space after INPUT2) § TEST// (includes a space before TEST)</p>						

Table 14. General Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULTS		
				D0	D1	D2
Host device	C0	Value	*	None	None	None
<p>*00 = IBM PC (international keyboard) 01 = IBM AT, PS/2 30-286, 50, 50Z, 60, 70, 80, 90, 95 (international keyboard) 02 = IBM PS/2 25, 30 (international keyboard) NOTE: Settings 00–02 work with DOS only. They transmit the ASCII character set and are not full-keyboard compatible. 10 = IBM PC (U.S. keyboard) 11 = IBM AT, PS/2 30-286, 50, 50Z, 60, 70, 80, 90, 95 (U.S. keyboard); ADDS terminals; NCR 2900; I/O Corp 2476 12 = IBM PS/2 25, 30 (U.S. keyboard) 15 = IBM and Telex terminals (102-key keyboard) 17 = IBM and Telex terminals (122-key keyboard); Decision Data models 3496 and 3781 21 = Macintosh (U.S. keyboard) 25 = Data General D213, D413 32 = TeleVideo 40 = DEC 42 = NEC PowerMate 50 = Serial ASCII 51 = Serial PC scan codes NOTE: The host devices listed above were supported at the time this user's guide was printed. Additional devices may also be supported. Please contact your dealer or Customer Service for current information.</p>						

Table 15. Serial Programming Parameters

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULT (C8)
<i>Enter 1 for On and 0 for Off.</i>				
Data type	C0	Value	50 = ASCII 51 = PC scan codes	50
Baud rate	C1	Value	00 = 300 01 = 600 02 = 1200 03 = 2400 04 = 4800 05 = 9600 06 = 19200 07 = 38400 08 = 57600	05
Data bits*	C2	Value	07 = 7 Bits 08 = 8 Bits	08
Parity*	C3	Value	00 = None 01 = Mark 02 = Space 03 = Odd 04 = Even	00
Stop bits*	C4	Value	01 = 1 Bit 02 = 2 Bits	01
Xon/Xoff handshaking	C5	On/ Off	On or Off	Off
Enable auxiliary serial input	C7	On/ Off	On or Off	Off
Predefined serial defaults	C8			
Protocol	CA	Value	00 = EOR only 01 = ACK/NAK	00
*The PowerWedge 20 will not operate with a combination of 7 data bits, no parity, and 1 stop bit				

Table 15. Serial Programming Parameters (Continued)

CODE PARAMETER	I.D. #	TYPE	ACCEPTABLE INPUT	PREDEFINED DEFAULT (C8)
End-of-record (EOR) character	CC	Value	<i>Any single ASCII character</i>	(CR)
Timeout	CD	Value	01-99* 00 = 2.55 seconds	03
Require host response	CE	On/Off	On or Off	Off
Use host-controlled indicators	CF	On/Off	On or Off	Off
<i>*10-millisecond increments; the default setting (03) means 30 milliseconds</i>				

Programming Bar Codes

This section provides bar codes for common setup parameters for programming the PowerWedge 20. Factory default settings (D2) are underlined.

Alphabetical List of Contents

Auto-Learn	75
Cloning	76
Codabar/Ames	87
Code 11	85
Code 128	92
Code 39	76
Code 93	91
EAN/JAN	96
Host Device	107
Interleaved 2 of 5	78
Labelcode 4/5	94
Magnetic Stripe Channels	98
Matrix 2 of 5	81
MSI	89
Other Controls	100
Predefined Defaults	75
Serial Parameters	108
Standard 2 of 5	83
UPC/EAN/JAN Extensions	97
UPC-A	94
UPC-E	95

Predefined Defaults

DO



D1



D2



Auto-Learn

START



SAVE
AND
EXIT



Scan this twice.

EXIT
WITHOUT
SAVING



Scan this first.



Then scan this.

Cloning

EC



Code 39

ENABLE

On



Off



MINIMUM LENGTH

00



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



ENABLE CHECKSUM

On



Off



OUTPUT CHECKSUM

On



Off



FULL ASCII MODE

On



Off



MIL-STD-1189 SUPPORT

On



Off



Interleaved 2 of 5

ENABLE

On



Off



MINIMUM LENGTH

2



6



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



REQUIRED LENGTH (no default; overrides minimum and maximum settings)

2	 * \$ + \$ - 0 9 0 2 0 A 0 2 E E *
4	 * \$ + \$ - 0 9 0 4 0 A 0 4 E E *
6	 * \$ + \$ - 0 9 0 6 0 A 0 6 E E *
8	 * \$ + \$ - 0 9 0 8 0 A 0 8 E E *
10	 * \$ + \$ - 0 9 1 0 0 A 1 0 E E *
12	 * \$ + \$ - 0 9 1 2 0 A 1 2 E E *
14	 * \$ + \$ - 0 9 1 4 0 A 1 4 E E *
16	 * \$ + \$ - 0 9 1 6 0 A 1 6 E E *
18	 * \$ + \$ - 0 9 1 8 0 A 1 8 E E *
20	 * \$ + \$ - 0 9 2 0 0 A 2 0 E E *

ENABLE CHECKSUM



OUTPUT CHECKSUM



LENGTHS 6 AND 14 ONLY *(case code)*



Matrix 2 of 5

ENABLE



MINIMUM LENGTH

06



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



ENABLE CHECKSUM

On



Off



OUTPUT CHECKSUM

On



Off



Standard 2 of 5

ENABLE

On



Off



MINIMUM LENGTH

06



10



20



30



40 
 * \$ + \$ - 1 6 4 0 E E *

50 
 * \$ + \$ - 1 6 5 0 E E *

MAXIMUM LENGTH

10 
 * \$ + \$ - 1 7 1 0 E E *

20 
 * \$ + \$ - 1 7 2 0 E E *

30 
 * \$ + \$ - 1 7 3 0 E E *

40 
 * \$ + \$ - 1 7 4 0 E E *

50 
 * \$ + \$ - 1 7 5 0 E E *

ENABLE CHECKSUM

On 
 * \$ + \$ - 1 8 1 E E *

Off 
 * \$ + \$ - 1 8 0 E E *

OUTPUT CHECKSUM

On 
 * \$ + \$ - 1 9 1 E E *

Off 
 * \$ + \$ - 1 9 0 E E *

USE 2-BAR START/STOP

On



Off



Code 11

ENABLE

On



Off



MINIMUM LENGTH

4



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



REQUIRE 2 CHECK DIGITS

On



Off



OUTPUT CHECK DIGIT(S)

On



Off



Codabar/Ames

ENABLE

On



Off



MINIMUM LENGTH

04



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



OUTPUT STOP/START

On



Off



CODABAR-TO-CLSI CONVERSION

On



Off



WIDE INTERCHARACTER GAPS ALLOWED

On



Off



MSI

ENABLE

On



Off



MINIMUM LENGTH

1



4



7



10



12



14



MAXIMUM LENGTH

1



4



7



10



12



14



REQUIRE 2 CHECK DIGITS

On



Off



2ND CHECK DIGIT MOD 11

On



Off



OUTPUT CHECK DIGIT(S)

On



Off



Code 93

ENABLE

On



Off



MINIMUM LENGTH

02



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



Code 128

ENABLE

On



Off



MINIMUM LENGTH

2



10



20



30



40



50



MAXIMUM LENGTH

10



20



30



40



50



ENABLE UCC128

On



Off



Labelcode 4/5

ENABLE

On



Off



CONVERT

On



Off



UPC-A

ENABLE UPC-A

On



Off



OUTPUT SYSTEM DIGIT

On



Off



OUTPUT CHECK DIGIT

On



Off



CONVERT UPC-A TO EAN-13

On



Off



UPC-E

USE SYSTEM DIGIT 0

On



Off



USE SYSTEM DIGIT 1

On



Off



CONVERT UPC-E TO UPC-A

On



Off



OUTPUT SYSTEM DIGIT

On



Off



OUTPUT CHECK DIGIT

On



Off



EAN/JAN

ENABLE EAN-8/JAN-8

On



Off



ENABLE EAN-13/JAN-13

On



Off



CONVERT EAN-13 TO ISBN

On



Off



TRANSMIT EAN/JAN CHECKSUM

On



Off



UPC/EAN/JAN Extensions

ALLOW 2-DIGIT EXTENSIONS

On



Off



ALLOW 5-DIGIT EXTENSIONS

On



Off



REQUIRE EXTENSIONS

On



Off



Magnetic Stripe Channels

ENABLE CHANNEL 1

On



Off



REQUIRE CHANNEL 1

On



Off



ENABLE CHANNEL 2

On



Off



REQUIRE CHANNEL 2

On



Off



ENABLE CHANNEL 3

On



Off



REQUIRE CHANNEL 3

On



Off



CALIFORNIA DRIVER LICENSE/ID CARD ALPHA CONVERSION *(Track 3)*

On



Off



Other Controls

PROGRAMMING MODE

Off



Serial
Batch



Menu



Both



AUTOTERMINATOR

(CR)



(TAB)



None



ASCII UPPERCASE TO LOWERCASE CONVERSION

On



Off



INTERCHARACTER DELAY (in milliseconds)

0



5



10



20



40



CCD/LASER REDUNDANCY

On



Off



OUTPUT SYMBOLOGY IDENTIFIER

On



Off



GOOD-READ TONE *(in hertz)*

2400 Hz



3200 Hz



3600 Hz



4430 Hz



GOOD-READ BEEPS

1



2



3



4



GOOD-READ BEEP DURATION *(in seconds)*

0.07



0.13



0.18



0.36



END-OF-TRANSMISSION BEEP

On



Off



BEEPER VOLUME

Off



Low



Medium



High



LASER CONNECTED TO INPUT 2

On



Off



INTERFUNCTION DELAY *(in milliseconds)*

0



5



10



20



40



USE NUMERIC KEYPAD

On



Off



LASER/INPUT MODES

Normal



Autoscan



Multiscan



Symbol
Blinking



REQUIRE KEYBOARD

On



Off



AUTOSCAN TIMEOUT

1 min.



5 min.



10 min.



30 min.



60 min.



256 min.



CTRL OUT AT POWER-UP

High



Low



Host Device

PC/XT (International keyboard)



AT; PS/2™ models 30-286, 50, 50Z, 60, 70, 80, 90, and 95 (International keyboard)



PS/2 models 25 and 30 (International keyboard)



PC/XT (U.S. keyboard)



AT; PS/2 models 30-286, 50, 50Z, 60, 70, 80, 90, and 95 (U.S. keyboard); ADDS; NCR 2900; I/O Corp 2476



PS/2 models 25 and 30 (U.S. keyboard)



IBM and TELEX terminals (102-key keyboard)



IBM and TELEX terminals (122-key keyboard); Decision Data models 3496 and 3781



Macintosh™ (U.S. keyboard)



Data General models D213 and D214



TeleVideo



DEC



NEC PowerMate



Serial Parameters

DATA TYPE

ASCII



PC scan codes



BAUD RATE

300



600



1200



2400



4800



9600



19200



38400



57600



DATA BITS

7 bits



8 bits



PARITY

None



Mark



Space



Odd



Even



STOP BITS

1



2



XON/XOFF HANDSHAKING

On



Off



ENABLE AUXILIARY SERIAL INPUT

On



Off



PROTOCOL

EOR only



ACK/NAK



REQUIRE HOST RESPONSE

On



Off



USE HOST-CONTROLLED INDICATORS

On



Off



Full Keyboard Support

Almost every key on your keyboard—including nonprinting keys, such as **PgDn** and **Ctrl**—can be programmed into your PowerWedge 20 decoder. The tables in this section list ASCII values, “mnemonic” values, and Code 39 equivalents for programming all keyboard keys.



Some of the values listed in the **ASCII** column of the tables (for example, 03 for **Caps Lock**) are not really ASCII values. They are, however, the values you should use for programming the keys.

NOTE

Full ASCII mode for Code 39 must be enabled in the decoder for batch programming.
Be sure to include the parentheses when you enter mnemonics.

Use the *ASCII* values whenever you program your decoder with the menu method. For example, to turn on the **Caps Lock** key (value 03 from table) through menu programming, you would scan the bar codes for 0 and 3.

Use the *Code 39* values to create bar codes for batch programming or to include lowercase or nonalphanumeric characters in a bar code. For example, to include an exclamation mark (!) in a bar code, you would encode it as /A (slash capital a).

Use *mnemonics* for on-screen and serial batch programming. For example, to encode the **Enter** key, you would type (CR).

Some keys act immediately when read into the decoder. For example, the decoder transmits the page-down command to the computer as soon as it reads a bar code containing the characters %U\$Z.

Other keys are not quite so simple. For example, the **Ctrl** key has to be “turned” on and off. When you type **Ctrl+C**, for instance, you hold the **Ctrl** key down while you press C, and then you release the **Ctrl** key. Three signals are sent to the host device: **Ctrl** key on (down), C, **Ctrl** key off (up). This is the way you need to think when encoding **Ctrl**, **Alt**, **Shift**,

and other keys requiring a key to be held down while another is pressed. To include the **Ctrl+C** keystroke combination in a batch bar code, you would encode \$RC\$\$\$. For on-screen or serial batch programming for an IBM PC keyboard, you would need to enter (XC1)C(XC0). The ASCII equivalent for menu programming is 124313.

**NOTE**

The zap character does not eliminate preambles or postambles.

Including a function key in a bar code can present a problem if your decoder is programmed to follow every bar code transmission with an autoterminator character. You can eliminate the autoterminator by including the “zap” character, \$Z, in any bar code that you do *not* want followed by the autoterminator. For example, you would encode %U\$A\$Z to send function key f1 with no autoterminator after it.

Table 16 lists the equivalents for keys that are common to many keyboards. For encoding keys from a specific keyboard, see the appropriate table from the following list:

Computer or Terminal	Table	Page
ADDS	17	116
DEC	20	121
Decision Data	20	121
IBM PCs and compatibles	17	116
IBM terminals	21	126
Macintosh	18	117
NCR 2900	17	116
NEC PowerMate	17	116
TeleVideo terminal	19	119
Telex	21	126

For information about IBM terminals and illustrations of IBM keyboards, see the section beginning on page 123.

Table 16. Common Keyboard Keys

Key	Code 39	ASCII Value	Key	Code 39	ASCII Value	Key	Code 39	ASCII Value
SP	space	20	A	A	41	a	+A	61
!	/A	21	B	B	42	b	+B	62
"	/B	22	C	C	43	c	+C	63
#	/C	23	D	D	44	d	+D	64
\$	/D	24	E	E	45	e	+E	65
%	/E	25	F	F	46	f	+F	66
&	/F	26	G	G	47	g	+G	67
'	/G	27	H	H	48	h	+H	68
(*	/H	28	I	I	49	i	+I	69
)†	/I	29	J	J	4A	j	+J	6A
*	/J	2A	K	K	4B	k	+K	6B
+	/K	2B	L	L	4C	l	+L	6C
,	/L	2C	M	M	4D	m	+M	6D
-	- or /M	2D	N	N	4E	n	+N	6E
.	. or /N	2E	O	O	4F	o	+O	6F
/	/O	2F	P	P	50	p	+P	70
0	0 or /P	30	Q	Q	51	q	+Q	71
1	1 or /Q	31	R	R	52	r	+R	72
2	2 or /R	32	S	S	53	s	+S	73
3	3 or /S	33	T	T	54	t	+T	74

Table 16. Common Keyboard Keys (Continued)

Key	Code 39	ASCII Value	Key	Code 39	ASCII Value	Key	Code 39	ASCII Value
4	4 or /T	34	U	U	55	u	+U	75
5	5 or /U	35	V	V	56	v	+V	76
6	6 or /V	36	W	W	57	w	+W	77
7	7 or /W	37	X	X	58	x	+X	78
8	8 or /X	38	Y	Y	59	y	+Y	79
9	9 or /Y	39	Z	Z	5A	z	+Z	7A
:	/Z	3A	@	%V	40	`	%W	60
;	%F	3B	[%K	5B	{	%P	61
<	%G	3C	\	%L	5C		%Q	7C
=	%H	3D]	%M	5D	}	%R	7D
>	%I	3E	^	%N	5E	~	%S	7E
?	%J	3F	_	%O	5F	Delete	%T	7F
Zap [§]	\$Z	1A						
<p>*When used as a string value in on-screen programming, must be entered as ((†When used as a string value in on-screen programming, must be entered as () §Not an actual key; see information about the "zap" character on page 113</p>								

Table 17. IBM PC and NEC PowerMate Keyboard Keys

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
F1*	(X16)	%U\$A	8001	↑	(UP)	%U%A	801B
F2*	(X17)	%U\$B	8002	↓	(DOWN)	%U%B	801C
F3*	(X18)	%U\$C	8003	←	(LEFT)	%U%C	801D
F4*	(X19)	%U\$D	8004	→	(RIGHT)	%U%D	801E
F5*	(X20)	%U\$E	8005	Caps Lock*	(X3)	\$C	03
F6*	(X21)	%U\$F	8006	Num Lock*	(X4)	\$D	04
F7*	(X22)	%U\$G	8007	Scroll Lock*	(X5)	\$E	05
F8*	(X23)	%U\$H	8008	Horizontal Tab*	(TABR)	\$I	09
F9*	(X24)	%U\$I	8009	Vertical Tab*	(X10)	\$K	0B
F10*	(X25)	%U\$J	800A	Enter*	(CR)	\$M	0D
F11*	(X26)	%U\$K	800B	Alt Off*	(XA0)	\$N	0E
F12*	(X27)	%U\$L	800C	Alt On*	(XA1)	\$O	0F
Insert	(X36)	%U\$U	8015	Left Ctrl Off*	(XC0)	\$R	12
Home	(X37)	%U\$V	8016	Left Ctrl On*	(XC1)	\$S	13
Page Up	(X38)	%U\$W	8017	Right Ctrl On	(X511)	%U\$P	8010
Delete	(X39)	%U\$X	8018	Right Ctrl Off	(X510)	%U\$O	800F
End	(X40)	%U\$Y	8019	Shift Off*	(XE0)	\$V	16

Table 17. IBM PC and NEC PowerMate Keyboard Keys (Continued)

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
Page Down	(X41)	%U\$Z	801A	Shift On*	(XE1)	\$W	17
Backspace	(X8)	\$H	08	Esc*	(X11)	%A	1B
<i>*Keys supported for keyboard data input (see Input Editing on page 45)</i>							
Numeric Keypad							
Enter	(Enter)	%U%E	801F	3	(NP3)	%U3	8033
*	(X52)	%U/J	802A	4	(NP4)	%U4	8034
+	(X53)	%U/K	802B	5	(NP5)	%U5	8035
-	(X55)	%U-	802D	6	(NP6)	%U6	8036
/	(X57)	%U/O	802F	7	(NP7)	%U7	8037
0	(NP0)	%U0	8030	8	(NP8)	%U8	8038
1	(NP1)	%U1	8031	9	(NP9)	%U9	8039
2	(NP2)	%U2	8032				

Table 18. Macintosh Keyboard Keys

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
F1	(X16)	%U\$A	8001	End	(X40)	%U\$Y	8019
F2	(X17)	%U\$B	8002	Page Down	(X41)	%U\$Z	801A
F3	(X18)	%U\$C	8003	↑	(UP)	%U%A	801B
F4	(X19)	%U\$D	8004	↓	(DOWN)	%U%B	801C

Table 18. Macintosh Keyboard Keys (Continued)

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
F5	(X20)	%U\$E	8005	←	(LEFT)	%U%C	801D
F6	(X21)	%U\$F	8006	→	(RIGHT)	%U%D	801E
F7	(X22)	%U\$G	8007	Tab	(TABR)	\$I	09
F8	(X23)	%U\$H	8008	Return	(CR)	\$M	0D
F9	(X24)	%U\$I	8009	ζ	(XB0)	\$P	10
F10	(X25)	%U\$J	800A	Apple	(XB1)	\$Q	11
F11	(X26)	%U\$K	800B	Control	(XC0)	\$R	12
F12	(X27)	%U\$L	800C	Control	(XC1)	\$S	13
F13	(X28)	%U\$M	800D	Option	(XD0)	\$T	14
F14	(X29)	%U\$N	800E	Option	(XD1)	\$U	15
F15	(X30)	%U\$O	800F	Shift	(XE0)	\$V	16
Help	(X36)	%U\$U	8015	Shift	(XE1)	\$W	17
Home	(X37)	%U\$V	8016	Caps Lock	(XF0)	\$X	18
Page Up	(X38)	%U\$W	8017	Caps Lock	(XF1)	\$Y	19
Delete	(X39)	%U\$X	8018	Esc	(X11)	%A	1B
Numeric Keypad							
Enter	(ENTER)	%U%E	801F	3	(NP3)	%U3	8033
*	(X52)	%U/J	802A	4	(NP4)	%U4	8034
+	(X53)	%U/K	802B	5	(NP5)	%U5	8035
-	(X55)	%U-	802D	6	(NP6)	%U6	8036

Table 18. Macintosh Keyboard Keys (Continued)

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
/	(X57)	%U/O	802F	7	(NP7)	%U7	8037
0	(NP0)	%U0	8030	8	(NP8)	%U8	8038
1	(NP1)	%U1	8031	9	(NP9)	%U9	8039
2	(NP2)	\$U2	8032				

Table 19. TeleVideo Keyboard Keys

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
F1	(X16)	%U\$A	8001	FUNCT	(XF0)	\$X	18
F2	(X17)	%U\$B	8002	FUNCT	(XF1)	\$Y	19
F3	(X18)	%U\$C	8003	TAB	(TABR)	\$I	09
F4	(X19)	%U\$D	8004	←Tab	(X10)	\$K	0B
F5	(X20)	%U\$E	8005	Enter	(CR)	\$M	0D
F6	(X21)	%U\$F	8006	ESC	(X11)	%A	1B
F7	(X22)	%U\$G	8007	CHAR INSERT	(X43)	%U/A	8021
F8	(X23)	%U\$H	8008	LINE INSERT	(X44)	%U/B	8022
F9	(X24)	%U\$I	8009	LINE ERASE	(X45)	%U/C	8023
F10	(X25)	%U\$J	800A	NO SCROLL	(X46)	%U/D	8024
F11	X26)	%U\$K	800B	SEND	(X47)	%U/E	8025

Table 19. TeleVideo Keyboard Keys (Continued)

Key	Mnemonic	Code 39	ASCII Value	Key	Mnemonic	Code 39	ASCII Value
F12	(X27)	%U\$L	800C	CHAR DELETE	(X48)	%U/F	8026
F13	(X28)	%U\$M	800D	LINE DELETE	(X49)	%U/G	8027
F14	(X29)	%U\$N	800E	PAGE ERASE	(X50)	%U/H	8028
F15	(X30)	%U\$O	800F	PAGE	(X51)	%U/I	8029
F16	(X31)	%U\$P	8010	LINE FEED	(X58)	%U/Z	803A
BACK-SPACE	(X8)	\$H	08	CLEAR SPACE	(X59)	%U%F	803B
↑	(UP)	%U%A	801B	BREAK	(X60)	%U%G	803C
↓	(DOWN)	%U%B	801C	CE	(X61)	%U%H	803D
←	(LEFT)	%U%C	801D	PRINT	(X62)	%U%I	803E
→	(RIGHT)	%U%D	801E				
Numeric Keypad							
=	(X54)	%U/L	802C	3	(NP3)	%U3	8033
-	(X55)	%U/M	802D	4	(NP4)	%U4	8034
.	(X56)	%U/N	802E	5	(NP5)	%U5	8035
00	(X15)	%U%J	803F	6	(NP6)	%U6	8036
0	(NP0)	%U0	8030	7	(NP7)	%U7	8037
1	(NP1)	%U1	8031	8	(NP8)	%U8	8038
2	(NP2)	\$U2	8032	9	(NP9)	%U9	8039

Table 20. DEC Keyboard Keys

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
F1	(X16)	%U\$A	8001	Prev Screen	(X38)	%U\$W	8017
F2	(X17)	%U\$B	8002	Next Screen	(X41)	%U\$W	801A
F3	(X18)	%U\$C	8003	Lock	(X3)	\$C	03
F4	(X19)	%U\$D	8004	Num Lock	(X4)	\$D	04
F5	(X20)	%U\$E	8005	Scroll Lock	(X5)	\$E	05
F6	(X21)	%U\$F	8006	Backspace	(X8)	\$H	08
F7	(X22)	%U\$G	8007	Tab	(TABR)	\$I	09
F8	(X23)	%U\$H	8008	Enter	(CR)	\$M	0D
F9	(X24)	%U\$I	8009	Esc	(X11)	%A	1B
F10	(X25)	%U\$J	800A	Insert Here	(X36)	%U\$U	8015
F11	(X26)	%U\$K	800B	Remove	(X39)	%U\$X	8018
F12	(X27)	%U\$L	800C	Ctrl Off	(XC0)	\$R	12
F13	(X28)	%U\$M	800D	Ctrl On	(XC1)	\$S	13
F14	(X29)	%U\$N	800E	Shift Off	(XE0)	\$V	16
F15	(X30)	%U\$O	800F	Shift On	(XE1)	\$W	17
F16	(X31)	%U\$P	8010	Help	(X43)	%U/A	8021
F17	(X32)	%U\$Q	8011	Do	(X44)	%U/B	8022
F18	(X33)	%U\$R	8012	Find	(X45)	%U/C	8023
F19	(X34)	%U\$S	8013	PF1	(X46)	%U/D	8024

Table 20. DEC Keyboard Keys (Continued)

Key	Mne- monic	Code 39	ASCII Value	Key	Mne- monic	Code 39	ASCII Value
F20	(X35)	%U\$T	8014	PF2	(X47)	%U/E	8025
↑	(UP)	%U%A	801B	PF3	(X48)	%U/F	8026
↓	(DOWN)	%U%B	801C	PF4	(X49)	%U/G	8027
←	(LEFT)	%U%C	801D	Select	(X50)	%U/H	8028
→	(RIGHT)	%U%D	801E	Compose Character	(X51)	%U/I	8029
Numeric Keypad							
,	(X54)	%U/L	802C	4	(NP4)	%U4	8034
-	(X55)	%U-	802D	5	(NP5)	%U5	8035
.	(X56)	%U/N	802E	6	(NP6)	%U6	8036
0	(NP0)	%U0	8030	7	(NP7)	%U7	8037
1	(NP1)	%U1	8031	8	(NP8)	%U8	8038
2	(NP2)	\$U2	8032	9	(NP9)	\$U9	8039
3	(NP3)	%U3	8033				

IBM Terminals



NOTE

Mnemonic keys (XA)–(XF) are “on/off” keys. For example, to encode an **Alt+B** keystroke combination, you need to turn **Alt** on by entering (XA1) before the **B** and then turn it off afterward with (XA0).

Several models of IBM terminals support more than one type of keyboard. Some key definitions depend on the keyboard, while others are the same for all keyboards. Figure 9 and Figure 10 show the layouts of two IBM-terminal keyboards.

To encode a key on your keyboard, find the key in the appropriate figure. Keys that are common to both keyboards appear with their normal labels; see Table 16 for the Code 39 and ASCII equivalents for these keys. Keyboard-specific keys in the figures begin with an X (for example, X11) or have a mnemonic label; to encode those keys, see Table 21.

Figure 9. IBM 102-key keyboard




Figure 10. IBM 122-key keyboard



Table 21. IBM Terminal Keyboard Keys

Mne- monic	Code 39	ASCII Value	Mne- monic	Code 39	ASCII Value	Mne- monic	Code 39	ASCII Value
(TABR)	\$I	09	(X13)	%C	1D	(X43)	%U/A	8021
(CR)	\$M	0D	(X14)	%D	1E	(X44)	%U/B	8022
(Enter)	%U%E	801F	(X15)	%E	1F	(X45)	%U/C	8023
(UP)	%U%A	801B	(X16)	%U\$A	8001	(X46)	%U/D	8024
(DOWN)	%U%B	801C	(X17)	%U\$B	8002	(X47)	%U/E	8025
(LEFT)	%U%C	801D	(X18)	%U\$C	8003	(X48)	%U/F	8026
(RIGHT)	%U%D	801E	(X19)	%U\$D	8004	(X49)	%U/G	8027
(XA0)	\$N	0E	(X20)	%U\$E	8005	(X50)	%U/H	8028
(XA1)	\$O	0F	(X21)	%U\$F	8006	(X51)	%U/I	8029
(XB0)	\$P	10	(X22)	%U\$G	8007	(X52)	%U/J	802A
(XB1)	\$Q	11	(X23)	%U\$H	8008	(X53)	%U/K	802B
(XC0)	\$R	12	(X24)	%U\$I	8009	(X54)	%U/L	802C
(XC1)	\$S	13	(X25)	%U\$J	800A	(X55)	%U/M	802D
(XD0)	\$T	14	(X26)	%U\$K	800B	(X56)	%U/N	802E
(XD1)	\$U	15	(X27)	%U\$L	800C	(X57)	%U/O	802F
(XE0)	\$V	16	(X28)	%U\$M	800D	(X58)	%U/Z	803A
(XE1)	\$W	17	(X29)	%U\$N	800E	(X59)	%U%F	803B
(XF0)	\$X	18	(X30)	%U\$O	800F	(X60)	%U%G	803C
(XF1)	\$Y	19	(X31)	%U\$P	8010	(X61)	%U%H	803D
(X1)	\$A	01	(X32)	%U\$Q	8011	(X62)	%U%i	803E

Table 21. IBM Terminal Keyboard Keys

Mne- monic	Code 39	ASCII Value	Mne- monic	Code 39	ASCII Value	Mne- monic	Code 39	ASCII Value
(X2)	\$B	02	(X33)	%U\$R	8012	(X63)	%U%J	803F
(X3)	\$C	03	(X34)	%U\$S	8013	(X64)	%U%V	8040
(X4)	\$D	04	(X35)	%U\$T	8014	(X65)	%UA	8041
(X5)	\$E	05	(X36)	%U\$U	8015	(X66)	%UB	8042
(X6)	\$F	06	(X37)	%U\$V	8016	(X67)	%UC	8043
(X7)	\$G	07	(X38)	%U\$W	8017	(X68)	%UD	8044
(X8)	\$H	08	(X39)	%U\$X	8018	(X69)	%UE	8045
(X9)	\$J	0A	(X40)	%U\$Y	8019	(X70)	%UF	8046
(X10)	\$K	0B	(X41)	%U\$Z	801A	(X71)	%UH	8047
(X11)	%A	1B	(X42)	%USP	8020	(X72)	%U\$U	8048
(X12)	%B	1C						
Numeric Keypad								
(NP0)	%U0 or %U/P		8030		(NP5)	%U5 or %U/U		8035
(NP1)	%U1 or %U/Q		8031		(NP6)	%U6 or %U/V		8036
(NP2)	%U2 or %U/R		8032		(NP7)	%U7 or %U/S		8037
(NP3)	%U3 or %U/S		8033		(NP8)	%U8 or %U/X		8038
(NP4)	%U4 or %U/T		8034		(NP9)	%U9 or %U/Y		8039

Connectors

Host Interface Connector




Table 22

Pin #	Description	Usage Notes
1	Audio output	
2	No connection	Reserved
3	No connection	Reserved
4	No connection	Reserved
5	No connection	Reserved
6	Ready	Equivalent of Data Terminal Ready (DTR), Data Set Ready (DSR)
7	Keyboard interface	Keyboard wedge only
8	Keyboard interface	Keyboard wedge only
9	Keyboard interface	Keyboard wedge only

Table 22 (Continued)

Pin #	Description	Usage Notes
10	Keyboard interface	Keyboard wedge only
11	Serial handshake in	Serial configuration only
12	Keyboard interface	Keyboard wedge only
13	Keyboard interface	Keyboard wedge only
14	Ground	Signal ground
15	Keyboard interface	Keyboard wedge only
16	Keyboard interface	Keyboard wedge only
17	Keyboard interface	Keyboard wedge only
18	Keyboard interface	Keyboard wedge only
19	Serial handshake out	Serial configuration only
20	Serial data in	Serial configuration only
21	Serial data out	Serial configuration only
22	Serial tap in	Serial configuration only
23	+5V	
24	+12V	Serial configuration only
25	Ground	Signal ground

Input 1 Connector




Table 23

Pin #	Usage
1	Laser sync in / mag channel 1 data in
2	Bar code data in
3	Good-read out
4	Mag present in
5	Laser trigger in / mag channel 1 clock in
6	Laser-scan enable out / mag channel 2 clock in
7	Ground
8	Mag channel 2 data in
9	+5V

Input 2 Connector





Table 24

Pin #	Usage
1	Mag channel 1 data in / laser sync in (Dual model only)
2	Mag channel 3 data in / bar code data in (Dual model only)
3	Mag channel 3 clock in
4	Mag present in
5	Mag channel 1 clock in / laser trigger in (Dual model only)
6	Mag channel 2 clock in / laser scan enable out (Dual model only)
7	Ground
8	Mag channel 2 data in
9	+5V

Cloning Cable




The clip latches on one connector have been removed for easy switching of slave units. See page 32 for information about cloning.

NOTE

**DE-9 (Female)
To Input 1 on
"Master"**

**DE-9 (Female)
To Input 1 on
"Slave"**



Index

Symbols

// (end-of-string character) 22, 24, 29, 52

A

ACK/NAK protocol 40

Ames

bar codes for 87–89

programming parameters for 63

Apple Macintosh

connectors 10, 11

keyboard support 117–119

modem port 10, 11

ASCII

changing uppercase to lowercase 34,
68, 100

equivalents for serial characters 31

extended (full) 34

values for keyboard keys 112–127

Auto-Learn 19

bar codes for 75

autoscan mode 5

autoscan timeout 70

bar codes for 106

autoterminators 22, 34, 52, 113

bar codes for 100

programming parameters for 68

auxiliary serial device, installing 15

auxiliary serial input 2, 4

enabling 38

modifying *see* input editing

B

bar code reader, attaching to PowerWedge

20 9, 12

bar codes

for batch programming 74–111

for host device 107–108

for predefined defaults 18, 75, 1

for serial parameters 12, 108–111

bar codes for 108–111

batch programming 23–24, 29–31

bar code batch 23–24

bar codes for 74–111

serial batch 29–31

baud rate 36

bar codes for 109

default 12

beeper options 35, 69

bar codes for 102–103

blinking mode 5

C

cable 7, 8, 10, 11, 17, 18, 19, 20, 21, 23,
25, 27, 28, 29, 32, 36, 37, 38, 39, 40, 41,
48, 55, 60, 112, 113, 123

attaching 8–9, 10–11

for cloning 33, 132

for on-screen programming 25

keyboard wedge 13

pin assignments (pinouts) for connectors 128–132

serial 8, 10

California driver's license magnetic stripe
4, 44

bar codes for 99

CCD *see* charge-coupled device

CCD/laser redundancy 35, 68

bar codes for 101

character set, extended ASCII 34

charge-coupled device (CCD)

- attaching to PowerWedge 20 9, 12
 - redundancy option 35, 68
 - bar codes for 101
- cloning 32–33, 61
 - bar code for 32, 76
- cloning cable pin assignments (pinouts) 132
- Codabar
 - bar codes for 87–89
 - programming parameters for 63
 - wide intercharacter gaps option 34, 64
- Code 11
 - bar codes for 85–86
 - programming parameters for 63
- Code 128
 - bar codes for 92–93
 - programming parameters for 65
- Code 39
 - bar codes for 76–78
 - equivalents for keyboard keys 112–127
 - equivalents for serial characters 31
 - full (extended) ASCII option for 34
 - programming parameters for 62
- Code 93
 - bar codes for 91–92
 - programming parameters for 64
- communications (serial) 108, 111
 - default settings for 12, 15, 20
- configurations
 - eavesdrop 11
 - stand-alone 10, 11
- connectors 4
 - host interface 8, 10–11, 128
 - input 9, 12
 - pin assignments (pinouts) 128–131
- conversion options 34, 64, 65

D

- D0, D1, D2 (predefined defaults) 18, 61
 - bar codes for 18, 75
- data bits 37, 72
 - bar codes for 109
 - default setting 12
- data strings 22, 24, 29
- data type 36, 72
 - bar codes for 108
 - default 12
- decoder *see* PowerWedge 20
- defaults
 - for serial communications 12, 15, 20
 - predefined 18, 61
 - bar codes for 75, 1
- definitions (for input editing) 47–51, 56

E

- eavesdrop configuration 11
- editing input *see* input editing
- end-of-string character (*//*) 22, 24, 29, 52
- EOR-only protocol 39
- European Article Numbering (EAN)
 - bar codes for 96–98
 - EAN-13
 - converting from UPC-A 34, 64
 - converting to ISBN 65
 - extensions 34, 65, 98
 - programming parameters for 65
- extended ASCII character set 34
- extended keyboard support 112–127
- extensions (UPC, EAN, and JAN) 34, 65
 - bar codes for 97
 - programming parameters for 65
- extra fields (input editing) 53, 58

F

fields (input editing) 47
 extra 53, 58
full ASCII Code 39 34
full keyboard support 112–127

H

handheld laser, attaching to PowerWedge 20 9, 12
handshaking, Xon/Xoff 38
 bar codes for 110
 default setting 12
host device 18, 35, 71
 bar codes for 107–108
host interface connector 8, 10–11, 128
host-controlled indicators (HCI) 41–43
host-response-required option 40

I

identifying symbologies 35, 67, 101
input connectors 4, 9, 12
 pin assignments (pinouts) 128–131
input editing 45–59
 definitions 47–51, 56
 examples 46, 55–59
 extra fields 53, 58
 output sequence 47, 51, 59
 parameters 48–51, 52, 53, 54
input modes 5, 70
 bar codes for 105
installation 7–15
 auxiliary serial device 15
 bar code reader 13
 keyboard wedge 8–9
 magnetic stripe reader 14
 serial 10–12
intercharacter delay 35, 68

 bar codes for 101

interfunction delay 40, 69
 bar codes for 103
Interleaved 2 of 5
 bar codes for 78–81
 programming parameters for 62
ISBN, converting from EAN-13 65

J

Japan Article Numbering (JAN)
 bar codes for 96–98
 extensions 34, 65, 97
 programming parameters for 65

K

keyboard keys, programming 112–127
keyboard types, bar codes for 107–108
keyboard wedge
 cable 13
 installation 8–9
keyboard, modifying input from *see* input editing

L

Labelcode 4/5
 bar codes for 94
 programming parameters for 66

laser

 attaching to PowerWedge 20 9, 12
 redundancy option 35, 68
 bar codes for 101
laser modes 5, 70
 bar codes for 105

M

Macintosh
 connectors 10, 11

keyboard support 117–119
modem port 10, 11

magnetic stripe reader 4
attaching to PowerWedge 20 14
bar codes for 98–99
modifying input from *see* input editing
programming options 44
programming parameters for 66–67

Matrix 2 of 5
bar codes for 81–83
programming parameters for 62

menu programming 21–22
autoterminators 22
enabling, bar codes for 100
enabling, programming parameters for 68
entering strings 22
entering values 22

mnemonics for keyboard keys 112–127

model number 2
location of 7

models 2
dual (FD-000-22) 2
location of model number 7
standard (FD-000-20) 2

modes, laser/input 5, 70
bar codes for 105

MSI
bar codes for 89–91
programming parameters for 64

MSR *see* magnetic stripe reader

multiscan mode 5

N

normal mode 5

numeric keypad option 35, 103, 104

O

on-screen programming 25–28

output sequence (for input editing) 47, 51, 59

P

parameters
displaying and printing 28, 61
general 34–35, 62–71
for input editing 48–51, 52, 53, 54
magnetic stripe reader 44, 66–67
predefined defaults 18, 61
bar codes for 18, 75
serial 36–43, 72–73

parity 37, 72
bar codes for 110
default setting 12

pin assignments (pinouts) 128–132
cloning cable 132
input connectors 128–131

ports on Macintosh computers 10, 11

postambles 18, 24, 29, 35, 52, 68, 70
and input editing 46, 47, 51
magnetic stripe 18, 44, 66, 67

power adapter 12

PowerWedge 20
attaching power adapter to 12
bar codes for programming 74–111
input connectors 4, 9, 12
pin assignments (pinouts) 128–131

input devices 4

installation 7–15
keyboard wedge 8–9
serial 10–12

models 2

pin assignments (pinouts) 128–131

- predefined defaults 18, 61
 - bar codes for 18, 75
- programming 17–44
 - bar codes for 18, 74–111
 - resetting 18
 - supported symbologies 3
- preambles 18, 24, 29, 35, 52, 68, 70
 - and input editing 46, 47, 51
 - magnetic stripe 18, 44, 66, 67
- predefined defaults 18, 61
 - bar codes for 18, 75
- programming 17–44
 - autoterminators, setting 22
 - bar codes for 74–111
 - entering strings 22
 - entering values 22
 - menu 21–22
 - menu for 1
 - predefined defaults 61
 - bar 18
 - bar codes for 75
 - see also* parameters *and* programming methods
- programming menu 1
- programming methods
 - Auto-Learn 19
 - bar codes for 75
 - batch programming 23–24, 29–31
 - bar code batch 23–24
 - bar codes for 74–111
 - serial batch 29–31
 - cloning 32–33, 61
 - bar code for 32, 76
 - on-screen programming 25–28
 - predefined defaults 18, 61
 - bar codes for 18, 75
- programming mode

- bar codes for 100
- programming parameters for 68

protocol 39–40, 72

- ACK/NAK 40
- bar codes for 111
- end-of-record (EOR) 39

Q

- qualification definitions (for input editing) 47–51, 56

R

- require-host-response option 40, 73
 - bar codes for 111

S

scanner

- attaching to PowerWedge 20 9, 12
- modifying input from *see* input editing

- serial batch programming 29–31

- serial characters 31

- serial communications

- bar codes for 108–111

- default settings for 12, 15, 20

- parameters for 36–43, 72–73

- serial communications, bar codes for 12

- serial device (auxiliary), installing 15

- serial installation 10–12

- cable for 8

- configurations

- eavesdrop 11

- stand-alone 10, 11

- serial programming parameters 36–43, 72–73

- bar codes for 108–111

- default settings for 12

stand-alone configuration 10, 11
Standard 2 of 5
 bar codes for 83–85
 programming parameters for 63
stop bits 37, 72
 bar codes for 110
 default setting 12
strings 22, 24, 29
 terminator for (//) 22, 24, 29
 see also output sequence
Symbol blinking mode 5
symbolologies 3
symbology identifiers 35, 67, 101

T

terminators for data string (//) 22, 24, 29
timeout
 autoscan 70
 bar codes for 106
 serial 39–40, 73

U

Universal Product Code (UPC)
 conversion options 34, 64, 65
 extensions 34
 bar codes for 97–98
 programming parameters for 65
UPC-A
 bar codes for 94–95
 converting from UPC-E 34, 65
 converting to EAN-13 34, 64
 programming parameters for 64
UPC-E
 bar codes for 95–96
 converting to UPC-A 34, 65
 programming parameters for 65

V
values, entering 22

W

wand
 attaching to PowerWedge 20 9, 12
wedge
 cable 13
 installation 8–9
wide intercharacter gaps option for Coda-
bar 34, 89

X

Xon/Xoff handshaking 38
 bar codes for 110
 default setting 12

Z
“zap” character 113

NOTES

Technical Support

PSC Website Technical Support

The most comprehensive source for technical support and information for PSC products is the PSC website: www.pscnet.com. The site offers product support, product registration, warranty information, answers to frequently asked questions (product FAQs), product manuals, product tech notes, software updates, patches, demos, and instructions for returning products for repair.

Reseller Technical Support

Another excellent source for technical assistance and information is an authorized PSC reseller. A reseller is directly acquainted with specific types of businesses, application software, and computer systems and, therefore, is in the best position to provide individualized assistance.

E-Mail Technical Support

If the solution to a technical support question is not available through the PSC website or a local reseller, contact PSC technical support directly via E-mail at TechSupport@pscnet.com.























Telephone Technical Support

For those without E-mail access, call toll-free in the USA 1 (800) 547-2507 or (541) 683-5700 from outside the United States of America.

PSC Solutions Group

For advanced, cost-effective services, contact the PSC Solutions Group (PSG) at (888) 583-3008 or (541) 683-5700 from outside the United States of America, or psg@pscnet.com. You can also visit PSG's webpage, accessible at www.pscnet.com.

Bar Code Menu

START	 * \$ + \$ - *	OFF	 0	5	 * 5 *
ESC	 * % A *	ON	 1	6	 * 6 *
//	 * / / *	2	 * 2 *	7	 * 7 *
A	 * A *	3	 * 3 *	8	 * 8 *
B	 * B *	4	 * 4 *	9	 * 9 *
C	 * C *	<div style="border: 1px solid black; padding: 10px;"> <p>PREDEFINED DEFAULTS</p> <p>DO  * \$ + \$ - D 0 E E *</p> <p>D1  * \$ + \$ - D 1 E E *</p> <p>D2  * \$ + \$ - D 2 E E *</p> </div>			
D	 * D *				
E	 * E *				
F	 * F *				

Asia Pacific

PSC Hong Kong
Hong Kong
Telephone: [852]-2-584-6210
Fax: [852]-2-521-0291

Australia

PSC Asia Pacific Pty Ltd.
North Ryde, Australia
Telephone: [61] 0 (2) 9878 8999
Fax: [61] 0 (2) 9878 8688

France

PSC S.A.R.L.
LES ULIS Cedex, France
Telephone: [33].01.64.86.71.00
Fax: [33].01.64 46.72.44

Germany

PSC GmbH
Darmstadt, Germany
Telephone: 49 (0) 61 51/93 58-0
Fax: 49 (0) 61 51/93 58 58

Corp. Headquarters

PSC Inc.
Portland, OR
Telephone: (503) 553-3920
Fax: (503) 553-3940

Italy

PSC S.p.A.
Vimercate (MI), Italy
Telephone: [39] (0) 39/62903.1
Fax: [39] (0) 39/685496

Japan

PSC Japan K.K.
Shinagawa-ku, Tokyo, Japan
Telephone: 81 (0)3 3491 6761
Fax: 81 (0)3 3491 6656

Latin America

PSC S.A., INC.
Miami, Florida, USA
Telephone: (305) 539-0111
Fax: (305) 539-0206

United Kingdom

PSC Bar Code Ltd.
Watford, England
Telephone: 44 (0) 1923 809500
Fax: 44 (0) 1923 809 505



www.pscnet.com

PSC Inc.

959 Terry Street
Eugene, OR
Telephone: (541) 683-5700
Fax: (541) 345-7140



Printed on recycled paper

