

**Intermec**

**Reference  
Manual**

# 97XX Wedge Interface

Intermec® Corporation  
6001 36th Avenue West  
P.O. Box 4280  
Everett, WA 98203-9280

U.S. service and technical support: 1-800-755-5505  
U.S. media supplies ordering information: 1-800-227-9947

Canadian service and technical support: 1-800-688-7043  
Canadian media supplies ordering information: 1-800-268-6936

Outside U.S. and Canada: Contact your local Intermec service supplier.

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Intermec manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Information and specifications in this manual are subject to change without notice.

© 1996 by Intermec Corporation  
All Rights Reserved

The word Intermec, the Intermec logo, JANUS, IRL, Duratherm, Virtual Wedge, and CrossBar are trademarks of Intermec Corporation.

Throughout this manual, trademarked names may be used. Rather than put a trademark (™) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

### ***Manual Change Record***

This page records the changes to this manual. The manual was originally released as version A.

<b>Version</b>	<b>Date</b>	<b>Description of Change</b>
B	6/91	The configuration I.D. for the Unisys PW2 286 was changed from 0 to 339. A separate section was made for the AT&T 6580 and 6591 stations. The terminal cable number for the AT&T 65XX section was changed back to the old number: 054228.
C	10/91	A new section was added which combined the NEC 386, the IBM PC/ST/AT Series, and the Compaq/PS-2 Series sections into one section.
D	2/92	The Wang 4230 section was added to the reference manual. The existing Wang 4230, 4430 section was changed to the Wang 4230A, 4430 section.
-001	9/96	Reformatted and updated to wedge software release F.





# Contents

<i>AT&amp;T 615 and 65XX Series</i>	1
<i>AT&amp;T 6286</i>	3
<i>AT&amp;T 6580 and 6591</i>	4
<i>Bull DKU 710X Series</i>	5
<i>Bull Questar 210</i>	6
<i>Burroughs UniSys Series</i>	7
<i>Compaq/PS-2 Series</i>	8
<i>DEC VT and VXT Series</i>	12
<i>Decision Data 349X Series</i>	16
<i>Decision Data 3791</i>	18
<i>Decision Data Series</i>	19
<i>Harris Series</i>	26
<i>HP 2392A</i>	27
<i>HP HIL Series</i>	29
<i>IBM 3151 and 34XX Series</i>	35
<i>IBM 316X and 319X Series</i>	45
<i>IBM 3178</i>	48
<i>IBM 7552</i>	49
<i>IBM PC/XT/AT Series</i>	50
<i>Idea Courier</i>	55
<i>I-O Corporation Series</i>	56
<i>LynkLyte Series</i>	58
<i>Macintosh II and SE Series</i>	59
<i>Memorex/Telex 2291 and 2391</i>	62
<i>Memorex/Telex Series</i>	63
<i>Microterm 5530</i>	65
<i>NEC 386</i>	66
<i>Nokia 4111 and 9164 Series</i>	67
<i>Nokia 9014 DU</i>	68
<i>PC/AT, PS/2 Universal</i>	69
<i>Sun Stations Series</i>	86
<i>Unisys 1120</i>	87
<i>Unisys 1224</i>	89
<i>Unisys SVT 1220</i>	91
<i>WANG 4230</i>	92
<i>WANG 4230A</i>	93
<i>WANG 4430</i>	93
<i>Wyse 50</i>	94
<i>Wyse Series</i>	95

## Alphabetical List of Contents

*Note: The bold entries represent individual Wedge Interface Guide (WIF) headings as well as workstation models. The regular entries represent workstation models contained within the individual WIF Guides.*

*Alfaskop DS/DT 50, 69*  
*AST 286/386 50, 69*  
*AT&T 605 50, 69*  
*AT&T 615 1*  
***AT&T 615 and 65XX Series 1***  
***AT&T 6286 3***  
*AT&T 6386SX 8*  
*AT&T 6386SX and 6386WGS 69*  
*AT&T 6386WGS 8*  
*AT&T 6518 1*  
*AT&T 6528 1*  
*AT&T 6529 1*  
*AT&T 6538 1*  
*AT&T 6539 1*  
*AT&T 6578 1*  
*AT&T 6579 1*  
*AT&T 6580 4*  
***AT&T 6580 and 6591 4***  
*AT&T 6591 4*  
*Bull DKU 7102 5*  
*Bull DKU 7104 5*  
*Bull DKU 7105 5*  
*Bull DKU 7107 5*  
***Bull DKU 710X Series 5***  
***Bull Questar 210 6***  
*Burroughs UniSys B25 7*  
*Burroughs UniSys B28 7*  
***Burroughs UniSys Series 7***  
*Compaq 286/386 50, 69*  
*Compaq 286/e 8, 69*  
*Compaq 386/20e 8, 69*  
*Compaq 386/33 8, 69*  
*Compaq 386/s 8, 69*  
*Compaq 486 8, 69*  
*Compaq Prolinea 69*  
***Compaq/PS-2 Series 8***  
*DEC 486 69*  
***DEC VT and VXT Series 12***  
*DEC VT1000 12*



<i>DEC VT1200</i>	12
<i>DEC VT220</i>	12
<i>DEC VT240</i>	12
<i>DEC VT241</i>	12
<i>DEC VT320</i>	12
<i>DEC VT330</i>	12
<i>DEC VT340</i>	12
<i>DEC VT420</i>	12
<i>DEC VT510</i>	69
<i>DEC VT520</i>	69
<i>DEC VT525</i>	69
<i>DEC VXT2000</i>	12
<i>Decision Data 3496</i>	16
<i>Decision Data 3497</i>	16
<b><i>Decision Data 349X Series</i></b>	<b>16</b>
<i>Decision Data 3596</i>	19
<i>Decision Data 3597</i>	19
<i>Decision Data 3697</i>	19
<i>Decision Data 3776</i>	19
<i>Decision Data 3777</i>	19
<b><i>Decision Data 3791</i></b>	<b>18</b>
<b><i>Decision Data Series</i></b>	<b>19</b>
<i>Dell Dimension 386 and 486</i>	69
<i>Dell Optiplex 486 PC</i>	69
<i>Gateway 2000 386</i>	69
<i>Gateway 2000 486</i>	69
<i>Harris 179</i>	26
<i>Harris 180</i>	26
<i>Harris 192</i>	26
<b><i>Harris Series</i></b>	<b>26</b>
<b><i>HP 2392A</i></b>	<b>27</b>
<i>HP 486</i>	69
<i>HP 700/32</i>	19
<i>HP 700/43</i>	19
<i>HP 700/44</i>	19
<i>HP 700/60</i>	19
<i>HP 700/92</i>	19
<i>HP 700/94</i>	19
<i>HP 700/96</i>	19
<i>HP 700/98</i>	19
<b><i>HP HIL Series</i></b>	<b>29</b>
<i>HP Vectra ES</i>	50
<i>HP Vectra ES</i>	69
<i>HP X-Station 700/RX</i>	69
<i>IBM 3151</i>	35

## **97XX Wedge Interface Reference Manual**

### **IBM 3151 and 34XX Series 35**

IBM 3161 45

IBM 3162 45

IBM 3163 45

IBM 3164 45

### **IBM 316X and 319X Series 45**

**IBM 3178 48**

IBM 3191 45

IBM 3192 45

IBM 3193 45

IBM 3196 45

IBM 3197 45

IBM 3471 35

IBM 3472 35

IBM 3476 35

IBM 3477 35

IBM 3481 35

IBM 3482 35

IBM 3486 35

IBM 3487 35

IBM 3488 35

IBM 7531 50

IBM 7531 69

IBM 7532 50

**IBM 7552 49**

IBM AT 50, 69

IBM PC/XT 50, 69

### **IBM PC/XT/AT Series 50**

IBM PS/1 69

IBM PS/2 25, 69

IBM PS/2 30 69

IBM PS/2 50 69

IBM PS/2 50Z 69

IBM PS/2 55SX 69

IBM PS/2 60 69

IBM PS/2 70 69

IBM PS/2 80 69

IBM PS/2 90 69

IBM PS/2 95 69

IBM ValuePoint 69

### **Idea Courier 55**

Idea Courier 12471 55

Idea Courier 12472-01C 55

Idea Courier 9292 50, 69

I-O Corporation 1181D 56



<i>I-O Corporation 1181EP</i>	56
<i>I-O Corporation 1181ES</i>	56
<i>I-O Corporation 1181WP</i>	56
<i>I-O Corporation 1196</i>	56
<i>I-O Corporation 1196D</i>	56
<i>I-O Corporation 1197</i>	56
<i>I-O Corporation 2196</i>	56
<i>I-O Corporation 2476C</i>	56
<i>I-O Corporation 2497C</i>	56
<i>I-O Corporation 2497D</i>	56
<b><i>I-O Corporation Series</i></b>	<b>56</b>
<i>ITF Keyboard 46020A or 46021A</i>	29
<b><i>LynkLyte Series</i></b>	<b>58</b>
<i>Macintosh II</i>	59
<b><i>Macintosh II and SE Series</i></b>	<b>59</b>
<i>Macintosh SE</i>	59
<i>Memorex/Telex 1191</i>	63
<i>Memorex/Telex 1192</i>	63
<i>Memorex/Telex 1196</i>	63
<i>Memorex/Telex 1197</i>	63
<i>Memorex/Telex 1471</i>	63
<i>Memorex/Telex 1472</i>	63
<i>Memorex/Telex 1476</i>	63
<i>Memorex/Telex 1477</i>	63
<i>Memorex/Telex 2291</i>	62
<b><i>Memorex/Telex 2291 and 2391</i></b>	<b>62</b>
<i>Memorex/Telex 2296</i>	63
<i>Memorex/Telex 2391</i>	62
<b><i>Memorex/Telex Series</i></b>	<b>63</b>
<b><i>Microterm 5530</i></b>	<b>65</b>
<i>NCD X-Station 15-b</i>	69
<i>NEC 286</i>	50
<i>NEC 386</i>	69
<b><i>NEC 386</i></b>	<b>66</b>
<b><i>Nokia 4111 and 9164 Series</i></b>	<b>67</b>
<i>Nokia 4111 DU</i>	67
<i>Nokia 7414-0011</i>	50, 69
<b><i>Nokia 9014 DU</i></b>	<b>68</b>
<i>Nokia 9164 DU</i>	67
<i>Nokia ASC/AWS</i>	50, 69
<i>Nokia Mikro Mikko 3/4</i>	50, 69
<i>Nokia VDU 192</i>	50, 69
<b><i>PC/AT, PS/2 Universal</i></b>	<b>69</b>
<i>PS/2 25</i>	8
<i>PS/2 30</i>	8
<i>PS/2 50</i>	8

## **97XX Wedge Interface Reference Manual**

*PS/2 50Z 8*  
*PS/2 55SZ 8*  
*PS/2 60 8*  
*PS/2 70 8*  
*PS/2 80 8*  
*PS/2 90 8*  
*PS/2 95 8*  
**Sun Stations Series 86**  
*Tandy 1000 50*  
*Tandy 1000 69*  
*Tandy 2500 8, 69*  
*Tandy 4016 8, 69*  
*Tandy 5000 8, 69*  
*Tektronix X-Station XP11 69*  
**Unisys 1120 87**  
**Unisys 1224 89**  
*Unisys PW2 286 50, 69*  
**Unisys SVT 1220 91**  
*Vectra Keyboard 46030A 29*  
*Wang 240 50, 69*  
*Wang 280 50, 69*  
*Wang 380 50, 69*  
**WANG 4230 92**  
**WANG 4230A, 4430 93**  
*WANG 4430 93*  
*Wyse 150 95*  
*Wyse 160 95*  
*Wyse 185 95*  
*Wyse 2108 95*  
*Wyse 2112 95*  
*Wyse 2116 95*  
*Wyse 2200 95*  
*Wyse 285 95*  
*Wyse 30 95*  
*Wyse 3116SX 95*  
*Wyse 3216 95*  
*Wyse 3225 95*  
*Wyse 325 95*  
**Wyse 50 94**  
*Wyse 60 95*  
*Wyse 85 95*  
**Wyse Series 95**  
*Wyse WM-15C 95*  
*Wyse WM-17C 95*



*This reference manual is a collection of all the individual wedge reference (WIF) guides. It lists the part numbers for wedge interface kit, keyboard and terminal cables, and gives the power supply requirements and bar codes for configuring the wedge reader for specific terminal. Use this reference manual with a Wedge Reader User's Manual for complete instructions on using a wedge reader.*

## **AT&T 615 and 65XX Series**

---

This section covers these workstations:

- AT&T 615
- AT&T 6518
- AT&T 6528
- AT&T 6529
- AT&T 6538
- AT&T 6539
- AT&T 6578
- AT&T 6579

The individual Wedge Interface Guide corresponding to this section is part number 0542351.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use these part numbers:

- Wedge interface kit - Part No. 054230
- Keyboard cable - Part No. 054229
- Terminal cable - Part No. 054228

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

## ***Configuring the Reader***

Scan the appropriate label in this table to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beep identification.

To Set Workstation Configuration to	Scan This Bar Code
AT&T 615	 * \$+TA320 *
AT&T 6518, 6578	 * \$+TA104 *
AT&T 6528	 * \$+TA105 *
AT&T 6529	 * \$+TA106 *
AT&T 6538	 * \$+TA107 *
AT&T 6539	 * \$+TA108 *
AT&T 6579	 * \$+TA110 *

## AT&T 6286

---

This section covers the AT&T 6286 workstation. The individual Wedge Interface Guide corresponding to this section is Part No. 054235.

*Note: The AT&T 6286 terminal is not supported with the introduction of wedge software release F (November 1995).*

---

### ***Cables***

Connecting the reader to the workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054234
- Keyboard cable - Part No. 054233
- Terminal cable - Part No. 054232

---

### ***Power Supply***

The reader does not require an external power supply to work with the AT&T 6286 workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

AT&T 6286



\*\$+TA102\*

## AT&T 6580 and 6591

---

This section covers these workstations:

- AT&T 6580
- AT&T 6591

*Note: These terminals are not supported with the introduction of wedge software release F (November 1995).*

The individual Wedge Interface Guide corresponding to this section is part number 056310.

---

### **Cables**

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 056309
- Keyboard cable - Part No. 054229
- Terminal cable - Part No. 056307

---

### **Power Supply**

The reader does not require an external power supply to work with the workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

AT&T 6580, 6591



\*\$+TA111\*



## ***Bull DKU 710X Series***

---

This section covers these workstations:

- Bull DKU 7102
- Bull DKU 7104
- Bull DKU 7105
- Bull DKU 7107

The individual Wedge Interface Guide corresponding to this section is part number 054275.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054274
- Keyboard cable - Part No. 054273
- Terminal cable - Part No. 054272

---

### ***Power Supply***

The reader does not require an external power supply to work with this workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Bull DKU 7102, 7104, 7105, 7107



\*\$+TA113\*

## **Bull Questar 210**

---

This section covers the Bull Questar 210 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054146.

---

### ***Cables***

Connecting the reader to this workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054145
- Keyboard cable - Part No. 054144
- Terminal cable - Part No. 054143

---

### ***Power Supply***

The reader does not require an external power supply to work with this workstation. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel even though an external power supply is not used. This is an exception for the Bull Questar 210.



#### **Caution**

*Failure to have the PCB jumper on pins 2 and 3 will damage the reader.*

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Bull Questar 210



\*\$+TA4\*





## **Burroughs UniSys Series**

---

This section covers these workstations:

- Burroughs UniSys B25
- Burroughs UniSys B28

The individual Wedge Interface Guide corresponding to this section is part number 055398.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 055397
- Keyboard cable - Part No. 055396
- Terminal cable - Part No. 055395

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Burroughs UniSys B25, B28



\*\$+TA103\*

## **Compaq/PS-2 Series**

---

This section covers these workstations:

- AT&T 6386SX
- AT&T 6386WGS
- Compaq 286/e
- Compaq 386/s
- Compaq 386/20e
- Compaq 386/33
- Compaq 486
- PS/2 25
- PS/2 30
- PS/2 50
- PS/2 50Z
- PS/2 55SZ
- PS/2 60
- PS/2 70
- PS/2 80
- PS/2 90
- PS/2 95
- Tandy 2500
- Tandy 4016
- Tandy 5000

The individual Wedge Interface Guide corresponding to this section was revised to include more terminals. It is now titled "PC/AT, PS/2 Universal" and is part number 056945.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 056944
- Keyboard cable - Part No. 054140
- Terminal cable - Part No. 056311
- Adapter - Part No. 056943

---

### ***Power Supply***

The reader does not require an external power supply to work with these workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.



---

## ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

### **To Set Workstation Configuration to**

### **Scan This Bar Code**

AT&T 6386SX, AT&T 6386 WGS



\*\$+TA1\*

Compaq  
US Keyboard



\*\$+TA5\*

Compaq  
Danish Keyboard



\*\$+TA7\*

Compaq  
French Keyboard



\*\$+TA8\*

Compaq  
French Canadian Keyboard



\*\$+TA9\*

Compaq  
German Keyboard



\*\$+TA15\*

Compaq  
Italian Keyboard



\*\$+TA10\*

Compaq  
Norwegian Keyboard



\*\$+TA11\*

Compaq  
Spanish Keyboard



\*\$+TA12\*

Compaq  
Swedish/Finnish Keyboard



\*\$+TA13\*

To Set Workstation Configuration to

Compaq  
Swiss Keyboard

Scan This Bar Code



\*\$+TA14\*

Compaq  
United Kingdom Keyboard



\*\$+TA6\*

PS/2 101/102-keys  
US Keyboard



\*\$+TA87\*

PS/2 101/102-keys  
Arabic Keyboard



\*\$+TA208\*

PS/2 101/102-keys  
Belgian Keyboard



\*\$+TA195\*

PS/2 101/102-keys  
Danish Keyboard



\*\$+TA196\*

PS/2 101/102-keys  
Dutch Keyboard



\*\$+TA197\*

PS/2 101/102-keys  
French Keyboard



\*\$+TA199\*

PS/2 101/102-keys  
French Canadian Keyboard



\*\$+TA198\*

PS/2 101/102-keys  
German Keyboard



\*\$+TA200\*

PS/2 101/102-keys  
Israeli Keyboard




\*\$+TA209\*

PS/2 101/102-key  
Italian Keyboard



\*\$+TA201\*



**To Set Workstation Configuration to**

**Scan This Bar Code**

PS/2 101/102-keys  
Latin American  
Spanish Keyboard



\*\$+TA202\*

PS/2 101/102-keys  
Norwegian Keyboard



\*\$+TA203\*

PS/2 101/102-keys  
Portuguese Keyboard



\*\$+TA204\*

PS/2 101/102-keys  
Spanish Keyboard



\*\$+TA205\*

PS/2 101/102-keys  
Swedish Keyboard



\*\$+TA206\*

PS/2 101/102-keys  
Swiss Keyboard



\*\$+TA207\*

PS/2 101/102-keys  
United Kingdom Keyboard



\*\$+TA194\*

Tandy 2500, 4016, 5000



\*\$+TA1\*

Tandy 2500, 4016, 5000  
Host-Connected Keyboard



\*\$+TA450\*

## **DEC VT and VXT Series**

---

This section covers these workstations:

- DEC VT240
- DEC VT220
- DEC VT241
- DEC VT320
- DEC VT330
- DEC VT420
- DEC VT340
- DEC VT1000
- DEC VT1200
- DEC VXT2000

The individual Wedge Interface Guide corresponding to this section is part number 054134.

---

### ***Cables***

Use the two cables supplied with this WIF kit to connect the reader to your workstation and keyboard, as shown in your *Wedge Reader User's Manual*. To order a replacement cable, use these part numbers:

- Wedge interface kit - Part No. 054133
- Keyboard cable - Part No. 054132
- Terminal cable - Part No. 054131

---

### ***Power Supply***

The reader requires an external power supply only if you use a laser scanner with these workstations. Otherwise, the reader does not require an external power supply. For either type of power supply, set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

**Note:** *If you use an external power supply with the reader, you must plug in the power supply before switching on the workstation. If you do not, the reader will lock up.*

---

### ***DEC VT420 Firmware Version***

If you are using a DEC VT420, you must determine the terminal's firmware version (1.x or 2.x) before you configure the reader.

To determine the firmware version

1. Turn on the VT420 terminal.
2. Press **F2** (Alt-Setup). The firmware version (1.x or 2.x) is displayed on the right side of the screen. Take note of the number.
3. Scan the correct configuration label from the next section, "Configuring the Reader," making sure it matches your terminal's firmware version.



For example, the table below contains two configuration labels for VT420 terminals with German keyboards:

DEC VT 420 (1.x Firmware) LK201 and LK401 German Keyboard	 *\$+TA401*
---	--



DEC VT 420 (2.x Firmware) LK201 and LK401 German Keyboard	 *\$+TA406*
---	--

If your VT420 has version 1.0 firmware and a German keyboard, you must scan the first label to configure your reader.

---

## ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. The reader should emit one low beep followed by four low beeps, indicating that the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
DEC VT 220, 240, 241, 320, 330, 340 LK201 US/United Kingdom Keyboard	 *\$+TA16*
DEC VT 220, 240, 241, 320, 330, 340 LK201 Danish Keyboard	 *\$+TA18*
DEC VT 220, 240, 241, 320, 330, 340 LK201 Finnish Keyboard	 *\$+TA19*
DEC VT 220, 240, 241, 320, 330, 340 LK201 French Keyboard	 *\$+TA20*
DEC VT 220, 240, 241, 320, 330, 340 LK201 French Canadian Keyboard	 *\$+TA17*
DEC VT 220, 240, 241, 320, 330, 340 LK201 German Keyboard	 *\$+TA21*
DEC VT 220, 240, 241, 320, 330, 340 LK201 Italian Keyboard	 *\$+TA212*

**To Set Workstation Configuration to**

DEC VT 220, 240, 241, 320, 330, 340  
LK201 Norwegian Keyboard

**Scan This Bar Code**



\*\$+TA213\*

DEC VT 220, 240, 241, 320, 330, 340  
LK201 Spanish Keyboard



\*\$+TA214\*

DEC VT 220, 240, 241, 320, 330, 340  
LK201 Swedish Keyboard



\*\$+TA215\*

DEC VT 420 (1.x Firmware)  
LK201 and LK401 US Keyboard



\*\$+TA22\*

DEC VT 420 (1.x Firmware)  
LK201 and LK401 French Keyboard



\*\$+TA400\*

DEC VT 420 (1.x Firmware)  
LK201 and LK401 German  
Keyboard



\*\$+TA401\*

DEC VT 420 (1.x Firmware)  
LK201 and LK401 Italian  
Keyboard



\*\$+TA402\*

DEC VT 420 (1.x Firmware)  
LK201 and LK401 Spanish  
Keyboard



\*\$+TA403\*

DEC VT 420 (2.x Firmware)  
LK201 and LK401 US Keyboard



\*\$+TA404\*

DEC VT 420 (2.x Firmware)  
LK201 and LK401 French  
Keyboard



\*\$+TA405\*

DEC VT 420 (2.x Firmware)  
LK201 and LK401 German Keyboard



\*\$+TA406\*

DEC VT 420 (2.x Firmware)  
LK201 and LK401 Italian  
Keyboard



\*\$+TA407\*





**To Set Workstation Configuration to**

DEC VT 420 (2.x Firmware)  
LK201 and LK401 Spanish  
Keyboard

DEC VT 1000, 1200  
LK401 US Keyboard

DEC VXT2000  
LK401-AA  
US/United Kingdom Keyboard

**Scan This Bar Code**



\*\$+TA408\*



\*\$+TA22\*



\*\$+TA16\*

## Decision Data 349X Series

---

This section covers these workstations:

- Decision Data 3496
- Decision Data 3497

The individual Wedge Interface Guide for this section is part number 054271.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054270
- Keyboard cable - Part No. 054269
- Terminal cable - Part No. 054268

---

### ***Power Supply***

The reader does not require an external power supply to work with the Decision Data 349X workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

#### **To Set Workstation Configuration to**

Decision Data 3496  
83-key Keyboard

#### **Scan This Bar Code**



\*\$+TA90\*

Decision Data 3496  
102-key Keyboard



\*\$+TA217\*



To Set Workstation Configuration to

Decision Data 3496  
122-key Keyboard

Scan This Bar Code



Decision Data 3497  
83-key Keyboard



Decision Data 3497  
102-key Keyboard



Decision Data 3497  
122-key Keyboard



## Decision Data 3791

---

This section covers the Decision Data 3791 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054765.

---

### **Cables**

Connecting the reader to the Decision Data 3791 workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054764
- Keyboard cable - Part No. 054763
- Terminal cable - Part No. 054762

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Workstation Configuration**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to

83-key Keyboard

Scan This Bar Code



\*\$+TA227\*

122-key Keyboard



\*\$+TA314\*



## Decision Data Series

---

This section covers these workstations:

- Decision Data 3596
- Decision Data 3597
- Decision Data 3697
- Decision Data 3776
- Decision Data 3777
- HP 700/32
- HP 700/43
- HP 700/44
- HP 700/60
- HP 700/92
- HP 700/94
- HP 700/96
- HP 700/98

The individual Wedge Interface Guide corresponding to this section is part number 054288.

---

### **Cables**

Use the two cables supplied with this WIF kit to connect the reader to your workstation and keyboard, as shown in your *Wedge Reader User's Manual*. To order a replacement cable, use these part numbers:

- Wedge interface kit - Part No. 054287
- Keyboard cable - Part No. 054286
- Terminal cable - Part No. 054285

---

### **Power Supply**

The reader might require external power, depending on the type of workstation you use:

#### **Workstation**

Decision Data 3776  
 Decision Data 3777  
 Decision Data 3697  
 HP 700/43  
 HP 700/92  
 HP 700/94  
 HP 700/96

#### **Power Supply and Jumper Setting**

The reader does not require an external power supply to work with these workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

#### **Workstation**

Decision Data 3596  
 Decision Data 3597  
 HP 700/32  
 HP 700/44  
 HP 700/60  
 HP 700/98

#### **Power Supply and Jumper Setting**

The reader requires an external power supply to work with these workstations. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

**Note:** *If you use an external power supply for the reader, plug in the power supply before switching on the workstation. If you do not, the reader will lock up.*

---

## Configuring the Reader

Scan the appropriate label to configure the reader for your workstation. The reader should emit one low beep followed by four low beeps, indicating that the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

### To Set Workstation Configuration to

### Scan This Bar Code

Decision Data 3596, 3597, 3697  
83-key Keyboard



\*\$+TA173\*

Decision Data 3596, 3597, 3697  
102-key Keyboard



\*\$+TA222\*

Decision Data 3596, 3597, 3697  
122-key Keyboard



\*\$+TA172\*

Decision Data 3776, 3777  
102-key Keyboard



\*\$+TA460\*

Decision Data 3776, 3777  
122-key Keyboard



\*\$+TA461\*

HP 700/32  
ANSI US Keyboard



\*\$+TA413\*

HP 700/32  
ANSI French Keyboard



\*\$+TA414\*

HP 700/32  
ANSI German Keyboard



\*\$+TA415\*

HP 700/32  
ANSI Italian Keyboard




\*\$+TA416\*

HP 700/32  
ANSI Spanish Keyboard



\*\$+TA417\*



To Set Workstation Configuration to

Scan This Bar Code

HP 700/43  
US Keyboard



\*\$+TA298\*

HP 700/43  
Canadian/French Canadian  
Keyboard



\*\$+TA328\*

HP 700/43  
Danish Keyboard



\*\$+TA336\*

HP 700/43  
Dutch Keyboard



\*\$+TA342\*

HP 700/43  
Finnish/Swedish Keyboard



\*\$+TA335\*

HP 700/43  
Flemish/French Keyboard



\*\$+TA334\*

HP 700/43  
German Keyboard



\*\$+TA329\*

HP 700/43  
Latin American Keyboard



\*\$+TA331\*

HP 700/43  
Norwegian Keyboard



\*\$+TA332\*

HP 700/43  
Spanish Keyboard



\*\$+TA340\*

HP 700/43  
Swiss (French/German)  
Keyboard



\*\$+TA337\*

HP 700/43  
United Kingdom Keyboard



\*\$+TA333\*

To Set Workstation Configuration to

Scan This Bar Code

HP 700/44  
US Keyboard



\*\$+TA423\*

HP 700/44  
French Keyboard



\*\$+TA424\*

HP 700/44  
German Keyboard



\*\$+TA425\*

HP 700/44  
Italian Keyboard



\*\$+TA426\*

HP 700/44  
Spanish Keyboard



\*\$+TA427\*

HP 700/60  
ANSI US Keyboard



\*\$+TA418\*

HP 700/60  
PC US Keyboard



\*\$+TA462\*

HP 700/60  
ANSI French Keyboard



\*\$+TA419\*

HP 700/60  
PC French Keyboard



\*\$+TA463\*

HP 700/60  
ANSI German Keyboard



\*\$+TA420\*

HP 700/60  
PC German Keyboard



\*\$+TA464\*

HP 700/60  
ANSI Italian Keyboard



\*\$+TA421\*



**To Set Workstation Configuration to****Scan This Bar Code**

HP 700/60  
PC Italian Keyboard



\*\$+TA465\*

HP 700/60  
ANSI Spanish Keyboard



\*\$+TA422\*

HP 700/60  
PC Spanish Keyboard



\*\$+TA466\*

HP 700/92, 700/94, 700/96, 700/98  
US Keyboard



\*\$+TA303\*

HP 700/92, 700/94, 700/98  
Canadian/French Canadian  
Keyboard



\*\$+TA343\*

HP 700/92, 700/94, 700/98  
Danish/Norwegian Keyboard



\*\$+TA347\*

HP 700/92, 700/94, 700/98  
Dutch Keyboard



\*\$+TA358\*

HP 700/92, 700/94, 700/98  
Finnish/United Kingdom Keyboard



\*\$+TA348\*

HP 700/92, 700/94, 700/96, 700/98  
Flemish/French Keyboard



\*\$+TA349\*

HP 700/92, 700/94, 700/98  
German Keyboard



\*\$+TA344\*

HP 700/92, 700/94, 700/98  
Italian Keyboard



\*\$+TA352\*

HP 700/92, 700/94, 700/98  
Latin American Keyboard



\*\$+TA346\*

**To Set Workstation Configuration to**

HP 700/92, 700/94, 700/96, 700/98  
Spanish Keyboard

**Scan This Bar Code**



\*\$+TA356\*

HP 700/92, 700/94, 700/98  
Swedish Keyboard



\*\$+TA355\*

HP 700/92, 700/94, 700/98  
Swiss (French/German) Keyboard



\*\$+TA353\*

HP 700/96  
German Keyboard



\*\$+TA499\*

HP 700/96  
Italian Keyboard



\*\$+TA500\*

---

## ***Keyboard Equivalent Tables***

Several HP workstations use special keyboard mapping:

- HP 700/32 uses standard ASCII mapping (Table A-3, *Wedge Reader User's Manual*).
- HP 700/44 uses standard PC mapping (Table A-1, *Wedge Reader User's Manual*).
- With an ANSI keyboard, HP 700/60 uses standard ASCII mapping (Table A-3, *Wedge Reader User's Manual*). With a PC keyboard, HP700/60 uses standard PC mapping (Table A-1 *Wedge Reader User's Manual*).
- HP 700/43, 700/92, 700/96, and 700/98 use the next map.

**Note:** *Alphanumeric characters (Aa to Zz, and 0 to 9) are not listed in this table because the workstation's keystrokes match the ASCII characters.*

---

 HP 700/43, HP 700/92, 700/96, and HP 700/98 Keyboard Mapping

ASCII Character	Keystroke	ASCII Character	Keystroke
NUL	+ Num	SP	Spacebar
SOH	Left Enter	!	!
STX	Left Extend Char/ Scroll Lock	"(quote)	"(quote)
ETX	- Num	#	#
EOT	Ins Char	\$	\$
ENQ	Del Char	%	%
ACK	Ins Line	&	&
BEL	Del Line	'(apostrophe)	'(apostrophe)
BS	Scroll Down	(	(
HT	→  (tab)	)	)
LF	Caps Lock	*	*
VT	← (tab)/Funct	+	+
FF	Scroll Up	, (comma)	, (comma)
CR	↵ (Return)	-(dash)	-(dash)
SO	Ctrl	. (period)	. (period)
SI	↑ (shift)	/	/
DLE	F1	:	:
DC1	F2	;	;
DC2	F3	<	<
DC3	F4	=	=
DC4	F5	>	>
NAK	F6	?	?
SYN	F7	@	@
ETB	F8	[	[
CAN	F9/Menu	\	\
EM	F10/System	]	]
SUB	Break	^	^
ESC	Esc	_ (underline)	_ (underline)
FS	Prev	` (accent)	` (accent)
GS	Next	{	↑
RS	Clear Line		↓
US	Clear Display	}	←
DEL	← (bksp del)	~	→

## Harris Series

---

This section covers these workstations:

- Harris 179
- Harris 180
- Harris 192

The individual Wedge Interface Guide corresponding to this section is part number 060101.

---

### **Cables**

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 060098
- Keyboard cable - Part No. 060100
- Terminal cable - Part No. 060099

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Harris Workstations (Typewriter Keyboard)



\*\$+TA478\*

## HP 2392A

---

This section covers the HP 2392A workstation. The individual Wedge Interface Guide corresponding to this section is part number 056076.

---

### ***Cables***

Connecting the reader to the HP 2392A workstation requires one cable. The interface kit contains the keyboard/terminal cable. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 056075
- Keyboard/Terminal cable - Part No. 056074

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Even though the reader does not require a power supply, set the PCB jumper to connect pins 2 and 3 on the reader's rear panel. This is an exception for the HP 2392A.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

There are two HP2392A terminals that look identical, but require different configuration IDs. To distinguish between the two versions, you need to find the firmware part number which can be displayed using the ROM display option on the workstation.

To display the ROM part number

1. Press [SYSTEM] located on your keyboard in the center of the row of function keys.
2. Press [F3] (service keys) the [F6] (identify ROMs).
3. Depending on the message displayed, scan the appropriate label.

Message

Scan This Label

Firmware ROMs

-----  
1818-3433  
1818-3434



\*\$+TA359\*

Firmware ROMs

-----  
1818-3508  
1818-3509



\*\$+TA360\*

Firmware ROMs

-----  
1818-3440  
1818-3441



\*\$+TA360\*

Firmware ROMs

-----  
1818-3732  
1818-3509



\*\$+TA360\*

**Note:** Use this firmware with  
Rev. B interface cables only.

## HP HIL Series

---

This section covers Hewlett-Packard PCs, workstations, and terminals equipped with an HP-HIL interface port and one of these keyboards:

- ITF Keyboard 46020A or 46021A
- Vectra Keyboard 46030A

The individual Wedge Interface Guide for this section is part number 059307.

---

### **Cables**

Use the two cables supplied with this WIF kit to connect the reader to your workstation and keyboard, as shown in your *Wedge Reader User's Manual*. To order a replacement cable, use these part numbers:

- Wedge interface kit - Part No. 059306
- Keyboard cable - Part No. 057900
- Terminal cable - Part No. 057899

---

### **Power Supply**

The reader requires an external power supply if the total current drawn by the reader and all connected HP-HIL devices exceeds 1000 mA. Otherwise, the reader does not require an external power supply. For either type of power supply, set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

Use this table to determine the amount of current drawn by all attached HP-HIL devices.

<b>Intermec Model</b>	<b>Input Device</b>	<b>Milliamps</b>
9710D02	Wand	180
9710D02	1545A	380
9720D02	Wand	200
9720D02	1545A	400
<b>HP Model</b>	<b>HP Device Name</b>	<b>Milliamps</b>
HP 35723A	Touchscreen Bezel	250
HP 46020A	ITF Keyboard	100
HP 46021A	ITF Keyboard	145
HP 46030A	Vectra Keyboard	145
HP 46060A	HP Mouse	200
HP 46080A	Extension Module	25
HP 46081A	3 Meter Extension	25
HP 46082A/B	15/30 Meter Extension <sup>1</sup>	50
HP 46083A	Rotary Control Knob	110

HP Model	HP Device Name	Milliamps
HP 46084A	ID Module	60
HP 46085A	Control Dials	350
HP 46086A	Button Box	80
HP 46087A	A-Size Digitizer <sup>2</sup>	200
HP 46088A	B-Size Digitizer <sup>2</sup>	200
HP 46094A	Quadrature Port Device <sup>3</sup>	80
HP 46095A	3-Button Mouse	80
HP 92916A	Barcode Reader	100

<sup>1</sup> The extension cables have two boxes, each drawing 25 mA.

<sup>2</sup> The digitizer includes the HP 46089A 4-Button Cursor.

<sup>3</sup> The port device requires 80 mA. The attached device cannot exceed 120 mA.

---

## Configuring the Reader

There are two methods for configuring the reader: automatic and manual. The method you choose depends on the reader's position in the HP-HIL daisy-chain network:

- If the reader is the first device, use Automatic Configuration.
- If the reader is not the first device, use Manual Configuration.

*Note: The reader cannot be the last device in the HP-HIL network. There must always be another device plugged into the reader's keyboard cable.*

---

## Automatic Configuration

For automatic configuration, **the reader must be the first device in the HP-HIL network.** The reader determines the keyboard type and address and configures itself, as follows:

- If the reader is already in autoconfigure mode when you power it on, the reader passively monitors HP-HIL bus until it finds the keyboard. If unsuccessful after 15 seconds, the reader configures itself to emulate an ITF keyboard at address 1 (where address 1 is the first HP-HIL device connected to the terminal).
- If you scan the Automatic Configuration label in Table 2, the reader actively interrogates the HP-HIL devices for their device IDs. When the reader locates the keyboard, it configures itself, beeps, and resumes operation. If the reader cannot locate the keyboard, it configures itself to emulate an ITF keyboard at address 1.





Follow these guidelines:





- If you cannot install the reader as the first device in the HP-HIL network, you must manually configure the reader.
- If the reader does not beep for 15 seconds after being powered on, it cannot locate the keyboard. If the keyboard is attached and working, you must manually configure the reader.
- The reader emulates the first keyboard it finds in the HP-HIL network. If the reader must emulate the second of two keyboards in the network, either swap the keyboards or manually configure the reader for the second keyboard's address.
- If the reader appears to successfully configure itself, but transmits the wrong keycodes, it failed to correctly identify the keyboard. Manually configure the reader.












---

## **Manual Configuration**

If autoconfiguration fails or if you cannot install the reader as the first device in the HP-HIL network, follow these steps:

1. Install the reader into the network (not as the last device).
2. Determine the keyboard's address, where address 1 is the network's first device.
3. Scan a bar code with the correct keyboard (ITF or Vectra) and address. The reader should emit one low beep followed by four low beeps, indicating that the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
Automatic Configuration	 *\$+TA428*
ITF Keyboard at Address 1	 *\$+TA429*
ITF Keyboard at Address 2	 *\$+TA430*
ITF Keyboard at Address 3	 *\$+TA431*

To Set Workstation Configuration to	Scan This Bar Code
ITF Keyboard at Address 4	 *\$+TA432*
ITF Keyboard at Address 5	 *\$+TA433*
ITF Keyboard at Address 6	 *\$+TA434*
ITF Keyboard at Address 7	 *\$+TA435*
Vectra Keyboard at Address 1	 *\$+TA436*
Vectra Keyboard at Address 2	 *\$+TA437*
Vectra Keyboard at Address 3	 *\$+TA438*
Vectra Keyboard at Address 4	 *\$+TA439*
Vectra Keyboard at Address 5	 *\$+TA440*
Vectra Keyboard at Address 6	 *\$+TA441
Vectra Keyboard at Address 7	 *\$+TA442*

## Keyboard Equivalent Tables

The next two tables show the ASCII keyboard equivalent for the ITF and Vectra keyboards, respectively.

*Note: Alphanumeric characters (Aa to Zz, and 0 to 9) are not listed in this table because they map to the same characters on the ITF and Vectra keyboards.*

### Keyboard Mapping for ITF Keyboards

ASCII Character	ITF Keystroke	ASCII Character	ITF Keystroke
NUL	F1	SP	Spacebar
SOH	F2	!	!
STX	F3	"	" (quote)
ETX	F4	#	#
EOT	F5	\$	\$
ENQ	F6	%	%
ACK	F7	&	&
BEL	F8	'	' (apostrophe)
BS	Backspace	(	(
HT	« (tab)_)_»LF	Enter (keypad)	** (keypad)
VT	Home Cursor	+	+
FF	Ctrl	,	, (comma)
CR	↵ (Return)	-	- (dash)
SO	Caps Lock	.	. (period)
SI	Left Shift	/	/
DLE	Break	:	:
DC1	Stop	;	;
DC2	Menu	<	<
DC3	System	=	=
DC4	Select	>	>
NAK	Clear Line	?	?
SYN	Left Extend Char	@	@
ETB	Right Extend Char	[	[
CAN	Clear Display	\	\
EM	Prev	]	]
SUB	Next	^	^
ESC	Esc	_	_ (underline)
FS	Insert Line	`	` (accent)
GS	Delete Line	{	↑
RS	Insert Char		↓
US	Delete Char	}	←
DEL	Delete	~	« _

*Note: The term "(keypad)" indicates that the key is in the numeric keypad.*

---

*Keyboard Mapping for Vectra Keyboards*

ASCII Character	ITF Keystroke	ASCII Character	ITF Keystroke
NUL	+ (keypad)	SP	Spacebar
SOH	Num Lock	!	!
STX	Scroll Lock	"	" (quote)
ETX	- (keypad)	#	#
EOT	Ins	\$	\$
ENQ	Del	%	%
ACK	SysReq	&	&
BEL	Not Supported	'	' (apostrophe)
BS	Not Supported	(	(
HT	« (tab)__)»LF	Caps Lock	** (keypad)
VT	← (tab)	+	+
FF	Alt	,	, (comma)
CR	↵ (Return)	-	- (dash)
SO	Ctrl	.	. (period)
SI	Left Shift Key	/	/
DLE	F1	:	:
DC1	F2	;	;
DC2	F3	<	<
DC3	F4	=	=
DC4	F5	>	>
NAK	F6	?	?
SYN	F7	@	@
ETB	F8	[	[
CAN	F9	\	\
EM	F10	]	]
SUB	Home	^	^
ESC	Esc	_	_ (underline)
FS	PgUp	`	` (accent)
GS	PgDn	{	↑
RS	Print Screen		↓
US	End	}	←
DEL	Backspace	~	« _

**Note:** The term "(keypad)" indicates that the key is in the numeric keypad.

## IBM 3151 and 34XX Series

---

This section covers these workstations:

- IBM 3151
- IBM 3471
- IBM 3472
- IBM 3476
- IBM 3477
- IBM 3481
- IBM 3482
- IBM 3486
- IBM 3487
- IBM 3488

The individual Wedge Interface Guide for this section is part number 054239.

---

### ***Cables***

Use the two cables supplied with this WIF kit to connect the reader to your workstation and keyboard, as shown in your *Wedge Reader User's Manual*. To order a replacement cable, use these part numbers:

- Wedge interface kit - Part No. 054238
- Keyboard cable - Part No. 054237
- Terminal cable - Part No. 054236

---

### ***Power Supply***

The reader does not require an external power supply to operate with these workstations. Set the PCB jumper to connect pins 1 and 2 on the rear panel.

---

### ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. The reader should emit one low beep followed by four low beeps, indicating that the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beep identification.

#### **To Set Workstation Configuration to**

IBM 3151 model 310  
US Keyboard

IBM 3151 model 510  
US Keyboard

#### **Scan This Bar Code**



\*\$+TA115\*



\*\$+TA473\*

To Set Workstation Configuration to

Scan This Bar Code

IBM 3151 model 310  
Japanese Keyboard



\*\$+TA117\*

IBM 3151 model 310  
Spanish Keyboard



\*\$+TA116\*

IBM 3471  
IBM 3472 Enhanced  
102-key US Keyboard



\*\$+TA182\*

IBM 3471  
IBM 3472 104-key and  
122-key US Keyboard



\*\$+TA250\*

IBM 3471  
104-key Data Entry  
US Keyboard



\*\$+TA251\*

IBM 3471, 3472  
122-key Data Entry  
US Keyboard



\*\$+TA252\*

IBM 3471  
IBM 3472 122-key  
Austrian/German Keyboard



\*\$+TA133\*

IBM 3471, 3472  
Data Entry Austrian/  
German Keyboard



\*\$+TA241\*

IBM 3472 Enhanced  
Austrian Keyboard



\*\$+TA281\*

IBM 3471  
IBM 3472 122-key  
Belgian Keyboard



\*\$+TA88\*

IBM 3472 Enhanced  
Belgian Keyboard




\*\$+TA282\*

IBM 3471  
IBM 3472 122-key  
Canadian Keyboard



\*\$+TA89\*



To Set Workstation Configuration to

Scan This Bar Code

IBM 3472 Enhanced  
Canadian Keyboard



\*\$+TA283\*

IBM 3471  
IBM 3472 122-key  
Danish Keyboard



\*\$+TA91\*

IBM 3471, 3472  
Data Entry Danish Keyboard



\*\$+TA242\*

IBM 3472 Enhanced  
Danish Keyboard



\*\$+TA284\*

IBM 3472 Enhanced  
Dutch Keyboard



\*\$+TA285\*

IBM 3471  
IBM 3472 122-key  
Finnish/Swedish Keyboard



\*\$+TA92\*

IBM 3471, 3472  
Data Entry Finnish/  
Swedish Keyboard



\*\$+TA243\*

IBM 3472  
Enhanced Finnish/  
Swedish Keyboard



\*\$+TA286\*

IBM 3471  
IBM 3472 122-key  
French AZERTY Keyboard



\*\$+TA93\*

IBM 3471, 3472  
Data Entry French Keyboard



\*\$+TA244\*

IBM 3472 Enhanced  
French Keyboard



\*\$+TA287\*

IBM 3471  
IBM 3472 122-key  
Italian Keyboard



\*\$+TA94\*

To Set Workstation Configuration to

Scan This Bar Code

IBM 3471, 3472  
Data Entry  
Italian Keyboard



\*\$+TA245\*

IBM 3472 Enhanced  
Italian Keyboard



\*\$+TA288\*

IBM 3471  
IBM 3472 Enhanced  
104-key Japanese  
Katakana Keyboard



\*\$+TA95\*

IBM 3471, 3472  
124-key Japanese  
Katakana Keyboard



\*\$+TA246\*

IBM 3472 122-key  
Latin American Keyboard



\*\$+TA289\*

IBM 3472 Enhanced  
Latin American Keyboard



\*\$+TA290\*

IBM 3471  
IBM 3472 122-key Norwegian  
Keyboard



\*\$+TA96\*

IBM 3471, 3472  
Data Entry  
Norwegian Keyboard



\*\$+TA247\*

IBM 3472 Enhanced  
Norwegian Keyboard



\*\$+TA291\*

IBM 3471  
IBM 3472 122-key  
Portuguese Keyboard



\*\$+TA97\*

IBM 3471, 3472  
Data Entry  
Portuguese Keyboard



\*\$+TA248\*

IBM 3472 Enhanced  
Portuguese Keyboard



\*\$+TA292\*





**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM 3471  
IBM 3472 122-key  
Spanish Keyboard



\*\$+TA98\*

IBM 3471  
Spanish (speaking) Keyboard



\*\$+TA99\*

IBM 3472 Enhanced  
Spanish Keyboard



\*\$+TA293\*

IBM 3471  
IBM 3472 122-key  
Swiss/French Keyboard



\*\$+TA100\*

IBM 3472 Enhanced  
Swiss/French Keyboard



\*\$+TA294\*

IBM 3471  
IBM 3472 122-key  
Swiss/German Keyboard



\*\$+TA101\*

IBM 3472 Enhanced  
Swiss/German Keyboard



\*\$+TA295\*

IBM 3471  
IBM 3472 122-key  
United Kingdom Keyboard



\*\$+TA181\*

IBM 3471  
Data Entry United Kingdom Keyboard



\*\$+TA249\*

IBM 3472  
Enhanced United Kingdom Keyboard



\*\$+TA296\*

IBM 3476, 3477  
Enhanced 103-key US Keyboard



\*\$+TA137\*

IBM 3476, 3477  
Enhanced 103-key  
Austrian/German Keyboard



\*\$+TA139\*

To Set Workstation Configuration to

Scan This Bar Code

IBM 3476, 3477  
Enhanced 103-key  
Belgian Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Danish Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Dutch Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Finnish/Swedish Keyboard



IBM 3476, 3477  
Enhanced 103-key  
French AZERTY Keyboard



IBM 3476, 3477  
Enhanced 103-key  
French Canadian Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Italian Keyboard



IBM 3476, 3477  
Enhanced 104-key  
Japanese Katakana Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Norwegian Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Portuguese Keyboard




IBM 3476, 3477  
Enhanced 103-key  
Spanish Keyboard



IBM 3476, 3477  
Enhanced 103-key  
Spanish (speaking) Keyboard





**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM 3476, 3477  
Enhanced 103-key  
Swiss/French Keyboard



\*\$+TA151\*

IBM 3476, 3477  
Enhanced 103-key  
Swiss/German Keyboard



\*\$+TA152\*

IBM 3476, 3477  
Enhanced 103-key  
United Kingdom Keyboard



\*\$+TA138\*

IBM 3476, 3477  
Enhanced 122-key  
US Data Entry Keyboard



\*\$+TA154\*

IBM 3476, 3477  
122-key US  
Typewriter Keyboard



\*\$+TA155\*

IBM 3476, 3477  
122-key Austrian/German  
Typewriter Keyboard



\*\$+TA157\*

IBM 3476, 3477  
122-key Belgian  
Typewriter Keyboard



\*\$+TA158\*

IBM 3476, 3477  
122-key Danish  
Typewriter Keyboard



\*\$+TA160\*

IBM 3476, 3477  
122-key Finnish/Swedish  
Typewriter Keyboard



\*\$+TA161\*

IBM 3476, 3477  
122-key French AZERTY  
Typewriter Keyboard



\*\$+TA162\*

IBM 3476, 3477  
122-key French Canadian  
Typewriter Keyboard



\*\$+TA159\*

IBM 3476, 3477  
122-key Italian  
Typewriter Keyboard



\*\$+TA163\*

**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM 3476, 3477  
124-key Japanese Katakana  
Typewriter Keyboard



IBM 3476, 3477  
122-key Norwegian  
Typewriter Keyboard



IBM 3476, 3477  
122-key Portuguese  
Typewriter Keyboard



IBM 3476, 3477  
122-key Spanish  
Typewriter Keyboard



IBM 3476, 3477  
122-key Spanish (speaking)  
Typewriter Keyboard



IBM 3476, 3477  
122-key Swiss/French  
Typewriter Keyboard



IBM 3476, 3477  
122-key Swiss/German  
Typewriter Keyboard



IBM 3476, 3477  
122-key United Kingdom  
Typewriter Keyboard



IBM 3481, 3482  
122-key US  
Typewriter Keyboard



IBM 3481, 3482  
122-key French  
Typewriter Keyboard



IBM 3481, 3482  
122-key German/Austrian  
Typewriter Keyboard



IBM 3481, 3482  
122-key German/Swiss  
Typewriter Keyboard





To Set Workstation Configuration to

Scan This Bar Code

IBM 3481, 3482  
122-key Italian  
Typewriter Keyboard



\*\$+TA444\*

IBM 3481, 3482  
122-key Spanish  
Typewriter Keyboard



\*\$+TA445\*

IBM 3486  
102-key US Keyboard



\*\$+TA486\*

IBM 3486  
122-key US Keyboard



\*\$+TA487\*

IBM 3487  
122-key US  
Typewriter Keyboard



\*\$+TA467\*

IBM 3487  
122-key French  
Typewriter Keyboard



\*\$+TA468\*

IBM 3487  
122-key German/Austrian  
Typewriter Keyboard



\*\$+TA470\*

IBM 3487  
122-key German/Swiss  
Typewriter Keyboard



\*\$+TA469\*

IBM 3487  
122-key Italian  
Typewriter Keyboard



\*\$+TA471\*

IBM 3487  
122-key Spanish  
Typewriter Keyboard



\*\$+TA472\*

IBM 3488  
122-key US  
Typewriter Keyboard



\*\$+TA494\*

IBM 3488  
122-key  
US Data Entry Keyboard



\*\$+TA495\*

*IBM 3151 and 34XX Series*

To Set Workstation Configuration to

IBM 3488  
102-key US Keyboard

Scan This Bar Code



\*\$+TA496\*

## IBM 316X and 319X Series

---

This section covers these workstations:

- IBM 3161
- IBM 3162
- IBM 3163
- IBM 3164
- IBM 3191
- IBM 3192
- IBM 3193
- IBM 3196
- IBM 3197

The individual Wedge Interface Guide corresponding to this section is part number 054525.

---

### **Cables**

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054524
- Keyboard cable - Part No. 054523
- Terminal cable - Part No. 054522

---

### **Power Supply**

The reader does not require an external power supply to work with the workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to  
IBM 3161

Scan This Bar Code



\*\$+TA118\*

To Set Workstation Configuration to

Scan This Bar Code

IBM 3162



\*\$+TA115\*

IBM 3163  
US Keyboard



\*\$+TA118\*

IBM 3163  
Japanese Keyboard



\*\$+TA120\*

IBM 3163  
Spanish Keyboard



\*\$+TA119\*

IBM 3164  
US Keyboard



\*\$+TA121\*

IBM 3164  
Japanese Keyboard



\*\$+TA123\*

IBM 3164  
Spanish Keyboard



\*\$+TA122\*

IBM 3191  
102-key US Keyboard



\*\$+TA124\*

IBM 3191  
122-key US Keyboard



\*\$+TA316\*

IBM 3191  
Japanese Keyboard



\*\$+TA126\*

IBM 3191  
Spanish Keyboard



\*\$+TA125\*

IBM 3192  
102-key US Keyboard



\*\$+TA127\*





**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM 3192  
122-key US Keyboard



\*\$+TA317\*

IBM 3192  
Japanese Keyboard



\*\$+TA129\*

IBM 3192  
Spanish Keyboard



\*\$+TA128\*

IBM 3193  
102-key US Keyboard



\*\$+TA130\*

IBM 3193  
122-key US Keyboard



\*\$+TA318\*

IBM 3193  
Japanese Keyboard



\*\$+TA132\*

IBM 3193  
Spanish Keyboard



\*\$+TA131\*

IBM 3196, 3197  
102-key Keyboard



\*\$+TA304\*

IBM 3196, 3197  
122-key Keyboard



\*\$+TA315\*

## IBM 3178

---

This section covers the IBM 3178 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054808.

---

### ***Cables***

Connecting the reader to the IBM 3178 workstation requires one cable. The interface kit contains the keyboard/terminal cable. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054809
- Keyboard/Terminal cable - Part No. 054807

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to

Scan This Bar Code

C1 Keyboard



\*\$+TA308\*

C2 Keyboard



\*\$+TA309\*

C3 Keyboard



\*\$+TA310\*

C4 Keyboard



\*\$+TA311\*

## IBM 7552

---

This section covers the IBM 7552 workstation. The individual Wedge Interface Guide corresponding to this section is part number 055821.

---

### ***Cables***

Connecting the reader to the IBM 7552 workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 055820
- Keyboard cable - Part No. 055819
- Terminal cable - Part No. 055818

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

IBM 7552



\*\$+TA319\*

## **IBM PC/XT/AT Series**

---

This section covers these workstations:

- Alfaskop DS/DT\*
- AST 286/386
- AT&T 605
- Compaq 286/386
- HP Vectra ES
- IBM 7531
- IBM 7532
- IBM AT
- IBM PC/XT
- Idea Courier 9292
- NEC 286
- Nokia 7414-0011
- Nokia ASC/AWS\*
- Nokia Mikro Mikko 3/4\*
- Nokia VDU 192
- Tandy 1000
- Unisys PW2 286
- Wang 240
- Wang 280
- Wang 380

*\*With Nokia AT configured keyboard*

The individual Wedge Interface Guide corresponding to this section was revised to include more terminals. It is now titled "PC/AT, PS/2 Universal" and is part number 056945.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 056944
- Keyboard cable - Part No. 054140
- Terminal cable - Part No. 056311
- Adapter - Part No. 056943

---

### ***Power Supply***











The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.



---

## ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
Alfaskop DS/DT*	 *\$+TA171
AST 286/386	 *\$+TA327*
AT&T 605	 *\$+TA2*
Compaq 286/386	 *\$+TA114*
HP Vectra ES US Keyboard	 *\$+TA75*
HP Vectra ES Belgian Keyboard	 *\$+TA86*
HP Vectra ES Danish Keyboard	 *\$+TA83*
HP Vectra ES French Keyboard	 *\$+TA78*
HP Vectra ES French Canadian Keyboard	 *\$+TA85*
HP Vectra ES German Keyboard	 *\$+TA76*

**To Set Workstation Configuration to**

**Scan This Bar Code**

HP Vectra ES  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

HP Vectra ES  
Italian Keyboard



\*\$+TA84\*

HP Vectra ES  
Norwegian Keyboard



\*\$+TA79\*

HP Vectra ES  
Spanish Keyboard



\*\$+TA77\*

HP Vectra ES  
Swedish/Finnish Keyboard



\*\$+TA81\*

HP Vectra ES  
Swiss French/German Keyboard  
Keyboard



\*\$+TA80\*

HP Vectra ES  
United Kingdom Keyboard



\*\$+TA82\*

IBM 7531, 7532



\*\$+TA312\*

IBM AT  
US 84/101/102-keyboard



\*\$+TA1\*

IBM AT  
French 102-keyboard



\*\$+TA29\*

IBM AT  
French 84-keyboard




\*\$+TA409\*

IBM AT  
German 102-keyboard



\*\$+TA31\*



**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM AT  
German 84-keyboard



\*\$+TA411\*

IBM AT  
101/102-key Host-Connected  
US Keyboard Map



\*\$+TA450\*

IBM AT  
Italian 102-keyboard



\*\$+TA32\*

IBM AT  
Italian 84-keyboard



\*\$+TA410\*

IBM AT  
Spanish 102-keyboard



\*\$+TA30\*

IBM AT  
Spanish 84-keyboard



\*\$+TA412\*

IBM AT  
United Kingdom 102-keyboard



\*\$+TA28\*

IBM AT  
United Kingdom 84-keyboard



\*\$+TA413\*

IBM PC/XT  
US Keyboard



\*\$+TA0\*

IBM PC/XT  
French AZERTY Keyboard



\*\$+TA24\*

IBM PC/XT  
German Keyboard



\*\$+TA26\*

IBM PC/XT  
Italian Keyboard



\*#+TA27\*

To Set Workstation Configuration to

Scan This Bar Code

IBM PC/XT  
Spanish Keyboard



\*\$+TA25\*

IBM PC/XT  
United Kingdom Keyboard



\*\$+TA23\*

Idea Courier 9292



\*\$+TA305

NEC 286/386



\*\$+TA1\*

Nokia PC/XT  
Configured Keyboard



\*\$+TA216\*

NEC 286/386  
101/102-keyboard Host-Connected  
US Map



\*\$+TA450\*

Nokia AT Configured  
Keyboard



\*\$+TA171\*

Nokia 7414-0011  
Nokia VDU 192  
AC42100.001 Keyboard



\*\$+TA239\*

Nokia 7414-0011  
Nokia VDU 192  
AF51211 Keyboard



\*\$+TA240\*

Tandy 1000 Enhanced Keyboard



\*\$+TA0\*

Unisys PW2 286



\*\$+TA1\*

Wang 240, 280, 380  
Model 724, 301 Keyboard



\*\$+TA1\*



## Idea Courier

---

This section covers these workstations:

- Idea Courier 12471
- Idea Courier 12472-01C

The individual Wedge Interface Guide for this section is part number 059308.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 059309
- Keyboard cable - Part No. 057470
- Terminal cable - Part No. 057471

---

### ***Power Supply***

If you use a 15XX laser scanner with these workstations, the reader requires an external power supply. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

If you use a wand with these workstations, the reader uses workstation power. Set the PCB jumper to connect pins 1 and 2.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

**Note:** *This interface uses the standard Twinax/Coax keyboard mapping (Table A-2, in the Wedge Reader User's Manual).*

Idea Courier  
US Keyboard (model 701920-001)



\*\$+TA202\*

## ***I-O Corporation Series***

---

This section covers these workstations:

- I-O Corporation 1181D
- I-O Corporation 1181EP
- I-O Corporation 1181ES
- I-O Corporation 1181WP
- I-O Corporation 1196
- I-O Corporation 1196D
- I-O Corporation 1197
- I-O Corporation 2196
- I-O Corporation 2476C
- I-O Corporation 2497C
- I-O Corporation 2497D

The individual Wedge Interface Guide corresponding to this section is part number 055873.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 055872
- Keyboard cable - Part No. 055871
- Terminal cable - Part No. 055870

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Even though the reader does not require a power supply, set the PCB jumper to connect pins 2 and 3 on the reader's rear panel. This is an exception for the I-O Corporation workstations.

---

### ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to

I-O Corporation  
83-key Keyboard

Scan This Bar Code



\*\$+TA321\*



**To Set Workstation Configuration to**

I-O Corporation  
102-key Keyboard

I-O Corporation  
122-key Keyboard

**Scan This Bar Code**



\*\$+TA322\*



\*\$+TA323\*

## LynkLyte Series

---

This section covers the LynkLyte 1 workstation. The individual Wedge Interface Guide corresponding to this section is part number 055756.

---

### **Cables**

Connecting the reader to the LynkLyte workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054849
- Keyboard cable - Part No. 054848
- Terminal cable - Part No. 054847

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

#### To Set Workstation Configuration to

LynkLyte 1 (5 pin PC/XT DIN)  
102-key Keyboard

#### Scan This Bar Code



\*\$+TA307\*

LynkLyte 1 (7-pin DIN)  
122-key Keyboard



\*\$+TA306\*



## Macintosh II and SE Series

---

This section covers these workstations:

- Macintosh SE
- Macintosh II

The individual Wedge Interface Guide corresponding to this section is part number 054842.

---

### Cables

Connecting the reader to one of these workstations requires a terminal cable. The expansion cable is required when connecting other input devices (for example, a mouse). The interface kit contains both the expansion and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054841
- Expansion cable - Part No. 054840
- Terminal cable - Part No. 054839

---

### Power Supply

The reader does not require an external power supply to work with the workstations. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### Configuring the Reader

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to  
US and United Kingdom Keyboard

Scan This Bar Code



\*\$+TA175\*

Danish Keyboard



\*\$+TA178\*

To Set Workstation Configuration to

Scan This Bar Code

Dutch Keyboard



\*\$+TA134\*

Finnish Keyboard



\*\$+TA135\*

Flemish and French  
Keyboard



\*\$+TA185\*

French Canadian  
Keyboard



\*\$+TA177\*

German Keyboard



\*\$+TA300\*

Italian Keyboard



\*\$+TA274\*

Icelandic Keyboard



\*\$+TA275\*

Norwegian Keyboard



\*\$+TA276\*

Portuguese Keyboard



\*\$+TA277\*

Spanish Keyboard



\*\$+TA278\*

Swedish Keyboard



\*\$+TA279\*

Swiss (French and German)  
Keyboard



\*\$+TA299\*



To Set Workstation Configuration to  
Turkish Keyboard

Scan This Bar Code



\*\$+TA301\*

## Memorex/Telex 2291 and 2391

---

This section covers these workstations:

- Memorex/Telex 2291
- Memorex/Telex 2391

The individual Wedge Interface Guide corresponding to this section is part number 054850.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054837
- Keyboard cable - Part No. 054144
- Terminal cable - Part No. 054143

---

### ***Power Supply***

The reader requires an external power supply to work with the workstation. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

*Note: If you are using an external power supply with the reader, plug in the power supply before powering ON the workstation. If you do not, the reader will lock up.*

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Memorex/Telex 2291, 2391



\*\$+TA186\*





## Memorex/Telex Series

---

This section covers these workstations:

- Memorex/Telex 1191
- Memorex/Telex 1192
- Memorex/Telex 1196
- Memorex/Telex 1197
- Memorex/Telex 1471
- Memorex/Telex 1472
- Memorex/Telex 1476
- Memorex/Telex 1477
- Memorex/Telex 2296

The individual Wedge Interface Guide corresponding to this section is part number 054303.

---

### **Cables**

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054302
- Keyboard cable - Part No. 054301
- Terminal cable - Part No. 054300

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to

Memorex/Telex 1191  
88-key Keyboard

Scan This Bar Code



\*\$+TA361\*

*Memorex/Telex Series*

**To Set Workstation Configuration to**

Memorex/Telex 1191 A/B  
1196 A/B/C, 1192, 1197  
Typewriter Keyboard

Memorex/Telex 1191 A/B,  
1196 A/B/C, 1192, 1197  
Data Entry Keyboard

Memorex/Telex 1471, 1472  
88-key Typewriter Keyboard

Memorex/Telex 1471, 1472  
104-key Data Entry Keyboard

Memorex/Telex 1471, 1472  
104-key Typewriter Keyboard

Memorex/Telex 1471, 1472  
122-key Data Entry Keyboard

Memorex/Telex 1471, 1472  
122-key Typewriter Keyboard

Memorex/Telex 1476

Memorex/Telex 1477  
122-key Typewriter Keyboard

Memorex/Telex 2296

**Scan This Bar Code**



\*\$+TA179\*



\*\$+TA180\*



\*\$+TA453\*



\*\$+TA454\*



\*\$+TA455\*



\*\$+TA456\*



\*\$+TA457\*



\*\$+TA297\*



\*\$+TS458\*



\*\$+TA364\*

## Microterm 5530

---

This section covers the Microterm 5530 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054834.

---

### **Cables**

Connecting the reader to the workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054833
- Keyboard cable - Part No. 054832
- Terminal cable - Part No. 054831

---

### **Power Supply**

The reader requires an external power supply to work with the workstation. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

***Note:** If you are using an external power supply with the reader, plug in the power supply before powering ON the workstation. If you do not, the reader will lock up.*

---

### **Configuring the Reader**

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Microterm 5530



\*\$+TA136\*

## NEC 386

---

This section covers the NEC 386 workstation. The individual Wedge Interface Guide corresponding to this section was revised to include more terminals. It is now titled "PC/AT, PS/2 Universal" and is part number 056945.

---

### ***Cables***

Connecting the reader to the workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 056944
- Keyboard cable - Part No. 054140
- Terminal cable - Part No. 056311
- Adapter - Part No. 056943

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beep identification.

To Set Workstation Configuration to

NEC 386

Scan This Bar Code



\*\$+TA1\*

NEC Host-Connected  
Keyboard Map



\*\$+TA450\*



## Nokia 4111 and 9164 Series

---

This section covers these workstations:

- Nokia 4111 DU
- Nokia 9164 DU

The individual Wedge Interface Guide for this section is part number 054854.

---

### **Cables**

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054853
- Keyboard cable - Part No. 054852
- Terminal cable - Part No. 054851

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

#### To Set Workstation Configuration to

Nokia 4111  
Nokia 9164  
4143-001 Keyboard

#### Scan This Bar Code



\*\$+TA189\*

Nokia 4111  
Nokia 9164  
9140-1001 Keyboard



\*\$+TA187\*

Nokia 4111  
Nokia 9164  
9140-7001 Keyboard



\*\$+TA280\*

## Nokia 9014 DU

---

This section covers the Nokia 9014 DU workstation with the 9140-6601 keyboard. The individual Wedge Interface Guide corresponding to this section is part number 054858.

---

### **Cables**

Connecting the reader to the workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054857
- Keyboard cable - Part No. 054856
- Terminal cable - Part No. 054855

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Nokia 9014 DU with 9140-6601 Keyboard



\*\$+TA188\*

## PC/AT, PS/2 Universal

---

This section covers these workstations:

- Alfaskop DS/DT\*
- AST 286/386
- AT&T 605
- AT&T 6386SX and 6386WGS
- Compaq 286/386
- Compaq 286/e
- Compaq 386/s
- Compaq 386/20e
- Compaq 386/33
- Compaq 486
- Compaq Prolinea
- DEC 486
- DEC VT510
- DEC VT520
- DEC VT525
- Dell Dimension 386 and 486
- Dell Optiplex 486 PC
- Gateway 2000 386 and 486
- HP 486
- HP X-Station 700/RX
- HP Vectra ES
- IBM 7531 and 7532
- IBM AT
- IBM PC/XT
- IBM PS/1
- IBM PS/2 25, 30, 50
- IBM PS/2 50Z
- IBM PS/2 55SX
- IBM PS/2 60, 70, 80, 90, 95
- IBM ValuePoint
- Idea Courier 9292
- NCD X-Station 15-b
- NEC 286 and 386
- Nokia 7414-0011
- Nokia ASC/AWS\*
- Nokia Mikro Mikko 3/4\*
- Nokia VDU 192
- Tandy 1000
- Tandy 2500, 4016, 5000
- Tektronix X-Station XP11
- Unisys PW2 286
- Wang 240, 280, and 380

\* *Nokia AT configured keyboard*

The individual Wedge Interface Guide corresponding to this section is part number 056945.

---

### **Cables**

Use the two cables and cable adapter supplied with this WIF kit to connect the reader to your workstation and keyboard, as shown in the following illustration and also in your *Wedge Reader User's Manual*. To order a replacement cable, use these part numbers:


- Wedge interface kit - Part No. 056944
- Keyboard cable - Part No. 054140
- Terminal cable - Part No. 056311
- Adapter - Part No. 056943

There are two ways to use the cable adapter:

- If your workstation keyboard cable has a large connector, connect the cable adapter between the workstation keyboard cable and the reader keyboard cable as shown in Configuration A in the illustration.
- If your workstation keyboard cable has a small connector, connect the cable adapter between the terminal and the reader terminal cable as shown in Configuration B in the illustration.

---

*Workstation Cables and Adapter*



9710-001





---

## ***Power Supply***

The reader requires an external power supply to work with these workstations. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

- HP X-Station 700/RX
- NCD X-Station 15-b
- DEC VT520
- DEC VT525

**Note:** *If you use an external power supply for the reader, you must plug in the power supply before switching on the workstation. If you do not, the reader may lock up.*

If you have a different workstation other than these, the reader does not require an external power supply to operate. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

## ***Caps Lock Sensing***

The Caps Lock Sensing feature allows the reader to sense if the workstation keyboard has Caps Lock enabled or disabled. The reader can then transmit the characters from scanned labels to the workstation in the same case as they are printed on the label.

Scan this label to enable Caps Lock Sensing:



\*\$+WC1\*

Scan this label to disable Caps Lock Sensing:



\*\$+WCO\*

By default, Caps Lock Sensing is disabled.

These workstations support Caps Lock Sensing:

- AT&T 6386SX
- AT&T 6386WGS
- Compaq (all models)
- DEC 486
- Dell Dimension 386
- Dell Dimension 486
- Dell Optiplex 486 PC
- Gateway 2000 386 and 486
- HP 486
- IBM AT
- IBM PS/1
- IBM PS/2 (all models except PS/2 25)
- IBM ValuePoint
- NEC 286 and 386
- Tandy 2500
- Tandy 4016
- Tandy 5000
- Wang 240
- Wang 280
- Wang 380

*Note: If your workstation does not support Caps Lock sensing, you can use the Caps Lock configuration command (\$+WL), as described in the Wedge Reader User's Manual, to allow the reader to sense Caps Lock mode.*

If the reader has Caps Lock Sensing enabled, the Caps Lock configuration command (\$+WL) has no effect on the reader's ability to sense Caps Lock mode.

---

## **Keyboard Maps for Host Connections**

If your PC is connected to a host computer (with terminal emulation software, for example), you must use an alternate keyboard map.

Alternate keyboard maps are available for these workstations:

- AT&T 6386SX
- AT&T 6386WGS
- Compaq
- Compaq Prolinea
- DEC 486
- HP 486
- HP Vectra ES
- IBM AT
- IBM ValuePoint
- NEC 286
- NEC 386
- PS/2 90 (122-key)
- PS/2 95 (122-key)
- PS/2 (101/102-key)
- Tandy 2500
- Tandy 4016
- Tandy 5000

To select the alternate keyboard map, scan the appropriate "Host-Connected Keyboard Map" bar code from the workstation configuration chart (see "Configuring the Reader" later in this section). Scanning a "Host-Connected Keyboard Map" bar code maps your keyboard to one of two maps.

The keyboard maps are described in these two tables:

- The first table describes the keyboard mapping for PS/2 90 and PS/2 95 workstations with 122-key keyboards.
- The second table describes the keyboard mapping for workstations with 101/102-key keyboards.

---

### Host-Connected Mapping for PS/2 90 and 95 122-Key Keyboards

ASCII Character	Keystroke	ASCII Character	Keystroke
NUL	F17	SP	Spacebar
SOH	F18	!	!
STX	F19	" (quote)	" (quote)
ETX	F20	#	#
EOT	F21	\$	\$
ENQ	F22	%	%
ACK	F23	&	&
BEL	F24	' (apostrophe)	' (apostrophe)
BS	Pause	(	(
HT	→  (tab)	)	)
LF	Enter (keypad)	*	* (keypad)
VT	← (tab)/Funct	+	+
FF	Alt	, (comma)	, (comma)
CR	↵(Return)	- (dash)	- (dash)
SO	Ctrl	. (period)	. (period)
SI	↑(shift)	/	Home (keypad)
DLE	F1	:	PgUp (keypad)
DC1	F2	;	PgDn (keypad)
DC2	F3	<	End (keypad)
DC3	F4	=	← (keypad)
DC4	F5	>	→ (keypad)
NAK	F6	?	?
SYN	F7	@	@
ETB	F8	[	↑ (keypad)
CAN	F9	\	Clear
EM	F10	]	↓ (keypad)
SUB	F11	^	Play
ESC	F12	_ (underline)	+ (keypad)
FS	F13	` (accent)	- (keypad)
GS	F14	{	Attn
RS	F15		ErEOF
US	F16	}	ExSel
DEL	← (bksp del)	~	CrSel

**Note:** The term "(keypad)" indicates that the key is in the numeric keypad.

---

Host-Connected Keyboard Mapping for 101/102-Key Keyboards

ASCII Character	Keystroke	ASCII Character	Keystroke
NUL	+ Num	SP	Spacebar
SOH	SysRq	!	!
STX	PrtScrn	" (quote)	" (quote)
ETX	- Num	#	#
EOT	Ins (keypad)	\$	\$
ENQ	Del (keypad)	%	%
ACK	F11	&	&
BEL	F12	' (apostrophe)	' (apostrophe)
BS	← Alt GR	(	(
HT	→   (tab)	)	)
LF	Caps Lock	*	*
VT	← (tab)/Funct	+	+
FF	Alt	, (comma)	, (comma)
CR	↵ (Return)	- (dash)	- (dash)
SO	Ctrl	. (period)	. (period)
SI	↑ (shift)	/	/
DLE	F1	:	:
DC1	F2	;	;
DC2	F3	<	<
DC3	F4	=	=
DC4	F5	>	>
NAK	F6	?	?
SYN	F7	@	@
ETB	F8	[	/ (keypad)
CAN	F9	\	* (keypad)
EM	F10	]	5 (keypad)
SUB	Home (keypad)	^	Enter (keypad)
ESC	Esc	_ (underline)	_ (underline)
FS	PgUp (keypad)	` (accent)	` (accent)
GS	PgDn (keypad)	{	↑ (keypad)
RS	Pause		↓ (keypad)
US	End (keypad)	}	← (keypad)
DEL	← (bksp del)	~	→ (keypad)











**Note:** The term "(keypad)" indicates that the key is in the numeric keypad.



---

## Configuring the Reader

Scan the appropriate label to configure the reader for your workstation. The reader should emit one low beep followed by four low beeps, indicating that the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
AST 286/386	 *\$+TA327*
AT&T 605	 *\$+TA2*
AT&T 6386SX, 6386WGS	 *\$+TA1*
AT&T 6386SX, 6386WGS 101/102-key Host-Connected Keyboard Map	 *\$+TA450*
Compaq Danish Keyboard	 *\$+TA7*
Compaq French Keyboard	 *\$+TA8*
Compaq French Canadian Keyboard	 *\$+TA9*
Compaq German Keyboard	 *\$+TA15*
Compaq 101/102-key Host-Connected Keyboard Map	 *\$+TA450*
Compaq Italian Keyboard	 *\$+TA10*

To Set Workstation Configuration to

Scan This Bar Code

Compaq  
Norwegian Keyboard



\*\$+TA11\*

Compaq  
Spanish Keyboard



\*\$+TA12\*

Compaq  
Swedish/Finnish Keyboard



\*\$+TA13\*

Compaq  
Swiss Keyboard



\*\$+TA14\*

Compaq  
United Kingdom Keyboard



\*\$+TA6\*

Compaq  
US Keyboard



\*\$+TA5\*

Compaq Prolinea  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

Compaq Prolinea  
Standard US Keyboard



\*\$+TA1\*

DEC 486  
US Keyboard



\*\$+TA1\*

DEC 486  
French Keyboard



\*\$+TA29\*

DEC 486  
German Keyboard




\*\$+TA31\*

DEC 486  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*



**To Set Workstation Configuration to**

**Scan This Bar Code**

DEC 486  
Italian Keyboard



\*\$+TA32\*

DEC 486  
Spanish Keyboard



\*\$+TA30\*

DEC 486  
United Kingdom Keyboard



\*\$+TA28\*

DEC VT510, VT520, VT525  
PC7XL-AA Keyboard



\*\$+TA476\*

DEC VT510, VT520, VT525  
LK411-AA Keyboard



\*\$+TA477\*

Dell Dimension 386 and 486  
US Keyboard



\*\$+TA1\*

Dell Optiplex 486 PC  
US Keyboard



\*\$+TA1\*

Dell Optiplex 486 PC  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

Gateway 2000 386 and 486  
French Keyboard



\*\$+TA29\*

Gateway 2000 386 and 486  
German Keyboard



\*\$+TA31\*

Gateway 2000 386 and 486  
Italian Keyboard



\*\$+TA32\*

Gateway 2000 386 and 486  
Spanish Keyboard



\*\$+TA30\*

To Set Workstation Configuration to

Scan This Bar Code

Gateway 2000 386 and 486  
US Keyboard



\*\$+TA1\*

Gateway 2000 386 and 486  
United Kingdom Keyboard



\*\$+TA28\*

HP Vectra ES  
Belgian Keyboard



\*\$+TA86\*

HP Vectra ES  
Danish Keyboard



\*\$+TA83\*

HP Vectra ES  
French Keyboard



\*\$+TA78\*

HP Vectra ES  
French Canadian Keyboard



\*\$+TA85\*

HP Vectra ES  
German Keyboard



\*\$+TA76\*

HP Vectra ES  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

HP Vectra ES  
Italian Keyboard



\*\$+TA84\*

HP Vectra ES  
Norwegian Keyboard



\*\$+TA79\*

HP Vectra ES  
Spanish Keyboard



\*\$+TA77\*

HP Vectra ES  
Swedish/Finnish Keyboard



\*\$+TA81\*





**To Set Workstation Configuration to**

**Scan This Bar Code**

HP Vectra ES  
Swiss French/German Keyboard



\*\$+TA80\*

HP Vectra ES  
United Kingdom Keyboard



\*\$+TA82\*

HP Vectra ES  
US Keyboard



\*\$+TA75\*

HP 486  
US Keyboard



\*\$+TA1\*

HP 486  
French Keyboard



\*\$+TA29\*

HP 486  
German Keyboard



\*\$+TA31\*

HP 486  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

HP 486  
Italian Keyboard



\*\$+TA32\*

HP 486  
Spanish Keyboard



\*\$+TA30\*

HP X-Station 700/RX  
PS/2 Keyboard



\*\$+TA493\*

IBM 7531, 7532



\*\$+TA312\*

IBM AT  
French 84-key Keyboard



\*\$+TA409\*

To Set Workstation Configuration to

Scan This Bar Code

IBM AT  
French 102-key Keyboard



\*\$+TA29\*

IBM AT  
German 84-key Keyboard



\*\$+TA411\*

IBM AT  
German 102-key Keyboard



\*\$+TA31\*

IBM AT  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

IBM AT  
Italian 84-key Keyboard



\*\$+TA410\*

IBM AT  
Italian 102-key Keyboard



\*\$+TA32\*

IBM AT  
Spanish 84-key Keyboard



\*\$+TA412\*

IBM AT  
Spanish 102-key Keyboard



\*\$+TA30\*

IBM AT  
United Kingdom 84-key Keyboard



\*\$+TA451\*

IBM AT  
United Kingdom 102-key Keyboard



\*\$+TA28\*

IBM AT  
US 84/101/102-key Keyboards




\*\$+TA1\*

IBM PC/XT  
French AZERTY Keyboard



\*\$+TA24\*



**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM PC/XT  
German Keyboard



\*\$+TA26\*

IBM PC/XT  
Italian Keyboard



\*\$+TA27\*

IBM PC/XT  
Spanish Keyboard



\*\$+TA25\*

IBM PC/XT  
United Kingdom Keyboard



\*\$+TA23\*

IBM PC/XT  
US Keyboard



\*\$+TA0\*

IBM PS/1 and PS/2  
84/101/102-key  
US Keyboard



\*\$+TA87\*

IBM PS/2 101/102-key  
Arabic Keyboard



\*\$+TA208\*

IBM PS/2 101/102-key  
Belgian Keyboard



\*\$+TA195\*

IBM PS/2 101/102-key  
Danish Keyboard



\*\$+TA196\*

IBM PS/2 101/102-key  
Dutch Keyboard



\*\$+TA197\*

IBM PS/2 101/102-key  
French Keyboard



\*\$+TA199\*

IBM PS/2 101/102-key  
French Canadian Keyboard



\*\$+TA198\*

To Set Workstation Configuration to

IBM PS/2 101/102-key  
German Keyboard

Scan This Bar Code



\*\$+TA200\*

IBM PS/2  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA449\*

IBM PS/2 90 and 95  
88/101/122-key  
US Keyboard



\*\$+TA87\*

IBM PS/2 90 and 95  
122-key Host-Connected  
Keyboard Map



\*\$+TA448\*

IBM PS/2 101/102-key  
Israeli Keyboard



\*\$+TA209\*

IBM PS/2 101/102-key  
Italian Keyboard



\*\$+TA201\*

IBM PS/2 101/102-key  
Latin American Spanish Keyboard



\*\$+TA202\*

IBM PS/2 101/102-key  
Norwegian Keyboard



\*\$+TA203\*

IBM PS/2 101/102-key  
Portuguese Keyboard



\*\$+TA204\*

IBM PS/2 101/102-key  
Spanish Keyboard



\*\$+TA205\*

IBM PS/2 101/102-key  
Swedish Keyboard



\*\$+TA206\*

IBM PS/2 101/102-key  
Swiss Keyboard



\*\$+TA207\*



**To Set Workstation Configuration to**

**Scan This Bar Code**

IBM PS/2 101/102-key  
United Kingdom Keyboard



\*\$+TA194\*

IBM ValuePoint  
US Keyboard



\*\$+TA1\*

IBM ValuePoint  
French Keyboard



\*\$+TA29\*

IBM ValuePoint  
German Keyboard



\*\$+TA31\*

IBM ValuePoint  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

IBM ValuePoint  
Italian Keyboard



\*\$+TA32\*

IBM ValuePoint  
Spanish Keyboard



\*\$+TA28\*

IBM ValuePoint  
United Kingdom Keyboard



\*\$+TA28\*

Idea Courier 9292



\*\$+TA305\*

NCD X-Station 15-b  
DEC Keyboard



\*\$+TA492\*

NEC 286, 386



\*\$+TA1\*

NEC 286, 386  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

**To Set Workstation Configuration to**

**Scan This Bar Code**

Nokia AT  
Configured Keyboard



\*\$+TA171\*

Nokia PC/XT  
Configured Keyboard



\*\$+TA216\*

Nokia 7414-0011, Nokia VDU 192  
AC42100.001 Keyboard



\*\$+TA239\*

Nokia 7414-0011  
Nokia VDU 192  
AF51211 Keyboard



\*\$+TA240\*

Tandy 1000 Enhanced  
Keyboard



\*\$+TA0\*

Tandy 2500, 4016, 5000



\*\$+TA1\*

Tandy 2500, 4016, 5000  
101/102-key Host-Connected  
Keyboard Map



\*\$+TA450\*

Tektronix X-Station XP11  
PS/2 Keyboard



\*\$+TA488\*

Tektronix X-Station XP11  
DEC Keyboard



\*\$+TA489\*

Tektronix X-Station XP11  
Unix Keyboard



\*\$+TA490\*

Tektronix X-Station XP11  
IBM 3270 Keyboard



\*\$+TA491\*

Unisys PW2 286



\*\$+TA1\*



**To Set Workstation Configuration to**

Wang 240, 280, 380  
Model 724, 301 Keyboard

**Scan This Bar Code**



\*\$+TA1\*

## Sun Stations Series

---

This section covers these workstations:

- Sparc Station 1+ with Type IV keyboard
- Sparc Station LX with Type V keyboard
- Sparc Station IPX with Type V keyboard
- Sun 3/80 with Type IV keyboard

The individual Wedge Interface Guide for this section is part number 056245.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 056244
- Keyboard cable - Part No. 056243
- Terminal cable - Part No. 056242

---

### ***Power Supply***

If you use a Sparc Station IPX with a Type V keyboard, the reader requires an external power supply. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

If you use another workstation, the reader does not require an external power supply. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Sun Stations



\*\$+TA330\*



## Unisys 1120

---

This section covers the Unisys 1120 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054344.

---

### **Cables**

Connecting the reader to the Unisys 1120 workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054343
- Keyboard cable - Part No. 054342
- Terminal cable - Part No. 054341

---





### **Power Supply**

The reader does not require external power to work with this workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
US Keyboard	 *\$+TA190*
Danish/Norwegian Keyboard	 *\$+TA253*
French Keyboard	 *\$+TA254*
German Keyboard	 *\$+TA255*

**To Set Workstation Configuration to**

Italian Keyboard

**Scan This Bar Code**



\*\$+TA256\*

Spanish Keyboard



\*\$+TA257\*

Swedish/Finnish Keyboard



\*\$+TA258\*

United Kingdom Keyboard



\*\$+TA259\*

## Unisys 1224

---

This section covers the Unisys 1224 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054340.

---

### **Cables**

Connecting the reader to the this workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054339
- Keyboard cable - Part No. 054338
- Terminal cable - Part No. 054337

---





### **Power Supply**

The reader does not require external power to work with this workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
US Keyboard	 *\$+TA192*
Danish Keyboard	 *\$+TA226*
Dutch Keyboard	 *\$+TA230*
Finnish Keyboard	 *\$+TA228*

To Set Workstation Configuration to

Scan This Bar Code

Flemish Keyboard



\*\$+TA184\*

French Canadian  
Keyboard



\*\$+TA225\*

French/Belgian Keyboard



\*\$+TA236\*

German Keyboard



\*\$+TA229\*

Italian Keyboard



\*\$+TA231\*

Norwegian Keyboard



\*\$+TA235\*

Office System Keyboard



\*\$+TA238\*

Spanish Keyboard



\*\$+TA237\*

Swedish Keyboard



\*\$+TA234\*

Swiss/French Keyboard



\*\$+TA232\*

Swiss/German Keyboard



\*\$+TA233\*

United Kingdom Keyboard



\*\$+TA183\*

## Unisys SVT 1220

---

This section covers the Unisys SVT 1220 workstation. The individual Wedge Interface Guide corresponding to this section is part number 054761.

*Note: The Unisys SVT 1220 is not supported with the introduction of wedge software release F (November 1995).*

---

### **Cables**

Connecting the reader to the Unisys SVT 1220 workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 054760
- Keyboard cable - Part No. 054759
- Terminal cable - Part No. 054758

---

### **Power Supply**

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### **Configuring the Reader**

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Unisys SVT 1220



\*\$+TA191\*

## WANG 4230

---

This section covers the Wang 4230 workstation. The individual Wedge Interface Guide corresponding to this section is part number 057585.

---

### ***Cables***

Connecting the reader to the workstation requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 057584
- Keyboard cable - Part No. 057583
- Terminal cable - Part No. 057582

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Wang 4230



\*\$+TA362\*

## WANG 4230A, 4430

---

This section covers these workstations:

- Wang 4230A
- Wang 4430

The individual Wedge Interface Guide corresponding to this section is part number 055825.

---

### ***Cables***

Connecting the reader to one of these workstations requires two cables: a keyboard cable and a terminal cable. The interface kit contains both the keyboard and terminal cables. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 055824
- Keyboard cable - Part No. 055823
- Terminal cable - Part No. 055822

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to

Model 725-3155 Keyboard

Scan This Bar Code



\*\$+TA325\*

Model 725-3488 Keyboard



\*\$+TA326\*

## Wyse 50

---

This section covers the Wyse 50 workstation. The individual Wedge Interface Guide corresponding to this section is part number 055942.

---

### ***Cables***

Connecting the reader to the Wyse 50 workstation requires one cable. The interface kit contains the keyboard/terminal cable. If you need to order a replacement cable, use the part numbers listed below:

- Wedge interface kit - Part No. 055941
- Keyboard/Terminal cable - Part No. 055939

---

### ***Power Supply***

The reader does not require an external power supply to work with the workstation. Set the PCB jumper to connect pins 1 and 2 on the reader's rear panel.

---

### ***Configuring the Reader***

Scan this label to configure the reader for your workstation. After the label is scanned, the reader emits one low beep followed by four low beeps. The four low beeps indicate the reader has successfully stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

Wyse 50



\*\$+TA74\*



## Wyse Series

---

This section covers these workstations:

- Wyse 30
- Wyse 60
- Wyse 85
- Wyse 150
- Wyse 160
- Wyse 185
- Wyse 285
- Wyse 325
- Wyse 2108
- Wyse 2112
- Wyse 2116
- Wyse 2200
- Wyse 3216
- Wyse 3225
- Wyse 3116SX
- Wyse WM-15C
- Wyse WM-17C

The individual Wedge Interface Guide corresponding to this section is part number 054130.

---

### ***Cables***

Use the two cables supplied with this WIF kit to connect the reader to your workstation and keyboard, as shown in your *Wedge Reader User's Manual*. To order a replacement cable, use these part numbers:

- Wedge interface kit - Part No. 054129
- Keyboard cable - Part No. 054128
- Terminal cable - Part No. 054127

---

### ***Power Supply***











The reader requires an external power supply to operate with these workstations. Set the PCB jumper to connect pins 2 and 3 on the reader's rear panel.

**Note:** *If you use an external power supply with the reader, you must plug in the power supply before switching on the workstation. If you do not, the reader will lock up.*

---

## ***Configuring the Reader***

Scan the appropriate label to configure the reader for your workstation. The reader should emit one low beep followed by four low beeps, indicating that the reader has stored the configuration and is ready to read labels. If the reader emits a different beep sequence, refer to the *Wedge Reader User's Manual*, Section 2, for beeper identification.

To Set Workstation Configuration to	Scan This Bar Code
Wyse 30	 *\$+TA68*
Wyse 60 ASCII Keyboard	 *\$+TA70*
Wyse 60 AT-Style Keyboard	 *\$+TA71*
Wyse 60 PC Enhanced Keyboard	 *\$+TA50*
Wyse 60 IBM 316X Keyboard	 *\$+TA72*
Wyse 85	 *\$+TA73*
Wyse 150 ASCII US Keyboard	 *\$+TA48*
Wyse 150 ASCII French Canadian Keyboard	 *\$+TA49*
Wyse 150 ANSI US Keyboard	 *\$+TA54*
Wyse 150 ANSI French Canadian Keyboard	 *\$+TA55*

**To Set Workstation Configuration to**

Wyse 60, 150, 160, 325  
Enhanced PC US Keyboard

**Scan This Bar Code**

\*\$+TA50\*

Wyse 60, 150, 160, 325  
Enhanced PC French Canadian  
Keyboard



\*\$+TA52\*

Wyse 150, 160, 325  
Enhanced PC Latin Spanish  
American Keyboard



\*\$+TA53\*

Wyse 150, 160, 325  
Enhanced PC United Kingdom Keyboard



\*\$+TA51\*

Wyse 185  
US/United Kingdom Keyboard



\*\$+TA33\*

Wyse 185  
Danish Keyboard



\*\$+TA34\*

Wyse 185  
Dutch Keyboard



\*\$+TA44\*

Wyse 185  
Finnish Keyboard



\*\$+TA45\*

Wyse 185  
Flemish Keyboard



\*\$+TA46\*

Wyse 185  
French Belgian Keyboard



\*\$+TA47\*

Wyse 185  
French Canadian Keyboard



\*\$+TA35\*

Wyse 185  
German Keyboard



\*\$+TA36\*

To Set Workstation Configuration to

Scan This Bar Code

Wyse 185  
Italian Keyboard



\*\$+TA37\*

Wyse 185  
Norwegian Keyboard



\*\$+TA38\*

Wyse 185  
Portuguese Keyboard



\*\$+TA39\*

Wyse 185  
Spanish Keyboard



\*\$+TA40\*

Wyse 185  
Swedish Keyboard



\*\$+TA41\*

Wyse 185  
Swiss (French) Keyboard



\*\$+TA42\*

Wyse 185  
Swiss (German) Keyboard



\*\$+TA43\*

Wyse 285  
ANSI US Keyboard



\*\$+TA475\*

Wyse 285, 325  
Enhanced PC US Keyboard



\*\$+TA50\*

Wyse 2XXX, 3XXX  
AT-Style US Keyboard



\*\$+TA62\*

Wyse 2XXX, 3XXX  
AT-Style French Keyboard



\*\$+TA64\*

Wyse 2XXX, 3XXX  
AT-Style German Keyboard



\*\$+TA65\*



**To Set Workstation Configuration to**

**Scan This Bar Code**

Wyse 2XXX, 3XXX  
AT-Style Italian Keyboard



\*\$+TA66\*

Wyse 2XXX, 3XXX  
AT-Style Spanish Keyboard



\*\$+TA67\*

Wyse 2XXX, 3XXX  
AT-Style United Kingdom Keyboard



\*\$+TA63\*

Wyse 2XXX, 3XXX  
Enhanced PC US Keyboard



\*\$+TA56\*

Wyse 2XXX, 3XXX  
Enhanced PC French Keyboard



\*\$+TA58\*

Wyse 2XXX, 3XXX  
Enhanced PC German Keyboard



\*\$+TA59\*

Wyse 2XXX, 3XXX  
Enhanced PC Italian Keyboard



\*\$+TA60\*

Wyse 2XXX, 3XXX  
Enhanced PC Spanish Keyboard



\*\$+TA61\*

Wyse 2XXX, 3XXX  
Enhanced PC United Kingdom Keyboard



\*\$+TA57\*

Wyse WM-15C, WM-17C  
Wyse 60 ASCII US Keyboard



\*\$+TA497\*

Wyse WM-15C, WM-17C  
Wyse 85 Gate Array Keyboard



\*\$+TA498\*