

Documentation

to ship or store the computer. The CN2 shipping box contains these items:



What Is the CN2?

computer that runs client/server applications and web-based applications.

The CN2 makes data collection easy and includes these features:

• 802.11b/g radio

• 1D linear imager

CERTIFIED

• .NET Compact Framework

• Color display with touch screen

• 64MB flash/128MB RAM memory

• 400 MHz Intel[®] XScale[™] processor

g

LAN devices.

b

The Intermec CN2 Handheld Computer is an ergonomically designed handheld computer

This quick start guide describes how to set basic parameters to start using the CN2. You

should read this guide if you are a system administrator or person installing the CN2 in a

network. For a list of additional documents you may need, see "Where to Go From Here."

The CN2 computer with an IEEE 802.11b/g radio installed is

Wi-Fi[®] certified for interoperability with other 802.11b/g wireless

built on the Microsoft[®] Windows[®] CE .NET operating system. It is a semi-rugged, lightweight





099

8 8 8 C

วอนเองบ

ZND

CN2 Handheld

Computer



You may need additional information to use the CN2 in your data collection system. Refer to

 CN2 Handheld Computer User's Manual (P/N 075464) these documents for more information:

Intermec Computer Command Reference Manual (P/N 073529)

Intermec sales representative. purchase a printed copy of the CN2 Handheld Computer User's Manual, contact your local These documents are available from the Intermec web site at www.intermec.com. To



Corporation. All rights reserved.

© 2005 Intermec Technologies тор.рэтнэлл.www

> 1225.355.254 x61 tel 425.348.2600

> > .A.2.U

CN2 Handheld Computer



P/N 075480-002







5% to 95% relative humidity, non-condensing

-10°C to 50°C (14°F to 122°F)

0°C to 50°C (32°F to 122°F)

Physical Dimensions

(ni 8.č) mɔ 7.41

Environmental rating:

:VibimuH :eberot2

:poitaring:

:цұбиәๅ

_	
:puital lectrical rating:	Явэq А ⋶. î , \
gsckup:	Rechargeable UMiN 02 HMiN والتعالية Am 02 HMiN المتتعامية
Operating:	Rechargeable 2150 mAh lithium-ion battery
Power and Elec	ctrical Specifications
9075 stdpi∋W	(zo 9.11) p
	(
Thickness: 3.5 cl	(ui 1 , f) ma
Width: 8.6 ci Thickness: 3.5 ci	(ni 4.£) mɔ (ni 4.ť) mɔ

₽9dl

Temperature and Humidity Specifications

Installing and Charging the Battery

To charge the battery, you need the CN2 communications dock (P/N 225-696-001), sold and ordered separately.

To install and charge the battery

Push down on the battery door latch, and pull up on the battery door. Set the battery door aside.



2 Align the battery contacts, and insert the battery in the compartment. Press down on the battery until it clicks into place.



- Install the battery door.
- Place the CN2 in the CN2 communications dock. Connect the communications dock to AC power. The battery is fully charged in approximately 4 hours. For more information, see the instructions that ship with the communications dock.

To remove the battery

Caution

 If you need to remove the battery, insert the stylus between the battery and the CN2 case and press straight down until the battery is released. Lift the battery out of the battery compartment.



Only use the stylus to remove the battery. If you use any other tool or method to remove the battery, you may damage the battery or the CN2.

Utilisez uniquement le stylet pour retirer la pile. Si vous utilisez un autre instrument ou une autre méthode pour le faire, vous risquez d'endommager la pile ou le CN2.

Turning On the CN2 and Finding Keys

The CN2 has either an 18-key numeric keypad or a 10-key scroll keypad.



To access a function printed on a key

• Press that key just as you do on a standard keyboard.

To access a function printed on the keypad overlay

- On the 18-key numeric keypad, you access the functions printed in orange by pressing the **Orange** key (**•**) and then the key below the function. You access the functions printed in green by pressing the **Green** key ($\Box \bullet$) and then the key below the function.
- On the 10-key scroll keypad, you access the functions printed on the keypad overlay by pressing the **Shift** key (=) and then the key below the function.

To turn on the CN2

Press and release the **Power** key. The CN2 turns on.

To turn off the CN2

• Press and hold the **Power** key for 2 seconds and then release the key to turn off the CN2.

Scanning a Bar Code With ScanDemo

Use the ScanDemo application to see how the imager on your CN2 works. You can read 1D bar codes with the CN2.

To scan a bar code with ScanDemo

- 0 From the CN2 desktop, double-tap the ScanDemo icon. The ScanDemo application opens.
- 2 Press the Scan button or press one of the Side Scan buttons, and center the red aiming beam over a bar code label. (This illustration shows the 10-key scroll keypad.)



When the CN2 successfully reads a bar code label, you hear a high beep and the green Good Read light turns on briefly.

- 3 Release the Scan button or Side Scan button. The decoded bar code label data appears in the ScanDemo application.
- 4 Tap the Exit button to exit the ScanDemo application.

Configuring the CN2

After the CN2 finishes booting up for the first time, the Setup Assistant appears. The Setup Assistant walks you through the process of setting the time and date and the configuration parameters necessary to connect the CN2 to your network.



To open Intermec Settings

Intermec Settings.

Troubleshooting

Problem

You press the **F** turn on the CN happens.

You see a batte icon (the Battery ligh

You use your st screen and not

You are using t radio and the r the network ice on the status b

CN2 Handheld Computer Quick Start Guide

Setup Assistant Start Screen

Follow the directions on the Setup Assistant screens to quickly configure your CN2. If you need to set additional parameters or change any parameters you set with the Setup Assistant, you can use the Intermec Settings application.

• Go to Start > Intermec Settings.

For help loading applications on the CN2, see the CN2 Handheld Computer User's Manual. For help using Intermec Settings, see the online manual available from the Help menu in

	Possible Solution
ower key to 2 and nothing	The battery door may be missing or open. Make sure the battery door is completely closed.
	The battery may be discharged. Place the CN2 in a CN2 communications dock to charge the battery. Try to turn on the CN2 again.
ry critically low le status bar, and t is on.	Place the CN2 in a CN2 communications dock to charge the battery.
ylus to tap the hing happens.	Recalibrate your screen:
	 On the 18-key numeric keypad, press and hold the key and then press the Enter key.
	 On the 10-key scroll keypad, press and hold the ■□ key and then press the ▲ key.
	The calibration screen appears. Follow the instructions to recalibrate the screen.
he 802.11b/g o connection to on (🛣) appears ar.	The CN2 may not be communicating with your access point:
	• Make sure the network name on the CN2 is the same as the network name (SSID) on the access point you are trying to communicate with. For help, see your network administrator.
	• The CN2 may not have an IP address. You must configure an IP address for the CN2 or make sure that DHCP assigned an address. Use Intermec Settings and select the radio tab to make sure an IP address has been assigned. For help, see the CN2 Handheld Computer User's Manual.
	• Make sure the CN2 is within range of an access point.
	• Make sure the CN2 is configured correctly for the network.