

# Reference Manual

P/N 062038-002

# JANUS<sup>®</sup> PSK for Ada

 **ntermec**

A **UNOVA** Company

Intermec® Corporation  
6001 36th Avenue West  
P.O. Box 4280  
Everett, WA 98203-9280

U.S. technical and service support: 1-800-755-5505  
U.S. media supplies ordering information: 1-800-227-9947

Canadian technical and service support: 1-800-688-7043  
Canadian media supplies ordering information: 1-800-268-6936

Outside U.S. and Canada: Contact your local Intermec service supplier.

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and /or service Intermec manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Information and specifications in this manual are subject to change without notice.

© 1995 by Intermec Corporation  
All Rights Reserved

The word Intermec, the Intermec logo, JANUS, IRL, Duratherm, Virtual Wedge, and CrossBar are trademarks of Intermec Corporation.

Throughout this manual, trademarked names may be used. Rather than put a trademark (™) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

## ***Contributors***

|                        |                                |
|------------------------|--------------------------------|
| Authors                | Beryl Doane<br>Maureen Norling |
| Editor                 | Craig Thompson                 |
| Technical Illustrators | John Bickley<br>George Wilson  |
| Technical Reviewers    | Roy Law<br>Yong-Qin Lu         |

## ***Manual Change Record***

This page records the changes to this manual.

| <b>Version</b> | <b>Date</b> | <b>Description of Change</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 001            | 9/94        | This manual was first released as version -001.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 002            | 7/95        | <p>Renumbered chapters and made other changes according to current Technical Publications document standards.</p> <p>Updated manual to support the Programmer's Software Kit version 2.1. The new information includes:</p> <ul style="list-style-type: none"><li>Functions to support JANUS J2050 VMU.</li><li>Preamble and postamble functions.</li></ul> <p>Other new topics include:</p> <ul style="list-style-type: none"><li>Using the status code macros.</li><li>Using JANUS Application Simulator.</li></ul> <p>Deleted the following five functions from the manual. They are still available in the PSK library, but Intermec does not recommend using them:</p> <ul style="list-style-type: none"><li>im_flush_expanded_keyboard</li><li>im_get_expanded_keyboard</li><li>im_set_expanded_keyboard</li><li>im_kb_insert_keycodes</li><li>im_kb_insert_string</li></ul> |

# Contents

## ***Before You Begin xi***

*Warranty Information xi*

*Cautions xi*

*About This Manual xii*

*Other Intermec Manuals xv*

# 1

---

## ***Getting Started***

***What Your JANUS Reader Can Do 1-3***

***Virtual Wedge 1-4***

***Reader Services 1-5***

*Function Libraries 1-6*

*Software Interrupts 1-6*

***Installing the JANUS PSK Ada Library 2-3***

# 2

---

## ***Working With Ada***

***Programming With Ada 2-4***

***Building an Executable File 2-5***

*Build Requirements 2-6*

*Compiling 2-7*

*Binding 2-8*

*Linking 2-9*

***Debugging With JANUS Application Simulator 2-10***

***Building a Sample Program Using a Batch Program 2-10***

***Running Your Program on the Reader 2-11***

## Contents

### **Runtime Requirements 2-12**

*Protocol Handlers 2-12*

*Reader Wedge 2-13*

*Specific Functions With Runtime Requirements 2-14*

### **Status Code Macros 2-16**

# 3

---

## **Ada Library**

### **Using the Ada Library Functions 3-3**

#### **Ada Library Functions Listed by Category 3-4**

*im\_appl\_break\_status 3-6*

*im\_backlight\_off 3-8*

*im\_backlight\_on 3-9*

*im\_backlight\_toggle 3-10*

*im\_cancel\_rx\_buffer 3-11*

*im\_cancel\_tx\_buffer 3-12*

*im\_command 3-13*

*im\_cursor\_to\_viewport 3-15*

*im\_decrease\_contrast 3-16*

*im\_get\_config\_info 3-18*

*im\_get\_contrast 3-20*

*im\_get\_control\_key 3-22*

*im\_get\_display\_mode 3-24*

*im\_get\_display\_type 3-27*

*im\_get\_follow\_cursor 3-29*

*im\_get\_input\_mode 3-30*

*im\_get\_keyclick 3-32*

*im\_get\_label\_symbolology 3-33*

*im\_get\_length 3-35*

*im\_get\_postamble 3-36*

*im\_get\_preamble 3-38*

*im\_get\_viewport\_lock 3-40*

*im\_get\_warm\_boot 3-42*

*im\_increase\_contrast 3-43*

|                                    |       |
|------------------------------------|-------|
| <i>im_input_status</i>             | 3-45  |
| <i>im_irl_a</i>                    | 3-47  |
| <i>im_irl_k</i>                    | 3-51  |
| <i>im_irl_n</i>                    | 3-55  |
| <i>im_irl_v</i>                    | 3-59  |
| <i>im_irl_y</i>                    | 3-64  |
| <i>im_iserror</i>                  | 3-69  |
| <i>im_isgood</i>                   | 3-70  |
| <i>im_issuccess</i>                | 3-71  |
| <i>im_iswarn</i>                   | 3-72  |
| <i>im_link_comm</i>                | 3-73  |
| <i>im_message</i>                  | 3-75  |
| <i>im_number_pad_off</i>           | 3-76  |
| <i>im_number_pad_on</i>            | 3-78  |
| <i>im_power_status</i>             | 3-80  |
| <i>im_protocol_extended_status</i> | 3-83  |
| <i>im_receive_buffer</i>           | 3-85  |
| <i>im_receive_buffer_no_wait</i>   | 3-89  |
| <i>im_receive_buffer_noprot</i>    | 3-93  |
| <i>im_receive_byte</i>             | 3-97  |
| <i>im_receive_input</i>            | 3-100 |
| <i>im_rs_installed</i>             | 3-103 |
| <i>im_rx_check_status</i>          | 3-104 |
| <i>im_serial_protocol_control</i>  | 3-105 |
| <i>im_set_contrast</i>             | 3-108 |
| <i>im_set_control_key</i>          | 3-110 |
| <i>im_set_display_mode</i>         | 3-112 |
| <i>im_set_follow_cursor</i>        | 3-115 |
| <i>im_set_input_mode</i>           | 3-117 |
| <i>im_set_keyclick</i>             | 3-119 |
| <i>im_set_viewport_lock</i>        | 3-121 |
| <i>im_set_warm_boot</i>            | 3-123 |
| <i>im_sound</i>                    | 3-125 |
| <i>im_standby_wait</i>             | 3-127 |
| <i>im_transmit_buffer</i>          | 3-129 |
| <i>im_transmit_buffer_no_wait</i>  | 3-131 |

## Contents

*im\_transmit\_buffer\_noprot* 3-132  
*im\_transmit\_byte* 3-134  
*im\_unlink\_comm* 3-137  
*im\_viewport\_end* 3-138  
*im\_viewport\_getxy* 3-139  
*im\_viewport\_home* 3-141  
*im\_viewport\_move* 3-142  
*im\_viewport\_page\_down* 3-145  
*im\_viewport\_page\_up* 3-146  
*im\_viewport\_setxy* 3-147  
*im\_viewport\_to\_cursor* 3-148



---

## Status Codes

**Status Code Bit Values** A-3

**Status Codes Listed Numerically** A-4

**Status Codes Listed by Subsystem** A-22

*Subsystem 0100 RS (Reader Services)* A-23  
*Subsystem 0200 CM (Configuration Management)* A-24  
*Subsystem 0300 SC (Scanner)* A-27  
*Subsystem 0400 DC (Decodes)* A-28  
*Subsystem 0500 RW (Reader Wedge)* A-30  
*Subsystem 0600 CU (Communications)* A-32  
*Subsystem 0800 PM (Power Management)* A-34  
*Subsystem 0A00 TM (Timer)* A-35  
*Subsystem 0B00 BP (Beep)* A-36  
*Subsystem 0E00 IM (Intermec Library)* A-37  
*Subsystem 0F00 LG (Event Logger)* A-38  
*Subsystem 1000 KB (Keyboard Buffer)* A-39  
*Subsystem 1100 SS (System Configuration)* A-40  
*Subsystem 1200 KP (Keypad Services)* A-41  
*Subsystem 1300 DP (Display)* A-42

# **B**

## ***Sample Programs***

---

***DISPMODE.ADA B-3***

***KEYCLICK.ADA B-5***

***PWR\_STAT.ADA B-7***

***XCOMM.ADA B-9***

***Index I-3***



## ***Before You Begin***

---

This section introduces you to standard warranty provisions, safety precautions, warnings and cautions, document formatting conventions, and sources of additional product information.

---

### ***Warranty Information***

To receive a copy of the standard warranty provision for this product, contact your local Intermec sales organization. In the U.S. call (800) 755-5505, and in Canada call (800) 688-7043. Otherwise, refer to the Worldwide Sales & Service list shipped with this manual for the address and telephone number of your Intermec sales organization.

---

### ***Cautions***

The cautions in this manual use the following format.



#### **Caution**

***A caution alerts you to an operating procedure, practice, condition, or statement that must be strictly observed to prevent equipment damage or destruction, or corruption or loss of data.***

#### **Conseil**

***Une précaution vous alerte d'une procédure de fonctionnement, d'une méthode, d'un état ou d'un rapport qui doit être strictement respecté pour empêcher l'endommagement ou la destruction de l'équipement, ou l'altération ou la perte de données.***

---

## ***About This Manual***

This manual is part of the JANUS Programmer's Software Kit manual set. It describes the special features and methods needed for programming the JANUS family of PC-compatible readers. If you plan to write programs in Ada, the information in this manual is very valuable. You may also refer to one of the other books listed under "Other Intermec Manuals" later in this section.

## ***Organization***

The *JANUS Programmer's Software Kit for Ada Reference Manual* is divided into three chapters and one appendix as described below:

| <b>Chapter</b>    | <b>What You Will Find</b>                                                                                                                                                                                                                                                      |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b>          | <i>Getting Started</i><br>This chapter describes the capabilities and programming methods applicable to the Intermec family of PC-compatible readers. It also explains how to install the Programmer's Software Kit Language Libraries disk that is provided with this manual. |
| <b>2</b>          | <i>Working With Ada</i><br>This chapter describes how to write applications in Ada using the library functions.                                                                                                                                                                |
| <b>3</b>          | <i>Ada Library</i><br>This chapter explains the purpose and syntax for each Ada function and provides samples.                                                                                                                                                                 |
| <b>Appendix A</b> | <i>Status Codes</i><br>This appendix lists status codes that are returned by the PSK functions.                                                                                                                                                                                |
| <b>Appendix B</b> | <i>Sample Programs</i><br>This appendix lists sample applications written in the Ada language.                                                                                                                                                                                 |



### ***Terms and Conventions***

- A *reader* is the JANUS 2010, 2020, or 2050 PC-compatible bar code reader.
- An *operator* is anyone who runs applications on the reader.
- A *programmer* is anyone who writes applications for the reader.
- A *normal PC* is assumed to be a DOS-based PC / AT-compatible 386, with a hard disk, 14-inch monitor, full-size keyboard, floppy disk drives, and at least two communication ports.
- *Reader services* are the functional abilities that distinguish the Intermec family of PC-compatible readers from a normal PC. For example, the reader's ability to decode bar code data as if it came from a PC keyboard is a typical reader service.
- *Software interrupts* are the synchronous triggering of interrupts used for application program interfaces.
- *Library functions* are the specialized Ada functions provided in the language libraries that you use to invoke various reader services.
- *PSK* means the Programmer's Software Kit and refers to both the language libraries and this manual.
- The *Programmer's Software Kit Language Libraries* is the disk shipped with this manual. It contains sample programs and library functions for interfacing with the reader.
- The *keypad* is the custom JANUS keyboard. Throughout this manual, specific references to the JANUS keyboard use the term *keypad*.
- The *keyboard* buffer is the machine-level buffer that stores key presses and scanned labels. Throughout this manual, specific references to this buffer and its status flags use the term *keyboard*.

### **Keypad Input**

- Keys that you press on the keypad are emphasized in **bold**. For example, “press **Enter**” means you press the key labeled “Enter” on the reader keypad.
- All key names use first-letter capitalization. For example:  
**Ctrl** = Control key  
**Enter** = Enter key  
**F3** = F3 key
- When you are required to press and release a series of keys in order, the keys are listed in order with no connectors. For example, to enter the uppercase character A, press **Shift A**. To enter this character, you press and release the **Shift** key, and then press the key marked **A**.
- When you are required to press more than one key at the same time, the keys are connected by a dash in the text. For example, press **Ctrl-Alt-Del** to perform a warm boot on a standard PC. When the keys are connected by a dash, it is important that you press and hold the keys in the order they are listed in the text.

### **Commands**

- DOS commands are printed in Courier, exactly as you must type them. For example:

```
COPY INTERMEC.* E:\
```

- Code examples are printed in 8-point Courier. For example:

```
if(step != 0) level = step;    // use step value if provided  
if(level >= 31) level = 0;    // keep level within bounds
```

### **Other Conventions**

- *Italic type* identifies a syntax parameter where it is defined in text. Italic type is also used to indicate references to other manuals and to indicate important terminology.
- Hexadecimal numbers in text are followed by an uppercase H. For example, 03 hex is shown as 03H.
- Hexadecimal numbers in C language code segments begin with 0x. For example, `AX_REG = 0x5300`.



---

## ***Other Intermec Manuals***

You may need additional information for working with the PSK in a data collection system. To order additional manuals, contact your local Intermec representative or distributor.

The following publications contain useful information for programming the Intermec family of PC-compatible readers:

| <b>Manual</b>                                                     | <b>Intermec<br/>Part No.</b> |
|-------------------------------------------------------------------|------------------------------|
| <i>JANUS Programmer's Software Kit for C/C++ Reference Manual</i> | 062133                       |
| <i>JANUS Programmer's Software Kit for Basic Reference Manual</i> | 063191                       |
| <i>JANUS 2010 Hand-Held Computer User's Manual</i>                | 058426                       |
| <i>JANUS 2020 Hand-Held Computer User's Manual</i>                | 059951                       |
| <i>JANUS 2050 Vehicle Mount Unit User's Guide</i>                 | 062874                       |
| <i>JANUS Application Simulator User's Manual</i>                  | 062778                       |
| <i>IRL Programming Reference Manual</i>                           | 048609                       |
| <i>Data Communications Reference Manual</i>                       | 044737                       |
| <i>The Bar Code Book</i>                                          | 051241                       |

For additional programming information, see the software development kit manuals provided with your language.

**Note:** *The Programmer's Software Kit Language Libraries disk accompanying this manual includes a file called README.TXT. This file contains updates to this document and errata of specific importance to programmers.*



*1*


## ***Getting Started***



*This chapter briefly describes the programming methods and capabilities that apply to the JANUS family of readers and explains how to install the PSK.*

## What Your JANUS Reader Can Do

---



Your JANUS reader is a portable, programmable bar code reader and a 386-based computer in one. Each reader has the Intermec controlled BIOS and Microsoft ROM DOS 5.0. The reader behaves and functions like a normal PC with 640K of memory, with these exceptions:

- The JANUS 2010 and 2020 are hand-held, with a small LCD display, custom keyboard, and either a port for a bar code input device or a built-in scanner.
- The JANUS 2050 is mounted to a vehicle, such as a forklift, and has a monochrome CGA display, custom keyboard, built-in RF, and a port for a bar code input device.
- The operating system and protocol support programs reduce the memory available for your application to about 450K.

You can run batch programs and copy, name, or move files in the same manner as you would with any normal PC. The only difference is that the JANUS reader has ROM and RAM drives and a PC card drive.

You can also run DOS-based programs on the reader the same as you can on a PC. When you do, the reader behaves like a PC, but has the advantage of accepting bar code input as if it came from the keypad. If you are an experienced PC programmer, you have already written programs that will run on the reader.

## ***Virtual Wedge***

---

The Virtual Wedge feature of the reader allows application programs to receive decoded bar codes from the keyboard buffer. The Virtual Wedge makes the reader functionally equivalent to a reader wedge connected to a PC. Bar code input is inserted into the PC keyboard buffer as if entered from the keypad. The Virtual Wedge also allows rapid porting of PC applications to the reader.

***Note:*** *If your PC application follows DOS programming conventions, it should run correctly on the JANUS reader. Not all programming languages, especially database languages, follow these conventions. If your PC application does not follow DOS programming conventions, your scanned input will be incorrect.*

Valid configuration commands and reader commands are not put into the keyboard buffer. Bar code configuration commands beginning with \$+ are tagged as configuration commands by the Virtual Wedge and sent to the configuration manager to reconfigure the reader. The command parser in the Virtual Wedge software recognizes and processes reader commands.

You can run applications that use the Virtual Wedge (instead of Intermec interrupt extensions or function libraries) on either the reader or on your PC.

## Reader Services

---

Reader services include several functions ranging in complexity from controlling the reader beeper to controlling the function of the power management software. With reader services, you can easily use bar code input from a wand or scanner by using the direct program interface to handle the functions of the reader keyboard, display, and beeper.

There are two methods for incorporating the reader services into your programs:

- Using function libraries
- Using software interrupts

You can use either one or a combination of both methods.

**Note:** Do **not** run programs that use **PSK library functions** on your PC, **unless** you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### Caution

**Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### Conseil

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**

---

## ***Function Libraries***

The Intermec library functions provide extensive access to reader services. The supported language functions are stored in libraries on the Programmer's Software Kit Language Libraries disk. The list of supported languages includes:

- Borland C/C++
- Microsoft C/C++
- Microsoft Visual C/C++
- Microsoft QuickBasic
- Microsoft Visual Basic for MS-DOS
- Janus/Ada

When you write applications in Ada, link your program to the library by including the header files in your program, and then invoke the reader services using the Ada reader service command. See "Building an Executable File" in Chapter 2 for instructions on compiling, binding, linking, and running an Ada program. Refer to the *PSK Reference Manual* for more information about other language support.

---

## ***Software Interrupts***

The reader supports special software interrupts in addition to those available on a normal PC. If your programming language supports software interrupts, you can write applications that use the reader services. However, it is much easier to use the PSK library functions.

Interrupts are a very *low-level* method of controlling a computer. Programming with interrupts is more difficult than with a high-level language (such as Ada, C, or Basic).

Some of the most popular languages have built-in commands for triggering software interrupts (Microsoft C, Borland C++, and QuickBasic, for example). Languages that do not have built-in interrupt commands sometime allow you to access interrupts by embedding fragments of assembly language inside your program. There are other methods for triggering software interrupts, and you can generate software interrupts from almost any language.

For complete descriptions and examples of the software interrupts that govern reader services, see Chapter 3, “Software Interrupts,” and Appendix B, “Sample Interrupt Programs,” in the *PSK for C/C++ Reference Manual*.

**Caution**

***Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.***

**Conseil**

***N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.***



# 2

## ***Working With Ada***



*This chapter explains how to install the Intermec Ada library and how to build a program using Ada.*

## ***Installing the JANUS PSK Ada Library***

---

The files on the Programmer's Software Kit Language Libraries disk are distributed in several subdirectories, each corresponding to the supported language:

| <b>Subdirectory Name</b> | <b>Language</b>                  |
|--------------------------|----------------------------------|
| INTERMEC\ADA             | Janus/Ada                        |
| INTERMEC\BORLANDC        | Borland C/C++                    |
| INTERMEC\MICROSFT        | Microsoft C/C++ and Visual C/C++ |
| INTERMEC\QUICKB          | Microsoft QuickBasic             |
| INTERMEC\VBDOS           | Visual Basic for MS-DOS          |

The exact contents of the PSK Language Libraries disk are listed in the README.TXT file contained on the disk. To use the library functions, install the correct files on your computer. You can also use the DOS copy command to copy only the specific files you are sure you will need.

**Note:** *If you have an existing Intermec directory, the installation process will update any files in the existing Intermec directory with the new version files having the same name.*

### **To install the library files**

1. Insert the PSK Language Libraries disk into the disk drive on your PC.
2. Change to the appropriate disk drive. For example, type A:.
3. Enter the following command:

```
INSTALL ADA drive
```

where *drive* is the location where you want to install the utilities library. If no drive is designated, the utilities library is installed on drive C.

## ***Programming With Ada***

---

The PSK disk contains the following files for building programs with the Ada functions library:

- The IM20ADAD.LIB file contains the constant definitions.
- The IM20ADAP.LIB file contains the function prototypes.
- The IM20\_ADA.LIB file contains the object modules.
- The following six files are compiled Ada definition library files and symbol tables:

|              |              |
|--------------|--------------|
| INTRMECD.SRL | INTRMECP.SRL |
| INTRMECD.JRL | INTRMECP.JRL |
| INTRMECD.SYM | INTRMECP.SYM |

While the PSK disk includes complete JANUS reader Ada functions, you will require additional products before you can use Intermec's Ada functions and procedures. You will need the following:

- Janus/Ada Compiler
- Text editor for creating source code
- Microsoft Linker


Support for Intermec's Ada is only available using the Janus/Ada "nonprofessional" compiler by R.R. Software, Inc. of Madison, Wisconsin. You can order the Janus/Ada compiler through Intermec. It is coincidental that the name of the Janus/Ada software compiler resembles the tradename of the Intermec JANUS reader.

Your text editor must create standard ASCII text files. You can use the DOS Edit program or any other ASCII editor.

Microsoft C/C++ linkers are the only linkers certified to work with Intermec Ada. The Microsoft QuickBasic, Visual Basic, Visual C, and MASM linkers have not been tested, but may link your object files successfully.

## Building an Executable File

The procedures in this section lead you through the process of compiling, binding, linking, and running a program that use the PSK Ada Library. The following figure outlines the build process and shows the types of files produced at each stage.



AIT-23

---

## ***Build Requirements***

Use the following checklist to make sure you meet the requirements for building your program:

- The following six files must be in your working directory or in your DOS path:

|              |              |
|--------------|--------------|
| INTRMECD.SRL | INTRMECP.SRL |
| INTRMECD.JRL | INTRMECP.JRL |
| INTRMECD.SYM | INTRMECP.SYM |

- Your DOS path must include the following directories in this exact order:

C:\JADOS\M1; C:\JADOS; C:\INTERMEC\ADA\WITH

- The following lines must be at the start of your program:

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;
```

- You must have a Microsoft linking program, LINK.EXE.
- You must compile and bind your program with memory model 1 (M1). Your DOS path must include the M1 subdirectory, as in C:\JADOS\M1.

---

## Compiling

The compiler processes your source code and produces a compiled output file, *progrname.SRL*. If you do not have the Janus / Ada compiler, you can order it through Intermec.

### To compile an Ada program

- From the DOS prompt, enter the following command:

```
JANUS progrname.ADA /O1 /3 /T
```

where:

*progrname* is the name of your source file.

/O1 (letter “O”) tells the JANUS reader to use memory model 1, which is required by Intermec’s utilities libraries.

/3 creates 386-machine instruction code, which executes on 80386, 80486, or compatible processors.

/T parameter results in a smaller executable program and is optional. When combined with the JBIND /T option, the /T parameter directs JBIND to remove procedures in this compilation that can never be called.

---

## ***Binding***

After compiling your program, you must *bind* the compiled output file, *progrname.SRL*, into an object file that can be read by a linking program.

### **To bind your Ada program**

- From the DOS prompt, enter the following command:

```
JBIND progrname /O1 /M /T
```

where:

*progrname* is the compiled output file, *progrname.SRL*, without the extension.

/O1 (letter “O”) tells JBIND to use object code memory model 1, which Intermec’s utilities libraries require.

/M tells JBIND to create a main program compatible with Microsoft C. The resulting file is *progrname.OBJ*.

/T tells JBIND to trimout unreachable subprograms from units that were compiled with the compiler’s /T option.

---

## Linking

You use a Microsoft LINK.EXE program to link your Ada program with the IM20\_ADA.LIB object library file. The Janus/Ada compiler does not include a linking program. The Microsoft C/C++ linkers are the only linkers certified to work with Intermec Ada. The Microsoft QuickBasic, Visual Basic, Visual C, and MASM linkers have not been tested, but may link your object files successfully.

### To link your Ada program

1. If your linker is not in your path, change to the directory containing LINK.EXE.
2. Create a response file, *progrname.RSP*, for linking. The response file consists of the following four lines:

```
progrname.OBJ  
progrname  
(a blank line)  
C:\INTERMEC\ADA\IM20_ADA.LIB
```

where:

the first line lists the program object file, including the path.

the second line lists only the executable filename with no extension.

the third line is left blank.

the fourth line lists the library files, including the path.

3. Link your program from DOS:  
`LINK /NOE @progrname.RSP`
4. Copy your program to the reader. Refer to your JANUS user's manual for complete copying instructions.

## ***Debugging With JANUS Application Simulator***

---

The JANUS Application Simulator is a terminate-and-stay resident (TSR) program that you use to run JANUS applications on a PC. Without the Simulator, you cannot run JANUS applications on your PC because JANUS applications contain functions and system interrupts that may lock up a PC.

The Simulator captures the functions and interrupts before they can disrupt the PC. Then, the Simulator uses those functions and interrupts to make the PC mimic a JANUS reader. For more information on the Simulator, refer to the *JANUS Application Simulator User's Manual*, Part No. 062778.

### **To debug a JANUS application with the Simulator**

1. Start the Simulator from the DOS prompt by entering this command:  
`janussim`
2. Follow the debugging instructions provided with Janus/Ada.

## ***Building a Sample Program Using a Batch Program***

---

Intermec provides a batch program that compiles, binds, and links a sample program. Follow the steps below to use the batch program.

### **To build the sample programs using a batch program**

1. From the \INTERMEC\ADA\SAMPLES directory, enter the following command:  
`CLL filename`  
where *filename* is the name of one of the sample programs without the .ADA extension.
2. Connect the JANUS reader to a PC using the communications dock or the optical interface cable.
3. Copy the *filename*.EXE file to the reader. Refer to your JANUS user's manual for complete copying instructions.

## ***Running Your Program on the Reader***

---

After you copy your program to the reader, you are ready to run it.

**Note:** Do **not** run programs that use **PSK library functions** on your PC, **unless** you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### **Caution**

**Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### **Conseil**

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**

### **To run your program on the reader**

1. From the DOS prompt on the reader, change to the drive where the program file *programe.EXE* is located. For example, enter the following command to use drive E:  
  
E:
2. Change to the directory where the program file filename.EXE is located. For example, enter the following command to use the root directory:  
  
CD \
3. Enter the following command:  
  
*programe*

Your program begins executing.

## ***Runtime Requirements***

---

For some library functions to work properly, you must install and run specific software components at program execution time. For example, if the reader is using a communications port, you must load a protocol handler. Because protocol handlers use a lot of memory, they are not automatically loaded for you. Other functions require the Reader Wedge.

---

### ***Protocol Handlers***

You use the Intermec protocol handler (PHIMEC.EXE) when the reader is connected with other Intermec devices. PHIMEC.EXE works with User-Defined, Point-to-Point, Polling Mode D, and Multi-Drop protocols.

You use the PC standard protocol handler (PHPCSTD.EXE) when the reader is connected to devices that use PC standard protocol. PHPCSTD.EXE provides low-level communications abilities and protocol services at the DOS level for non-communications software. It also provides byte-by-byte transfer.

If your reader is a radio frequency (RF) unit, RFPH.EXE is automatically loaded.

For more information on protocol handlers, refer to your JANUS user's manual.

#### **To install a protocol handler**

- From the DOS prompt, enter the following command:

*handler n*

where:

*handler* is either PHIMEC or PHPCSTD.

*n* is the number of the communications port.

When your application is finished, the protocol handler TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the protocol handler TSR by adding the unload command as the last line of the batch file that launches your application.

**To unload a protocol handler**

- From the DOS prompt, enter the following command:

```
unload handler n
```

where:

*handler* is the installed handler (PHIMEC or PHPCSTD).

*n* is the number of the communications port.

---

***Reader Wedge***

Some functions, such as `im_receive_input`, allow the reader to receive input from multiple sources and process the input depending on the source. You must load the Reader Wedge (RWTSR.EXE) TSR to use these functions.

When your application is finished, the Reader Wedge TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the Reader Wedge TSR by adding the unload command as the last line of the batch file that launches your application.

**To load the Reader Wedge TSR**

- From the DOS prompt, enter the following command:

```
RWTSR
```

**To unload the Reader Wedge TSR**

- From the DOS prompt, enter the following command:

```
RWTSR -D
```

---

## ***Specific Functions With Runtime Requirements***

The following table lists the PSK functions that have runtime requirements.

---

### ***Specific Runtime Requirements***

| <b>This Function</b>                   | <b>Requires</b>                                                                                                      |
|----------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| <code>im_cancel_rx_buffer</code>       | Protocol Handler                                                                                                     |
| <code>im_cancel_tx_buffer</code>       | Protocol Handler                                                                                                     |
| <code>im_clear_abort_callback</code>   | Reader Wedge                                                                                                         |
| <code>im_command</code>                | Reader Wedge                                                                                                         |
| <code>im_get_input_mode</code>         | Reader Wedge                                                                                                         |
| <code>im_get_label_symbolology</code>  | Reader Wedge                                                                                                         |
| <code>im_get_length</code>             | Reader Wedge                                                                                                         |
| <code>im_input_status</code>           | Reader Wedge                                                                                                         |
| <code>im_irl_a</code>                  | Reader Wedge                                                                                                         |
| <code>im_irl_k</code>                  | Reader Wedge                                                                                                         |
| <code>im_irl_n</code>                  | Reader Wedge                                                                                                         |
| <code>im_irl_v</code>                  | Reader Wedge<br>If the data is from a communications port, use a<br>Protocol Handler and <code>im_link_comm</code> . |
| <code>im_irl_y</code>                  | Reader Wedge<br>Protocol Handler<br>Use <code>im_link_comm</code> .                                                  |
| <code>im_link_comm</code>              | Reader Wedge<br>Protocol Handler                                                                                     |
| <code>im_receive_buffer</code>         | Protocol Handler<br>Do not use <code>im_link_comm</code> .                                                           |
| <code>im_receive_buffer_no_wait</code> | Protocol Handler<br>Do not use <code>im_link_comm</code> .                                                           |
| <code>im_receive_buffer_noprot</code>  | Protocol Handler<br>Do not use <code>im_link_comm</code> .                                                           |
| <code>im_receive_byte</code>           | PHPCSTD.EXE<br>You must use PC standard protocol on the host.<br>Do not use <code>im_link_comm</code> .              |

---

**Specific Runtime Requirements (continued)**

| This Function              | Requires                                                                                         |
|----------------------------|--------------------------------------------------------------------------------------------------|
| im_receive_input           | Reader Wedge<br>Protocol Handler<br>If the data is from a communications port, use im_link_comm. |
| im_rx_check_status         | Protocol Handler                                                                                 |
| im_serial_protocol_control | Use im_link_comm.                                                                                |
| im_set_abort_callback      | Reader Wedge                                                                                     |
| im_set_display_mode        | Reader Wedge                                                                                     |
| im_set_input_mode          | Reader Wedge                                                                                     |
| im_standby_wait            | Reader Wedge                                                                                     |
| im_transmit_buffer         | Protocol Handler                                                                                 |
| im_transmit_buffer_no_wait | Protocol Handler                                                                                 |
| im_transmit_buffer_noprot  | Protocol Handler                                                                                 |
| im_transmit_byte           | Protocol Handler<br>You must install PHPCSTD.                                                    |
| im_unlink_comm             | Reader Wedge<br>Protocol Handler                                                                 |

**Note:** Do not run programs that use PSK library functions or Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.

## Status Code Macros

---

When using any of the Intermec library functions, you can check for a specific status value or you can use one of the PSK macros to determine the severity of the returned status codes. For portability with future Intermec products, we recommend that you use the macros.

The following macros are included in IM20ADAD.LIB:

**im\_iserror (status)** This macro returns a nonzero number when *status* indicates an error (either fatal or nonfatal). Zero is returned if *status* indicates either success or warning.

**im\_issuccess (status)** This macro returns a nonzero number when *status* indicates either success or warning. Zero is returned if *status* indicates an error (either fatal or nonfatal).

**im\_isgood (status)** This macro returns a nonzero number when *status* indicates success.

**im\_iswarn (status)** This macro returns a nonzero number when *status* indicates a warning.

The following example uses IM\_ISERROR to test for an error and then prints the error message on the reader display.

```
im_get_display_mode (size, video, scroll, char_ht, status);
if im_iserror (status) then
  Put ("Get Disp Mode error = ");
  SYSWORD_IO.Put (status, WIDTH => 8);
  New_Line;
end if;
```



***Ada Library***



*This chapter explains the functions and procedures available in the Intermec Ada library and provides samples and notes to help you write application programs.*

## ***Using the Ada Library Functions***

---

In Ada, a procedure differs from a function in two major ways:

### **A Procedure**

Can pass output parameters.

Does **not** return a result when called.

### **A Function**

Can **not** pass output parameters.

Returns a result when called.

The Intermec Ada library uses the following conventions to determine when to use a function and when to use a procedure.

- A subroutine that only needs to pass out the status code without any other output variables is a function. The status code is returned as the function return value.
- A subroutine that needs to pass values as output variables is a procedure. The status code is returned as one of the output parameters.

**Note:** Do **not** run programs that use **PSK library functions** on your PC, **unless** you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### **Caution**

**Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### **Conseil**

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**

## ***Ada Library Functions Listed by Category***

---

### ***Communications***

im\_cancel\_rx\_buffer, 3-11  
im\_cancel\_tx\_buffer, 3-12  
im\_link\_comm, 3-73, 3-137  
im\_protocol\_extended\_status, 3-83  
im\_receive\_buffer, 3-85  
im\_receive\_buffer\_no\_wait, 3-89  
im\_receive\_buffer\_noprot, 3-93  
im\_receive\_byte, 3-97  
im\_receive\_input, 3-100  
im\_rx\_check\_status, 3-104  
im\_serial\_protocol\_control, 3-105  
im\_transmit\_buffer, 3-129  
im\_transmit\_buffer\_no\_wait, 3-131  
im\_transmit\_buffer\_noprot, 3-132  
im\_transmit\_byte, 3-134

### ***Display***

im\_backlight\_off, 3-8  
im\_backlight\_on, 3-9  
im\_backlight\_toggle, 3-10  
im\_decrease\_contrast, 3-16  
im\_get\_contrast, 3-20  
im\_get\_display\_mode, 3-24  
im\_get\_display\_type, 3-27  
im\_get\_follow\_cursor, 3-29  
im\_increase\_contrast, 3-43  
im\_set\_contrast, 3-108  
im\_set\_display\_mode, 3-112  
im\_set\_follow\_cursor, 3-115

### ***Input***

im\_get\_label\_symbolology, 3-33  
im\_get\_length, 3-35  
im\_input\_status, 3-45  
im\_receive\_input, 3-100  
im\_set\_input\_mode, 3-117

### ***IRL***

im\_irl\_a, 3-47  
im\_irl\_k, 3-51  
im\_irl\_n, 3-55  
im\_irl\_v, 3-59  
im\_irl\_y, 3-64

### ***Keypad***

im\_get\_control\_key, 3-22  
im\_get\_keyclick, 3-32  
im\_get\_warm\_boot, 3-42  
im\_number\_pad\_off, 3-76  
im\_number\_pad\_on, 3-78  
im\_set\_control\_key, 3-110  
im\_set\_keyclick, 3-119  
im\_set\_warm\_boot, 3-123

### ***Program Control***

im\_appl\_break\_status, 3-6  
im\_standby\_wait, 3-127

### ***Sound***

im\_sound, 3-125

### ***Status macros***

im\_iserror, 3-69  
im\_isgood, 3-70  
im\_issuccess, 3-71  
im\_iswarn, 3-72

### ***System***

im\_command, 3-13  
im\_get\_config\_info, 3-18  
im\_get\_postamble, 3-36  
im\_get\_preamble, 3-38  
im\_message, 3-75  
im\_power\_status, 3-80  
im\_rs\_installed, 3-103

## **Viewport**

- im\_cursor\_to\_viewport, 3-15
- im\_get\_viewport\_lock, 3-40
- im\_set\_follow\_cursor, 3-115
- im\_set\_viewport\_lock, 3-121
- im\_viewport\_end, 3-138
- im\_viewport\_getxy, 3-139
- im\_viewport\_home, 3-141
- im\_viewport\_move, 3-142
- im\_viewport\_page\_down, 3-145
- im\_viewport\_page\_up, 3-146
- im\_viewport\_setxy, 3-147
- im\_viewport\_to\_cursor, 3-148

**Note:** The following syntax descriptions refer to many named constant variables, such as *IM\_COM1*. These variables always appear in uppercase in this manual and are described in *IM20ADAD.LIB*.

## *im\_appl\_break\_status*

---

### ***im\_appl\_break\_status***

**Purpose:** This function checks whether the application break sequence has been pressed. All PSK functions are terminated when the application break sequence is keyed in.

Place calls to this function at strategic locations in your program to detect when a user wants to break out of a loop. Your program can determine what action to take when the break sequence is detected.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
  procedure im_appl_break_status (  
    break_status  : Out IM_APPBREAK_STATUS;  
    status_code   : Out System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The break\_status parameter is one of the following constants:

|                     |                                                    |
|---------------------|----------------------------------------------------|
| IM_REQUEST_NOT_MADE | Request for an application break has not been made |
|---------------------|----------------------------------------------------|

|                 |                                                |
|-----------------|------------------------------------------------|
| IM_REQUEST_MADE | Request for an application break has been made |
|-----------------|------------------------------------------------|

The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** The *break\_status* flag is reset each time this routine is called. Because this function is also called during the input routines provided in the library, you should check the return code from input functions for the hex value 8515H. This value indicates that the input function has terminated because the application break sequence was entered. In this case, the break\_status flag is cleared by the input function's call to im\_appl\_break\_status.

**To enter an application break sequence**

1. Press  to turn off the reader.
2. Press  -  -  at the same time.
3. Press . This sets the reader's application break bit.
4. Press  to turn on the reader.

**Example**

With System, Text\_IO, Intrmechd\_IO, Intrmecp\_IO;  
 Use System, Text\_IO, Intrmechd\_IO, Intrmecp\_IO;

procedure appl\_br Is

```

package SYSWORD_IO is new INTEGER_IO (System.Word);
package IM_APPBREAK_STATUS_IO is new ENUMERATION_IO
  (enum => IM_APPBREAK_STATUS);
break   : IM_APPBREAK_STATUS;
status  : System.Word;
in_char : Character := ' ';

begin
  Put_Line ("Appl Brk Status");
  Put_Line ("Set brk bit and then");
  Put_Line ("press any key & return");
  Get (in_char);

  -- Press the following sequence at this pause (to set application break bit):
  -- 1/0 key (Turn OFF the reader)
  -- F3-2-Left Arrow (Press F3, 2 and left arrow at the same time)
  -- 1 (Press the 1 (one) key to set application break bit)
  -- 1/0 key (Turn ON the reader)

  -- set break to known value
  break := IM_REQUEST_MADE;
  im_appl_break_status (break, status);
  if break = IM_REQUEST_MADE then
    Put_Line ("Break status ON");
    Put ("return status : ");
    SYSWORD_IO.Put (status, WIDTH => 4);
    New_Line;
    Put ("break_status : ");
    IM_APPBREAK_STATUS_IO.Put (break);

  elsif break = IM_REQUEST_NOT_MADE then
    Put_Line ("Break status OFF");
    Put ("return status : ");
    SYSWORD_IO.Put (status, WIDTH => 4);
    New_Line;
    Put ("break_status : ");
    IM_APPBREAK_STATUS_IO.Put (break);
  end if;
  New_Line;
end appl_br;
```

## *im\_backlight\_off*

---

### ***im\_backlight\_off***

|                      |                                                                                                                                                                                                                                                                                                                                        |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose:</b>      | This procedure turns the display backlight off. Turn off the backlight to prolong the reader's battery life.                                                                                                                                                                                                                           |
| <b>Syntax:</b>       | With Intrmechd_IO, Intrmecp_IO;<br>Use Intrmechd_IO, Intrmecp_IO;<br>procedure im_backlight_off;                                                                                                                                                                                                                                       |
| <b>Parameters:</b>   | None.                                                                                                                                                                                                                                                                                                                                  |
| <b>Return Value:</b> | None.                                                                                                                                                                                                                                                                                                                                  |
| <b>Notes:</b>        | <p>You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1-second increments. The default is 10 seconds.</p> <p>This procedure has no effect on the JANUS 2050.</p> |
| <b>See Also:</b>     | im_backlight_on, im_backlight_toggle                                                                                                                                                                                                                                                                                                   |

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
  
procedure lightoff Is  
begin  
    im_backlight_off;  
    Put_Line ("Backlight off");  
end lightoff;
```

---

## ***im\_backlight\_on***

**Purpose:** This procedure turns the JANUS display backlight on to help you see the reader display in dimly lit environments.

**Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
procedure im\_backlight\_on;

**Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1-second increments. The default is 10 seconds.

This procedure has no effect on the JANUS 2050.

**See Also:** im\_backlight\_off, im\_backlight\_toggle

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;
```

```
procedure lighton Is
```

```
begin  
    im_backlight_on;  
    Put_Line ("Backlight on");  
end lighton;
```

## *im\_backlight\_toggle*

---

### ***im\_backlight\_toggle***

- Purpose:** This function toggles the LCD display backlight on and off.
- Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
function im\_backlight\_toggle return System.Word;
- Parameters:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1-second increments. The default is 10 seconds.
- This procedure has no effect on the JANUS 2050.
- See Also:** im\_backlight\_on, im\_backlight\_off

---

### ***Example***

```
With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure lightogl Is
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;

begin
    status := im_backlight_toggle;
    Put_Line ("Backlt toggled");
    if Tstbit(status, 15) then
        Put ("Backlight toggle error = ");
        SYSWORD_IO.Put (status, WIDTH => 8);
        New_Line;
    end if;
end lightogl;
```

---

## ***im\_cancel\_rx\_buffer***

- Purpose:** This function clears the receive buffer of the designated communications port.
- Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
function im_cancel_rx_buffer (  
    port : IN IM_COM_PORT  
) return System.Word;
```
- IN Parameter:** The *port\_id* parameter identifies the communications port as follows:
- |         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”
- If there is no pending input to receive, this function returns 4602H (no client).
- Notes:** You must install a protocol handler to use this function.
- See Also:** im\_receive\_buffer\_no\_wait, im\_receive\_buffer\_noprot

---

### ***Example***

See example for im\_receive\_buffer.

## *im\_cancel\_tx\_buffer*

---

### ***im\_cancel\_tx\_buffer***

**Purpose:** This function clears the contents of the transmit buffer, stops transmission in progress, and resets the communications port.

Use this function with Polling Mode D to clear out the buffer. Other protocols clear the buffer automatically.

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function im\_cancel\_tx\_buffer (  
    port : IN IM\_COM\_PORT  
) return System.Word;

**IN Parameter:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

If there are no pending transmissions to receive, this function returns 4602H (no client).

**Notes:** You must install a protocol handler to use this function.

**See also:** im\_transmit\_buffer\_no\_wait, im\_transmit\_buffer\_noprot,  
im\_transmit\_buffer

---

#### ***Example***

See example for im\_receive\_buffer.

---

## ***im\_command***

- Purpose:** This function modifies the reader's configuration. For example, you can use this function to set a specific communications port's baud rate.
- Syntax:**
- ```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
function im_command (  
    command          : IN String;  
    command_length   : IN System.Word  
) return System.Word;
```
- IN Parameter:** The *command* parameter is a reader command string. The command string may include more than one reader command. For example, the command string `%.1$+BV9` turns on the backlight and raises the beep volume.
- Reader commands are listed in your JANUS user's manual.
- The *command\_length* parameter is the length of the reader command string.
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:** For more information on reader commands, refer to your JANUS user's manual.
- You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" in Chapter 2, "Working With Ada."

## *im\_command*

---

### **Example**

```
With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure command Is
    status      : System.Word;
    high_trast  : String(1..5) := "$+DJ7";
    low_trast   : String(1..5) := "$+DJ0";
    norm_trast  : String(1..5) := "$+DJ3";
begin
    Put_Line ("Setting high contrast");
    status := im_command (high_trast, high_trast'Length);
    status := im_standby_wait (5000);

    Put_Line ("Setting low contrast");
    status := im_command (low_trast, low_trast'Length);
    status := im_standby_wait (5000);

    Put_Line ("Setting normal contrast");
    status := im_command (norm_trast, norm_trast'Length);
end command;
```

---

## ***im\_cursor\_to\_viewport***

- Purpose:** This function moves the cursor to the center of the current viewport. Since the viewport can move around with or without the cursor, you can use this function to recenter the cursor.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
procedure im\_cursor\_to\_viewport;
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** None.
- Notes:** This function has no effect on the JANUS 2050.
- See also:** im\_viewport\_end, im\_viewport\_home, im\_viewport\_page\_down,  
im\_viewport\_page\_up, im\_viewport\_to\_cursor, im\_viewport\_move

---

### ***Example***

```
With System, Bit, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure crsrview Is
package STATUS_IO is new INTEGER_IO (System.Word);
row, col : System.Word;
status   : System.Word;

begin
  im_viewport_move (IM_VIEWPORT_RIGHT, 15, row, col, status);
  im_cursor_to_viewport;
  status := im_standby_wait (5000);

  -- show that viewport moved
  STATUS_IO.Put (row);
  STATUS_IO.Put (col);
  New_Line;
  im_viewport_home;
end crsrview;
```

## *im\_decrease\_contrast*

---

### ***im\_decrease\_contrast***

**Purpose:** This function decreases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast (0 to 31).

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function `im_decrease_contrast` return System.Word;

**Parameters:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

**Notes:** The 0 to 31 scale fine-tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table shows the equivalent values for the 0 to 7 scale.

| Scale 0 to 7 | Scale 0 to 31 | Level      |
|--------------|---------------|------------|
| 0            | 10            | Very light |
| 1            | 12            |            |
| 2            | 14            |            |
| 3            | 16            |            |
| 4            | 18            |            |
| 5            | 20            |            |
| 6            | 22            | Very dark  |
| 7            | 24            |            |

This function has no effect on the JANUS 2050.

**See Also:** `im_increase_contrast`, `im_set_contrast`, `im_get_contrast`

---

**Example**

```
With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure decontr Is
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
begin
    Put_Line ("Decreasing contrast");
    status := im_decrease_contrast;
    if Tstbit(status, 15) then
        Put ("Dec contrast error = ");
        SYSWORD_IO.Put (status, WIDTH => 8);
        New_Line;
    end if;
end decontr;
```

## *im\_get\_config\_info*

---

### ***im\_get\_config\_info***

**Purpose:** This procedure retrieves the current reader configuration information string and its length.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_get_config_info (  
    config_string : OUT String;  
    length        : OUT System.Word;  
    status_code   : OUT System.Word);
```

**IN/OUT Parameters:** The *config\_string* parameter is the configuration information string. The first two characters specify the type of configuration information returned.

For example, to get the beep duration setting, set the *config\_string* to “BD.” The procedure retrieves the currently configured setting for beep duration.

The *length* parameter is the length of the configuration information string.

The *status\_code* parameter is one of the standard status codes defined in Appendix A, “Status Codes.”

For a list of the configuration commands, see your JANUS user’s manual.

**Return Value:** None.

**Notes:** This procedure differs from *im\_command* in that you only pass the two-character command identifier. The *im\_command* procedure passes an entire command string.

**See Also:** *im\_command*

**Example**

```
With System, Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;
Use Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;
```

```
procedure CONINFO is
```

```
    package SYSBYTE_IO is new INTEGER_IO(System.Byte);
    package SYSWORD_IO is new INTEGER_IO(System.Word);
    use SYSBYTE_IO, SYSWORD_IO;
    config_string : String(1..300) := (others => Ascii.NUL);
    config_length : System.Word;
    status       : System.Word;
    config_command : constant String := "BV";
```

```
begin
```

```
    clrscr;
    Put_Line("im_get_config_info example:");
    New_Line;
```

```
-- Set config request for Beeper Volume
    config_string(1..2) := config_command;
    im_get_config_info(config_string, config_length, status);
```

```
    Put("Beep Volume: ");
    for i in Integer range 1..300 loop
        exit when config_string(i) = Ascii.NUL;
        Put(config_string(i));
```

```
    end loop;
```

```
    New_Line;
```

```
    Put("Length      : ");
```

```
    Put(config_length);
```

```
    New_Line;
```

```
    Put("Status      : ");
```

```
    Print_status_code(status);
```

```
    New_Line;
```

```
end CONINFO;
```

## *im\_get\_contrast*

---

### ***im\_get\_contrast***

**Purpose:** This procedure retrieves the reader's display contrast level. There are eight levels of contrast from very light (level 0) to very dark (level 7).

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;

```
procedure im_get_contrast (  
    contrast      : OUT System.Byte;  
    status_code   : OUT System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The *contrast* parameter is a number from 0 to 7 or is one of the following constants:

|                 |   |                  |
|-----------------|---|------------------|
| IM_MIN_CONTRAST | 0 | minimum contrast |
| IM_MAX_CONTRAST | 1 | maximum contrast |

The *status\_code* parameter is a standard status code listed in Appendix A, "Status Codes."

**Notes:** The functions *im\_set\_contrast* and *im\_get\_contrast* use a scale of 0 to 7 that is related to the scale of 0 to 31 used by *im\_increase\_contrast* and *im\_decrease\_contrast*. The following table shows the equivalent values for the 0 to 7 scale.

| Scale 0 to 7 | Scale 0 to 31 | Level      |
|--------------|---------------|------------|
| 0            | 10            | Very light |
| 1            | 12            |            |
| 2            | 14            |            |
| 3            | 16            |            |
| 4            | 18            |            |
| 5            | 20            |            |
| 6            | 22            | Very dark  |
| 7            | 24            |            |

This function has no effect on the JANUS 2050.

**Return Value:**       None.

**See Also:**           im\_increase\_contrast, im\_decrease\_contrast, im\_set\_contrast

---

**Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure getcontr Is

  package SYSBYTE_IO is new INTEGER_IO (System.Byte);
  package SYSWORD_IO is new INTEGER_IO (System.Word);
  contrast : System.Byte;
  status   : System.Word;

begin
  im_get_contrast (contrast, status);
  Put_Line ("Getting contrast");
  if im_isgood (status) then
    Put_Line ("The contrast level");
    Put ("setting is : ");
    SYSBYTE_IO.Put (contrast, Width => 3);
  else
    Put ("Get Contrast error = ");
    SYSWORD_IO.Put (status, WIDTH => 8);
  end if;
  New_Line;
end getcontr;
```

## *im\_get\_control\_key*

---

### ***im\_get\_control\_key***

**Purpose:** You can enable or disable the **Ctrl** key. This procedure retrieves the current setting.

When you disable this keycode, none of the key combinations that use the **Ctrl** key will work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_get_control_key (  
    control_key_status : OUT IM_CONTROL;  
    status_code        : OUT System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The *control\_key\_status* parameter is one of the following constants:

|            |                             |
|------------|-----------------------------|
| IM_ENABLE  | <b>Ctrl</b> key is enabled  |
| IM_DISABLE | <b>Ctrl</b> key is disabled |

The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**See also:** *im\_set\_control\_key*

---

**Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure getcntrl Is
    control_key_status : IM_CONTROL;
    status_code        : System.Word;

begin
    im_get_control_key (control_key_status, status_code);
    if control_key_status = IM_ENABLE then
        put_Line ("Ctrl key ENABLED");
    else
        put_Line ("Ctrl key DISABLED");
    end if;
end getcntrl;
```

## *im\_get\_display\_mode*

---

### ***im\_get\_display\_mode***

**Purpose:** This procedure retrieves the current size mode, video mode, scroll mode, character height, and status code of the display.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_get_display_mode (  
    size_mode      : OUT IM_STD_SIZE_MODE;  
    video_mode     : OUT IM_STD_VIDEO_MODE;  
    scroll_mode    : OUT IM_SCROLL_MODE;  
    character_height : OUT IM_CHARACTER_HEIGHT;  
    status_code    : OUT System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The *size\_mode* parameter is required and is one of these constants:

|                    |                                   |
|--------------------|-----------------------------------|
| IM_SIZE_MODE_80X25 | 80 x 25 text mode                 |
| IM_SIZE_MODE_20X16 | 20 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_20X8  | 20 x 8 text mode (2010 and 2020)  |
| IM_SIZE_MODE_10X16 | 10 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_10X8  | 10 x 8 text mode (2010 and 2020)  |

If IM\_SIZE\_MODE\_80X25 is set, you also need to set the video mode, scroll mode, and character height.

If any other *size\_mode* is set, the video mode, scroll mode, and character height are automatically set.

The *video\_mode* parameter requires IM\_SIZE\_MODE\_80X25. The standard BIOS supports up to mode 13 but the JANUS only supports up to mode 6. You can also set video modes 0 through 3 with IC.EXE.

The *video\_mode* parameter is one of these constants:

|                     |                                         |
|---------------------|-----------------------------------------|
| IM_STD_VIDEO_MODE_0 | 40 x 25 (use for double wide character) |
| IM_STD_VIDEO_MODE_1 | 40 x 25 (use for double wide character) |
| IM_STD_VIDEO_MODE_2 | 80 x 25                                 |
| IM_STD_VIDEO_MODE_3 | 80 x 25                                 |
| IM_STD_VIDEO_MODE_4 | 300 x 200 2-color                       |
| IM_STD_VIDEO_MODE_5 | 300 x 200 monochrome                    |
| IM_STD_VIDEO_MODE_6 | 640 x 200 2-color (2050)                |

The *scroll\_mode* parameter requires IM\_SIZE\_MODE\_80X25 and is one of the following constants:

|                     |                                            |
|---------------------|--------------------------------------------|
| IM_LCD_SCROLL_AT_25 | Scroll at line 25                          |
| IM_LCD_SCROLL_AT_16 | Scroll at line 16 (2010 and 2020)          |
| IM_LCD_SCROLL_AT_13 | Scroll at line 13 (2050 and double height) |
| IM_LCD_SCROLL_AT_8  | Scroll at line 8 (2010 and 2020)           |

The *character\_height* parameter requires IM\_SIZE\_MODE\_80X25 and is one of the following constants:

|                         |                                                                                   |
|-------------------------|-----------------------------------------------------------------------------------|
| IM_STANDARD_CHAR_HEIGHT | Standard height characters, applies to all scroll modes except line 8 and line 13 |
| IM_DOUBLE_CHAR_HEIGHT   | Double height characters, applies only to scroll at line 8 and line 13            |

The *status\_code* is one of the standard status codes defined in Appendix A, “Status Codes.”

**Return Value:** None.

**See Also:** im\_set\_display\_mode

## *im\_get\_display\_mode*

---

### **Example**

With System, Text\_IO, Intrmeacd\_IO, Intrmecp\_IO;  
Use System, Text\_IO, Intrmeacd\_IO, Intrmecp\_IO;

procedure getdisdl Is

```
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    package IM_STD_SIZE_MODE_IO is new ENUMERATION_IO
        (enum => IM_STD_SIZE_MODE);
    package IM_STD_VIDEO_MODE_IO is new ENUMERATION_IO
        (enum => IM_STD_VIDEO_MODE);
    package IM_SCROLL_MODE_IO is new ENUMERATION_IO
        (enum => IM_SCROLL_MODE);
    package IM_CHARACTER_HEIGHT_IO is new ENUMERATION_IO
        (enum => IM_CHARACTER_HEIGHT);
    status : System.Word;
    size : IM_STD_SIZE_MODE;
    video : IM_STD_VIDEO_MODE;
    scroll : IM_SCROLL_MODE;
    char_ht : IM_CHARACTER_HEIGHT;

    begin
        Put_Line ("Getting disp mode");
        im_get_display_mode (size, video, scroll, char_ht, status);
        if im_iserror (status) then
            Put ("Get Disp Mode error = ");
            SYSWORD_IO.Put (status, WIDTH => 8);
            New_Line;
        end if;

        Put ("size : ");
        IM_STD_SIZE_MODE_IO.Put (size);
        New_Line;

        Put ("video : ");
        IM_STD_VIDEO_MODE_IO.Put (video);
        New_Line;

        Put ("scroll : ");
        IM_SCROLL_MODE_IO.Put (scroll);
        New_Line;

        Put ("char_ht : ");
        IM_CHARACTER_HEIGHT_IO.Put (char_ht);
        New_Line;
    end getdisdl;
```

---

## ***im\_get\_display\_type***

**Purpose:** This function retrieves the hardware display type, either standard JANUS reader or JANUS 2050 (VMU).

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
procedure im_get_display_type (  
    type          : OUT IM_STD_DISPLAY_TYPE;  
    status_code   : OUT System.Word);
```

**IN Parameters:** None.

**OUT Parameters:** The *type* parameter is one of the following constants:

|              |                        |
|--------------|------------------------|
| IM_LCD_20X16 | Standard JANUS display |
| IM_CRT_80X25 | JANUS VMU display      |

The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**See Also:** *im\_get\_display\_mode*, *im\_set\_display\_mode*

### ***im\_get\_display\_type***

---

#### **Example**

```
With System, Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;  
Use Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;
```

```
procedure DISTYPE is
```

```
    package SYSBYTE_IO is new INTEGER_IO(System.Byte);  
    package SYSWORD_IO is new INTEGER_IO(System.Word);  
    use SYSBYTE_IO, SYSWORD_IO;  
    display_type : IM_DISPLAY_TYPE;  
    status      : System.Word;
```

```
begin
```

```
    clrscr;  
    Put_Line("im_get_display_type example:");  
    New_line;  
    im_get_display_type(display_type, status);  
    if (display_type = IM_LCD_20X16) then  
        Put_Line("Display type is Standard JANUS display");  
    else  
        Put_Line("Display type is JANUS VMU display");  
    end if;  
    Put("Status : ");  
    Print_status_code(status);  
    New_line;  
end DISTYPE;
```

---

## ***im\_get\_follow\_cursor***

- Purpose:** When the display is in 80X25 mode, the viewport follows the cursor as it moves. The follow-the-cursor feature can be enabled or disabled. This function retrieves the current setting.
- Syntax:**
- ```
With Intrmechd_IO, Intrmecp_IO;
Use Intrmechd_IO, Intrmecp_IO;
procedure im_get_follow_cursor (
    follow_cursor_status : OUT IM_CONTROL;
    status_code           : OUT System.Word);
```
- IN Parameter:** None.
- OUT Parameter:** The *follow\_cursor\_status* parameter is one of the following constants:
- |            |                                    |
|------------|------------------------------------|
| IM_ENABLE  | Follow-the-cursor mode is enabled  |
| IM_DISABLE | Follow-the-cursor mode is disabled |
- The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."
- Return Value:** None.
- Notes:** This procedure has no effect on the JANUS 2050.
- See Also:** im\_set\_follow\_cursor, im\_cursor\_to\_viewport, im\_viewport\_to\_cursor

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure getfolcr Is
    follow_cursor_status : IM_CONTROL;
    status_code : System.Word;

begin
    Put_Line ("Getting foll curs mode");
    im_get_follow_cursor (follow_cursor_status, status_code);
    if follow_cursor_status = IM_ENABLE then
        Put_Line ("Follow Cursor ENABLED");
    else
        Put_Line ("Follow Cursor DISABLED");
    end if;
end getfolcr;
```

## *im\_get\_input\_mode*

---

### ***im\_get\_input\_mode***

**Purpose:** This function returns the current mode of the input manager. The different modes affect how the reader interprets and stores input.

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function im\_get\_input\_mode return IM\_MODE;

**Parameters:** None.

**Return Value:** The IM\_MODE return value is one of the following constants:

|               |                 |
|---------------|-----------------|
| IM_WEDGE      | Wedge mode      |
| IM_PROGRAMMER | Programmer mode |
| IM_DESKTOP    | Desktop mode    |

**Notes:** There are three different reader input modes: Wedge, Programmer, and Desktop. These different modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label input goes into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. Use Wedge mode when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions, such as TEXT\_IO.Get, to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader's power management capabilities. You will probably notice reduced battery life when the reader is in this mode compared to either Programmer or Desktop mode. For more information on power management, see Chapter 5, "Advanced Programming," in the *PSK Reference Manual*.

**Programmer Mode** Inputs are echoed to the screen. Reader commands are executed and saved. Use Programmer mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in Programmer mode.

**Desktop Mode** The application is responsible for retrieving and displaying input. Use Desktop mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes for the keyboard flags (Shift, Ctrl, Alt).

For more information about reader input modes, see Chapter 5, “Advanced Programming,” in the *PSK Reference Manual*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

**See Also:** im\_set\_input\_mode, im\_receive\_input

---

### Example

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure getinmod Is
    package IM_MODE_IO is new ENUMERATION_IO
        (enum => IM_MODE);
    mode : IM_MODE;
begin
    mode := im_get_input_mode;
    Put ("Mode is ");
    IM_MODE_IO.Put (mode);
    New_Line;
end getinmod;
```

## *im\_get\_keyclick*

---

### ***im\_get\_keyclick***

**Purpose:** Every time you press a key, the reader can emit a click. This procedure retrieves the current setting (enabled or disabled) of the keyclick.

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
procedure im_get_keyclick (  
    keyclick_status : OUT IM_CONTROL;  
    status_code      : OUT System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The *keyclick\_status* parameter is one of the following constants:

|            |                           |
|------------|---------------------------|
| IM_ENABLE  | Keyclick mode is enabled  |
| IM_DISABLE | Keyclick mode is disabled |

The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**See Also:** *im\_set\_keyclick*

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
  
procedure getkeycl Is  
    keyclick_status : IM_CONTROL;  
    status_code      : System.Word;  
  
begin  
    im_get_keyclick (keyclick_status, status_code);  
    if keyclick_status = IM_ENABLE then  
        Put_Line ("Keyclick ENABLED");  
    else  
        Put_Line ("Keyclick DISABLED");  
    end if;  
end getkeycl;
```

---

## ***im\_get\_label\_symbology***

**Purpose:** This function retrieves the symbology, such as Code 39, from the most recently scanned label. Call this function after receiving the data using `im_receive_input`.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;
Use Intrmeacd_IO, Intrmecp_IO;
procedure im_get_label_symbology (
    symbology      : OUT IM_DECTYPE;
    status_code    : OUT System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The symbology parameter is one of the following constants:

|                   |                        |
|-------------------|------------------------|
| IM_CODE_11        | Code 11 bar code       |
| IM_CODE_16K       | Code 16K bar code      |
| IM_CODE_39        | Code 39 bar code       |
| IM_CODE_49        | Code 49 bar code       |
| IM_CODE_93        | Code 93 bar code       |
| IM_CODE_128       | Code 128 bar code      |
| IM_CODABAR        | Codabar bar code       |
| IM_I_2_of_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PLESSEY        | Plessey bar code       |
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_UPC            | Universal Product Code |

The *status\_code* is one of the standard status codes defined in Appendix A, “Status Codes.”

**Return Value:** None.

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

**See Also:** `im_receive_input`

*im\_get\_label\_symbology*

---

***Example***

See example for `im_receive_input`.

---

## ***im\_get\_length***

**Purpose:** This function retrieves the length of the last input of the type selected. Use this function after calling the `im_receive_input` function to get the data. The length is saved when the call is initiated.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
function im_get_length (  
    origin : IN IM_ORIGIN  
) return System.Word;
```

**IN Parameter:** The *origin* parameter is one of these constants:

|                    |                                             |
|--------------------|---------------------------------------------|
| IM_LABEL_SELECT    | Label selected                              |
| IM_KEYBOARD_SELECT | Keypad selected                             |
| IM_COM1_SELECT     | COM1 selected                               |
| IM_COM2_SELECT     | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)                     |

**OUT Parameter:** None.

**Return Value:** This function retrieves the length of the last input read.

**Notes:** For this function, all COM input is considered to be from the same source. For example, if you call `im_receive_input` with `IM_COM1_SELECT` and again with `IM_COM4_SELECT`, then a call to `im_get_length` with a source of `IM_COM1_SELECT` returns the length of the message received from COM4 because that was the last message read from a communications port.

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

**See Also:** `im_receive_input`

---

### ***Example***

See example for `im_receive_input`.

## *im\_get\_postamble*

---

### ***im\_get\_postamble***

**Purpose:** This procedure retrieves the currently configured postamble string and its length.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_get_postamble (  
    post_string : OUT String;  
    post_length : OUT System.Word;  
    status_code : OUT System.Word);
```

**IN Parameters:** None.

**OUT Parameters:** The *post\_string* parameter is the postamble string.

The *length* parameter is the length of the postamble string.

The *status\_code* parameter is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** You can set the postamble with IC.EXE, with the *im\_command* function and \$+AE command, or by scanning a postamble. Refer to your JANUS user's manual for more information on configuring a postamble.

**See Also:** *im\_get\_postamble*, *im\_get\_config\_info*

---

**Example**

```
With System, Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;
Use Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;

procedure POSAMBLE is

    package SYSBYTE_IO is new INTEGER_IO(System.Byte);
    package SYSWORD_IO is new INTEGER_IO(System.Word);
    use SYSBYTE_IO, SYSWORD_IO;
    postamble_string : String(1..300) := (others => Ascii.NUL);
    postamble_length : System.Word;
    status : System.Word;

begin
    clrscr;
    Put_Line("im_get_postamble example:");
    New_line;
    im_get_postamble(postamble_string, postamble_length, status);

    Put("Postamble: ");
    for i in Integer range 1..300 loop
        exit when postamble_string(i) = Ascii.NUL;
        Put(postamble_string(i));
    end loop;
    New_line;
    Put("Length   : ");
    Put(postamble_length);
    New_line;
    Put("Status    : ");
    Print_status_code(status);
    New_line;
end POSAMBLE;
```

## *im\_get\_preamble*

---

### ***im\_get\_preamble***

**Purpose:** This procedure retrieves the currently configured preamble string and its length.

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
procedure im_get_postamble (  
    preamble_string : OUT String;  
    preamble_length : OUT System.Word;  
    status_code      : OUT System.Word);
```

**IN Parameters:** None.

**OUT Parameters:** The *preamble\_string* parameter is the preamble string.

The *length* parameter is the length of the preamble string.

The *status\_code* parameter is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** You can set the preamble with IC.EXE, with the *im\_command* function and \$+AE command, or by scanning a preamble. Refer to your JANUS user's manual for more information on configuring a preamble.

**See Also:** *im\_get\_postamble*, *im\_get\_config\_info*

---

**Example**

```
With System, Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;
Use Intrmechd_IO, Intrmecp_IO, Text_IO, RTEXT_IO, ITTOOLS;

procedure PREAMBLE is

    package SYSBYTE_IO is new INTEGER_IO(System.Byte);
    package SYSWORD_IO is new INTEGER_IO(System.Word);
    use SYSBYTE_IO, SYSWORD_IO;
    preamble_string : String(1..300) := (others => Ascii.NUL);
    preamble_length : System.Word;
    status : System.Word;

begin
    clrscr;
    Put_Line("im_get_preamble example:");
    New_line;
    im_get_preamble(preamble_string, preamble_length, status);

    Put("Preamble: ");
    for i in Integer range 1..300 loop
        exit when preamble_string(i) = Ascii.NUL;
        Put(preamble_string(i));
    end loop;
    New_line;
    Put("Length : ");
    Put(preamble_length);
    New_line;
    Put("Status : ");
    Print_status_code(status);
    New_line;
end PREAMBLE;
```

## *im\_get\_viewport\_lock*

---

### ***im\_get\_viewport\_lock***

**Purpose:** This function retrieves the current setting of the viewport lock. When the display is in 80X25 mode, you can use the viewport in virtual display mode unless the currently running application program restricts it. The application program may require the viewport to be locked or unlocked.

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
procedure im_get_viewport_lock (  
    viewport_lock_status : OUT IM_CONTROL;  
    status_code           : OUT System.Word);
```

**IN Parameter:** None.

**OUT Parameter:** The *viewport\_lock\_status* parameter is one of the following constants:

|            |                      |
|------------|----------------------|
| IM_ENABLE  | Viewport is locked   |
| IM_DISABLE | Viewport is unlocked |

The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** The display must be in 80X25 mode (see *im\_set\_display\_mode*) to use this function.

This function has no effect on the JANUS 2050.

When the viewport is "locked," the viewport movement keys do not move the viewport. The viewport can still move if follow-the-cursor mode is enabled.

**See Also:** *im\_set\_viewport\_lock*, *im\_set\_display\_mode*, *im\_get\_display\_mode*

---

**Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure getviewl is
    viewport_lock_status : IM_CONTROL;
    status_code : System.Word;
begin
    im_get_viewport_lock (viewport_lock_status, status_code);
    if viewport_lock_status = IM_ENABLE then
        Put_Line ("Viewport Lock ENABLED");
    else
        Put_Line ("Viewport Lock DISABLED");
    end if;
end getviewl;
```

*im\_get\_warm\_boot*

---

## ***im\_get\_warm\_boot***

**Purpose:** This function retrieves the current setting of the warm boot status. You can enable or disable the **Ctrl-Alt-Del** warm boot key sequence. When disabled, pressing the **Ctrl-Alt-Del** sequence does not reboot the reader.

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
procedure im\_get\_warm\_boot (  
    warmboot\_status : OUT IM\_CONTROL;  
    status\_code      : OUT System.Word);

**IN Parameter:** None.

**OUT Parameter:** The *warmboot\_status* parameter is one of the following constants:

|            |                           |
|------------|---------------------------|
| IM_ENABLE  | The warm boot is enabled  |
| IM_DISABLE | The warm boot is disabled |

The *status\_code* is one of the standard status codes defined in Appendix A, "Status Codes."

**Return Value:** None.

**See Also:** im\_set\_warm\_boot

---

### ***Example***

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
  
procedure get_warm Is  
    warmboot_status : IM_CONTROL;  
    status_code     : System.Word;  
  
begin  
    im_get_warm_boot (warmboot_status, status_code);  
  
    if warmboot_status = IM_ENABLE then  
        Put_Line ("Warmboot ENABLED");  
    else  
        Put_Line ("Warmboot DISABLED");  
    end if;  
end get_warm;
```

---

## ***im\_increase\_contrast***

- Purpose:** This function decreases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast (0 to 31), where 0 is very light, and 31 is very dark.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function im\_increase\_contrast return System.Word;
- Parameters:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”
- Notes:** The 0 to 31 scale fine-tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions im\_set\_contrast and im\_get\_contrast use a scale of 0 to 7 that is related to the scale of 0 to 31 used by im\_increase\_contrast and im\_decrease\_contrast. The following table shows the equivalent values for the 0 to 7 scale.

| Scale 0 to 7 | Scale 0 to 31 | Level      |
|--------------|---------------|------------|
| 0            | 10            | Very light |
| 1            | 12            |            |
| 2            | 14            |            |
| 3            | 16            |            |
| 4            | 18            |            |
| 5            | 20            |            |
| 6            | 22            | Very dark  |
| 7            | 24            |            |

This function has no effect on the JANUS 2050.

- See Also:** im\_get\_contrast, im\_decrease\_contrast, im\_set\_contrast

### ***im\_increase\_contrast***

---

#### **Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure incrcont Is
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
begin
    Put_Line ("Increasing contrast");
    status := im_increase_contrast;

    if im_iserror (status) then
        Put ("Inc contrast error = ");
        SYSWORD_IO.Put (status, WIDTH => 8);
        New_Line;
    end if;
end incrcont;
```

---

## ***im\_input\_status***

**Purpose:** This function checks to see if any input buffers have data and returns the buffer identification.

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function *im\_input\_status* return IM\_ORIGIN;

**Parameters:** None.

**Return Value:** IM\_ORIGIN is one of the following constants:

|                    |                               |
|--------------------|-------------------------------|
| IM_NO_SELECT       | No selection made             |
| IM_LABEL_SELECT    | Label selected                |
| IM_KEYBOARD_SELECT | Keyboard selected             |
| IM_COM1_SELECT     | COM1 selected                 |
| IM_COM2_SELECT     | COM2, scanner (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)       |

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

## *im\_input\_status*

---

### **Example**

```
With System, Intrmeacd_IO, Intrmecp_IO, Text_IO;
Use Intrmeacd_IO, Intrmecp_IO, Text_IO;

procedure exinput is
    label          : String(1..256) := (others => Ascii.NUL);
    input_status    : IM_ORIGIN := IM_NO_SELECT;
    receive_status   : System.Word;
    returned_origin  : IM_ORIGIN;

begin
    New_Line(2);
    Put_Line("      Janus 2010 ");
    Put_Line("      Input Status");
    Put_Line("Input from keyboard");
    Put_Line("or read label");
    New_Line;
    im_set_input_mode(IM_DESKTOP);

    -- Loop while waiting for im_input_status
    while input_status = IM_NO_SELECT loop
        input_status := im_input_status;
    end loop;

    Put("Input from ");
    if input_status = IM_KEYBOARD_SELECT then
        Put("Keyboard");
    else
        Put("Label");
    end if;
    New_Line;

    -- Read input
    im_receive_input(input_status, IM_ZERO_TIMEOUT, returned_origin,
        label, receive_status);

    if im_isgood(receive_status) then
        Put(label);
        New_Line;
    else
        Put("Rec status: ");
        im_message(receive_status);
        New_Line;
    end if;

    im_set_input_mode(IM_WEDGE);
end exinput;
```

---

## ***im\_irl\_a***

**Purpose:** This procedure retrieves input from bar code labels or the keypad in the same manner as IRL ASCII input command A. This procedure returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command A, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;
Use Intrmeacd_IO, Intrmecp_IO;
procedure im_irl_a (
    timeout      : In System.Word;
    test_table   : In IM_LENGTH_SPEC_ARRAY_PTR;
    mask_string  : In String;
    irl_string   : Out String;
    cmd_count    : Out System.Word;
    symbology    : Out IM_DECTYPE;
    status_code  : Out System.Word);
```

**IN Parameter:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *test\_table*. The *test\_table* parameter must be a matrix in this form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

*im\_irl\_a*

The *a* position in the matrix is one of the following:

|              |                                    |
|--------------|------------------------------------|
| IM_NO_LENGTH | Accept data of any length          |
| IM_LENGTH    | Accept data with a specific length |
| IM_RANGE     | Accept data within a length range  |

If IM\_LENGTH is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If IM\_RANGE is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {IM\_NO\_LENGTH,0,0,0}.

The *mask\_string* parameter sets up a data mask that received data must match. *mask\_string* can accept a string of constants or wildcard characters. For example, use the string ### - ##### to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

|                 |                        |
|-----------------|------------------------|
| #               | Numeric                |
| @               | Alpha                  |
| ?               | Alphanumeric printable |
| NULL (CHR\$(0)) | No mask                |

**OUT Parameter:** You must allocate at least 256 bytes to the *irl\_string* parameter.

The *cmd\_count* returned will be 0 unless an abort command is passed to the string. Refer to Chapter 5, “Advanced Programming,” in the *PSK Reference Manual* for more information.

The *symbology* parameter is one of the following constants:

|             |                   |
|-------------|-------------------|
| IM_CODE_11  | Code 11 bar code  |
| IM_CODE_16K | Code 16K bar code |
| IM_CODE_39  | Code 39 bar code  |
| IM_CODE_49  | Code 49 bar code  |
| IM_CODE_93  | Code 93 bar code  |
| IM_CODE_128 | Code 128 bar code |
| IM_CODABAR  | Codabar bar code  |

|                   |                        |
|-------------------|------------------------|
| IM_I_2_of_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PLESSEY        | Plessey bar code       |
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_UPC            | Universal Product Code |

The *status\_code* parameter is one of the standard status codes listed in Appendix A, “Status Codes.”

**Return Value:** None.

**Notes:** You must set the reader to Programmer mode with the `im_set_input_mode` function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

Data does not display correctly on the screen if the display is in the 80X25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `im_set_display_mode`.

**See Also:** `im_irl_k`, `im_irl_n`, `im_irl_v`, `im_irl_y`, `im_set_input_mode`, `im_set_display_mode`

---

### Example

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure ex_irl_a is
  cmd_count      : System.Word;
  display_status : System.Word;
  irl_string      : String(1..256) := (others => Ascii.NUL);
  length_table   : IM_LENGTH_SPEC_ARRAY;
  mask           : String(1..80) := (others => Ascii.NUL);
  status         : System.Word;
  symbol         : IM_DECTYPE;
  timeout        : System.Word := 25000;      -- 25 second timeout

  package SYMBOL_IO is new ENUMERATION_IO(enum=>IM_DECTYPE);

begin
  length_table := IM_LENGTH_SPEC_ARRAY'(
    (IM_LENGTH, 0, 0, 2),
    (IM_RANGE, 9, 14, 0),
    (IM_LENGTH, 2, 2, 4),
```

### ***im\_irl\_a***

```
(IM_RANGE, 16, 17, 2),
(IM_NO_LENGTH, 2, 2, 2));

-- Set display mode to something other than 80X25
display_status := im_set_display_mode(IM_SIZE_MODE_20X16,
IM_STD_VIDEO_MODE_0, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);

Put_Line(" Example im_irl_a");
New_Line;
Put_Line("Enter 8 AlphaNums");
Put_Line("  from keyboard");
Put_Line("  or read label");
Put_Line("q to quit");

-- Set Reader Wedge mode to program interface
im_set_input_mode(IM_PROGRAMMER);
mask(1..8) := "???????";

loop
  -- Read input using im_irl_a
  im_irl_a (timeout, length_table, mask, irl_string,
            cmd_count, symbol, status);
  exit when irl_string(1) = 'q';

  if im_isgood(status) then
    New_Line;
    Put("Data read: ");
    Put(irl_string(1..8));
    New_Line;

    Put_Line("The symbology read:");
    SYMBOL_IO.Put(symbol);
    New_Line;

  else
    im_message(status);
    New_Line;
  end if;
end loop;

-- Set Reader Wedge mode back to Virtual Wedge mode
im_set_input_mode(IM_WEDGE);

-- Set display mode back to 80X25
display_status := im_set_display_mode(IM_SIZE_MODE_80X25,
IM_STD_VIDEO_MODE_3, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);

end ex_irl_a;
```

---

## ***im\_irl\_k***

**Purpose:** This procedure receives input from the keypad in any format in the same manner as IRL ASCII input command K. This procedure returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command K, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;
Use Intrmeacd_IO, Intrmecp_IO;
procedure im_irl_k (
    timeout      : In System.Word;
    test_table   : In IM_LENGTH_SPEC_ARRAY_PTR;
    mask_string  : In String;
    irl_string   : Out String;
    cmd_count    : Out System.Word;
    status_code  : Out System.Word);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

```
IM_ZERO_TIMEOUT      No wait
IM_INFINITE_TIMEOUT  Wait forever
```

If *IM\_INFINITE\_TIMEOUT* is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *test\_table*. The *test\_table* parameter must be a matrix in this form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

*im\_irl\_k*

The *a* position in the matrix is one of the following:

|              |                                   |
|--------------|-----------------------------------|
| IM_NO_LENGTH | Accept data of any length         |
| IM_LENGTH    | Accept data of a specific length  |
| IM_RANGE     | Accept data within a length range |

If IM\_LENGTH is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If IM\_RANGE is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {IM\_NO\_LENGTH,0,0,0}.

The *mask\_string* parameter sets up a data mask that received data must match. *mask\_string* can accept a string of constants or wildcard characters. For example, use the string ### - ##### to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

|                 |                        |
|-----------------|------------------------|
| #               | Numeric                |
| @               | Alpha                  |
| ?               | Alphanumeric printable |
| NULL (CHR\$(0)) | No mask                |

**OUT Parameters:** You must allocate at least 256 bytes to the *irl\_string* parameter.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *status\_code* parameter is a standard status codes listed in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** You must set the reader to Programmer mode with the `im_set_input_mode` function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

Data does not display correctly on the screen if the display is in the 80X25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `im_set_display_mode`.

**See Also:** `im_irl_a`, `im_irl_n`, `im_irl_v`, `im_irl_y`, `im_set_display_mode`, `im_set_input_mode`

---

### Example

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure ex_irl_k is

  cmd_count      : System.Word;
  display_status : System.Word;
  irl_string      : String(1..256);
  length_table   : IM_LENGTH_SPEC_ARRAY;
  mask           : String(1..80) := (others => Ascii.NUL);
  status         : System.Word;
  timeout        : System.Word := 30000;      -- 30 second timeout

begin
  length_table := IM_LENGTH_SPEC_ARRAY'(
    (IM_LENGTH, 0, 0, 0),
    (IM_LENGTH, 0, 0, 0),
    (IM_LENGTH, 0, 0, 0),
    (IM_LENGTH, 0, 0, 0),
    (IM_LENGTH, 0, 0, 0));

  -- Set display mode to something other than 80X25
  display_status := im_set_display_mode(IM_SIZE_MODE_20X16,
    IM_STD_VIDEO_MODE_0, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);

  Put_Line(" Example im_irl_k");
  New_Line;
  Put_Line("Enter 8 AlphaNums");
  Put_Line(" from keyboard");
  Put_Line("q to quit");

  -- Set Reader Wedge mode to program interface
  im_set_input_mode(IM_PROGRAMMER);
  mask(1..8) := "????????";
  loop
    -- Clear input string
    irl_string := (others => Ascii.NUL);
```

### *im\_irl\_k*

```
-- Read input from keyboard
im_irl_k (timeout, length_table, mask, irl_string, cmd_count, status);

exit when irl_string(1) = 'q';

if im_isgood(status) then
    New_Line;
    Put("Data:");
    Put(irl_string(1..8));
    Put("::");
    New_Line;
else
    im_message(status);
    New_Line;
end if;
end loop;

-- Set Reader Wedge mode back to Virtual Wedge mode
im_set_input_mode(IM_WEDGE);

-- Set display mode back to 80X25
display_status := im_set_display_mode(IM_SIZE_MODE_80X25,
    IM_STD_VIDEO_MODE_3, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);
end ex_irl_k;
```

---

## ***im\_irl\_n***

**Purpose:** This procedure receives numeric input from the keypad or a label in the same manner as IRL numeric input command N. Nonnumeric data is ignored.

This procedure clears any data existing in the keypad or label buffers before the function was called, edits reader commands from input, and displays input data. For more information on IRL and command N, refer to the *IRL Programming Reference Manual*.

This procedure corresponds to IRL command N. Refer to the *IRL Programming Reference Manual* for more information on IRL commands.

**Syntax:**

```
With Intrmecd_IO, Intrmecp_IO;
Use Intrmecd_IO, Intrmecp_IO;
procedure im_irl_n (
    timeout      : In System.Word;
    test_table   : In IM_LENGTH_SPEC_ARRAY_PTR;
    irl_string    : Out String;
    cmd_count    : Out System.Word;
    symbology    : Out IM_DECTYPE;
    status_code  : Out System.Word);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

*im\_irl\_n*

Data is returned only if its length matches one of the five lengths specified in the *test\_table*. The *test\_table* parameter must be a matrix in this form:

```
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},
```

The *a* position in the matrix is one of the following:

|              |                                   |
|--------------|-----------------------------------|
| IM_NO_LENGTH | Accept data of any length         |
| IM_LENGTH    | Accept data of a specific length  |
| IM_RANGE     | Accept data within a length range |

If IM\_LENGTH is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If IM\_RANGE is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {IM\_NO\_LENGTH,0,0,0}.

**OUT Parameters:** You must allocate at least 256 bytes to the *irl\_string* parameter.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *symbology* parameter is one of the following constants:

|                   |                   |
|-------------------|-------------------|
| IM_UNKNOWN_DECODE | Unknown bar code  |
| IM_CODABAR        | Codebar bar code  |
| IM_CODE_11        | Code 11 bar code  |
| IM_CODE_16K       | Code 16K bar code |
| IM_CODE_39        | Code 39 bar code  |
| IM_CODE_49        | Code 93 bar code  |
| IM_CODE_93        | Code 49 bar code  |
| IM_CODE_128       | Code 128 bar code |

|             |                        |
|-------------|------------------------|
| IM_I_2_OF_5 | Interleaved 2 of 5     |
| IM_MSI      | MSI bar code           |
| IM_PLESSEY  | Plessey bar code       |
| IM_UPC      | Universal Product code |

The *status\_code* parameter is a standard status codes listed in Appendix A, “Status Codes.”

**Return Value:** None.

**Notes:** You must set the reader to Programmer mode with the *im\_set\_input\_mode* function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

Data does not display correctly on the screen if the display is in the 80X25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using *im\_set\_display\_mode*.

**See Also:** *im\_irl\_a*, *im\_irl\_k*, *im\_irl\_v*, *im\_irl\_y*, *im\_set\_input\_mode*, *im\_set\_display\_mode*

---

### Example

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure ex_irl_n is
  cmd_count      : System.Word;
  display_status : System.Word;
  irl_string     : String(1..256);
  length_table   : IM_LENGTH_SPEC_ARRAY;
  status        : System.Word;
  symbol        : IM_DECTYPE;

  package SYMBOL_IO is new ENUMERATION_IO(enum=>IM_DECTYPE);

begin
  length_table := IM_LENGTH_SPEC_ARRAY'(
    (IM_LENGTH, 0, 0, 2),
    (IM_RANGE, 9, 14, 0),
    (IM_LENGTH, 0, 0, 4),
    (IM_RANGE, 16, 17, 2),
    (IM_LENGTH, 0, 0, 6));
```

### *im\_irl\_n*

```
-- Set display mode to something other than 80X25
display_status := im_set_display_mode(IM_SIZE_MODE_20X16,
    IM_STD_VIDEO_MODE_0, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);

Put_Line(" Example im_irl_n");
New_Line;
Put_Line("Enter Numeric data");
Put_Line("  from keyboard");
Put_Line("  or read label");
Put_Line("99 to quit");

-- Set Reader Wedge mode to program interface
im_set_input_mode(IM_PROGRAMMER);

loop

    -- Clear input string
    irl_string := (others => Ascii.NUL);

    -- Read numeric input from keyboard or label
    im_irl_n (IM_INFINITE_TIMEOUT, length_table, irl_string,
        cmd_count, symbol, status);
    exit when irl_string(1..2) = "99";

    if im_isgood(status) then
        New_Line;
        Put_Line("Data read: ");

        -- Print only printable charaters
        for i in Integer range 1..256 loop
            exit when irl_string(i) = Ascii.NUL;
            if irl_string(i) in '0'..'9' then
                Put(irl_string(i));
            else
                Put('?');
            end if;
        end loop;

        New_Line;
        Put_Line("The symbology read:");
        SYMBOL_IO.Put(symbol);
        New_Line;
    else
        im_message(status);
        New_Line;
    end if;
end loop;

-- Set Reader Wedge mode back to Virtual Wedge mode
im_set_input_mode(IM_WEDGE);

-- Set display mode back to 80X25
display_status := im_set_display_mode(IM_SIZE_MODE_80X25,
    IM_STD_VIDEO_MODE_3, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);
end ex_irl_n;
```

---

## ***im\_irl\_v***

**Purpose:** This procedure receives input from any specified source in any format, in the same manner as an IRL universal input command V. For more information on IRL and command V, refer to the *IRL Programming Reference Manual*.

This procedure corresponds to IRL command V. Refer to the *IRL Programming Reference Manual* for more information on IRL commands.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;
Use Intrmeacd_IO, Intrmecp_IO;
procedure im_irl_v (
    timeout      : In System.Word;
    edit         : In IM_CONTROL;
    beep         : In IM_LABEL_BEEP_CONTROL;
    display      : In IM_CONTROL;
    source       : In Out IM_ORIGIN;
    irl_string    : Out String;
    cmd_count    : Out System.Word;
    symbology    : Out IM_DECTYPE;
    status_code  : Out System.Word);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

```
IM_ZERO_TIMEOUT      No wait
IM_INFINITE_TIMEOUT  Wait forever
```

If *IM\_INFINITE\_TIMEOUT* is selected, the function will not return until the end of message character has been received.

If *IM\_INFINITE\_TIMEOUT* is selected, the function does not return until data is received.

## *im\_irl\_v*

The *edit* parameter determines whether the Reader Wedge parses reader commands. Use one of the following constants:

|            |                                |
|------------|--------------------------------|
| IM_DISABLE | Disable reader command parsing |
| IM_ENABLE  | Enable reader command parsing  |

If *edit* is IM\_DISABLED, reader commands are treated as data.

The *beep* parameter determines whether the IRL V command beeps or not when data is entered.

If *beep* is set to IM\_APPLI\_BEEP, the Reader Wedge does not control the beep. Instead, you code the application to sound a beep when your program design requires one.

If *beep* is set to IM\_WEDGE\_BEEP, the reader always beeps when data is entered. The *beep* parameter is one of the following constants:

|               |                               |
|---------------|-------------------------------|
| IM_APPLI_BEEP | Application controls the beep |
| IM_WEDGE_BEEP | Beeps occur automatically     |

The *display* parameter determines if the data is displayed as it is entered. The *display* parameter is one of the following constants:

|            |                         |
|------------|-------------------------|
| IM_DISABLE | Disable display of data |
| IM_ENABLE  | Enable display of data  |

## **IN/OUT Parameters:**

The *source* parameter determines which input sources are allowed. When the IRL V command returns, *source* indicates where the data came from. When both keyboard and label inputs are allowed, the *source* always returns keyboard because it is possible for keyed and scanned data to be intermixed. Although intermixing is possible, it is not likely to occur.

If you have both the keyboard and scanner enabled, and you want to know where the data came from, first check the symbology:

- If the symbology is IM\_UNKNOWN\_DECODE, then the data came from the keyboard.
- If the symbology is one of the other values (such as IM\_CODE\_39), then some or all of the data came from the scanner.
- If only the scanner is enabled, then all of the data came from the scanner.

The *source* parameter is one of the following constants:

|                    |                               |
|--------------------|-------------------------------|
| IM_NO_SELECT       | No designated source          |
| IM_LABEL_SELECT    | Label                         |
| IM_KEYBOARD_SELECT | Keyboard                      |
| IM_COM1_SELECT     | COM1                          |
| IM_COM2_SELECT     | COM2, scanner (2010 and 2050) |
| IM_COM4_SELECT     | COM4 (RF only)                |
| IM_ALL_SELECT      | All sources are designated    |

**OUT Parameters:** The *irl\_string* parameter is the returned string containing the IRL commands and must have at least 256 bytes allocated.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *symbology* parameter is one of the following constants:

|                   |                        |
|-------------------|------------------------|
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_CODABAR        | Codebar bar code       |
| IM_CODE_11        | Code 11 bar code       |
| IM_CODE_16K       | Code 16K bar code      |
| IM_CODE_39        | Code 39 bar code       |
| IM_CODE_49        | Code 93 bar code       |
| IM_CODE_93        | Code 49 bar code       |
| IM_CODE_128       | Code 128 bar code      |
| IM_I_2_OF_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PLESSEY        | Plessey bar code       |
| IM_UPC            | Universal Product code |

## *im\_irl\_v*

**OUT Parameters**    The *status\_code* parameter is a standard status code listed in Appendix A, “Status Codes.”

**Return Value:**     None.

**Notes:**            You must set the reader to Programmer mode with the *im\_set\_input\_mode* function.

To receive data from a communications port, you must install a protocol handler.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

Data is automatically cleared from both the scanner and the keypad buffers but not from any communications port buffer.

Use the *im\_link\_comm* function to establish a link between the Reader Wedge function and a communications port, and use the *im\_unlink\_comm* function to remove the link.

Data does not display correctly on the screen if the display is in the 80X25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using *im\_set\_display\_mode*.

**See Also:**            *im\_irl\_a*, *im\_irl\_k*, *im\_irl\_n*, *im\_irl\_y*, *im\_set\_input\_mode*

---

### **Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure ex_irl_v is
  cmd_count      : System.Word;
  display_status : System.Word;
  irl_string      : String(1..256);
  status         : System.Word;
  source         : IM_ORIGIN;
  symbol         : IM_DECTYPE;
  package SYMBOL_IO is new ENUMERATION_IO(enum=>IM_DECTYPE);

begin
  -- Set display mode to something other than 80X25
  display_status := im_set_display_mode(IM_SIZE_MODE_20X16,
```

```

    IM_STD_VIDEO_MODE_0, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);
Put_Line(" Example im_irl_v");
New_Line;
Put_Line("Enter AlphaNums");
Put_Line(" from keyboard");
Put_Line(" or read label");
Put_Line("q to quit");

-- Set Reader Wedge mode to program interface
im_set_input_mode(IM_PROGRAMMER);

loop
-- Clear input string
irl_string := (others => Ascii.NUL);

-- Set input source
source := IM_KEYBOARD_SELECT + IM_LABEL_SELECT;

-- Read input using im_irl_v
im_irl_v (IM_INFINITE_TIMEOUT, IM_ENABLE, IM_WEDGE_BEEP, IM_DISABLE,
          source, irl_string, cmd_count, symbol, status);
exit when irl_string(1) = 'q';

if im_isgood(status) then
New_Line;
Put("Source: ");
if source = IM_LABEL_SELECT then
Put("Label");
elsif source = IM_KEYBOARD_SELECT then
Put("Keyboard");
end if;
New_Line;
Put("Data read:");

-- Display printable characters
for i in Integer range 1..256 loop
exit when irl_string(i) = Ascii.NUL;

if irl_string(i) in ' '..~' then
Put(irl_string(i));
else
Put('?');
end if;
end loop;
Put("::");
New_Line;

Put_Line("The symbology read:");
SYMBOL_IO.Put(symbol);
New_Line;

else
im_message(status);
New_Line;
end if;
end loop;

-- Reset display mode and Reader Wedge mode
im_set_input_mode(IM_WEDGE);
display_status := im_set_display_mode(IM_SIZE_MODE_80X25,
IM_STD_VIDEO_MODE_3, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);
end ex_irl_v;

```

*im\_irl\_y*

---

## ***im\_irl\_y***

**Purpose:** This procedure receives input from the designated communications port the same as IRL ASCII input command Y. This procedure receives a single block, not an entire file, and always clears input from the host and edits reader commands from input. Unlike the other IRL instructions, the data is not automatically displayed. For more information on IRL and command Y, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_irl_y (  
    timeout      : In System.Word;  
    port         : In IM_COM_PORT;  
    term_char    : In Character;  
    prot_mode    : In IM_PROTOCOL_CMD;  
    irl_string   : Out String;  
    cmd_count    : Out System.Word;  
    status_code  : Out System.Word);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *term\_char* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

The *prot\_mode* parameter is one of the following constants:

|                  |                                   |
|------------------|-----------------------------------|
| IM_NO_CHANGE     | Keep the current protocol         |
| IM_PROTOCOL_OFF  | Turn the protocol off             |
| IM_PROTOCOL_ON   | Turn the protocol on              |
| IM_NEW_TERM_CHAR | Use the new termination character |

The *break\_status* parameter affects how incoming messages are received:

- If IM\_NO\_CHANGE is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If IM\_PROTOCOL\_OFF is specified, the incoming data is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.
- If IM\_PROTOCOL\_ON is specified, the incoming message is terminated with the end of message character of the active protocol.
- If IM\_NEW\_TERM\_CHAR is specified, IM\_PROTOCOL\_OFF is assumed and the new end of message character specified in the parameter list is used.

**OUT Parameters:** You must allocate at least 256 bytes to the *irl\_string* parameter.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *status\_code* parameter is a standard status codes listed in Appendix A, “Status Codes.”

**Return Value:** None.

**Notes:** The receive buffers are cleared whenever the protocol is turned on or off. To change the termination character (or to not change the setting at all), use IM\_NEW\_TERM\_CHAR or IM\_NO\_CHANGE instead of toggling the protocol.

## *im\_irl\_y*

Data does not display correctly on the screen if the display is in the 80X25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `im_set_display_mode`.

To use this function, set the reader to Programmer mode using `im_set_input_mode`.

You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

**See Also:** `im_irl_a`, `im_irl_k`, `im_irl_n`, `im_irl_v`, `im_set_display_mode`,  
`im_set_input_mode`

---

### **Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use  System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure ex_irl_y is
  comm_buff      : Im_Buffer;
  buff_size      : System.Word := 300;
  buff_ptr       : System.Address := comm_buff(comm_buff'First)'Address;
  cmd_count      : System.Word;
  display_status : System.Word;
  irl_string     : String(1..256);
  link_status    : System.Word;
  status         : System.Word;

begin
  -- Set display mode to something other than 80X25
  display_status := im_set_display_mode(IM_SIZE_MODE_20X16,
    IM_STD_VIDEO_MODE_0, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);

  Put_Line(" Example im_irl_y");
  New_Line;
  Put_Line("Waiting for input");
  Put_Line("  from COM1");
  Put_Line("q to quit");

  -- Link to protocol handler. A protocol handler MUST be installed.
  link_status := im_link_comm(IM_COM1, buff_ptr, buff_size);
  if im_isgood(link_status) then

    -- Set Reader Wedge mode to program interface
    im_set_input_mode(IM_PROGRAMMER);
```

```

loop
  -- Clear input string
  irl_string := (others => Ascii.NUL);
  -- Read COM1 with protocol ON
  im_irl_y (IM_INFINITE_TIMEOUT, IM_COM1, Ascii.CR, IM_PROTOCOL_ON,
            irl_string, cmd_count, status);
  exit when irl_string(1) = 'q';

  if im_isgood(status) then
    Put_Line("Protocol ON");

    -- Display printable characters
    for i in Integer range 1..256 loop
      exit when irl_string(i) = Ascii.NUL;

      if irl_string(i) in '..~' then
        Put(irl_string(i));
      else
        Put('?');
      end if;
    end loop;
    New_Line;
  else
    im_message(status);
    New_Line;
  end if;

  -- Clear input string
  irl_string := (others => Ascii.NUL);

  -- Read COM1 with protocol OFF
  im_irl_y (IM_INFINITE_TIMEOUT, IM_COM1, Ascii.CR,
            IM_PROTOCOL_OFF, irl_string, cmd_count, status);

  exit when irl_string(1) = 'q';
  if im_isgood(status) then
    Put_Line("Protocol OFF");

    -- Display printable characters
    for i in Integer range 1..256 loop
      exit when irl_string(i) = Ascii.NUL;

      if irl_string(i) in '..~' then
        Put(irl_string(i));
      else
        Put('?');
      end if;
    end loop;
    New_Line;
  else
    im_message(status);
    New_Line;
  end if;

  -- Clear input string
  irl_string := (others => Ascii.NUL);

  -- Read COM1 with no change in protocol
  im_irl_y (IM_INFINITE_TIMEOUT, IM_COM1, Ascii.CR,
            IM_NO_CHANGE, irl_string, cmd_count, status);
  exit when irl_string(1) = 'q';

```

*im\_irl\_y*

```
if im_isgood(status) then
  Put_Line("Protocol No change");
  -- Display printable characters
  for i in Integer range 1..256 loop
    exit when irl_string(i) = Ascii.NUL;
    if irl_string(i) in '..~' then
      Put(irl_string(i));
    else
      Put('?');
    end if;
  end loop;
  New_Line;
else
  im_message(status);
  New_Line;
end if;
end loop;
end if;

-- Unlink to protocol handler.
link_status := im_unlink_comm(IM_COM1);

-- Set Reader Wedge mode back to Virtual Wedge mode
im_set_input_mode(IM_WEDGE);

-- Set display mode back to 80X25
display_status := im_set_display_mode(IM_SIZE_MODE_80X25,
  IM_STD_VIDEO_MODE_3, IM_LCD_SCROLL_AT_16, IM_STANDARD_CHAR_HEIGHT);
end ex_irl_y;
```

---

## ***im\_iserror***

- Purpose:** This macro determines if the return status code from another PSK function is an error (either fatal or nonfatal).
- Syntax:**

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
function im_iserror(  
    status :System.Word  
) return Boolean;
```
- IN Parameters:** The *status* parameter is any PSK function that returns a status code.
- OUT Parameters:** None.
- Return Value:** 0 Indicates success or warning  
nonzero Indicates an error (either fatal or nonfatal)
- See Also:** “Status Code Macros” in Chapter 2, “Working With Ada,”  
im\_isgood, im\_issuccess, im\_iswarn

---

### ***Example***

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
  
procedure ex_iserror is  
    status : System.Word;  
  
begin  
    status := im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME);  
    if im_iserror(status) then  
        Put_Line('Beep Error!');  
    else  
        Put_Line('Beep success or warning');  
    end if;  
    New_Line;  
end ex_iserror;
```

*im\_isgood*

## ***im\_isgood***

**Purpose:** This macro determines if the return status code from another PSK function is a success.

**Syntax:**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
function im_isgood(  
    status :System.Word  
) return Boolean;
```

**IN Parameters:** The *status* parameter is any PSK function that returns a status code.

**OUT Parameters:** None.

**Return Value:**

|         |                                                            |
|---------|------------------------------------------------------------|
| 0       | Indicates a warning or an error (either fatal or nonfatal) |
| nonzero | Indicates success                                          |

**See Also:** “Status Code Macros” in Chapter 2, “Working With Ada,”  
*im\_iserror*, *im\_issuccess*, *im\_iswarn*

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
  
procedure ex_isgood is  
    status : System.Word;  
  
begin  
    status := im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME);  
    if im_isgood(status) then  
        Put_Line('Beep successful!');  
    else  
        Put_Line('Beep error or warning!');  
    end if;  
    New_Line;  
end ex_isgood;
```

---

## ***im\_issuccess***

- Purpose:** This macro determines if the return status code from another PSK function is either a success or warning.
- Syntax:**
- ```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
function im_issuccess(  
    status : System.Word  
) return Boolean;
```
- IN Parameters:** The *status* parameter is any PSK function that returns a status code.
- OUT Parameters:** None.
- Return Value:**
- |         |                                               |
|---------|-----------------------------------------------|
| 0       | Indicates an error (either fatal or nonfatal) |
| nonzero | Indicates success or warning                  |
- See Also:** “Status Code Macros” in Chapter 2, “Working With Ada,”  
im\_iserror, im\_isgood, im\_iswarn

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
  
procedure ex_issuccess is  
    status : System.Word;  
  
begin  
    status := im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME);  
    if im_issuccess(status) then  
        Put_Line('Beep success or warning!');  
    else  
        Put_Line('Beep error!');  
    end if;  
    New_Line;  
end ex_issuccess;
```

*im\_iswarn*

---

## ***im\_iswarn***

**Purpose:** This macro determines if the return status code from another PSK function is a warning.

**Syntax:** With System, Text\_IO, Intrmeacd\_IO, Intrmecp\_IO;  
Use System, Text\_IO, Intrmeacd\_IO, Intrmecp\_IO;  
function *im\_iswarn*(  
    *status* :System.Word  
) return Boolean;

**IN Parameters:** The *status* parameter is any PSK function that returns a status code.

**OUT Parameters:** None.

**Return Value:** 0            Indicates success or an error (either fatal or nonfatal)  
nonzero       Indicates a warning

**See Also:** “Status Code Macros” in Chapter 2, “Working With Ada,”  
*im\_iserror*, *im\_isgood*, *im\_issuccess*

---

### ***Example***

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;


procedure ex_iswarn is
    status : System.Word;
begin
    status := im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME);
    if im_iswarn(status) then
        Put_Line('Beep warning!');
    else
        Put_Line('Beep success or error!');
    end if;
    New_Line;
end ex_iswarn;
```

im\_link\_comm

**Purpose:** This function establishes a link between the Reader Wedge function and a designated communications port. The following figure lists the different modes and the functions to use when linked or unlinked.

**Note:** Programmer mode and Desktop mode differ in how they handle keyboard inputs. In Programmer mode, the **Enter** key terminates keyboard input. In Desktop mode, keyboard entry terminates when you press each key.

Linking Specific Modes and Functions



AIT-27

## *im\_link\_comm*

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
function im_link_comm (  
    port      : In IM_COM_PORT,  
    buffer_ptr : In System.Address;  
    buffer_size : In System.Word;  
) return System.Word;
```

**IN Parameter:** The *port* parameter is one of the following constants:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *buffer\_ptr* parameter is a pointer to a memory area used by the Reader Wedge. Your application should not use this buffer.

The *buffer\_size* parameter is the actual number of bytes allocated in the buffer parameter (suggested size is 300 bytes).

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

Use this function if you want to receive data with *im\_irl\_y* or to use the communications port with *im\_receive\_input* and *im\_irl\_v*.

Your program only needs to call this function once, and you must unlink at the end of your application using *im\_unlink\_comm*.

**See Also:** *im\_unlink\_comm*, *im\_receive\_input*, *im\_irl\_v*, *im\_irl\_y*, *im\_serial\_protocol\_control*

---

### **Example**

See example for *im\_irl\_y*.

---

## ***im\_message***

**Purpose:** This procedure displays the error message associated with a specific status code returned by an Intermec function or procedure.

Use this procedure to display additional information about status codes during application development.

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
procedure im\_message (*status\_code* : IN System.Word);

**IN Parameter:** The *status\_code* parameter is one of the standard status codes listed in Appendix A, "Status Codes."

**OUT Parameter:** None.

**Return Value:** None.

**Notes:** The status message is displayed at the current cursor location without any formatting.

---

### ***Example***

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;  
  
procedure message Is  
    status : System.Word;  
  
begin  
    status := im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME);  
    if im_isgood(status) then  
        Put_Line('Beep successful!');  
    else  
        Put('Beep error: ');  
        im_message(status);  
        New_Line;  
    end if;  
    New_Line;  
end message;
```

*im\_number\_pad\_off*

---

## ***im\_number\_pad\_off***

- Purpose:** This function disables the number pad feature. When disabled, the numeric keys function the same as the **1** through **+** keys above the “QWERTY” keys on a normal PC keyboard.
- When the number pad is disabled, you cannot type characters from the extended ASCII character set or use the number pad to move the cursor. For more information, refer to your JANUS user’s guide.
- Syntax:** `With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
function im_number_pad_off return System.Word;`
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”
- See Also:** `im_number_pad_on`

---

**Example**

```
With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure numpadof Is

  package SYSWORD_IO is new INTEGER_IO (System.Word);
  status : System.Word;
  in_char : Character := ' ';

  begin
    status := im_number_pad_off;
    if not(Tstbit(status, 15)) then
      Put_line ("Number pad disable");
      Put_Line ("q to quit");
      loop
        exit when in_char = 'q';
        Get (in_char);
      end loop;
    else
      Put ("Nmbr Pad Off error = ");
      SYSWORD_IO.Put (status, WIDTH => 8);
      New_Line;
    end if;
  end numpadof;
```

*im\_number\_pad\_on*

---

## ***im\_number\_pad\_on***

**Purpose:** This function enables the reader's number pad. When enabled, the number pad functions the same way as the 10-key number pad on a standard PC keyboard. The numeric keys then provide cursor movement and editing keys, numbers, and access to the extended ASCII character set.

When you enable the number pad, you also turn number lock (Num Lock) off or on. When Num Lock is on, the number pad keys produce only numbers or extended ASCII characters with the same scan codes as the numeric keypad on a PC. The numeric keys always generate the same ASCII characters for numbers, but the scan codes depend on the status of the number pad and Num Lock.

When Num Lock is off, the number pad keys move the cursor (**Home**) or edit text (**Del**). Refer to your JANUS user's manual for more information on the number pad.

**Syntax:** With Intrmecd\_IO, Intrmecp\_IO;  
Use Intrmecd\_IO, Intrmecp\_IO;  
function im\_number\_pad\_on (  
    *numlock* : IN IM\_NUMBER\_LOCK  
) return System.Word;

**IN Parameter:** The *numlock* parameter passed to this function indicates whether the Num Lock key is on or off, using one of the following constants:

IM\_NUMLOCK\_ON    Enable the number pad with Num Lock on  
IM\_NUMLOCK\_OFF   Enable the number pad with Num Lock off

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

**See Also:** im\_number\_pad\_off

---

**Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;
```

```
procedure numpadon Is
```

```
    status : System.Word;  
    in_char : Character := ' '  
  
begin  
    Put_Line ("Turn numlock ON/OFF");  
  
    -- IM_NUMLOCK_ON : Number pad enable with Numlock ON  
    status := im_number_pad_on (IM_NUMLOCK_ON);  
    Put_Line ("NP enable NL ON");  
    Put_Line ("q to quit");  
    loop  
        exit when in_char = 'q';  
        Get (in_char);  
    end loop;  
  
    New_Line;  
    in_char := ' '  
  
    -- IM_NUMLOCK_OFF : Number pad enable with Numlock OFF  
    status := im_number_pad_on (IM_NUMLOCK_OFF);  
    Put_Line ("NP enable NL OFF");  
    Put_Line ("q to quit");  
    loop  
        exit when in_char = 'q';  
        Get (in_char);  
    end loop;  
end numpadon;
```

## *im\_power\_status*

---

### ***im\_power\_status***

**Purpose:** This procedure retrieves the line status, battery status, backup status, and the percentage of remaining battery life.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_power_status (  
    line_status      : OUT IM_LINE_STATUS;  
    battery_status   : OUT IM_BATTERY_STATUS;  
    backup_status    : OUT IM_BACKUP_STATUS;  
    fuel_gauge       : OUT System.Byte;  
    status_code      : OUT System.Word );
```

**IN Parameter:** None.

**OUT Parameter:** The *line\_status* parameter is one of the following constants:

|                         |                          |
|-------------------------|--------------------------|
| IM_Acline_NOT_CONNECTED | AC line is not connected |
| IM_Acline_CONNECTED     | AC line is connected     |
| IM_UNKNOWN_Acline       | Unknown AC line          |

The *battery\_status* parameter is one of the following constants:

|                 |                               |
|-----------------|-------------------------------|
| IM_HIGH_BAT     | Battery charge is high        |
| IM_LOW_BAT      | Battery charge is low         |
| IM_CRITICAL_BAT | Battery charge is in critical |
| IM_CHARGING_BAT | Charging battery now          |
| IM_UNKNOWN_BAT  | Unknown battery               |

The *backup\_status* parameter is one of the following constants:

|               |                    |
|---------------|--------------------|
| IM_BACKUP_OK  | Backup battery OK  |
| IM_BACKUP_LOW | Backup battery low |

The *fuel\_gauge* parameter retrieves one of the following values in increments of 10%:

|          |                  |
|----------|------------------|
| 0 to 100 | % of full charge |
| 255      | Unknown          |

The *status\_code* parameter is a standard status code listed in Appendix A, “Status Codes.”

**Return Value:** None.

---

### Example

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure powersta Is

  package SYSBYTE_IO is new INTEGER_IO (System.Byte);
  line_status      : IM_LINE_STATUS;
  battery_status   : IM_BATTERY_STATUS;
  backup_status    : IM_BACKUP_STATUS;
  fuel_gauge       : System.Byte;
  status           : System.Word;
  in_char          : Character := ' ';

begin
  loop
    exit when in_char = 'q';
    Put_Line("Checking power");
    New_Line;
    im_power_status(line_status, battery_status, backup_status,
      fuel_gauge, status);
    if im_isgood(status) then
      Put_Line("Line Status: ");

      case line_status is
        when IM_Acline_NOT_CONNECTED =>
          Put_Line("Not connected");

        when IM_Acline_CONNECTED =>
          Put_Line("Connected");

        when IM_UNKNOWN_Acline =>
          Put_Line("Unknown");

        when others =>
          Put_Line("Invalid");
      end case;

      New_Line;
      Put_Line("Battery Status: ");
      case battery_status is
        when IM_HIGH_BAT =>
          Put_Line("Charge high");
        when IM_LOW_BAT =>
          Put_Line("Charge low");

        when IM_CRITICAL_BAT =>
          Put_Line("Charge critical");

        when IM_CHARGING_BAT =>
          Put_Line("Charging battery");
```

### *im\_power\_status*

```
        when IM_UNKNOWN_BAT =>
            Put_Line("Unknown");

        when others =>
            Put_Line("Invalid");
    end case;

    New_Line;
    Put_Line("Backup Status: ");
    case backup_status is
        when IM_BACKUP_OK =>
            Put_Line("Backup battery OK");

        when IM_BACKUP_LOW =>
            Put_Line("Backup battery low");

        when others =>
            Put_Line("Invalid");
    end case;

    New_Line;
    Put("Fuel guage % ");
    case fuel_gauge is
        when 0..100 =>
            SYSBYTE_IO.Put(fuel_gauge);

        when 255 =>
            Put("Fuel gauge unknown");

        when others =>
            Put("Invalid");
    end case;

    New_Line;
    Put("q to quit");
    Get(in_char);
else
    im_message (status);
    New_Line;
end if;
end loop;
end powersta;
```

---

## ***im\_protocol\_extended\_status***

- Purpose:** This function retrieves the protocol extended status from the designated communications port. You allocate the protocol status buffer or RF status buffer, and the protocol returns the status and setup in hexadecimal values.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function im\_protocol\_extended\_status (  
    *port* : IN IM\_COM\_PORT,  
    *status\_buffer* : IN System.Address  
) return System.Word;
- IN Parameter:** The *port* parameter identifies the communications port as follows:
- |         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |
- The *status\_buffer* parameter is the address of the record of type IM\_COMM\_STATUS\_BUFFER\_S for IM\_COM1 and IM\_COM2, or IM\_COMM\_STATUS\_BUFFER\_RF for IM\_COM4.
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”
- Notes:** You must set the element status\_structure\_version to IM\_STATUS\_STRUCT\_VERSION before calling this function.
- See Also:** im\_receive\_buffer\_no\_wait, im\_transmit\_buffer\_no\_wait

### *im\_protocol\_extended\_status*

---

#### **Example**

```
With System, Intrmechd_IO, Intrmecp_IO, Text_IO;
Use System, Intrmechd_IO, Intrmecp_IO, Text_IO;

procedure protstat Is

    package SYSBYTE_IO is new INTEGER_IO (System.Byte);
    package LONGINT_IO is new INTEGER_IO (Long_integer);
    package IM_PROTOCOL_ID_IO is new ENUMERATION_IO (enum => IM_PROTOCOL_ID);
    package IM_PROTO_MODE_ID is new ENUMERATION_IO (enum => IM_PROTO_MODE);
    package IM_PH_ID_IO is new ENUMERATION_IO (enum => IM_PH_ID);
    serial_status_buffer_ptr : System.Address;
    serial_buffer : IM_COMM_STATUS_BUFFER_S;
    status : System.Word;

begin
    -- PHIMEC must be installed for this sample program to work correctly with COM1.

    serial_buffer.status_structure_version := IM_STATUS_STRUCT_VERSION;
    serial_buffer.handler_ver := " ";
    serial_status_buffer_ptr := serial_buffer'Address;
    status := im_protocol_extended_status (IM_COM1, serial_status_buffer_ptr);
    im_message (status);
    New_Line;

    Put ("Struct Ver:");
    SYSBYTE_IO.Put (serial_buffer.status_structure_version);
    New_Line;

    Put("Handler ver: ");
    Put(serial_buffer.handler_ver);
    New_Line;

    Put("Type: ");
    IM_PH_ID_IO.Put(serial_buffer.handler_type);
    New_Line;

    Put("Baud: ");
    LONGINT_IO.Put(serial_buffer.sb.baud_rate, WIDTH => 6);
    New_Line;

    Put("Parity:");
    SYSBYTE_IO.Put (serial_buffer.sb.parity);
    New_Line;

    Put("Stop bits:");
    SYSBYTE_IO.Put (serial_buffer.sb.stop_bits);
    New_Line;

    Put("Data bits:");
    SYSBYTE_IO.Put (serial_buffer.sb.data_bits);
    New_Line;

    Put("Act prot: ");
    IM_PROTOCOL_ID_IO.Put(serial_buffer.sb.active_prot);
    New_Line;
end protstat;
```

---

## ***im\_receive\_buffer***

**Purpose:** This procedure receives the contents of a data buffer from a designated communications port.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;
Use Intrmeacd_IO, Intrmecp_IO;
procedure im_receive_buffer (
    port          : IN IM_COM_PORT;
    user_length   : IN System.Word;
    buffer        : IN System.Address;
    timeout       : IN System.Word;
    comm_length   : OUT System.Word;
    status_code   : OUT System.Word);
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *user\_length* parameter is the maximum number of characters to be received and must be at least 256 bytes.

The *buffer* parameter is the address of the string that will receive the data. The string must be at least 256 bytes.

The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

If you select IM\_INFINITE\_TIMEOUT, the function will not return until the end of message character has been received.

### ***im\_receive\_buffer***

**OUT Parameter:** The *comm\_length* is the actual number of characters received upon completion of the call.

The *status\_code* parameter is a standard status code listed in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** This procedure will not return a parameter value until it reaches the end of message, the buffer is full, or an error or timeout occurs.

Do not link using the *im\_link\_comm* function for this procedure.

You must install a protocol handler to use this function.

**See Also:** *im\_receive\_buffer\_no\_wait*, *im\_receive\_buffer\_noprot*, *im\_cancel\_rx\_buffer*, *im\_rx\_check\_status*

---

### ***Example***

With System, Text\_IO, Intrmechd\_IO, Intrmecp\_IO;  
Use System, Text\_IO, Intrmechd\_IO, Intrmecp\_IO;

procedure rec\_buff is

```
package SYSWORD_IO is new INTEGER_IO (System.Word);
```

```
status      : System.Word;  
comm_length : System.Word;  
data_buffer : String (1..300);  
done        : Boolean;  
length      : System.Word := 300;  
timeout     : System.Word;
```

```
begin
```

```
-- Phimec protocol handler must be installed  
-- get the receive environment ready
```

```
status := im_cancel_rx_buffer(IM_COM1);
```

```
if im_iserror(status) then  
  Put ("cancel rx error = ");  
  im_message (status);  
  New_Line;
```

```
end if;
```

```
-- clear the buffer
```

```
data_buffer := (others=>Ascii.NUL);
```

```
done := FALSE;
```

```
Put_Line ("    Rx/Tx Buffer");
```

```
Put_Line ("enter string and CR ");
```

```
Put_Line ("at host");
```

```
Put_Line ("(q or Q to quit)");
```

```

-- call Intermec function
timeout := 20000; -- 20 seconds
im_receive_buffer (IM_COM1, length, data_buffer'Address,
                  timeout, comm_length, status);
if im_iserror(status) then
  Put ("rec buff error = ");
  im_message (status);
  New_Line;
  done := TRUE;
end if;

-- loop until first character in buffer is a 'Q' or 'q'
while not done loop
  if im_issuccess(status) then
    for i in Integer range 1..Integer(comm_length) loop
      Put(data_buffer(i));
    end loop;
    New_Line;
    Put ("comm_length is ");
    SYSWORD_IO.Put (comm_length, width => 3);
    New_Line;
  else
    Put ("Rx Again err = ");
    im_message (status);
    New_Line;
    done := TRUE;
  end if;

  --get the transmit environment ready
  status := im_cancel_tx_buffer(IM_COM1);
  if im_iserror(status) then
    Put ("canc tx1 status = ");
    im_message (status);
    New_Line;
  end if;
  status := im_transmit_buffer (IM_COM1, comm_length,
                              data_buffer'Address, timeout);
  if im_iserror(status) then
    Put ("transmit buff err: ");
    im_message (status);
    New_Line;
    done := TRUE;
  end if;

  --get ready to receive again
  status := im_cancel_rx_buffer (IM_COM1);
  if im_iserror(status) then
    Put ("canc rx2 status = ");
    im_message (status);
    New_Line;
  end if;

  -- clear the buffer
  data_buffer := (others => Ascii.NUL);
  im_receive_buffer (IM_COM1, length, data_buffer'Address,
                  timeout, comm_length, status);
  if im_iserror(status) then
    Put ("rec again status = ");
    im_message (status);
    New_Line;
    done := TRUE;
  end if;
end if;

```

### ***im\_receive\_buffer***

```
-- quit if first char in buffer is a 'Q' or a 'q'
if ((data_buffer(1) = 'Q') or (data_buffer(1) = 'q')) then
    done := TRUE;
end if;
end loop;

status := im_cancel_rx_buffer (IM_COM1);
if im_iserror(status) then
    Put ("canc rx last = ");
    im_message (status);
    New_Line;
end if;

status := im_cancel_tx_buffer (IM_COM1);
if im_iserror(status) then
    Put ("canc tx last = ");
    im_message (status);
    New_Line;
end if;
end rec_buff;
```

---

## ***im\_receive\_buffer\_no\_wait***

- Purpose:** This function receives a buffer of data as part of a record. It differs from `im_receive_buffer` in that the programmer must set up the data record and monitor the transfer status until transmission is complete. This function runs in the background after it is initiated.
- Use this function when receiving multiple buffer transmissions in conjunction with `im_rx_check_status`.
- Syntax:** With `Intrmecd_IO`, `Intrmecp_IO`;  
Use `Intrmecd_IO`, `Intrmecp_IO`;  

```
function im_receive_buffer_no_wait (  
    port      : IN IM_COM_PORT;  
    data_struct : IN System.Address  
) return System.Word;
```
- IN Parameter:** The *port* parameter identifies the communications port as follows:
- |         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |
- The *data\_struct* parameter is the address of the `IM_COM_DATA_BUFFER` record.
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:** Build and maintain the `IM_COM_DATA_BUFFER` record as described in `IM20ADAD.LIB`.
- You must periodically check the `protocol_xfer_status` element in the `IM_COM_DATA_BUFFER` record to see if all the data has been received. When `protocol_xfer_status` is no longer code 8602H (communications port in use), all data is received.
- You must install a protocol handler to use this function.

### ***im\_receive\_buffer\_no\_wait***

This procedure will not work if linked.

This procedure differs from `im_receive_buffer_noprot` in that program execution continues after `im_receive_buffer_no_wait` is called.

**See Also:** `im_receive_buffer_noprot`, `im_cancel_rx_buffer`, `im_rx_check_status`, `im_receive_buffer_no_wait`

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure exnowait is

  package SYSWORD_IO is new INTEGER_IO (System.Word);

  COMM_INUSE   : constant System.Word := 16#8602#; -- Comm port in use
  com_buff_rec : IM_COM_DATA_BUFFER;      --data record for rec/xmit
  status       : System.Word;
  data_buffer  : String (1..300);
  done        : Boolean := FALSE;

begin
  -- Phimec protocol handler must be installed to run this routine.
  New_Line(2);
  Put_Line("    JANUS 2010");
  Put_Line("Rx/Tx Buffer No Wait");
  New_Line;

  -- get the receive environment ready
  status := im_cancel_rx_buffer(IM_COM1);
  if im_iserror(status) then
    Put ("canc rx1 = ");
    im_message (status);
    New_Line;
  end if;
  Put_Line("Ready to receive");
  Put_Line("q to quit");
  New_Line;

  --fill the comm buffer structure
  com_buff_rec.command := IM_CU_RECEIVE;
  com_buff_rec.protocol_xfer_status := COMM_INUSE;
  com_buff_rec.user_length := System.Word (data_buffer'Length);
  com_buff_rec.comm_length := 0;
  com_buff_rec.data_ptr := data_buffer'Address;
  com_buff_rec.protocol_mode := IM_NO_PROTOCOL;
  com_buff_rec.eom_char := 16#0d#; -- CR for terminating char

  -- call Intermec function
  status := im_receive_buffer_no_wait (IM_COM1, com_buff_rec'Address);
  if im_iserror(status) then
    Put ("rec buff = ");
    im_message (status);
```

```

    New_Line;
end if;

-- loop until first character in buffer is a 'Q' or 'q'
while not done loop
    if im_issuccess(status) then
        -- get the receive data
        while (com_buff_rec.protocol_xfer_status = COMM_INUSE) loop
            null;
        end loop;
        Put_Line ("Receive done");
        status := im_rx_check_status (IM_COM1);
        if im_iserror(status) then
            Put ("rx check = ");
            im_message (status);
            New_Line;
        end if;

        Put ("comm_length is ");
        SYSWORD_IO.Put (com_buff_rec.comm_length, width => 3);
        New_Line;
        for i in Integer range 1..Integer(com_buff_rec.comm_length) loop
            Put(data_buffer(i));
        end loop;
        New_Line;
    else
        Put ("Rx no wait err = ");
        im_message (status);
        New_Line;
    end if;

    com_buff_rec.command := IM_CU_TRANSMIT;
    com_buff_rec.protocol_xfer_status := COMM_INUSE;
    com_buff_rec.user_length := com_buff_rec.comm_length;
    com_buff_rec.comm_length := 0;
    com_buff_rec.data_ptr := data_buffer'Address;
    com_buff_rec.protocol_mode := IM_NO_PROTOCOL;
    com_buff_rec.eom_char := 0;
    status := im_transmit_buffer_no_wait (IM_COM1, com_buff_rec'Address);

    if im_issuccess (status) then
        while (com_buff_rec.protocol_xfer_status = COMM_INUSE) loop
            Put_Line ("sending data");
        end loop;
        Put_Line ("Buffer sent");
        status := im_tx_check_status (IM_COM1);
        if im_iserror(status) then
            Put ("tx check = ");
            im_message (status);
            New_Line;
        end if;
    else
        Put ("transmit stat = ");
        im_message (status);
        New_Line;
    end if;
    New_Line;

    -- set up to receive again
    status := im_cancel_rx_buffer (IM_COM1);
    if im_iserror(status) then
        Put ("canc rx2 = ");

```

### ***im\_receive\_buffer\_no\_wait***

```
        im_message (status);
        New_Line;
    end if;

    --fill the comm buffer structure
    com_buff_rec.command      := IM_CU_RECEIVE;
    com_buff_rec.protocol_xfer_status := COMM_INUSE;
    com_buff_rec.user_length  := System.Word (data_buffer'Length);
    com_buff_rec.comm_length  := 0;
    com_buff_rec.data_ptr     := data_buffer'Address;
    com_buff_rec.protocol_mode := IM_NO_PROTOCOL;
    com_buff_rec.eom_char     := 16#0d#; -- CR for terminating char
    status := im_receive_buffer_no_wait(IM_COM1, com_buff_rec'Address);
    if im_iserror(status) then
        Put ("rec no wait = ");
        im_message (status);
        New_Line;
    end if;

    -- quit if first char in buffer is a 'Q' or a 'q'
    if ((data_buffer(1) = 'Q') or (data_buffer(1) = 'q')) then
        done := TRUE;
    end if;
end loop;

status := im_cancel_rx_buffer (IM_COM1);
if im_iserror(status) then
    Put ("canc rx last = ");
    im_message (status);
    New_Line;
end if;
status := im_cancel_tx_buffer (IM_COM1);
if im_iserror(status) then
    Put ("canc tx last = ");
    im_message (status);
    New_Line;
end if;
end exnowait;
```

---

## ***im\_receive\_buffer\_noprot***

**Purpose:** This procedure receives a text string from the designated port without using the active protocol. Only the PHIMEC.EXE protocol handler supports this procedure, which is often used to receive a host initialization string before beginning transmission.

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;
Use Intrmechd_IO, Intrmecp_IO;
procedure im_receive_buffer_noprot (
    port          : IN IM_COM_PORT;
    user_length   : IN System.Word;
    buffer        : IN System.Address;
    timeout       : IN System.Word;
    term_char     : IN Character;
    comm_length   : OUT System.Word;
    status_code   : OUT System.Word);
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1.                         |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *user\_length* parameter is the maximum number of characters you can receive and must be at least 256 bytes.

The *buffer* parameter is the address of the buffer that will receive the data. The buffer's length must be at least 256 bytes.

The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

### ***im\_receive\_buffer\_noprot***

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

The *term\_char* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

**OUT Parameter:** The *comm\_length* parameter retrieves the actual number of characters received.

The *status\_code* parameter is one of the standard status codes defined in Appendix A, “Status Codes.”

**Return Value:** None.

**Notes:** You must install the PHIMEC.EXE protocol handler. This procedure will not work if linked.

The difference between this procedure and *im\_receive\_buffer\_no\_wait* is that when *im\_receive\_buffer\_noprot* returns from the procedure call, the data has been read, the timeout has expired, or an error was encountered.

**See Also:** *im\_receive\_buffer\_no\_wait*, *im\_cancel\_rx\_buffer*

---

### ***Example***

With System, Intrmechd\_IO, Intrmecp\_IO, Text\_IO;  
Use System, Intrmechd\_IO, Intrmecp\_IO, Text\_IO;

procedure exnoproto Is

```
package SYSWORD_IO is new INTEGER_IO (System.Word);

status          : System.Word;
comm_length     : System.Word := 0;
timeout         : System.Word := 20000;    -- 20 seconds
eom_char        : System.Byte := 16#0D#;    -- CR for terminating char
RX_data_buffer  : String (1..300) := (others => Ascii.NUL);
TX_data_buffer  : String (1..300) := (others => Ascii.NUL);
RX_buff_length  : System.Word := System.Word(RX_data_buffer'Length);
TX_buff_length  : System.Word;
RX_data_ptr     : System.Address := RX_data_buffer'Address;
TX_data_ptr     : System.Address := TX_data_buffer'Address;
done            : Boolean := FALSE;
```

```

begin
-- Phimec protocol handler must be installed to run this routine
New_Line(2);
Put_Line("      Janus 2010 ");
Put_Line("Rx/Tx Buffer No Prot");
New_Line;

-- get the receive environment ready
status := im_cancel_rx_buffer(IM_COM1);
if (im_iserror(status)) then
  Put ("canc rx1 error = ");
  im_message (status);
  New_Line;
end if;

-- Clear the transmission buffer
status := im_cancel_tx_buffer (IM_COM1);
Put_Line("Ready to receive");
Put_Line("q to quit...");
New_Line;

-- call Intermec function
im_receive_buffer_noprot (IM_COM1, RX_Buff_length, RX_data_ptr,
  IM_INFINITE_TIMEOUT, eom_char, comm_length, status);

-- loop until first character in buffer is a 'q'
while not done loop
  if im_isgood(status) then
    Put_Line ("Receive done");

    -- Display number of characters received
    Put ("comm_length is ");
    SYSWORD_IO.Put (comm_length, width => 3);
    New_Line;

    -- Display buffer contents
    for i in Integer range 1..Integer(comm_length) loop
      Put(RX_data_buffer(i));
    end loop;
    New_Line;
  else
    Put_Line ("Rx no protocol err = ");
    im_message (status);
    New_Line;

    -- Since there was an error, clear the receive buffer and
    -- reset the comm port
    status := im_cancel_rx_buffer (IM_COM1);
  end if;

  -- copy RX_ to TX_
  for i in Integer range 1..Integer(comm_length) loop
    TX_data_buffer (i) := RX_data_buffer (i);
  end loop;

  TX_buff_length := comm_length + 1;
  TX_data_buffer(Integer(TX_buff_length)) := Ascii.CR;
  status := im_transmit_buffer_noprot (IM_COM1, TX_buff_length,
    TX_data_ptr, timeout);

  if im_isgood (status) then
    Put_Line ("Buffer transmitted");
  end if;
end while;

```

### ***im\_receive\_buffer\_noprot***

```
else
    Put_Line ("tx status = ");
    im_message (status);
    New_Line;

    -- Since there was an error in the transmission, clear the buffer
    -- and reset the comm port
    status := im_cancel_tx_buffer (IM_COM1);
end if;
New_Line;

-- call Intermec receive function
im_receive_buffer_noprot (IM_COM1, RX_Buff_length, RX_data_ptr,
    IM_INFINITE_TIMEOUT, eom_char, comm_length, status);
-- quit if first char in buffer is a 'Q' or a 'q'
if ((RX_data_buffer(1) = 'Q') or (RX_data_buffer(1) = 'q')) then
    done := TRUE;
end if;
end loop;

-- Clear buffers and reset comm port
status := im_cancel_rx_buffer (IM_COM1);
status := im_cancel_tx_buffer (IM_COM1);
end exnoprot;
```

---

## ***im\_receive\_byte***

- Purpose:** This procedure receives one byte of data through the designated communications port. This procedure is identical to MS-DOS INT 14H service 02H.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
procedure im\_receive\_byte (  
    *port* : IN IM\_COM\_PORT;  
    *receive\_byte* : OUT Character;  
    *status\_code* : OUT System.Word);
- IN Parameter:** The *port* parameter identifies the communications port as follows:
- |         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |
- OUT Parameter:** The *receive\_byte* parameter is the byte read from the communications port.
- The *status\_code* parameter is a standard status code listed in Appendix A, "Status Codes."
- Return Value:** None.
- Notes:** This procedure requires the PC standard protocol handler, PHPCSTD.EXE.
- If you are using PHIMEC.EXE and want to receive a single byte, use im\_receive\_buffer with a buffer length of one instead of the im\_receive\_byte procedure.
- This procedure will not work if linked.
- See Also:** im\_transmit\_byte

## *im\_receive\_byte*

---

### **Example**

```
With System, DosCall, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, DosCall, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure recbyte Is

  status      : System.Word;
  RX_byte     : Character := ' ';
  eom_char    : Character;
  setup_comm_status : Integer;

  function setup_com (port : System.Word) return Integer Is
    -- This function sets up the communications port for RS232,
    -- 9600 baud, even parity, 7-bit words, and 1 stop bit using
    -- a DosCall procedure.

    RS232      : Constant Integer := 16#14#;
    B9600      : Constant System.Word := 16#E0#;
    EVEN       : Constant System.Word := 16#18#;
    WORD7      : Constant System.Word := 16#02#;
    STOP1      : Constant System.Word := 16#00#;
    Regs       : DosCall.Simple_Regs;
    setup       : System.Word;

  begin
    setup := 0;
    if ((port /= 0) and (port /= 1)) then
      return -1;
    end if;
    setup := B9600 + WORD7 + EVEN + STOP1;
    Regs.AX := setup;
    Regs.DX := port;
    DosCall.Simple_Int_Call (RS232, Regs);
    return 0;
    -- Good return
  end setup_com;

  ..***** main program starts here *****
begin
  -- Phimec protocol handler must NOT be installed to run this routine
  -- get the comm environment ready

  setup_comm_status := setup_com(0);
  if setup_comm_status = 0 then
    eom_char := Ascii.CR;
    Put_Line("Enter characters at");
    Put_Line("terminal");
    Put_Line("<CR> to end");
    RX_byte := Ascii.NUL;
    loop
      -- Receive and display bytes until <CR> is sent
      im_receive_byte (IM_COM1, RX_byte, status);
      exit when RX_byte = eom_char;

      if (im_issuccess(status)) then
        if RX_byte in ' '..~' then
          Put(RX_byte);
        else
          Put_Line("Unprintable char");
        end if;
      end if;
    end loop;
  end if;
```

*im\_receive\_byte*

3

```
        else
            Put ("rec byte status = ");
            im_message (status);
            New_Line;
        end if;
    end loop;

    New_Line;
    Put_Line ("Receive done");
else
    Put_Line("Com setup failed");
    im_message (System.Word(setup_comm_status));
    New_Line;
end if;
end recbyte;
```

## *im\_receive\_input*

---

### ***im\_receive\_input***

**Purpose:** This procedure retrieves input from the source and places it into the receive buffer. You can use the `im_get_length` function after this procedure to get the input length.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
procedure im_receive_input (  
    allowed_source    : IN IM_ORIGIN;  
    timeout           : IN System.Word;  
    returned_source   : OUT IM_ORIGIN;  
    ret_string        : OUT String;  
    status_code       : OUT System.Word);
```

**IN Parameter:** The *allowed\_source* parameter defines the available input source and is one or more of the following constants:

|                    |                               |
|--------------------|-------------------------------|
| IM_LABEL_SELECT    | Label selected                |
| IM_KEYBOARD_SELECT | Keypad selected               |
| IM_COM1_SELECT     | COM1 selected                 |
| IM_COM2_SELECT     | COM2, scanner (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)       |
| IM_ALL_SELECT      | All selected                  |

The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

If `IM_INFINITE_TIMEOUT` is selected, the function will not return until the end of message character has been received.

**OUT Parameter:** The *returned\_source* parameter specifies the actual input source and is one of the following constants:

|                    |                               |
|--------------------|-------------------------------|
| IM_NO_SELECT       | No selection made             |
| IM_LABEL_SELECT    | Label selected                |
| IM_KEYBOARD_SELECT | Keypad selected               |
| IM_COM1_SELECT     | COM1 selected                 |
| IM_COM2_SELECT     | COM2, scanner (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)       |

The *ret\_string* parameter retrieves the string received.

The *status\_code* parameter is a standard status code listed in Appendix A, “Status Codes.”

**Return Value:** None.

**Notes:** If input from more than one source is received before this function is called, the first available input is returned in this order: label, keypad, COM1, COM2, and COM4.

If you are using a communications port, you must install a protocol handler and call *im\_link\_comm*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

**See Also:** *im\_get\_length*, *im\_get\_label\_symbology*, *im\_link\_comm*

---

### Example

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use   System, Text_IO, Intrmechd_IO, Intrmecp_IO;
```

```
procedure recinput Is
```

```
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    package SYMBOL_IO is new ENUMERATION_IO(enum => IM_DECTYPE);
    symbol      : IM_DECTYPE;
    status      : System.Word;
    selected_origin : IM_ORIGIN := IM_LABEL_SELECT + IM_KEYBOARD_SELECT;
    returned_origin : IM_ORIGIN;
    label       : String (1..256);
    len         : System.Word;
```

### ***im\_receive\_input***

```
begin
    Put_Line(" ");
    Put_Line("      Janus 2010");
    Put_Line("Receive input from");
    Put_Line("Keypad or Label");
    Put_Line("q to quit");
    New_Line;
    im_set_input_mode (IM_PROGRAMMER);

    loop
        -- Clear input
        label := (others=>Ascii.NUL);

        -- Call Intermec procedure
        im_receive_input (selected_origin, IM_INFINITE_TIMEOUT,
            returned_origin, label, status);
        New_Line;
        if im_isgood(status) then -- receive input successful
            New_Line;
            -- Get the length of the label or keypad input
            len := im_get_length (returned_origin);
            Put ("Length of input:");
            SYSWORD_IO.Put (len, Width => 3);
            New_Line;

            -- Display input
            for i in Integer range 1..Integer(len) loop
                Put(label(i));
            end loop;
            New_Line;

            -- If label is read then get the symbology and display it
            if returned_origin = IM_LABEL_SELECT then
                im_get_label_symbology (symbol, status);
                if im_isgood(status) then
                    Put_Line("Symbology read:");
                    SYMBOL_IO.Put (symbol);
                    New_Line;
                else
                    Put_Line ("Label errors");
                    im_message (status);
                    New_Line;
                end if;
            end if;
        else
            -- im_receive_input error or warning
            Put_Line("Receive input error");
            im_message(status);
            New_Line;
        end if;
        exit when label(1) = 'q' or label(1) = 'Q';
    end loop;
    im_set_input_mode (IM_WEDGE);
end recinput;
```

---

## ***im\_rs\_installed***

- Purpose:** This function determines whether or not the reader services (RSERVICE.EXE) program is installed.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
function im\_rs\_installed return IM\_RS\_INSTALL\_STATUS;
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- 

### ***Example***

With System, Text\_IO, Intrmeacd\_IO, Intrmecp\_IO;  
Use System, Text\_IO, Intrmeacd\_IO, Intrmecp\_IO;

```
procedure rsinstal Is
    rs_status : System.Word;
begin
    rs_status := im_rs_installed;
    case rs_status is
        when IM_RS_ALL_SUCCESS =>
            Put_Line("RS request successful");

        when IM_RS_NOT_INSTALLED =>
            Put_Line("RS not installed");

        when others =>
            Put("Invalid: ");
            im_message(rs_status);
            New_Line;
    end case;
    New_Line;
end rsinstal;
```

## *im\_rx\_check\_status*

---

### ***im\_rx\_check\_status***

**Purpose:** This function directs the active protocol handler to check the communications port buffer status variable to determine if the application program has accepted the previous data. Use this function with the `im_receive_buffer_no_wait` function to receive input from multiple buffers.

**Syntax:** With `Intrmecd_IO`, `Intrmecp_IO`;  
Use `Intrmecd_IO`, `Intrmecp_IO`;  
function `im_rx_check_status` (  
    `port` : IN `IM_COM_PORT`  
) return `System.Word`;

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|                      |                                             |
|----------------------|---------------------------------------------|
| <code>IM_COM1</code> | <code>COM1</code>                           |
| <code>IM_COM2</code> | <code>COM2</code> , scanner (2010 and 2050) |
| <code>IM_COM4</code> | <code>COM4</code> (RF only)                 |

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this function.

**See Also:** `im_receive_buffer_no_wait`

---

#### ***Example***

See example for `im_receive_buffer_no_wait`.

---

## ***im\_serial\_protocol\_control***

**Purpose:** This function controls the protocol mode for a designated communications port and determines whether the receive mode is with or without protocol according to the input parameter. Any change clears the input buffer and resets the reader command parser.

Use this function to set protocol when connected to a communications port. The return value indicates a success if the port is currently linked to the Reader Wedge. If the port is not currently linked to the Reader Wedge, the function returns an error.

**Syntax:**

```
With Intrmecd_IO, Intrmecp_IO;
Use Intrmecd_IO, Intrmecp_IO;
function im_serial_protocol_control (
    port      : IN IM_COM_PORT;
    prot_mode : IN IM_PROTOCOL_CMD;
    term_char : IN Character
) return System.Word;
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *prot\_mode* parameter affects how incoming messages are received and is one of the following constants:

|                  |                                       |
|------------------|---------------------------------------|
| IM_NO_CHANGE     | The protocol is unchanged             |
| IM_PROTOCOL_ON   | Turns the protocol off                |
| IM_PROTOCOL_OFF  | Turns the protocol on                 |
| IM_NEW_TERM_CHAR | Indicates a new termination character |

The *prot\_mode* parameter affects how incoming messages are received:

- If IM\_NO\_CHANGE is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If IM\_PROTOCOL\_ON is specified, the incoming message is terminated with the end of message character of the active protocol.

## *im\_serial\_protocol\_control*

- If IM\_PROTOCOL\_OFF is specified, the incoming data is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.
- If IM\_PROTOCOL\_OFF is used, you must specify a termination character, otherwise the data is returned in individual bytes.
- If IM\_NEW\_TERM\_CHAR is specified, IM\_PROTOCOL\_OFF is assumed and the new end of message character specified in the parameter list is used.

The *term\_char* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any character. This parameter is required for IM\_PROTOCOL\_OFF and IM\_NEW\_TERM\_CHAR.

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

**Notes:** Requires im\_link\_comm.

The receive buffers are cleared whenever the protocol is turned on or off. To change the termination character (or to not change the setting at all), use IM\_NEW\_TERM\_CHAR or IM\_NO\_CHANGE instead of toggling the protocol.

**See Also:** im\_link\_comm

---

### **Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;
```

```
procedure protctrl Is
```

```
    package IM_ORIGIN_IO is new INTEGER_IO (IM_ORIGIN);  
    comm_buff      : Im_Buffer;  
    comm_buff_ptr  : System.Address := comm_buff(comm_buff'First)'Address;  
    comm_buff_size : System.Word := comm_buff'Length;  
    ans            : Character := ' ';  
    status         : System.Word;  
    receive_status : System.Word;  
    eom            : Character := Ascii.CR;  
    label          : String(1..16) := (others => Ascii.NUL);
```

```

timeout      : System.Word := 10000;          -- 10 seconds
returned_origin: IM_ORIGIN;

begin
  status := im_link_comm(IM_COM1, comm_buff_ptr, comm_buff_size);
  Put("Link status:");
  im_message (status);
  New_Line;
  im_set_input_mode(IM_DESKTOP);

  -- turn off protocol and make a <CR> the end of message char
  Put_Line ("setting protocol");
  status := im_serial_protocol_control(IM_COM1, IM_PROTOCOL_OFF, eom);
  im_message (status);
  New_Line;
  label := (others => Ascii.NUL);
  Put_Line ("Waiting for COM1 input");
  im_receive_input(IM_COM1_SELECT, timeout, returned_origin,
    label, receive_status);
  im_set_input_mode (IM_WEDGE);

  if IM_ISSUCCESS(receive_status) then
    Put_Line("Rec status: ");
    im_message (receive_status);
    New_Line;
    Put("Origin: ");
    IM_ORIGIN_IO.Put(returned_origin, WIDTH => 8, BASE => 16);
    New_Line;
    Put_Line("Label:");
    for i in Integer range 1..16 loop
      exit when label(i) = Ascii.NUL;
      if label(i) in '..~' then
        Put(label(i));
      else
        New_Line;
        Put_Line("Unprintable char");
      end if;
    end loop;
    New_Line;
  else
    Put_Line("Rec error");
    im_message (receive_status);
    New_Line;
  end if;

  -- turn off protocol
  status := im_serial_protocol_control(IM_COM1, IM_PROTOCOL_OFF, Ascii.CR);
  status := im_unlink_comm(IM_COM1);
end protctrl;

```

## *im\_set\_contrast*

---

### ***im\_set\_contrast***

- Purpose:** This function sets the reader's display contrast level. There are eight levels of contrast from very light (level 0) to very dark (level 7).
- Syntax:**
- ```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
    function im_set_contrast (  
        contrast_level_requested: IN System.Byte  
    ) return System.Word;
```
- IN Parameter:** The *contrast\_level\_requested* parameter is one of the following constants:
- IM\_MIN\_CONTRAST Level 0  
IM\_AVE\_CONTRAST Level 4  
IM\_MAX\_CONTRAST Level 7
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:** The functions *im\_set\_contrast* and *im\_get\_contrast* use a scale of 0 to 7 that is related to the scale of 0 to 31 used by *im\_increase\_contrast* and *im\_decrease\_contrast*. The following table shows the equivalent values for the 0 to 7 scale.

| Scale 0 to 7 | Scale 0 to 31 | Level      |
|--------------|---------------|------------|
| 0            | 10            | Very light |
| 1            | 12            |            |
| 2            | 14            |            |
| 3            | 16            |            |
| 4            | 18            |            |
| 5            | 20            |            |
| 6            | 22            | Very dark  |
| 7            | 24            |            |

**See Also:** *im\_get\_contrast*, *im\_decrease\_contrast*, *im\_increase\_contrast*

---

**Example**

```
With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure setcontr Is

    package SYSBYTE_IO is new INTEGER_IO (System.Byte);
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
    level : System.Byte;

begin
    Put_Line ("Enter Contrast (0-7)");
    Put (">>> ");
    SYSBYTE_IO.Get (level);
    Skip_Line;
    status := im_set_contrast (level);
    if Tstbit(status, 15) then
        Put ("Set Contrast Error = ");
        SYSWORD_IO.Put (status, WIDTH => 8);
        New_Line;
    end if;
end setcontr;
```

*im\_set\_control\_key*

---

## ***im\_set\_control\_key***

- Purpose:** This function enables or disables the **Ctrl** key setting. When disabled, none of the key combinations that use the **Ctrl** key work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
    function im\_set\_control\_key (  
        control\_key : IN IM\_CONTROL  
    ) return System.Word;
- IN Parameter:** The *control\_key* parameter is set to one of the following constants:
- IM\_ENABLE    Enable the Ctrl key  
IM\_DISABLE   Disable the Ctrl key
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- See Also:** im\_get\_control\_key

---

### ***Example***

```
With System, Bit, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure setctrlkey Is

    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
    in_char : Character := ' ';

begin
    status := im_set_control_key (IM_DISABLE);
    if im_isgood (status) then
        Put_Line ("Control Key DISABLED");
        Put_Line ("q to quit");
        loop
            exit when in_char = 'q';
            Get(in_char);
        end loop;
    else
        Put ("Disable Ctrl Key error = ");
        SYSWORD_IO.Put (status, Width => 8);
        New_Line;
    end if;

    in_char := ' ';
    New_Line;
    status := im_set_control_key (IM_ENABLE);
```

```
if im_isgood (status)then
  Put_Line ("Control Key ENABLED");
  Put_Line ("q to quit");
  loop
    exit when in_char = 'q';
    Get(in_char);
  end loop;
else
  Put ("Enable Ctrl Key error = ");
  SYSWORD_IO.Put (status, Width => 8);
  New_Line;
end if;
end setclkey;
```

## *im\_set\_display\_mode*

---

## ***im\_set\_display\_mode***

**Purpose:** This function sets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
With Intrmecd_IO, Intrmecp_IO;  
Use Intrmecd_IO, Intrmecp_IO;  
function im_set_display_mode (  
    size_mode : IN IM_STD_SIZE_MODE;  
    video      : IN IM_STD_VIDEO_MODE;  
    scroll     : IN IM_SCROLL_MODE;  
    char_ht    : IN IM_CHARACTER_HEIGHT  
) return System.Word;
```

**IN Parameter:** The *size\_mode* parameter is required and is one of these constants:

|                    |                                   |
|--------------------|-----------------------------------|
| IM_SIZE_MODE_80X25 | 80 x 25 text mode                 |
| IM_SIZE_MODE_20X16 | 20 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_20X8  | 20 x 8 text mode (2010 and 2020)  |
| IM_SIZE_MODE_10X16 | 10 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_10X8  | 10 x 8 text mode (2010 and 2020)  |

If IM\_SIZE\_MODE\_80X25 is set, you also need to set the video mode, scroll mode, and character height.

If any other *size\_mode* is set, the video mode, scroll mode, and character height are automatically set.

The *video\_mode* parameter requires IM\_SIZE\_MODE\_80X25. The standard PC BIOS supports up to video mode 13H. The reader only supports up to video mode 6. You can also set video modes 0 through 3 with IC.EXE.

The *video\_mode* parameter is one of the following constants:

|                     |                                |
|---------------------|--------------------------------|
| IM_STD_VIDEO_MODE_0 | 40X25 (double-wide characters) |
| IM_STD_VIDEO_MODE_1 | 40X25 (double-wide characters) |
| IM_STD_VIDEO_MODE_2 | 80X25                          |
| IM_STD_VIDEO_MODE_3 | 80X25                          |
| IM_STD_VIDEO_MODE_4 | 300X200 2-color                |
| IM_STD_VIDEO_MODE_5 | 300X200 monochrome             |
| IM_STD_VIDEO_MODE_6 | 640X200 2-color (2050)         |

The *scroll* parameter requires IM\_SIZE\_MODE\_80X25 and is one of the following constants:

|                     |                                            |
|---------------------|--------------------------------------------|
| IM_LCD_SCROLL_AT_25 | Scroll at line 25                          |
| IM_LCD_SCROLL_AT_16 | Scroll at line 16 (2010 and 2020)          |
| IM_LCD_SCROLL_AT_13 | Scroll at line 13 (2050 and double height) |
| IM_LCD_SCROLL_AT_8  | Scroll at line 8 (2010 and 2020)           |

The *char\_ht* parameter requires IM\_SIZE\_MODE\_80X25 and is one of the following constants:

|                         |                                                                                   |
|-------------------------|-----------------------------------------------------------------------------------|
| IM_STANDARD_CHAR_HEIGHT | Standard height characters, applies to all scroll modes except line 8 and line 13 |
| IM_DOUBLE_CHAR_HEIGHT   | Double height characters, applies only to scroll at line 8 and line 13            |

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”

**Notes:** Using this function to set display modes clears the screen.

The IRL input commands will not display correctly if the display is in 80X25 mode and the cursor has scrolled off the display. To alleviate this problem, set the display mode to one of the other modes, such as 20X16.

The mode does not change if there are conflicting parameters, such as trying to set the *video\_mode* to 16 lines and the *scroll\_mode* to line 8.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

**See Also:** im\_get\_display\_mode, im\_set\_follow\_cursor

## *im\_set\_display\_mode*

---

### **Example**

With System, Text\_IO, Intrmecd\_IO, Intrmecp\_IO;  
Use System, Text\_IO, Intrmecd\_IO, Intrmecp\_IO;

procedure setdpmode Is

```
package SYSWORD_IO is new INTEGER_IO (System.Word);
package IM_STD_SIZE_MODE_IO is new ENUMERATION_IO
  (enum => IM_STD_SIZE_MODE);
package IM_STD_VIDEO_MODE_IO is new ENUMERATION_IO
  (enum => IM_STD_VIDEO_MODE);
package IM_SCROLL_MODE_IO is new ENUMERATION_IO
  (enum => IM_SCROLL_MODE);
package IM_CHARACTER_HEIGHT_IO is new ENUMERATION_IO
  (enum => IM_CHARACTER_HEIGHT);
size      : IM_STD_SIZE_MODE;
video     : IM_STD_VIDEO_MODE;
scroll    : IM_SCROLL_MODE;
char_ht   : IM_CHARACTER_HEIGHT;
status    : System.Word;

begin
  status := im_set_display_mode (IM_SIZE_MODE_80X25,
                                IM_STD_VIDEO_MODE_0,
                                IM_LCD_SCROLL_AT_25,
                                IM_DOUBLE_CHAR_HEIGHT);

  if im_isgood (status) then
    im_get_display_mode (size, video, scroll, char_ht, status);
    Put ("size :");
    IM_STD_SIZE_MODE_IO.Put (size);
    New_Line;

    Put ("video :");
    IM_STD_VIDEO_MODE_IO.Put (video);
    New_Line;

    Put ("scroll:");
    IM_SCROLL_MODE_IO.Put (scroll);
    New_Line;

    Put ("char_ht :");
    IM_CHARACTER_HEIGHT_IO.Put (char_ht);
    New_Line;
  else
    Put ("Set Disp Mode error = ");
    SYSWORD_IO.Put (status, Width => 8);
    New_Line;
  end if;
end setdpmode;
```

---

## ***im\_set\_follow\_cursor***

- Purpose:** When the display is in 80X25 mode, the viewport follows the cursor as it moves. This function enables or disables the follow-the-cursor feature.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
    function im\_set\_follow\_cursor (  
        follow\_status\_requested : IN IM\_CONTROL  
    ) return System.Word;
- IN Parameter:** The *follow\_status\_requested* parameter is one of the following constants:
- IM\_ENABLE    Enable follow-the-cursor mode  
IM\_DISABLE   Disable follow-the-cursor mode
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:** The display must be in 80X25 mode for this function to work correctly.
- See Also:** im\_get\_follow\_cursor

---

### ***Example***

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure setfolcr Is

    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
    in_char : Character := ' ';

begin
    status := im_set_follow_cursor (IM_DISABLE);
    if im_isgood (status) then
        Put_Line ("Follow cursor DISABLED");
        Put_Line ("q to quit");
        loop
            exit when in_char = 'q';
            Get(in_char);
        end loop;
    else
        Put ("Disable Foll Curs error = ");
        SYSWORD_IO.Put (status, Width => 8);
        New_Line;
```

### ***im\_set\_follow\_cursor***

```
end if;
in_char := ' ';
New_Line;
status := im_set_follow_cursor (IM_ENABLE);
if im_isgood (status) then
  Put_Line ("Follow cursor ENABLED");
  Put_Line ("q to quit");
  loop
    exit when in_char = 'q';
    Get(in_char);
  end loop;
else
  Put ("Enable Foll Curs error = ");
  SYSWORD_IO.Put (status, Width => 8);
  New_Line;
end if;
end setfolcr;
```

---

## ***im\_set\_input\_mode***

**Purpose:** This function clears the input buffers and sets the input manager to one of three modes: Wedge, Programmer, or Desktop.

**Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
Use Intrmeacd\_IO, Intrmecp\_IO;  
    procedure im\_set\_input\_mode (mode : IN IM\_MODE);

**IN Parameter:** The *mode* parameter is one of the following constants:

|               |                 |
|---------------|-----------------|
| IM_WEDGE      | Wedge mode      |
| IM_PROGRAMMER | Programmer mode |
| IM_DESKTOP    | Desktop mode    |

**OUT Parameter:** None.

**Return Value:** None.

**Notes:** There are three different reader input modes: Wedge, Programmer, and Desktop. These modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label input goes into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. Use Wedge mode when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions, such as TEXT\_IO.Get, to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader's power management capabilities. You will probably notice reduced battery life when the reader is in this mode compared to either Programmer or Desktop mode. For more information on power management, see Chapter 5, "Advanced Programming," in the *PSK Reference Manual*.

**Programmer Mode** Inputs are echoed to the screen. Reader commands are executed and saved. Use Programmer mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in Programmer mode.

### ***im\_set\_input\_mode***

**Desktop Mode** The application is responsible for retrieving and displaying input. Use Desktop mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes for the keyboard flags (Shift, Ctrl, Alt).

For more information about reader input modes, see Chapter 5, “Advanced Programming,” in the *PSK Reference Manual*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”

Upon exiting the program, set the input mode to IM\_WEDGE so that DOS will work as expected.

**See Also:** `im_get_input_mode`, `im_receive_input`

---

#### ***Example***

See example for `im_receive_input`.

---

## ***im\_set\_keyclick***

- Purpose:** Each time you press a key, the reader can emit a click. This function enables or disables the keyclick.
- Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
 Use Intrmechd\_IO, Intrmecp\_IO;  
     function im\_set\_keyclick (  
         keyclick\_status : IN IM\_CONTROL  
     ) return System.Word;
- IN Parameter:** The *keyclick\_status* parameter is one of the following constants:
- IM\_ENABLE    Enable the keyclick  
 IM\_DISABLE   Disable the keyclick
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- See Also:** im\_get\_keyclick

---

### ***Example***

```

With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure setkeyck Is

    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
    in_char : Character := ' ';

    begin
        status := im_set_keyclick (IM_DISABLE);
        if im_isgood (status)then

            Put_Line ("Keyclick DISABLED");
            Put_Line ("q to quit");
            loop
                exit when in_char = 'q';
                Get (in_char);
            end loop;
        else

            Put ("Disable Keyclick error = ");
            SYSWORD_IO.Put (status, Width => 8);
            New_Line;
        end if;
    end if;

```

### ***im\_set\_keyclick***

```
in_char := ' ';
New_Line;
status := im_set_keyclick (IM_ENABLE);

if im_isgood (status) then

    Put_Line ("Keyclick ENABLED");
    Put_Line ("q to quit");
    loop
        exit when in_char = 'q';
        Get (in_char);
    end loop;
else
    Put ("Enable Keyclick error = ");
    SYSWORD_IO.Put (status, Width => 8);
    New_Line;
end if;
end setkeyck;
```

---

## ***im\_set\_viewport\_lock***

- Purpose:** This procedure enables or disables the keys that move the viewport.
- Syntax:**

```

With Intrmechd_IO, Intrmecp_IO;
Use Intrmechd_IO, Intrmecp_IO;
    function im_set_viewport_lock (
        lock_status: IN IM_CONTROL
    ) return System.Word;

```
- IN Parameter:** The *lock\_status* parameter is one of the following constants:
- IM\_ENABLE    Lock the viewport  
IM\_DISABLE    Unlock the viewport
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:**

The display must be in 80X25 mode for this function to work correctly.

This function controls whether the viewport moves (unlocked) or does not move (locked) when the viewport movement keys are pressed.

This function has no effect on the JANUS 2050.
- See Also:** im\_get\_viewport\_lock, im\_set\_follow\_cursor

---

### ***Example***

```

With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure setview1 Is

    package STATUS_IO is new INTEGER_IO (System.Word);
    package SYSWORD_IO is new INTEGER_IO (System.Word);
    status : System.Word;
    in_char : Character := ' ';

begin
    status := im_set_viewport_lock (IM_DISABLE);

    if im_isgood (status)then
        Put_Line ("VP UNLOCKED");
        Put_Line ("q to quit");
    end if;
end setview1;

```

### ***im\_set\_viewport\_lock***

```
        loop
            exit when in_char = 'q';
            Get (in_char);
        end loop;
    else
        Put ("Unlock VP error = ");
        SYSWORD_IO.Put (status, Width => 8);
        New_Line;
    end if;

    in_char := ' ';
    New_Line;
    status := im_set_viewport_lock (IM_ENABLE);
    if im_isgood (status) then

        Put_Line ("VP LOCKED");
        Put_Line ("q to quit");
        loop
            exit when in_char = 'q';
            Get (in_char);
        end loop;
    else
        Put ("Lock VP error = ");
        SYSWORD_IO.Put (status, Width => 8);
        New_Line;
    end if;
end setview1;
```

---

## ***im\_set\_warm\_boot***

- Purpose:** This function enables or disables the **Ctrl-Alt-Del** warm boot key sequence. When disabled, the **Ctrl-Alt-Del** key sequence does not reboot the reader.
- Syntax:** With Intrmeacd\_IO, Intrmecp\_IO;  
 Use Intrmeacd\_IO, Intrmecp\_IO;  
     function im\_set\_warm\_boot (  
         warmboot\_status\_requested : IN IM\_CONTROL  
     ) return System.Word;
- IN Parameter:** The *warmboot\_status\_requested* parameter is one of the following constants:
- IM\_ENABLE    Enable **Ctrl-Alt-Del** warm boot  
 IM\_DISABLE   Disable **Ctrl-Alt-Del** warm boot
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- See Also:** im\_get\_warm\_boot
- 

### ***Example***

```
With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure setboot Is

package SYSWORD_IO is new INTEGER_IO (System.Word);
status : System.Word;
in_char : Character := ' ';

begin
    status := im_set_warm_boot (IM_DISABLE);
    if im_isgood (status)then
        Put_Line ("Warmboot DISABLED");
        Put_Line ("q to quit");
        loop
            exit when in_char = 'q';
            Get (in_char);
        end loop;
    else
        Put ("Disable warmboot err = ");
        SYSWORD_IO.Put (status, Width => 8);
        New_Line;
    end if;
```

### ***im\_set\_warm\_boot***

```
in_char := ' ';
New_Line;
status := im_set_warm_boot (IM_ENABLE);
if im_isgood (status)then
    Put_Line ("Warmboot ENABLED");
    Put_Line ("q to quit");
    loop
        exit when in_char = 'q';
        Get (in_char);
    end loop;
else
    Put ("Enable Warmboot err = ");
    SYSWORD_IO.Put (status, Width => 8);
    New_Line;
end if;
end setboot;
```

---

## ***im\_sound***

**Purpose:** This function generates a beep of specified pitch and duration. For example, use a soft beep for library use, a loud beep for manufacturing use, or a unique beep to distinguish between other readers.

**Syntax:**

```
With Intrmecd_IO, Intrmecp_IO;
Use Intrmecd_IO, Intrmecp_IO;
  function im_sound (
    pitch,      : IN System.Word;
    duration    : IN System.Word;
    volume      : IN System.Word
  ) return System.Word;
```

**IN Parameter:** The *pitch* parameter is the frequency of the beep you want the reader to make. The numeric range for *pitch* is from 20 to 20,000 Hz. You can also use one of the following constants:

|                   |         |
|-------------------|---------|
| IM_HIGH_PITCH     | 2400 Hz |
| IM_LOW_PITCH      | 1200 Hz |
| IM_VERY_LOW_PITCH | 600 Hz  |

The *duration* parameter is the length of the beep. The numeric range for *duration* is from 1 to 65,000 ms. You can also use one of the following constants:

|                   |       |
|-------------------|-------|
| IM_BEEP_DURATION  | 50 ms |
| IM_CLICK_DURATION | 4 ms  |

The *volume* parameter is one of the following constants:

|                      |                              |
|----------------------|------------------------------|
| IM_OFF_VOLUME        | Volume is off                |
| IM_QUIET_VOLUME      | Volume is quiet              |
| IM_NORMAL_VOLUME     | Volume is normal             |
| IM_LOUD_VOLUME       | Volume is loud               |
| IM_EXTRA_LOUD_VOLUME | Volume is extra loud         |
| IM_CURRENT_VOLUME    | Volume is the current volume |

**OUT Parameter:** None.

## *im\_sound*

**Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”

---

### **Example**

```
With System, Intrmechd_IO, Intrmecp_IO;  
Use System, Intrmechd_IO, Intrmecp_IO;
```

```
procedure sound Is
```

```
    C0 : Constant System.Word := 262;  
    D0 : Constant System.Word := 296;  
    E0 : Constant System.Word := 330;  
    F0 : Constant System.Word := 349;  
    G0 : Constant System.Word := 392;  
    A0 : Constant System.Word := 440;  
    B0 : Constant System.Word := 494;  
    C1 : Constant System.Word := 523;  
    D1 : Constant System.Word := 587;  
    E1 : Constant System.Word := 659;  
    F1 : Constant System.Word := 698;  
    G1 : Constant System.Word := 784;  
    A1 : Constant System.Word := 880;  
    B1 : Constant System.Word := 988;  
    EIGHTH : Constant System.Word := 125;  
    QUARTER : Constant System.Word := 250;  
    HALF : Constant System.Word := 500;  
    WHOLE : Constant System.Word := 1000;  
    END_NOTE : Constant System.Word := 0;  
    type song is array (1..8, 1..3) of System.Word;  
    this_song : song :=  
        (  
            (C1, HALF, 2),  
            (G0, HALF, 2),  
            (A0, HALF, 2),  
            (E0, HALF, 2),  
            (F0, HALF, 2),  
            (E0, QUARTER, 2),  
            (D0, QUARTER, 2),  
            (C0, WHOLE, 2) );  
    note : Integer;  
    status : System.Word;
```

```
begin  
    for note in 1..8 loop  
        status := im_sound (this_song(note,1), this_song(note,2), this_song(note,3));  
    end loop;  
end sound;
```

---

## ***im\_standby\_wait***

- Purpose:** This function requests that reader services wait in standby mode for a specific period of time. You use this function to suspend the reader for a length of time to save the battery power.
- Syntax:**
- ```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
    function im_standby_wait (  
        timeout : IN System.Word  
    ) return System.Word;
```
- IN Parameters:** The *timeout* parameter is the amount of time to wait in standby mode. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.
- The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:
- ```
IM_ZERO_TIMEOUT      No wait  
IM_INFINITE_TIMEOUT  Wait forever
```
- If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" in Chapter 2, "Working With Ada."
- See Also:** None.

### *im\_standby\_wait*

---

#### **Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure standby Is
    status : System.Word;
begin
    -- RWTSR must be installed for this to work correctly
    Put_Line ("Start waiting for 5 seconds");
    status := im_standby_wait (5000);
    Put_Line ("Done waiting for 5 seconds");
end standby;
```

---

## ***im\_transmit\_buffer***

**Purpose:** This function transmits the contents of a data buffer through a designated communications port. This function continues operating until the buffer transmission is complete or until an error status is detected.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;
Use Intrmeacd_IO, Intrmecp_IO;
  function im_transmit_buffer (
    port      : IN IM_COM_PORT;
    user_length : IN System.Word;
    buffer     : IN System.Address;
    timeout    : IN System.Word
  ) return System.Word;
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *user\_length* parameter is the length of the data string that you want to transmit.

The *buffer* parameter is the address of the string that you want to transmit.

The *timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

### ***im\_transmit\_buffer***

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** `im_receive_buffer`, `im_transmit_buffer_no_wait`, `im_transmit_buffer_noprot`

---

#### ***Example***

See example for `im_receive_buffer`.

---

## ***im\_transmit\_buffer\_no\_wait***

**Purpose:** This function transmits the contents of the transmit buffer and passes control back to its client.

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;
Use Intrmechd_IO, Intrmecp_IO;
    function im_transmit_buffer_no_wait (
        port      : IN IM_COM_PORT;
        data_struct : IN System.Address
    ) return System.Word;
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *data\_struct* parameter is the address of the IM\_COM\_DATA\_BUFFER record, which contains transmission information.

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

**Notes:** This function differs from *im\_transmit\_buffer* in that the client must set the buffer structure and monitor the buffer status until transmission is complete.

Use this function for multiple buffer transmissions in conjunction with checking the status in *data\_struct*.

You must install a protocol handler to use this function.

You must build and maintain the IM\_COM\_DATA\_BUFFER record.

**See Also:** *im\_transmit\_buffer\_noprot*, *im\_cancel\_tx\_buffer*

---

### ***Example***

See example for *im\_receive\_buffer\_no\_wait*.

## *im\_transmit\_buffer\_noprot*

---

### ***im\_transmit\_buffer\_noprot***

**Purpose:** This function transmits a buffer without protocol and sends only the specified number of characters.

**Syntax:**

```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
function im_transmit_buffer_noprot (  
    port      : IN IM_COM_PORT;  
    user_length : IN System.Word;  
    buffer     : IN System.Address;  
    timeout    : IN System.Word  
) return System.Word;
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *user\_length* parameter is the maximum number of characters to transmit.

The *buffer* parameter is the address of the string to transmit.

The *timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The numeric range for *timeout* is from 1 to 65,534 ms. You can also use one of the following constants:

|                     |              |
|---------------------|--------------|
| IM_ZERO_TIMEOUT     | No wait      |
| IM_INFINITE_TIMEOUT | Wait forever |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler other than PHPCSTD.EXE to use this function.

If an existing transmit client is linked to the host, you must issue a cancel command first.

**See Also:** `im_transmit_buffer_no_wait`, `im_cancel_tx_buffer`, `im_transmit_buffer`

---

**Example**

See example for `im_receive_buffer_noprot`.

## *im\_transmit\_byte*

---

### ***im\_transmit\_byte***

**Purpose:** This function transmits one byte of data out from the designated communications port. This function is identical to MS-DOS INT 14H Service 01H.

**Syntax:**

```
With Intrmecd_IO, Intrmecp_IO;  
Use Intrmecd_IO, Intrmecp_IO;  
    function im_transmit_byte (  
        port          : IN IM_COM_PORT;  
        transmit_byte : IN Character  
    ) return System.Word;
```

**IN Parameter:** The *port* parameter identifies the communications port as follows:

|         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |

The *transmit\_byte* parameter is the byte of data to transmit.

**OUT Parameter:** None.

**Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

Intermec recommends using *im\_transmit\_buffer* (with a *user\_length* of one) instead of using *im\_transmit\_byte*.

You can use this function for an acknowledgment.

**See Also:** *im\_receive\_byte*, *im\_transmit\_buffer*

**Example**

```

With System, DosCall, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, DosCall, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure txbyte Is

  status      : System.Word;
  TX_byte     : Character := ' ';
  eom_char    : Character;
  setup_comm_status : Integer;

  function setup_com (port : System.Word) return Integer Is
    -- This function sets up the communications port for RS232,
    -- 9600 baud, even parity, 7 data bits, and 1 stop bit using
    -- a DosCall procedure.

    RS232      : Constant Integer := 16#14#;
    B9600      : Constant System.Word := 16#E0#;
    EVEN       : Constant System.Word := 16#18#;
    WORD7      : Constant System.Word := 16#02#;
    STOP1      : Constant System.Word := 16#00#;
    Regs       : DosCall.Simple_Regs;
    setup       : System.Word;

  begin
    setup := 0;
    if ((port /= 0) and (port /= 1)) then
      return -1;
    end if;
    setup := B9600 + WORD7 + EVEN + STOP1;
    Regs.AX := setup;
    Regs.DX := port;
    DosCall.Simple_Int_Call (RS232, Regs);
    return 0; -- Good return
  end setup_com;

  --***** main program starts here *****
begin
  -- Phimec protocol handler must NOT be installed to run this routine
  -- get the comm environment ready

  setup_comm_status := setup_com(0);
  if setup_comm_status = 0 then
    eom_char := 'q';
    Put_Line("Enter characters at");
    Put_Line("Janus keypad");
    Put_Line("q to end");

    TX_byte := Ascii.NUL;
    loop
      Get (TX_byte);
      if TX_byte = Ascii.CR then
        New_Line;
      end if;
      exit when TX_byte = eom_char;

      -- Transmit bytes until 'q' is entered
      status := im_transmit_byte (IM_COM1, TX_byte);
    end loop;
  end if;
end txbyte;

```

### ***im\_transmit\_byte***

```
        if (im_iserror(status)) then
            Put ("tx byte status = ");
            im_message (status);
            New_Line;
        end if;
    end loop;
    New_Line;
    Put_Line ("Transmit done");
else
    Put_Line("Com setup failed");
    im_message (System.Word(setup_comm_status));
    New_Line;
end if;
end txbyte;
```

---

## ***im\_unlink\_comm***

- Purpose:** This function removes the link between the Reader Wedge function and a designated communications port. After this function executes, the Reader Wedge is not notified of receive buffer functions.
- You only need to use this procedure one time, at the end of your program.
- Syntax:**
- ```
With Intrmeacd_IO, Intrmecp_IO;  
Use Intrmeacd_IO, Intrmecp_IO;  
  function im_unlink_comm (  
    port : IN IM_COM_PORT  
  ) return System.Word;
```
- IN Parameter:** The *port* parameter identifies the communications port as follows:
- |         |                               |
|---------|-------------------------------|
| IM_COM1 | COM1                          |
| IM_COM2 | COM2, scanner (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                |
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, “Status Codes.”
- Notes:** You must install a protocol handler to use this function.
- You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” in Chapter 2, “Working With Ada.”
- See Also:** im\_link\_comm

---

### ***Example***

See example for im\_irl\_y.

*im\_viewport\_end*

---

## ***im\_viewport\_end***

- Purpose:** This procedure sets the viewport to the lower right corner (end) of the virtual display.
- Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
    procedure im\_viewport\_end;
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** None.
- Notes:** This function has no effect on the JANUS 2050.
- See Also:** im\_cursor\_to\_viewport, im\_viewport\_home, im\_viewport\_page\_down, im\_viewport\_page\_up, im\_viewport\_to\_cursor, im\_viewport\_move

---

### ***Example***

```
With System, Intrmechd_IO, Intrmecp_IO;  
Use System, Intrmechd_IO, Intrmecp_IO;  
  
procedure view_end Is  
begin  
    im_viewport_end;  
end view_end;
```

---

## ***im\_viewport\_getxy***

- Purpose:** This function retrieves the column and row of the upper left corner of the viewport.
- Syntax:**
- ```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
  procedure im_viewport_getxy (  
    row      : OUT System.Word;  
    column   : OUT System.Word;  
    status_code : OUT System.Word);
```
- IN Parameter:** None.
- OUT Parameter:** The *row* parameter retrieves the row value (Y-coordinate) of viewport.
- The *column* parameter retrieves the column value (X-coordinate) of viewport.
- The *status\_code* parameter is a standard status code listed in Appendix A, "Status Codes."
- Return Value:** None.
- Notes:** This function is valid only when the display is in 80X25 mode.
- This function has no effect on the JANUS 2050.
- See Also:** im\_viewport\_setxy, im\_viewport\_move, im\_viewport\_page\_up, im\_viewport\_page\_down, im\_viewport\_to\_cursor, im\_viewport\_end, im\_viewport\_home.

### *im\_viewport\_getxy*

---

#### **Example**

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;
```

```
procedure vpgetxy Is
```

```
    package SYSWORD_IO is new INTEGER_IO (System.Word);  
    row      : System.Word;  
    col      : System.Word;  
    status   : System.Word;  
    wait_status : System.Word;
```

```
begin
```

```
    im_viewport_getxy (row, col, status);  
    Put_Line ("Getting viewport");  
    if im_isgood(status) then  
        Put_Line ("Viewport:");  
        Put (" X :");  
        SYSWORD_IO.Put (row, Width => 3);  
        New_Line;  
        Put (" Y :");  
        SYSWORD_IO.Put (col, Width => 3);  
        New_Line;  
    else  
        Put_Line ("Viewport GetXY Error:");  
        SYSWORD_IO.Put (status, Width => 8);  
        New_Line;  
    end if;
```

```
    Put_Line ("Setting viewport");  
    Put_Line ("row to 8");  
    Put_Line ("col to 10");  
    row := 8;  
    col := 10;
```

```
    im_viewport_setxy (row, col, status);  
    wait_status := im_standby_wait(3000);  
    if im_isgood(status) then  
        Put ("Viewport:");  
        New_Line;  
        Put (" X :");  
        SYSWORD_IO.Put (row, Width => 3);  
        New_Line;  
        Put (" Y :");  
        SYSWORD_IO.Put (col, Width => 3);  
        New_Line;  
    else  
        Put_Line ("Viewport SetXY Error:");  
        SYSWORD_IO.Put (status, Width => 8);  
        New_Line;  
    end if;  
end vpgetxy;
```

---

## ***im\_viewport\_home***

**Purpose:** This function sets the viewport to the upper left corner (home) of the virtual display.

**Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
    procedure im\_viewport\_home;

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** im\_cursor\_to\_viewport, im\_viewport\_end, im\_viewport\_page\_down,  
im\_viewport\_page\_up, im\_viewport\_to\_cursor, im\_viewport\_move

---

### ***Example***

```
With System, Intrmechd_IO, Intrmecp_IO;  
Use System, Intrmechd_IO, Intrmecp_IO;  
  
procedure vp_home Is  
begin  
    im_viewport_home;  
end vp_home;
```

## *im\_viewport\_move*

---

### ***im\_viewport\_move***

**Purpose:** This function sets the viewport row and column to an offset from the current value.

**Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
  procedure im_viewport_move (  
    direction      : IN IM_VIEWPORT_DIRECTION;  
    distance       : IN System.Word;  
    row            : OUT System.Word;  
    column         : OUT System.Word;  
    status_code    : OUT System.Word);
```

**IN Parameter:** The *direction* is one of the following values:

|                   |   |
|-------------------|---|
| IM_VIEWPORT_LEFT  | 0 |
| IM_VIEWPORT_RIGHT | 1 |
| IM_VIEWPORT_UP    | 2 |
| IM_VIEWPORT_DOWN  | 3 |

The *distance* parameter indicates the number of units to move the viewport and is either a numeric value between 1 and 70 or IM\_DEFAULT\_DISTANCE.

If the distance parameter is IM\_DEFAULT\_DISTANCE, the default step size is used.

The distance moved is a configurable parameter. For more information on configuring the viewport, see your JANUS user's manual.

**OUT Parameter:** The *row* parameter retrieves the row number to which the viewport has moved.

The *column* parameter retrieves the column number to which the viewport has moved.

The *status\_code* parameter is a standard status code listed in Appendix A, "Status Codes."

**Return Value:** None.

**Notes:** The (*Row*, *Column*) pair represents the upper left corner of the viewport being displayed.

The minimum value for both the *Row* and *Column* is (0,0), which is the upper left corner of the virtual window. The maximum value is determined by the video mode and the number of lines and columns displayed.

For example, for the normal video mode 3 (80X25 display) with a 20X16 display size, the maximum value of *Row* is 9 (25 minus 16) and the maximum value of *Column* is 60 (80 minus 20).

Do not wraparound when changing the row and column viewport settings. They are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *row* and *col*.

This function has no effect on the JANUS 2050.

**See Also:** im\_viewport\_end, im\_viewport\_home, im\_viewport\_page\_down, im\_viewport\_page\_up, im\_viewport\_to\_cursor, im\_cursor\_to\_viewport

---

### Example

```
With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure vp_move is

  package STATUS_IO is new INTEGER_IO (System.Word);
  package SYSWORD_IO is new INTEGER_IO (System.Word);
  direction : IM_VIEWPORT_DIRECTION;
  dir_type   : Character := ' ';
  distance   : System.Word;
  row        : System.Word;
  col        : System.Word;
  status     : System.Word;

begin
  Put_Line ("Enter direction ");
  Put_Line (" 1 : up");
  Put_Line (" 2 : down");
  Put_Line (" 3 : left");
  Put_Line (" 4 : right");
  Put_Line (">>> ");
  Get (dir_type);
  case dir_type is
    when '1' => direction := IM_VIEWPORT_UP;
    when '2' => direction := IM_VIEWPORT_DOWN;
    when '3' => direction := IM_VIEWPORT_LEFT;
    when '4' => direction := IM_VIEWPORT_RIGHT;
```

### ***im\_viewport\_move***

```
        when others => direction := IM_VIEWPORT_RIGHT;
    end case;

    Put_Line ("Enter distance : ");
    Put_Line (">>> ");
    SYSWORD_IO.Get (distance);
    New_Line;
    im_viewport_move (direction, distance, row, col, status);
    if im_issuccess (status) then

        Put ("Row ");
        SYSWORD_IO.Put (row, WIDTH => 4);
        New_Line;
        Put ("Col ");
        SYSWORD_IO.Put (col, WIDTH => 4);
        New_Line;
    else
        Put ("VP Move Error = ");
        SYSWORD_IO.Put (status, WIDTH => 8);
        New_Line;
    end if;
end vp_move;
```

---

***im\_viewport\_page\_down***

**Purpose:** This procedure moves the viewport down one viewport length.

**Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
    procedure im\_viewport\_page\_down;

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** im\_cursor\_to\_viewport, im\_viewport\_end, im\_viewport\_home,  
im\_viewport\_page\_up, im\_viewport\_to\_cursor, im\_viewport\_move,  
im\_viewport\_setxy

---

***Example***

```
With System, Intrmechd_IO, Intrmecp_IO;  
Use System, Intrmechd_IO, Intrmecp_IO;  
  
procedure vp_down Is  
begin  
    im_viewport_page_down;  
end vp_down;
```

### *im\_viewport\_page\_up*

---

## ***im\_viewport\_page\_up***

**Purpose:** This procedure moves the viewport up one viewport length.

**Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
    procedure im\_viewport\_page\_up;

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** im\_cursor\_to\_viewport, im\_viewport\_end, im\_viewport\_home,  
im\_viewport\_page\_down, im\_viewport\_to\_cursor, im\_viewport\_move,  
im\_viewport\_setxy

---

### ***Example***

```
With System, Intrmechd_IO, Intrmecp_IO;  
Use System, Intrmechd_IO, Intrmecp_IO IO;  
  
procedure view_up Is  
  
begin  
    im_viewport_page_up;  
end view_up;
```

---

## ***im\_viewport\_setxy***

- Purpose:** This function sets the viewport row and column to a specific value when moving between two screens.
- Syntax:**

```
With Intrmechd_IO, Intrmecp_IO;  
Use Intrmechd_IO, Intrmecp_IO;  
    function im_viewport_setxy (  
        row      : IN OUT System.Word;  
        colum    : IN OUT System.Word  
    ) return System.Word;
```
- IN Parameter:** None.
- IN OUT**           The *row* parameter sets the row value (Y-coordinate) of the viewport.  
  
                    The *colum* parameter sets the column value (X-coordinate) of the viewport.
- OUT Parameter:** None.
- Return Value:** This function returns one of the standard status codes listed in Appendix A, "Status Codes."
- Notes:**           The (*row*, *col*) pair represents the upper left corner of the viewport being displayed. The minimum values for both the *row* and *col* are (0,0), which is the upper left corner of the virtual window. For the normal video mode 3 (80X25 display) with 20X6 display character size, the maximum value of *row* is 9 (25 minus 16) and the maximum value of *col* is 60 (80 minus 20).  
  
                    The row and column viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *row* and *col*.  
  
                    This function has no effect on the JANUS 2050.
- See Also:**       im\_viewport\_move, im\_viewport\_getxy

---

### ***Example***

See example for im\_viewport\_getxy.

## *im\_viewport\_to\_cursor*

---

### ***im\_viewport\_to\_cursor***

**Purpose:** This function centers the viewport around the cursor.

**Syntax:** With Intrmechd\_IO, Intrmecp\_IO;  
Use Intrmechd\_IO, Intrmecp\_IO;  
    procedure im\_viewport\_to\_cursor;

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** im\_cursor\_to\_viewport, im\_viewport\_end, im\_viewport\_home,  
im\_viewport\_page\_down, im\_viewport\_to\_cursor, im\_viewport\_move,  
im\_viewport\_setxy

---

### ***Example***

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
Use System, Text_IO, Intrmechd_IO, Intrmecp_IO;  
  
procedure vp2cursr Is  
  
  package STATUS_IO is new INTEGER_IO (System.Word);  
  row, col : System.Word;  
  status   : System.Word;  
  
  begin  
    im_viewport_end;  
    im_viewport_getxy (row,col,status);  
    status := im_standby_wait (5000);  
    im_viewport_to_cursor;  
  
    --show that viewport moved to end, then back to cursor  
    status := im_standby_wait (5000);  
    STATUS_IO.Put (row);  
    STATUS_IO.Put (col);  
    New_Line;  
  end vp2cursr;
```



## ***Appendix A: Status Codes***



*This appendix lists the status code hex values and error messages. Use the tables in this appendix to look up the meaning of a specific status code.*

## Status Code Bit Values

Most of the PSK functions return status codes. You can use the codes to test for error conditions that your application will act upon.

How you test for the status codes depends on the complexity of the function returning the status and your application needs. In some cases, you may use the status code macros discussed in “Status Code Macros” in Chapter 2 to check the severity level. In other cases, you may want to check the exact status code value.

Each status code is a 16-bit word structured as follows:

|    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 15 | 14 | 13 | 12 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| s  | s  | f  | f  | f  | f | f | m | m | m | m | m | m | m | m |

JPSK.002

where:

*s* is severity code: 00 = Success  
 10 = Error  
 01 = Warning  
 11 = Fatal

*f* is the subsystem code, explained later in this appendix.

*m* is the message code that identifies the error or warning condition.

The status codes are IM\_USHORT (unsigned short) values.

The tables in this appendix list the hex value of the message codes.

## ***Status Codes Listed Numerically***

---

The following table lists the return codes and the error message text provided by `im_message` and `imMessage`. For each message, there is an associated status return code, subsystem, and severity.

Some messages are abbreviated to fit the display and to save memory on the JANUS reader. The table includes an easy-to-read version of the abbreviated messages.

---

### ***Status Codes and Error Messages Listed in Numerical Order***

| Hex Code | Severity | Subsystem | Reader Message and Description                               |
|----------|----------|-----------|--------------------------------------------------------------|
| 0000     | Good     | NO        | Request successful                                           |
| 0001     | Good     | NO        | Prohibited                                                   |
| 0100     | Good     | RS        | Rservice request success<br>Reader services successful       |
| 0103     | Good     | RS        | Rservice resume success<br>Reader services resume successful |
| 0200     | Good     | CM        | Request success<br>Request successful                        |
| 0201     | Good     | CM        | Read End Of Record<br>End of record reached                  |
| 0202     | Good     | CM        | Read End Of File<br>End of file reached                      |
| 0300     | Good     | SC        | Scan success<br>Scan successful                              |
| 0400     | Good     | DC        | Success<br>Successful command                                |
| 0401     | Good     | DC        | Symbology already enabled<br>Symbology is already enabled    |
| 0402     | Good     | DC        | Symbology not enabled<br>Symbology is not enabled            |
| 040A     | Good     | DC        | Good decode<br>Successful decode                             |
| 040B     | Good     | DC        | Intermediate row re-read<br>Intermediate row reread          |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                   |
|----------|----------|-----------|--------------------------------------------------------------------------------------------------|
| 040C     | Good     | DC        | Intermediate decoded<br>Intermediate raw decoded                                                 |
| 0421     | Good     | DC        | Default command symbology                                                                        |
| 0422     | Good     | DC        | Mixed ASCII format                                                                               |
| 0500     | Good     | RW        | RW success<br>Reader Wedge successful                                                            |
| 0505     | Good     | RW        | No rdr cmds parsed<br>No reader commands parsed                                                  |
| 0506     | Good     | RW        | Valid rdr cmds parsed<br>Valid reader commands parsed                                            |
| 0509     | Good     | RW        | Accumulating rdr cmd<br>Accumulating reader command                                              |
| 050A     | Good     | RW        | Rdr cmd override<br>Reader command override                                                      |
| 050B     | Good     | RW        | Rdr cmd enter accum<br>Reader command enter accumulation                                         |
| 050C     | Good     | RW        | Rdr cmd exit accum<br>Reader command exit accumulation                                           |
| 050D     | Good     | RW        | Accumulate multi-read labels<br>Accumulating multiread labels                                    |
| 0510     | Good     | RW        | ENTER rdr cmd parsed<br>An Enter reader command was parsed                                       |
| 0513     | Good     | RW        | Protected field rdr cmd parsed<br>Protected field was parsed                                     |
| 0517     | Good     | RW        | Keycode label parsed<br>Keycode label was parsed                                                 |
| 0518     | Good     | RW        | Isolated ENTER cmd parsed<br>An isolated Enter command was parsed                                |
| 0519     | Good     | RW        | Good rdr cmd on exit accum<br>A reader command was parsed successfully on exit from accumulation |
| 051A     | Good     | RW        | Good rdr cmd on ENTER<br>A reader command was parsed successfully when Enter was parsed          |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| <b>Hex Code</b> | <b>Severity</b> | <b>Subsystem</b> | <b>Reader Message and Description</b>                                       |
|-----------------|-----------------|------------------|-----------------------------------------------------------------------------|
| 051C            | Good            | RW               | Enter accum parsed<br>An Enter Accumulate has been parsed when accumulating |
| 051D            | Good            | RW               | Exit multi-read<br>A label terminating a multiple-read sequence was scanned |
| 051E            | Good            | RW               | Enter multi-read<br>A label beginning a multiple-read sequence was scanned  |
| 0521            | Good            | RW               | No comms status<br>No communications status to report                       |
| 0525            | Good            | RW               | Rdr cmds parsed<br>Reader commands forwarded to the application were parsed |
| 0600            | Good            | CU               | Comm success<br>Communications operation success                            |
| 0601            | Good            | CU               | Comm Buff done<br>Communications buffer done                                |
| 0800            | Good            | PM               | PM success<br>Power management successful                                   |
| 0A00            | Good            | TM               | Timer success<br>Timer operation successful                                 |
| 0B00            | Good            | BP               | Beep success<br>Beeper call successful                                      |
| 0E00            | Good            | IM               | String Extract Complete                                                     |
| 0E01            | Good            | IM               | String Append complete                                                      |
| 0E02            | Good            | IM               | Search string found                                                         |
| 0E03            | Good            | IM               | String Copy complete                                                        |
| 0E04            | Good            | IM               | Operation success<br>Successful operation                                   |
| 0F00            | Good            | LG               | Successful operation                                                        |
| 1000            | Good            | KB               | Expanded keypad success<br>Expanded keyboard buffer successful              |
| 100A            | Good            | KB               | Expanded buffer enabled                                                     |
| 100B            | Good            | KB               | Expanded buffer disabled                                                    |
| 1100            | Good            | SS               | System Config success<br>System configuration successful                    |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                               |
|----------|----------|-----------|----------------------------------------------------------------------------------------------|
| 1200     | Good     | KP        | Keypad success<br>Successful keypad operation                                                |
| 1300     | Good     | DP        | Display success<br>Successful display operation                                              |
| 1A00     | Good     | EX        | Execution success<br>Transaction successful                                                  |
| 1A01     | Good     | EX        | ACK received<br>Transaction successful, ACK received                                         |
| 1A10     | Good     | EX        | Data received<br>Received host message on Read operation                                     |
| 4200     | Warning  | CM        | Not all config items copied<br>Not all configuration items copied                            |
| 4201     | Warning  | CM        | Rdr Cmd terminated config cmd<br>Reader command terminated configuration command string      |
| 4202     | Warning  | CM        | Client should not be notified                                                                |
| 4502     | Warning  | RW        | Input timeout                                                                                |
| 4503     | Warning  | RW        | No input data                                                                                |
| 450E     | Warning  | RW        | The app should be notified<br>The application should be notified                             |
| 4529     | Warning  | RW        | Input from source other than requested<br>Input from source is other than the ones requested |
| 452A     | Warning  | RW        | RWTSR already loaded                                                                         |
| 4600     | Warning  | CU        | Warning buff canceled<br>Buffer canceled                                                     |
| 4601     | Warning  | CU        | Comm Timeout warning<br>Communication timeout                                                |
| 4602     | Warning  | CU        | Comm had no client to cancel<br>Communication had no client to cancel                        |
| 4603     | Warning  | CU        | Comm Util no PH for config<br>No protocol handler to configure                               |
| 4604     | Warning  | CU        | Prot handler not loaded<br>Protocol handler is not yet loaded                                |
| 4605     | Warning  | CU        | Prot handler already receiving<br>Protocol handler is already receiving                      |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                     |
|----------|----------|-----------|------------------------------------------------------------------------------------|
| 4606     | Warning  | CU        | PH not active for link request<br>Protocol handler is not active for link request  |
| 4A00     | Warning  | TM        | Timer not active<br>Timer not currently active                                     |
| 5001     | Warning  | KB        | Expanded buffer installed<br>Expanded keyboard buffer installed or disabled        |
| 5201     | Warning  | KP        | Backdoor Comms failed<br>Backdoor communications failure                           |
| 5A02     | Warning  | EX        | NAK received<br>Transaction failed, NAK received                                   |
| 5A07     | Warning  | EX        | No more log records<br>Standby file is empty                                       |
| 5A11     | Warning  | EX        | Received data truncated<br>Data was truncated                                      |
| 5A12     | Warning  | EX        | Fields overflow<br>Too many fields                                                 |
| 5A20     | Warning  | EX        | Record logged<br>Record stored in standby file successfully                        |
| 5A21     | Warning  | EX        | Logged but upload error<br>Record stored in standby file, but upload standby error |
| 8100     | Error    | RS        | Rservice invalid request code<br>Invalid function code received                    |
| 8101     | Error    | RS        | Rservice not installed<br>Reader services is not installed                         |
| 8102     | Error    | RS        | Rservice resume failed<br>Reader services resume failed                            |
| 8103     | Error    | RS        | Rservice or App out of date<br>Reader services or application is out of date       |
| 8104     | Error    | RS        | RWTSR not connected<br>Reader Wedge TSR is not installed                           |
| 8200     | Error    | CM        | Invalid Object                                                                     |
| 8201     | Error    | CM        | Invalid subfunction                                                                |
| 8202     | Error    | CM        | Invalid Param length<br>Invalid parameter length                                   |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                      |
|----------|----------|-----------|-------------------------------------------------------------------------------------|
| 8203     | Error    | CM        | Invalid Param val<br>Invalid parameter value                                        |
| 8204     | Error    | CM        | Invalid Param 1 value<br>Invalid first parameter value                              |
| 8205     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and no check digit)   |
| 8206     | Error    | CM        | Invalid param 2 value<br>Invalid second parameter value                             |
| 8207     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and full ASCII)       |
| 8208     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and mixed full ASCII) |
| 8209     | Error    | CM        | Invalid Param 3 value<br>Invalid third parameter value                              |
| 820A     | Error    | CM        | Invalid Codabar cfg<br>Invalid Codabar configuration (ABC and discard start/stop)   |
| 820B     | Error    | CM        | Protocol not loaded                                                                 |
| 820C     | Error    | CM        | Invalid comm or protcl<br>Invalid port or protocol specified                        |
| 820D     | Error    | CM        | No end quote<br>No ending quote found                                               |
| 820E     | Error    | CM        | No dbl quote<br>No double quote (might be missing an opening quote)                 |
| 820F     | Error    | CM        | Invalid parser state                                                                |
| 8210     | Error    | CM        | Invalid config cmd<br>Invalid configuration command                                 |
| 8211     | Error    | CM        | Client returned err<br>Client deemed configuration command invalid                  |
| 8212     | Error    | CM        | Invalid beep duration                                                               |
| 8213     | Error    | CM        | Invalid beep freq<br>Invalid beep frequency                                         |
| 8214     | Error    | CM        | Invalid beep vol<br>Invalid beep volume                                             |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                    |
|----------|----------|-----------|---------------------------------------------------------------------------------------------------|
| 8215     | Error    | CM        | Beep vol alrdy off<br>Beep volume already off                                                     |
| 8216     | Error    | CM        | Beep vol alrdy on<br>Beep volume already on                                                       |
| 8217     | Error    | CM        | Invalid beep specifier<br>Invalid beep specifier (must be “L” or “H”)                             |
| 8218     | Error    | CM        | Inappropriate protcl<br>Inappropriate configuration for the current protocol                      |
| 8219     | Error    | CM        | BIOS rejected set config<br>BIOS rejected the set configuration command                           |
| 821A     | Error    | CM        | Bld string too small<br>Configuration command string object is too small                          |
| 821B     | Error    | CM        | Invalid Build cmd<br>Configuration ID is invalid                                                  |
| 821C     | Error    | CM        | Invalid Build param<br>Invalid build parameter                                                    |
| 821D     | Error    | CM        | No Build Func<br>No build function                                                                |
| 821E     | Error    | CM        | No more build entries                                                                             |
| 821F     | Error    | CM        | No more WM bld entries<br>No more build entries in wedge lookup table                             |
| 8220     | Error    | CM        | No more WM bld entries<br>No more build entries in wedge lookup table for “build next” WM command |
| 8221     | Error    | CM        | No LUM key entries<br>No entries found in the LUM key table                                       |
| 8222     | Error    | CM        | WM entry not found<br>No match in lookup table for specified character                            |
| 8223     | Error    | CM        | Invalid Temp config<br>At least one parameter rejected by client (see JANUS.ERR)                  |
| 8224     | Error    | CM        | Config Item not found<br>Configuration item is not found                                          |
| 8225     | Error    | CM        | File Open err<br>File open error                                                                  |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                       |
|----------|----------|-----------|------------------------------------------------------------------------------------------------------|
| 8226     | Error    | CM        | File Write err<br>File write error                                                                   |
| 8227     | Error    | CM        | File Read err<br>File read error                                                                     |
| 8228     | Error    | CM        | Read record too large<br>Record too large to read                                                    |
| 8229     | Error    | CM        | Invalid Hex Char in esc seq<br>Invalid hex character found in the escape sequence                    |
| 822A     | Error    | CM        | Invalid esc sequence<br>Invalid escape sequence                                                      |
| 822B     | Error    | CM        | Read file not opened<br>Read attempted on a file that was not opened                                 |
| 822C     | Error    | CM        | Write file not opened<br>Write attempted on a file that was not opened                               |
| 822D     | Error    | CM        | File close op fail<br>File close operation failed                                                    |
| 822E     | Error    | CM        | Attempt close non-open file<br>Attempt made to close a file that was not opened                      |
| 822F     | Error    | CM        | Invalid default config<br>Invalid default configuration                                              |
| 8230     | Error    | CM        | RF back not installd<br>RF back is not installed                                                     |
| 8231     | Error    | CM        | RF driver not installd<br>RF protocol handler is not installed                                       |
| 8232     | Error    | CM        | Path (IMPATH) not found<br>Path specified by IMPATH is not found                                     |
| 8233     | Error    | CM        | Bld BIOS val out of range<br>BIOS returned an invalid value during build                             |
| 8234     | Error    | CM        | Config Item not allowed by Prot<br>Configuration item is not allowed for the selected protocol       |
| 8235     | Error    | CM        | Config Item value out of range<br>Configuration item value is out of range for the selected protocol |
| 8236     | Error    | CM        | Invalid 4th param value<br>Invalid fourth parameter value                                            |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                       |
|----------|----------|-----------|--------------------------------------------------------------------------------------|
| 8237     | Error    | CM        | Invalid 5th param value<br>Invalid fifth parameter value                             |
| 8238     | Error    | CM        | Invalid 6th param value<br>Invalid sixth parameter value                             |
| 8239     | Error    | CM        | Can't open JANUS.ERR<br>Unable to open JANUS.ERR file                                |
| 823A     | Error    | CM        | Radio.cfg has invalid checksum<br>File checksum is invalid                           |
| 823B     | Error    | CM        | Invalid RF freq in RF config<br>Invalid RF frequency specified                       |
| 823C     | Error    | CM        | Invalid RF channel in RF config<br>Invalid channel specified                         |
| 823D     | Error    | CM        | CM_ENCODED_RF_DATA_S != CM_NUM_RF_CHANNELS<br>Structure mismatch                     |
| 823E     | Error    | CM        | Allowed RF channels after unallowed channel<br>Specified RF channel is not allowed   |
| 823F     | Error    | CM        | Ping cmd not allowed here<br>Ping command not allowed here                           |
| 8240     | Error    | CM        | Ping cmd not xmitted, prot busy<br>Ping command not transmitted (protocol busy)      |
| 8241     | Error    | CM        | Missing end of config cmd<br>Missing end of configuration command                    |
| 8242     | Error    | CM        | RF freq doesn't match RF back type<br>RF frequency does not match the RF back        |
| 8243     | Error    | CM        | Can't read RF back config data<br>Unable to read configuration data from the RF back |
| 8244     | Error    | CM        | Unallowed video display mode<br>Video display mode is not allowed                    |
| 8245     | Error    | CM        | Cmd source not allowed<br>Command source is not allowed                              |
| 8246     | Error    | CM        | Invalid 7th param value<br>Invalid seventh parameter value                           |
| 8300     | Error    | SC        | Scanner load err<br>Scanner load error                                               |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                |
|----------|----------|-----------|-------------------------------------------------------------------------------|
| 8301     | Error    | SC        | Insufficient timers<br>Not enough timers for the scanner to initialize        |
| 8302     | Error    | SC        | Insufficient memory<br>Insufficient memory for the scanner to initialize      |
| 8303     | Error    | SC        | IPM connect failed<br>Scanner not connected to power management               |
| 8304     | Error    | SC        | Invalid Laser Timeout<br>Invalid laser timeout configuration                  |
| 8305     | Error    | SC        | Counts obj integrity failed<br>Count object integrity check failed            |
| 8306     | Error    | SC        | Scanner vector table corrupt                                                  |
| 8402     | Error    | DC        | Autodiscrim table full<br>Autodiscrimination table full                       |
| 8403     | Error    | DC        | Insufficient resources for decode                                             |
| 8404     | Error    | DC        | Decode init failure<br>Decode initialization failure due to scanner           |
| 8405     | Error    | DC        | No scanner<br>Decode initialization failure - no scanner present              |
| 8406     | Error    | DC        | Invalid decodes cmd<br>Invalid decodes command                                |
| 8407     | Error    | DC        | Symbology out of range<br>Invalid symbology specified                         |
| 840D     | Error    | DC        | Can't decode scan<br>Unable to decode scan                                    |
| 840E     | Error    | DC        | Missing start/stop<br>Missing start/stop character                            |
| 840F     | Error    | DC        | Too few counts to decode                                                      |
| 8410     | Error    | DC        | Invalid char<br>Invalid character found                                       |
| 8411     | Error    | DC        | Invalid acceleration                                                          |
| 8412     | Error    | DC        | Insufficient chars for valid label<br>Insufficient characters for valid label |
| 8413     | Error    | DC        | Invalid check digit                                                           |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| <b>Hex Code</b> | <b>Severity</b> | <b>Subsystem</b> | <b>Reader Message and Description</b>                                                                          |
|-----------------|-----------------|------------------|----------------------------------------------------------------------------------------------------------------|
| 8414            | Error           | DC               | Output string too short                                                                                        |
| 8415            | Error           | DC               | No leading margin                                                                                              |
| 8416            | Error           | DC               | Invalid start / stop                                                                                           |
| 8417            | Error           | DC               | Attempted decode past end of buffer<br>Attempted decode past end of buffer (not enough counts for whole label) |
| 8418            | Error           | DC               | No trailing margin                                                                                             |
| 8419            | Error           | DC               | Invalid UPC supplemental                                                                                       |
| 841A            | Error           | DC               | Invalid parity                                                                                                 |
| 841B            | Error           | DC               | Guard char missing<br>Guard character missing                                                                  |
| 841C            | Error           | DC               | Invalid row number                                                                                             |
| 841D            | Error           | DC               | Unable to scale counts                                                                                         |
| 841E            | Error           | DC               | Invalid 2 of 5 label                                                                                           |
| 841F            | Error           | DC               | Invalid 2 of 5 length                                                                                          |
| 8420            | Error           | DC               | 2 of 5 label length exceeds maximum                                                                            |
| 8423            | Error           | DC               | No valid label region found                                                                                    |
| 8424            | Error           | DC               | Ink spread exceeded threshold                                                                                  |
| 8425            | Error           | DC               | Denominator of expression zero<br>Denominator of an expression is zero (divide by zero attempted)              |
| 8426            | Error           | DC               | ASCII conversion failed<br>Conversion to ASCII of full label failed                                            |
| 8501            | Error           | RW               | Input request err<br>Input request error                                                                       |
| 8504            | Error           | RW               | Illegal RW mode<br>Illegal reader commands parsed                                                              |
| 8507            | Error           | RW               | Rdr cmd parsing err<br>Reader commands parsing error                                                           |
| 8508            | Error           | RW               | Invalid config<br>Invalid configuration                                                                        |
| 850F            | Error           | RW               | Error in rdr cmd edit<br>Error in reader command edit                                                          |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                                                                                |
|----------|----------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8511     | Error    | RW        | Unable to allocate memory for input                                                                                                                           |
| 8512     | Error    | RW        | Prot handler not linked<br>Protocol handler not linked                                                                                                        |
| 8514     | Error    | RW        | Rdr cmd parsing err on exit accum<br>Reader command parsing error on exit accumulation                                                                        |
| 8515     | Error    | RW        | Application break detected                                                                                                                                    |
| 8516     | Error    | RW        | Invalid Rdr Wedge request<br>Invalid Reader Wedge request                                                                                                     |
| 851B     | Error    | RW        | Rdr cmd erroneously parsed<br>A reader command was incorrectly parsed when Enter was<br>parsed                                                                |
| 851F     | Error    | RW        | Label not accepted: App not requesting input<br>Label not accepted because the scan-ahead is not enabled and the<br>application is not at an input statement. |
| 8520     | Error    | RW        | Link failed, no buffers<br>Reader Wedge link failed                                                                                                           |
| 8522     | Error    | RW        | Invalid port value for input request<br>Invalid port specified in input request                                                                               |
| 8523     | Error    | RW        | Xmit buffer busy or Comm Utility err returned<br>Communications error                                                                                         |
| 8524     | Error    | RW        | Exit Accum with Comms Error<br>Communications error from an exit accumulation command                                                                         |
| 8526     | Error    | RW        | Invalid option in RW_DO<br>Invalid port specified in input request                                                                                            |
| 8527     | Error    | RW        | No label symbology, no label input yet<br>No symbology code available                                                                                         |
| 8528     | Error    | RW        | Bad parameter                                                                                                                                                 |
| 8600     | Error    | CU        | Invalid config<br>Invalid configuration                                                                                                                       |
| 8601     | Error    | CU        | Buffer length 0 error                                                                                                                                         |
| 8602     | Error    | CU        | Comm port in use                                                                                                                                              |
| 8603     | Error    | CU        | Protocol error                                                                                                                                                |
| 8604     | Error    | CU        | Comm port error                                                                                                                                               |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| <b>Hex Code</b> | <b>Severity</b> | <b>Subsystem</b> | <b>Reader Message and Description</b>                                                                              |
|-----------------|-----------------|------------------|--------------------------------------------------------------------------------------------------------------------|
| 8605            | Error           | CU               | Comm port busy                                                                                                     |
| 8606            | Error           | CU               | Service not supported<br>Communication request is not supported                                                    |
| 8607            | Error           | CU               | Prot handler already loaded<br>Protocol handler already loaded                                                     |
| 8608            | Error           | CU               | Prot buffer error<br>Protocol buffer error                                                                         |
| 8609            | Error           | CU               | Unknown service request                                                                                            |
| 860A            | Error           | CU               | No data available                                                                                                  |
| 860B            | Error           | CU               | ComUtil not loaded<br>Communications utility is not loaded                                                         |
| 860C            | Error           | CU               | Resume / Suspend failure                                                                                           |
| 860D            | Error           | CU               | INT 14 already in use<br>Communication utility INT 14 is already in use                                            |
| 860E            | Error           | CU               | Incompatible rev PH or ComUtil<br>Incompatible revision between the protocol handler and the communication utility |
| 860F            | Error           | CU               | Invalid EOF char                                                                                                   |
| 8610            | Error           | CU               | Buffer must be > 256 bytes                                                                                         |
| 8611            | Error           | CU               | Prot handler not active<br>Protocol handler is not active                                                          |
| 8612            | Error           | CU               | Buff size too big                                                                                                  |
| 8613            | Error           | CU               | Re-entrant request for service                                                                                     |
| 8614            | Error           | CU               | H / W I / O error<br>Hardware I / O error                                                                          |
| 86F0            | Error           | CU               | Non-supported Comm service<br>Non-supported communication service                                                  |
| 8821            | Error           | PM               | Cannot change state                                                                                                |
| 8822            | Error           | PM               | State mgr invalid cmd<br>Invalid state manager command                                                             |
| 8842            | Error           | PM               | IPM interface invalid cmd<br>Invalid IPM interface command                                                         |
| 8843            | Error           | PM               | Parameter out of range                                                                                             |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                  |
|----------|----------|-----------|---------------------------------------------------------------------------------|
| 8844     | Error    | PM        | Semaphore max value exceeded<br>Semaphore maximum value exceeded                |
| 8A00     | Error    | TM        | Invalid timer func cod<br>Invalid timer function code                           |
| 8A01     | Error    | TM        | No free timers available                                                        |
| 8A02     | Error    | TM        | Illegal timer mode specified                                                    |
| 8A03     | Error    | TM        | Timer not allocated                                                             |
| 8A04     | Error    | TM        | Timer currently active                                                          |
| 8A05     | Error    | TM        | Invalid timer delay specified                                                   |
| 8A06     | Error    | TM        | Invalid timer id specified                                                      |
| 8A07     | Error    | TM        | Timer Resume/Suspend failure                                                    |
| 8A08     | Error    | TM        | Cannot process user request<br>Timer utility cannot safely process user request |
| 8B00     | Error    | BP        | Pitch out of range                                                              |
| 8B01     | Error    | BP        | Duration out of range                                                           |
| 8B02     | Error    | BP        | Vol out of range<br>Volume out of range                                         |
| 8B03     | Error    | BP        | Not seq or preem beep<br>Not a sequential or preemptive beep                    |
| 8B04     | Error    | BP        | Invalid battery flag                                                            |
| 8B05     | Error    | BP        | No preem timer available<br>No preemptive timer available                       |
| 8B06     | Error    | BP        | No seq timer available<br>No sequential timer available                         |
| 8B07     | Error    | BP        | Sequence empty                                                                  |
| 8B08     | Error    | BP        | Beep sequence not started                                                       |
| 8B09     | Error    | BP        | Error init beep list<br>Error initializing beep list                            |
| 8B0A     | Error    | BP        | Beep avail list empty<br>Beep available list empty                              |
| 8B0B     | Error    | BP        | Bad beep mgr reques<br>Bad beep manager request                                 |

---

***Status Codes and Error Messages Listed in Numerical Order (continued)***

| <b>Hex Code</b> | <b>Severity</b> | <b>Subsystem</b> | <b>Reader Message and Description</b>            |
|-----------------|-----------------|------------------|--------------------------------------------------|
| 8B0C            | Error           | BP               | Beep sequence full                               |
| 8B0D            | Error           | BP               | Beep in suspend state<br>Beeper in suspend state |
| 8B0E            | Error           | BP               | Beeper Resume / Suspend failure                  |
| 8E00            | Error           | IM               | Substring not found                              |
| 8E01            | Error           | IM               | Extract string empty                             |
| 8E02            | Error           | IM               | Extract string too long                          |
| 8E03            | Error           | IM               | Append string overflow                           |
| 8E04            | Error           | IM               | Search string not found                          |
| 8E05            | Error           | IM               | Search string empty                              |
| 8E06            | Error           | IM               | Search string too long                           |
| 8E07            | Error           | IM               | String copy too long                             |
| 8E08            | Error           | IM               | Invalid parameter                                |
| 8E09            | Error           | IM               | Hex conversion length error                      |
| 8E0A            | Error           | IM               | Hex conversion overflow                          |
| 8E0B            | Error           | IM               | Invalid binary to ASCII radix                    |
| 8E0C            | Error           | IM               | Binary to ASCII field too small                  |
| 8F00            | Error           | LG               | Event queue empty                                |
| 8F01            | Error           | LG               | Prohibited area disable                          |
| 8F02            | Error           | LG               | Reader service disable                           |
| 8F03            | Error           | LG               | Configuration management disable                 |
| 8F04            | Error           | LG               | Scanner disable                                  |
| 8F05            | Error           | LG               | Decodes disable                                  |
| 8F06            | Error           | LG               | Reader Wedge disable                             |
| 8F07            | Error           | LG               | Communications utility disable                   |
| 8F08            | Error           | LG               | Protocol handler disable                         |
| 8F09            | Error           | LG               | Power management disable                         |
| 8F0A            | Error           | LG               | BIOS disable                                     |
| 8F0B            | Error           | LG               | Timer disable                                    |
| 8F0C            | Error           | LG               | Beeper disable                                   |

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                                                              |
|----------|----------|-----------|---------------------------------------------------------------------------------------------|
| 8F0D     | Error    | LG        | IRL desktop disable                                                                         |
| 8F0E     | Error    | LG        | Prompting configuration disable                                                             |
| 8F0F     | Error    | LG        | Intermec library disabled                                                                   |
| 8F10     | Error    | LG        | Event logger disable                                                                        |
| 8F11     | Error    | LG        | Keyboard disable                                                                            |
| 8F12     | Error    | LG        | System configuration disable                                                                |
| 8F13     | Error    | LG        | Keypad disable                                                                              |
| 8F14     | Error    | LG        | Display disable                                                                             |
| 8F15     | Error    | LG        | Communications manager disable                                                              |
| 8F16     | Error    | LG        | Workbench disable                                                                           |
| 8F17     | Error    | LG        | Severity success disable                                                                    |
| 8F18     | Error    | LG        | Severity warning disable                                                                    |
| 8F19     | Error    | LG        | Severity error disable                                                                      |
| 8F1A     | Error    | LG        | Severity fatal disable                                                                      |
| 8F1B     | Error    | LG        | Wrong subsystem ID entered                                                                  |
| 8F1C     | Error    | LG        | Wrong severity ID entered                                                                   |
| 9002     | Error    | KB        | Can't disable not empty buffer<br>Cannot disable because buffer is not empty                |
| 9003     | Error    | KB        | Keypad buffer full<br>Keyboard buffer is full, entire string rejected                       |
| 9004     | Error    | KB        | Expanded buffer not installed<br>Expanded keyboard buffer not installed                     |
| 9005     | Error    | KB        | Invalid mode value was passed                                                               |
| 9006     | Error    | KB        | Exp buffer flush not install<br>Expanded keyboard buffer flush failed                       |
| 9007     | Error    | KB        | Undefined message                                                                           |
| 9008     | Error    | KB        | 16.B3 err:Source str > dest bufr<br>Source string exceeds source or destination buffer size |
| 9009     | Error    | KB        | 16.B3 err:Unknown str descriptor<br>String descriptor type is unknown                       |
| 900C     | Error    | KB        | Invalid option requested from int 16 B4xxh                                                  |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| <b>Hex Code</b> | <b>Severity</b> | <b>Subsystem</b> | <b>Reader Message and Description</b>                                       |
|-----------------|-----------------|------------------|-----------------------------------------------------------------------------|
| 9100            | Error           | SS               | Invalid service number                                                      |
| 9101            | Error           | SS               | ASIC bit number out of range                                                |
| 9102            | Error           | SS               | Unknown ASIC I/O address                                                    |
| 9103            | Error           | SS               | Undefined message code                                                      |
| 9104            | Error           | SS               | Invalid COM Port id<br>Invalid communications port ID                       |
| 9105            | Error           | SS               | Invalid Args<br>Invalid Argument                                            |
| 9200            | Error           | KP               | Timeout mid. transaction<br>Timeout occurred in the middle of a transaction |
| 9201            | Error           | KP               | Timeout 1st transaction<br>Timeout occurred on the first transaction        |
| 9202            | Error           | KP               | Keypad busy                                                                 |
| 9203            | Error           | KP               | Forced transaction abort                                                    |
| 9204            | Error           | KP               | Failed to process command                                                   |
| 9205            | Error           | KP               | Invalid func number<br>Invalid function number                              |
| 9206            | Error           | KP               | Invalid keypad comms status<br>Invalid keypad communications status         |
| 9207            | Error           | KP               | Passed in wrong parameter                                                   |
| 9208            | Error           | KP               | BIOS returned invalid value                                                 |
| 9300            | Error           | DP               | Abs value out range<br>Absolute value out range                             |
| 9301            | Error           | DP               | Invalid display size mode                                                   |
| 9302            | Error           | DP               | Display function undefined                                                  |
| 9303            | Error           | DP               | Invalid backlight timeout value                                             |
| 9304            | Error           | DP               | Display BIOS returned an invalid status                                     |
| 9305            | Error           | DP               | Invalid viewport mode                                                       |
| 9306            | Error           | DP               | Invalid scroll mode                                                         |
| 9307            | Error           | DP               | Invalid video mode                                                          |
| 9308            | Error           | DP               | Invalid size mode                                                           |

---

**Status Codes and Error Messages Listed in Numerical Order (continued)**

| Hex Code | Severity | Subsystem | Reader Message and Description                       |
|----------|----------|-----------|------------------------------------------------------|
| 9309     | Error    | DP        | Invalid height mode<br>Invalid character height mode |
| 9A03     | Error    | EX        | Transmit fail                                        |
| 9A04     | Error    | EX        | Receive timeout                                      |
| 9A05     | Error    | EX        | Packet header error                                  |
| 9A06     | Error    | EX        | Transaction ID missing                               |
| 9A08     | Error    | EX        | Standby file missing                                 |
| 9A09     | Error    | EX        | Standby file I/O error                               |
| 9A40     | Error    | EX        | Buffer overflow<br>Host response buffer is too small |
| 9A41     | Error    | EX        | Buffer overflow and upload standby error             |

## ***Status Codes Listed by Subsystem***

---

The status codes in the following tables are organized by subsystems. To find a particular status code, identify the subsystem by looking at bits 8 through 13 and refer to that section:

| <b>Code</b> | <b>Abbrev.</b> | <b>Name</b>              |
|-------------|----------------|--------------------------|
| 0100        | RS             | Reader Services          |
| 0200        | CM             | Configuration Management |
| 0300        | SC             | Scanner                  |
| 0400        | DC             | Decodes                  |
| 0500        | RW             | Reader Wedge             |
| 0600        | CU             | Communications           |
| 0800        | PM             | Power Management         |
| 0A00        | TM             | Timer                    |
| 0B00        | BP             | Beep                     |
| 0E00        | IM             | Intermec Library         |
| 0F00        | LG             | Event Logger             |
| 1000        | KB             | Keyboard Buffer          |
| 1100        | SS             | System Configuration     |
| 1200        | KP             | Keypad Services          |
| 1300        | DP             | Display                  |

---

***Subsystem 0100 RS (Reader Services)***

| <b>Hex Code</b> | <b>Message</b>                                |
|-----------------|-----------------------------------------------|
| 0100            | Reader service successful                     |
| 0103            | Reader services resume successful             |
| 8100            | Invalid function hex code received            |
| 8101            | Reader services is not installed              |
| 8102            | Reader services resume failed                 |
| 8103            | Reader services or application is out of date |
| 8104            | Reader Wedge TSR is not installed             |

---

## ***Subsystem 0200 CM (Configuration Management)***

| <b>Hex Code</b> | <b>Message</b>                                             |
|-----------------|------------------------------------------------------------|
| 0200            | Request successful                                         |
| 0201            | End of record encountered                                  |
| 0202            | End of file encountered                                    |
| 4200            | Not all configuration items copied                         |
| 4201            | Reader command terminated configuration command string     |
| 4292            | Client should not be notified                              |
| 8200            | Invalid object                                             |
| 8201            | Invalid subfunction                                        |
| 8202            | Invalid parameter length                                   |
| 8203            | Invalid parameter value                                    |
| 8204            | Invalid first parameter                                    |
| 8205            | Invalid Code 39 configuration (HIBC and no check digit)    |
| 8206            | Invalid second parameter                                   |
| 8207            | Invalid Code 39 configuration (HIBC and full ASCII)        |
| 8208            | Invalid Code 39 configuration (HIBC and mixed full ASCII)  |
| 8209            | Invalid third parameter                                    |
| 820A            | Invalid Codabar configuration (ABC and discard start/stop) |
| 820B            | Protocol not loaded                                        |
| 820C            | Invalid port or protocol specified                         |
| 820D            | No ending quote found                                      |
| 820E            | No double quote (might be missing an opening quote)        |
| 820F            | Invalid parser state                                       |
| 8210            | Invalid configuration command                              |
| 8211            | Client deemed configuration command invalid                |
| 8212            | Invalid beep duration                                      |
| 8213            | Invalid beep frequency                                     |
| 8214            | Invalid beep volume                                        |
| 8215            | Beep volume already off                                    |
| 8216            | Beep volume already extra loud                             |
| 8217            | Invalid beep specifier (must be “L” or “H”)                |

---

**Subsystem 0200 CM (Configuration Management) (continued)**

| <b>Hex Code</b> | <b>Message</b>                                                          |
|-----------------|-------------------------------------------------------------------------|
| 8218            | Inappropriate configuration for the current protocol                    |
| 8219            | BIOS rejected the set configuration command                             |
| 821A            | Configuration command string object is too small                        |
| 821B            | Configuration ID is invalid                                             |
| 821C            | Invalid build parameter                                                 |
| 821D            | No build function                                                       |
| 821E            | No more build entries                                                   |
| 821F            | No more build entries in wedge lookup table                             |
| 8220            | No more build entries in wedge lookup table for “build next” WM command |
| 8221            | No entries found in the LUM key table                                   |
| 8222            | No match in lookup table for specified character                        |
| 8223            | At least one parameter rejected by client (see JANUS.ERR)               |
| 8224            | Configuration item is not found                                         |
| 8225            | File open error                                                         |
| 8226            | File write error                                                        |
| 8227            | File read error                                                         |
| 8228            | Record too large to be read                                             |
| 8229            | Invalid hex character found in the escape sequence                      |
| 822A            | Invalid escape sequence                                                 |
| 822B            | Read attempted on a file that was not opened                            |
| 822C            | Write attempted on a file that was not opened                           |
| 822D            | File close operation failed                                             |
| 822E            | Attempt made to close a file that is not open                           |
| 822F            | Invalid default configuration                                           |
| 8230            | RF back is not installed                                                |
| 8231            | RF protocol handler is not installed                                    |
| 8232            | Path specified by IMPATH is not found                                   |
| 8233            | BIOS returned an invalid value during build                             |
| 8234            | Configuration item is not allowed for the selected protocol             |

---

***Subsystem 0200 CM (Configuration Management) (continued)***

| <b>Hex Code</b> | <b>Message</b>                                                     |
|-----------------|--------------------------------------------------------------------|
| 8235            | Configuration item value is out of range for the selected protocol |
| 8236            | Invalid fourth parameter value                                     |
| 8237            | Invalid fifth parameter value                                      |
| 8238            | Invalid sixth parameter value                                      |
| 8239            | Unable to open JANUS.ERR                                           |
| 823A            | File checksum invalid                                              |
| 823B            | Invalid RF frequency                                               |
| 823C            | Invalid channel is specified                                       |
| 823D            | Structure mismatch                                                 |
| 823E            | Specified RF channel is not allowed                                |
| 823F            | Ping command not allowed here                                      |
| 8240            | Ping command not transmitted (protocol busy)                       |
| 8241            | Missing end of configuration command                               |
| 8242            | RF frequency does not match the RF back type                       |
| 8243            | Unable to read configuration data from the RF back                 |
| 8244            | Video display mode is not allowed                                  |
| 8245            | Command source is not allowed                                      |

---

***Subsystem 0300 SC (Scanner)***

| Hex Code | Message                                           |
|----------|---------------------------------------------------|
| 0300     | Scan successful                                   |
| 8300     | Scanner load error                                |
| 8301     | Not enough timers for the scanner to initialize   |
| 8302     | Insufficient memory for the scanner to initialize |
| 8303     | Scanner cannot connect to power management        |
| 8304     | Invalid laser timeout configuration               |
| 8305     | Counts object integrity check failed              |
| 8306     | Scanner vector table is corrupt                   |

---

## ***Subsystem 0400 DC (Decodes)***

| <b>Hex Code</b> | <b>Message</b>                                                              |
|-----------------|-----------------------------------------------------------------------------|
| 0400            | Successful command                                                          |
| 0401            | Symbology is already enabled                                                |
| 0402            | Symbology is not enabled                                                    |
| 040A            | Successful decode                                                           |
| 040B            | Intermediate row reread                                                     |
| 040C            | Intermediate row decoded                                                    |
| 0421            | Default command symbology                                                   |
| 0422            | Mixed ASCII format                                                          |
| 8402            | Autodiscrimination table full                                               |
| 8403            | Insufficient resources for decode                                           |
| 8404            | Decode initialization failure due to scanner                                |
| 8405            | Decode initialization failure—no scanner                                    |
| 8406            | Invalid decodes command                                                     |
| 8407            | Invalid symbology specified                                                 |
| 840D            | Unable to decode scan                                                       |
| 840E            | Missing start/stop character                                                |
| 840F            | Too few counts to decode                                                    |
| 8410            | Invalid character found                                                     |
| 8411            | Invalid acceleration                                                        |
| 8412            | Insufficient characters for valid label                                     |
| 8413            | Invalid check digit                                                         |
| 8414            | Output string too short                                                     |
| 8415            | No leading margin                                                           |
| 8416            | Invalid start/stop                                                          |
| 8417            | Attempted decode past end of buffer (not enough counts for the whole label) |
| 8418            | No trailing margin                                                          |
| 8419            | Invalid UPC supplemental                                                    |
| 841A            | Invalid parity                                                              |
| 841B            | Guard character missing                                                     |

---

**Subsystem 0400 DC (Decodes) (continued)**

| Hex Code | Message                                  |
|----------|------------------------------------------|
| 841C     | Invalid row number                       |
| 841D     | Unable to scale counts                   |
| 841E     | Invalid 2 of 5 label                     |
| 841F     | Invalid 2 of 5 length                    |
| 8420     | 2 of 5 label length exceeds maximum      |
| 8423     | No valid label region found              |
| 8424     | Ink spread exceeded threshold            |
| 8425     | Denominator of an expression is zero     |
| 8426     | Conversion to ASCII of full label failed |

---

## ***Subsystem 0500 RW (Reader Wedge)***

| <b>Hex Code</b> | <b>Message</b>                                                     |
|-----------------|--------------------------------------------------------------------|
| 0500            | Reader Wedge successful                                            |
| 0505            | No reader commands parsed                                          |
| 0506            | Valid reader commands parsed                                       |
| 0509            | Accumulating reader command                                        |
| 050A            | Reader command override                                            |
| 050B            | Reader command enter accumulation                                  |
| 050C            | Reader command exit accumulation                                   |
| 050D            | Accumulating multiple-read labels                                  |
| 0510            | An Enter reader command was parsed                                 |
| 0513            | Protected field has been parsed                                    |
| 0517            | Keycode label has been parsed                                      |
| 0518            | An isolated Enter command was parsed                               |
| 0519            | A successful reader command parse on exit from accumulation        |
| 051A            | A reader command has been successfully parsed when Enter is parsed |
| 051C            | An Enter Accumulate has been parsed when accumulating              |
| 051D            | A label terminating a multiple-read sequence has been scanned      |
| 051E            | A label beginning a multiple-read sequence has been scanned        |
| 0521            | No communications status to report                                 |
| 0525            | Reader commands forwarded to the application have been parsed      |
| 4502            | Input timeout                                                      |
| 4503            | No input data                                                      |
| 450E            | The application should be notified                                 |
| 4529            | Input from the source is other than the ones requested             |
| 452A            | RWTSR is already loaded                                            |
| 452B            | Prepare for reboot command received                                |
| 452C            | Cancel reboot command received                                     |
| 8501            | Input request error                                                |
| 8504            | Illegal reader commands parsed                                     |
| 8507            | Reader commands parsing error                                      |
| 8508            | Invalid configuration error                                        |

---

**Subsystem 0500 RW (Reader Wedge) (continued)**

| Hex Code | Message                                                                                               |
|----------|-------------------------------------------------------------------------------------------------------|
| 850F     | Error in reader command edit                                                                          |
| 8511     | Unable to allocate memory for input                                                                   |
| 8512     | Protocol handler is not linked                                                                        |
| 8514     | Reader command parse error on exit accumulation                                                       |
| 8515     | Application break detected                                                                            |
| 8516     | Invalid Reader Wedge request                                                                          |
| 851B     | A reader command has been erroneously parsed when Enter is parsed                                     |
| 851F     | Label not accepted because the scan-ahead is not enabled and application is not at an input statement |
| 8520     | Reader Wedge link failed                                                                              |
| 8522     | Invalid port specified in input request                                                               |
| 8523     | Communications error                                                                                  |
| 8524     | Communications error from an exit accumulation command                                                |
| 8526     | Library coding error                                                                                  |
| 8527     | No symbology code available                                                                           |
| 8528     | Bad parameter                                                                                         |

---

## ***Subsystem 0600 CU (Communications)***

| <b>Hex Code</b> | <b>Message</b>                                                                    |
|-----------------|-----------------------------------------------------------------------------------|
| 0600            | Communications operation success                                                  |
| 0601            | Communications buffer done                                                        |
| 4600            | Buffer canceled                                                                   |
| 4601            | Communications timeout                                                            |
| 4602            | Communications had no client to cancel                                            |
| 4603            | No protocol handler to configure                                                  |
| 4604            | Protocol handler is not yet loaded                                                |
| 4605            | Protocol handler already receiving                                                |
| 4606            | Protocol handler not active for link request                                      |
| 8600            | Invalid configuration                                                             |
| 8601            | Buffer length zero error                                                          |
| 8602            | Communications port is in use                                                     |
| 8603            | Protocol error                                                                    |
| 8604            | Communications port error                                                         |
| 8605            | Communications port is busy                                                       |
| 8606            | Communications request is not supported                                           |
| 8607            | Protocol handler already loaded                                                   |
| 8608            | Protocol buffer error                                                             |
| 8609            | Unknown service request                                                           |
| 860A            | No data available                                                                 |
| 860B            | Communications utility is not loaded                                              |
| 860C            | Resume/suspend failure                                                            |
| 860D            | Communications utility INT 14 is already in use                                   |
| 860E            | Incompatible revision between the protocol handler and the communications utility |
| 860F            | Invalid end of file character                                                     |
| 8610            | Buffer must be 256 bytes or greater                                               |
| 8611            | Protocol handler not active                                                       |
| 8612            | Buffer size is too big                                                            |



---

***Subsystem 0600 CU (Communications) (continued)***

| <b>Hex Code</b> | <b>Message</b>                     |
|-----------------|------------------------------------|
| 8613            | Reentrant request for service      |
| 8614            | Hardware I/O error                 |
| 86F0            | Unsupported communications service |

---

## ***Subsystem 0800 PM (Power Management)***

| <b>Hex Code</b> | <b>Message</b>                |
|-----------------|-------------------------------|
| 0800            | Power management success      |
| 8821            | Cannot change state           |
| 8822            | Invalid state manager command |
| 8842            | Invalid IPM interface command |
| 8843            | Parameter out of range        |
| 8844            | Semaphore maximum exceeded    |

---

***Subsystem 0A00 TM (Timer)***

| Hex Code | Message                                          |
|----------|--------------------------------------------------|
| 0A00     | Timer operation success                          |
| 4A00     | Timer not currently active                       |
| 8A00     | Invalid timer function code                      |
| 8A01     | No free timers available                         |
| 8A02     | Illegal timer mode specified                     |
| 8A03     | Timer not allocated                              |
| 8A04     | Timer is currently active                        |
| 8A05     | Invalid timer delay specified                    |
| 8A06     | Invalid timer ID specified                       |
| 8A07     | Timer resume/suspend failure                     |
| 8A08     | Timer utility cannot safely process user request |

---

## ***Subsystem 0B00 BP (Beep)***

| <b>Hex Code</b> | <b>Message</b>                        |
|-----------------|---------------------------------------|
| 0B00            | Beeper call success                   |
| 8B00            | Pitch out of range                    |
| 8B01            | Duration out of range                 |
| 8B02            | Volume out of range                   |
| 8B03            | Not a sequential or a preemptive beep |
| 8B04            | Invalid battery flag                  |
| 8B05            | No preemptive timer available         |
| 8B06            | No sequential timer available         |
| 8B07            | Sequence empty                        |
| 8B08            | Beep sequence not started             |
| 8B09            | Error initializing beep list          |
| 8B0A            | Beep available list empty             |
| 8B0B            | Bad beep manager request              |
| 8B0C            | Beep sequence full                    |
| 8B0D            | Beeper in suspend state               |
| 8B0E            | Beeper resume/suspend failure         |

---

**Subsystem 0E00 IM (Intermec Library)**

| Hex Code | Message                         |
|----------|---------------------------------|
| 0E00     | String extract complete         |
| 0E01     | String append complete          |
| 0E02     | String search found             |
| 0E03     | String copy complete            |
| 0E04     | Successful operation            |
| 8E00     | Substring not found             |
| 8E01     | String extract empty            |
| 8E02     | String extract too long         |
| 8E03     | String append overflow          |
| 8E04     | String search not found         |
| 8E05     | String search empty             |
| 8E06     | String search too long          |
| 8E07     | String copy too long            |
| 8E08     | Invalid parameter               |
| 8E09     | Hex conversion length error     |
| 8E0A     | Hex conversion overflow         |
| 8E0B     | Invalid binary to ASCII radix   |
| 8E0C     | Binary to ASCII field too small |

---

## ***Subsystem 0F00 LG (Event Logger)***

| <b>Hex Code</b> | <b>Message</b>                   |
|-----------------|----------------------------------|
| 0F00            | Successful logger operation      |
| 8F00            | Event queue empty                |
| 8F01            | Prohibited area disable          |
| 8F02            | Reader service disable           |
| 8F03            | Configuration management disable |
| 8F04            | Scanner disable                  |
| 8F05            | Decodes disable                  |
| 8F06            | Reader Wedge disable             |
| 8F07            | Communications utility disable   |
| 8F08            | Protocol handler disable         |
| 8F09            | Power management disable         |
| 8F0A            | BIOS disable                     |
| 8F0B            | Timer disable                    |
| 8F0C            | Beeper disable                   |
| 8F0D            | IRL desktop disable              |
| 8F0E            | Prompting configuration disable  |
| 8F0F            | Intermec library disabled        |
| 8F10            | Event logger disable             |
| 8F11            | Keyboard disable                 |
| 8F12            | System configuration disable     |
| 8F13            | Keypad disable                   |
| 8F14            | Display disable                  |
| 8F15            | Communications manager disable   |
| 8F16            | Workbench disable                |
| 8F17            | Severity success disable         |
| 8F18            | Severity warning disable         |
| 8F19            | Severity error disable           |
| 8F1A            | Severity fatal disable           |
| 8F1B            | Wrong subsystem ID entered       |
| 8F1C            | Wrong severity ID entered        |

---

**Subsystem 1000 KB (Keyboard Buffer)**

| Hex Code | Message                                                 |
|----------|---------------------------------------------------------|
| 1000     | Expanded keyboard buffer success                        |
| 100A     | Expanded buffer enabled                                 |
| 100B     | Expanded buffer disabled                                |
| 5001     | Expanded keyboard buffer installed or disabled          |
| 9002     | Cannot disable because buffer is not empty              |
| 9003     | Keyboard buffer is full (entire string rejected)        |
| 9004     | Expanded keyboard buffer not installed                  |
| 9005     | Invalid mode value was passed                           |
| 9006     | Expanded keyboard buffer flush not successful           |
| 9007     | Undefined message                                       |
| 9008     | Source string exceeds source or destination buffer size |
| 9009     | String descriptor type is unknown                       |
| 900C     | Invalid option requested from INT 16 B4xxh              |

---

## ***Subsystem 1100 SS (System Configuration)***

| <b>Hex Code</b> | <b>Message</b>                  |
|-----------------|---------------------------------|
| 1100            | System configuration successful |
| 9100            | Invalid service number          |
| 9101            | ASIC bit number is out of range |
| 9102            | Unknown ASIC I/O address        |
| 9103            | Undefined message code          |
| 9104            | Invalid communications port ID  |
| 9105            | Invalid argument                |

---

***Subsystem 1200 KP (Keypad Services)***

| Hex Code | Message                                         |
|----------|-------------------------------------------------|
| 1200     | Successful keypad operation                     |
| 5201     | Backdoor communications failure                 |
| 9200     | Timeout occurred in the middle of a transaction |
| 9201     | Timeout occurred on the first transaction       |
| 9202     | Keypad busy                                     |
| 9203     | Forced transaction abort                        |
| 9204     | Failed to process a command                     |
| 9205     | Invalid function number                         |
| 9206     | Invalid keypad communications status            |
| 9207     | Wrong parameter passed in                       |
| 9208     | BIOS returned an invalid value                  |

---

## ***Subsystem 1300 DP (Display)***

| <b>Hex Code</b> | <b>Message</b>                          |
|-----------------|-----------------------------------------|
| 1300            | Successful display operation            |
| 9300            | Absolute value out of range             |
| 9301            | Invalid display size mode               |
| 9302            | Display function undefined              |
| 9303            | Invalid backlight timeout value         |
| 9304            | Display BIOS returned an invalid status |
| 9305            | Invalid viewport mode                   |
| 9306            | Invalid scroll mode                     |
| 9307            | Invalid video mode                      |
| 9308            | Invalid size mode                       |
| 9309            | Invalid character height mode           |

# *B*

## ***Appendix B: Ada Programs***



*This appendix contains the Ada sample programs from your PSK Language Libraries disk.*

## DISPMODE.ADA

```
-- File Name:  dispmode.ada
--
-- Purpose:    This sample program demonstrates how to change the display
--             mode of the reader. It uses Intermec's Ada procedure
--             im_get_display_mode to get the current display size mode,
--             video mode, scroll mode, and character height, then displays
--             each parameter on the screen. It also calls Intermec's Ada
--             function im_set_display_mode to change the display mode
--             to use double height characters and resets to normal
--             display mode before exiting.
--
-- COPYRIGHT (c) 1994 INTERMEC CORPORATION, ALL RIGHTS RESERVED
```

```
With System, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use  System, Text_IO, Intrmechd_IO, Intrmecp_IO;
```

```
procedure dispmode Is
```

```
    package IM_STD_SIZE_MODE_IO is new ENUMERATION_IO
        (enum => IM_STD_SIZE_MODE);
    package IM_STD_VIDEO_MODE_IO is new ENUMERATION_IO
        (enum => IM_STD_VIDEO_MODE);
    package IM_SCROLL_MODE_IO is new ENUMERATION_IO
        (enum => IM_SCROLL_MODE);
    package IM_CHARACTER_HEIGHT_IO is new ENUMERATION_IO
        (enum => IM_CHARACTER_HEIGHT);
```

```
status  : System.Word;
size    : IM_STD_SIZE_MODE;
video   : IM_STD_VIDEO_MODE;
scroll  : IM_SCROLL_MODE;
char_ht : IM_CHARACTER_HEIGHT;
inchar  : Character := ' ';
```

```
begin
```

```
    -- RWTSR must be installed before running this program
```

```
    Put_Line ("Getting disp mode");
    New_Line;
```

```
    im_get_display_mode (size, video, scroll, char_ht, status);
```

```
    if im_iserror(status) then
        Put_Line ("Get Disp Mode error:");
        im_message(status);
        New_Line;
```

```
    else
        Put ("size : ");
        IM_STD_SIZE_MODE_IO.Put (size);
        New_Line;
```

## ***DISPMODE.ADA***

```
Put ("video : ");
IM_STD_VIDEO_MODE_IO.Put (video);
New_Line;

Put ("scroll : ");
IM_SCROLL_MODE_IO.Put (scroll);
New_Line;

Put ("char_ht : ");
IM_CHARACTER_HEIGHT_IO.Put (char_ht);
New_Line;

end if;

New_Line;
Put_Line("Setting disp mode");
Put_Line("Any key to continue");
Get(inchar);

status := im_set_display_mode (IM_SIZE_MODE_80X25,
                               IM_STD_VIDEO_MODE_0,
                               IM_LCD_SCROLL_AT_25,
                               IM_DOUBLE_CHAR_HEIGHT);

if im_isgood(status) then

  im_get_display_mode (size, video, scroll, char_ht, status);

  Put ("size :");
  IM_STD_SIZE_MODE_IO.Put (size);
  New_Line;

  Put ("video :");
  IM_STD_VIDEO_MODE_IO.Put (video);
  New_Line;
  Put ("scroll:");
  IM_SCROLL_MODE_IO.Put (scroll);
  New_Line;

  Put ("char_ht :");
  IM_CHARACTER_HEIGHT_IO.Put (char_ht);
  New_Line;

else
  Put_Line ("Set Disp Mode error:");
  im_message(status);
  New_Line;
end if;

Put_Line("Press any key");
Get(inchar);

-- Reset display to some standard mode
status := im_set_display_mode (IM_SIZE_MODE_80X25,
                               IM_STD_VIDEO_MODE_3,
                               IM_LCD_SCROLL_AT_25,
                               IM_STANDARD_CHAR_HEIGHT);

end dispmode;
```

---

**KEYCLICK.ADA**

```

-- File Name:  keyclick.ada
--
-- Purpose   :  This sample program demonstrates how to enable and disable
--               the click when a key is pressed on the reader keypad. It
--               uses Intermec's Ada function im_set_keyclick and the procedure
--               im_get_keyclick to retrieve the current status.
--
-- COPYRIGHT (c) 1994 INTERMEC CORPORATION, ALL RIGHTS RESERVED

With System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;
Use System, Bit, Text_IO, Intrmechd_IO, Intrmecp_IO;

procedure keyclick Is

    keyclick_status : IM_CONTROL;
    status_code     : System.Word;
    in_char         : Character := ' ';

begin
    im_get_keyclick (keyclick_status, status_code);

    if keyclick_status = IM_ENABLE then
        Put_Line ("Keyclick ENABLED");
    else
        Put_Line ("Keyclick DISABLED");
    end if;

    status_code := im_set_keyclick (IM_DISABLE);
    if im_isgood(status_code) then

        Put_Line ("Keyclick DISABLED");
        Put_Line ("q to quit");
        loop
            exit when in_char = 'q';
            Get (in_char);
        end loop;

    else
        Put_Line ("Disable Keyclick error:");
        im_message(status_code);
        New_Line;

    end if;

    in_char := ' ';
    New_Line;

    status_code := im_set_keyclick (IM_ENABLE);

    if im_isgood(status_code) then

        Put_Line ("Keyclick ENABLED");
        Put_Line ("q to quit");
        loop
            exit when in_char = 'q';
            Get (in_char);
        end loop;
    end if;
end keyclick;
```

## ***KEYCLICK.ADA***

```
    else
      Put_Line ("Enable Keyclick error:");
      im_message(status_code);
      New_Line;
    end if;
end keyclick;
```

---

**PWR\_STAT.ADA**

```

-- File Name:  pwr_stat.ada
--
-- Purpose:    This sample program demonstrates Intermec's
--             Ada procedure im_power_status. It retrieves the AC line status,
--             battery status, backup battery status, and the percentage
--             of remaining life in the battery.
--
-- COPYRIGHT (c) 1994 INTERMEC CORPORATION, ALL RIGHTS RESERVED

With System, Text_IO, Intrmeacd_IO, Intrmecp_IO;
Use  System, Text_IO, Intrmeacd_IO, Intrmecp_IO;

procedure pwr_stat Is

    package SYSBYTE_IO is new INTEGER_IO (System.Byte);

    line_status      : IM_LINE_STATUS;
    battery_status   : IM_BATTERY_STATUS;
    backup_status    : IM_BACKUP_STATUS;
    fuel_gauge       : System.Byte;
    status           : System.Word;
    in_char          : Character := ' ';

begin
    loop
        exit when in_char = 'q';

        Put_Line("Checking power");
        New_Line;

        im_power_status(line_status, battery_status, backup_status,
            fuel_gauge, status);

        if im_isgood(status) then

            Put_Line("Line Status: ");
            case line_status is
                when IM_ACl ine_NOT_CONNECTED =>
                    Put_Line("Not connected");

                when IM_ACl ine_CONNECTED =>
                    Put_Line("Connected");

                when IM_UNKNOWN_ACl ine =>
                    Put_Line("Unknown");

                when others =>
                    Put_Line("Invalid");
            end case;

            New_Line;

            Put_Line("Battery Status: ");
            case battery_status is
                when IM_HIGH_BAT =>
                    Put_Line("Charge high");
                when IM_LOW_BAT =>
                    Put_Line("Charge low");
            end case;
        end if;
    end loop;
end pwr_stat;
```

## ***PWR\_STAT.ADA***

```
        when IM_CRITICAL_BAT =>
            Put_Line("Charge critical");

        when IM_CHARGING_BAT =>
            Put_Line("Charging battery");

        when IM_UNKNOWN_BAT =>
            Put_Line("Unknown");

        when others =>
            Put_Line("Invalid");
    end case;

    New_Line;

    Put_Line("Backup Status: ");
    case backup_status is
        when IM_BACKUP_OK =>
            Put_Line("Backup battery OK");

        when IM_BACKUP_LOW =>
            Put_Line("Backup battery low");

        when others =>
            Put_Line("Invalid");
    end case;

    New_Line;

    Put("Fuel gauge % ");
    case fuel_gauge is
        when 0..100 =>
            SYSBYTE_IO.Put(fuel_gauge);

        when 255 =>
            Put("Fuel gauge unknown");

        when others =>
            Put("Invalid");
    end case;

    New_Line;
    Put("q to quit");
    Get(in_char);

else
    im_message (status);
    New_Line;

end if;

end loop;

end pwr_stat;
```

---

**XCOMM.ADA**

```
-- File Name:  xcomm.ada
--
-- Purpose   :  This sample program receives data from the communications
--               port 1 and transmits the same data back across the comm1
--               port. It expects a carriage return as the end-of-message
--               character. Program execution continues until the operator
--               sends a 'q' as the first byte in the buffer. This program
--               uses Intermec's Ada procedures im_receive_buffer_noprot,
--               im_transmit_buffer_noprot, im_cancel_rx_buffer, and
--               im_cancel_tx_buffer.
--
-- COPYRIGHT (c) 1994 INTERMEC CORPORATION, ALL RIGHTS RESERVED
```

```
With System, Intrmecd_IO, Intrmecp_IO, Text_IO;
Use  System, Intrmecd_IO, Intrmecp_IO, Text_IO;
```

```
procedure xcomm Is
```

```
    package SYSWORD_IO is new INTEGER_IO (System.Word);

    status          : System.Word;
    comm_length     : System.Word := 0;
    timeout         : System.Word := 20000;    -- 20 seconds
    eom_char        : System.Byte := 16#0D#;    -- CR for terminating char
    RX_data_buffer  : String (1..300) := (others => Ascii.NUL);
    TX_data_buffer  : String (1..300) := (others => Ascii.NUL);
    RX_buff_length  : System.Word := System.Word(RX_data_buffer'Length);
    TX_buff_length  : System.Word;
    RX_data_ptr     : System.Address := RX_data_buffer'Address;
    TX_data_ptr     : System.Address := TX_data_buffer'Address;
    done            : Boolean := FALSE;
```

```
begin
```

```
    -- Phimec protocol handler must be installed to run this routine
```

```
    New_Line(2);
    Put_Line("      Janus 2010 ");
    Put_Line("Rx/Tx Buffer No Prot");
    New_Line;

    -- get the receive environment ready
    status := im_cancel_rx_buffer(IM_COM1);
    if (im_iserror(status)) then
        Put ("canc rx1 error = ");
        im_message (status);
        New_Line;
    end if;

    -- Clear the transmission buffer
    status := im_cancel_tx_buffer (IM_COM1);

    Put_Line("Ready to receive");
    Put_Line("q to quit...");
    New_Line;

    -- call Intermec function
    im_receive_buffer_noprot (IM_COM1, RX_Buff_length, RX_data_ptr,
                             IM_INFINITE_TIMEOUT, eom_char, comm_length, status);
```

## ***XCOMM.ADA***

```
-- loop until first character in buffer is a 'q'
while not done loop

  if im_isgood(status) then
    Put_Line ("Receive done");

    -- Display number of characters received
    Put ("comm_length is ");
    SYSWORD_IO.Put (comm_length, width => 3);
    New_Line;

    -- Display buffer contents
    for i in Integer range 1..Integer(comm_length) loop
      Put(RX_data_buffer(i));
    end loop;
    New_Line;

  else
    Put_Line ("Rx no protocol err = ");
    im_message (status);
    New_Line;

    -- Since there was an error, clear the receive buffer and
    -- reset the comm port
    status := im_cancel_rx_buffer (IM_COM1);
  end if;

  -- copy RX_ to TX_
  for i in Integer range 1..Integer(comm_length) loop
    TX_data_buffer (i) := RX_data_buffer (i);
  end loop;

  TX_buff_length := comm_length + 1;
  TX_data_buffer(Integer(TX_buff_length)) := Ascii.CR;

  status := im_transmit_buffer_noprot (IM_COM1, TX_buff_length,
    TX_data_ptr, timeout);

  if im_isgood (status) then
    Put_Line ("Buffer transmitted");
  else
    Put_Line ("tx status = ");
    im_message (status);
    New_Line;

    -- Since there was an error in the transmission, clear the buffer
    -- and reset the comm port
    status := im_cancel_tx_buffer (IM_COM1);

  end if;

  New_Line;

  -- call Intermec receive function
  im_receive_buffer_noprot (IM_COM1, RX_Buff_length, RX_data_ptr,
    IM_INFINITE_TIMEOUT, eom_char, comm_length, status);

  -- quit if first char in buffer is a 'Q' or a 'q'
  if ((RX_data_buffer(1) = 'Q') or (RX_data_buffer(1) = 'q')) then
    done := TRUE;
  end if;
```

```
end loop;

-- Clear buffers and reset comm port
status := im_cancel_rx_buffer (IM_COM1);
status := im_cancel_tx_buffer (IM_COM1);
end xcomm;
```





***Index***



# Index

---

## **Symbols**

\*.EXE file, 2-5  
\*.RSP file, 2-9

## **A**

About This Manual, xii  
Ada compiler, 2-4, 2-7

## **B**

Backlight  
    im\_backlight\_off, 3-8  
    im\_backlight\_on, 3-9  
    im\_backlight\_toggle, 3-10  
Batch program, 2-10  
Battery  
    im\_power\_status, 3-80  
Beeper  
    im\_sound, 3-125  
Binding  
    Ada program, 2-8  
Break  
    im\_appl\_break\_status, 3-6  
Build procedure, 2-4  
    batch program, using, 2-10  
    binding, 2-8  
    compiling, 2-7  
    linking, 2-9  
Build requirements, 2-6

## **C**

Caution, 1-5  
Command  
    im\_command, 3-13  
Compiler  
    Janus/Ada, 2-4, 2-7, 2-9  
Compiling, 2-7

## Configuration

    im\_get\_config\_info, 3-18

## Contrast

    im\_decrease\_contrast, 3-16  
    im\_get\_contrast, 3-20  
    im\_increase\_contrast, 3-43  
    im\_set\_contrast, 3-108

## Control key

    im\_get\_control\_key, 3-22  
    im\_set\_control\_key, 3-110

## Conventions, manual, xiii

## Cursor

    im\_cursor\_to\_viewport, 3-15  
    im\_get\_follow\_cursor, 3-29  
    im\_get\_viewport\_lock, 3-40  
    im\_set\_follow\_cursor, 3-115  
    im\_set\_viewport\_lock, 3-121  
    im\_viewport\_to\_cursor, 3-148

## **D**

## Debugging

    using JANUS Application Simulator, 2-10

## Desktop mode, 3-31, 3-118

## Disk

    PSK, 2-3

## Display

    im\_get\_display\_mode, 3-24  
    im\_get\_display\_type, 3-27  
    im\_set\_display\_mode, 3-112

## DISPMODE.ADA, B-3

## **E**

## Error message

    im\_message, 3-75

## Examples

    im\_appl\_break\_status, 3-7  
    im\_backlight\_off, 3-8  
    im\_backlight\_on, 3-9  
    im\_backlight\_toggle, 3-10

## ***Index***

### *Examples continued*

- im\_command, 3-14
- im\_cursor\_to\_viewport, 3-15
- im\_decrease\_contrast, 3-17
- im\_get\_config\_info, 3-19
- im\_get\_contrast, 3-21
- im\_get\_control\_key, 3-23
- im\_get\_display\_mode, 3-26
- im\_get\_display\_type, 3-28
- im\_get\_follow\_cursor, 3-29
- im\_get\_input\_mode, 3-31
- im\_get\_keyclick, 3-32
- im\_get\_postamble, 3-37
- im\_get\_preamble, 3-39
- im\_get\_viewport\_lock, 3-41
- im\_get\_warm\_boot, 3-42
- im\_increase\_contrast, 3-44
- im\_input\_status, 3-46
- im\_irl\_a, 3-49
- im\_irl\_k, 3-53
- im\_irl\_n, 3-57
- im\_irl\_v, 3-62
- im\_irl\_y, 3-66
- im\_iserror, 3-69
- im\_isgood, 3-70
- im\_issuccess, 3-71
- im\_iswarn, 3-72
- im\_message, 3-75
- im\_number\_pad\_off, 3-77
- im\_number\_pad\_on, 3-79
- im\_power\_status, 3-81
- im\_protocol\_extended\_status, 3-84
- im\_receive\_buffer, 3-86
- im\_receive\_buffer\_no\_wait, 3-90
- im\_receive\_buffer\_noprot, 3-94
- im\_receive\_byte, 3-98
- im\_receive\_input, 3-101
- im\_rs\_installed, 3-103
- im\_serial\_protocol\_control, 3-106
- im\_set\_contrast, 3-109
- im\_set\_control\_key, 3-110
- im\_set\_display\_mode, 3-114
- im\_set\_follow\_cursor, 3-115
- im\_set\_keyclick, 3-119
- im\_set\_viewport\_lock, 3-121

### *Examples continued*

- im\_set\_warm\_boot, 3-123
- im\_sound, 3-126
- im\_standby\_wait, 3-128
- im\_transmit\_byte, 3-135
- im\_viewport\_end, 3-138
- im\_viewport\_getxy, 3-140
- im\_viewport\_home, 3-141
- im\_viewport\_move, 3-143
- im\_viewport\_page\_down, 3-145
- im\_viewport\_page\_up, 3-146
- im\_viewport\_to\_cursor, 3-148

### Executable file

- building, 2-5

## ***F***

### Function

- defined, 3-3

### Function libraries

- supported languages, 1-6

## ***H***

### Hexadecimal numbers

- manual conventions, xiv

## ***I***

- im\_appl\_break\_status, 3-6
- im\_backlight\_off, 3-8
- im\_backlight\_on, 3-9
- im\_backlight\_toggle, 3-10
- im\_cancel\_rx\_buffer, 3-11
- im\_cancel\_tx\_buffer, 3-12
- im\_command, 3-13
- im\_cursor\_to\_viewport, 3-15
- im\_get\_config\_info, 3-18
- im\_get\_contrast, 3-20
- im\_get\_control\_key, 3-22
- im\_get\_display\_mode, 3-24
- im\_get\_display\_type, 3-27
- im\_get\_follow\_cursor, 3-29
- im\_get\_input\_mode, 3-30
- im\_get\_keyclick, 3-32
- im\_get\_label\_symbolology, 3-33
- im\_get\_length, 3-35

im\_get\_postamble, 3-36  
 im\_get\_preamble, 3-38  
 im\_get\_viewport\_lock, 3-40  
 im\_get\_warm\_boot, 3-42  
 im\_increase\_contrast, 3-16, 3-43  
 im\_input\_status, 3-45  
 im\_irl\_a, 3-47  
 im\_irl\_k, 3-51  
 im\_irl\_n, 3-55  
 im\_irl\_v, 3-59  
 im\_irl\_y, 3-64  
 im\_iserror, 2-16, 3-69  
 im\_isgood, 2-16, 3-70  
 im\_issuccess, 2-16, 3-71  
 im\_iswarn, 2-16, 3-72  
 im\_link\_comm, 3-73  
 im\_message, 3-75  
 im\_number\_pad\_off, 3-76  
 im\_number\_pad\_on, 3-78  
 im\_power\_status, 3-80  
 im\_protocol\_extended\_status, 3-83  
 im\_receive\_buffer, 3-85  
 im\_receive\_buffer\_no\_wait, 3-89  
 im\_receive\_buffer\_noprot, 3-93  
 im\_receive\_byte, 3-97  
 im\_receive\_input, 3-100  
 im\_rs\_installed, 3-103  
 im\_rx\_check\_status, 3-104  
 im\_serial\_protocol\_control, 3-105  
 im\_set\_contrast, 3-108  
 im\_set\_control\_key, 3-110  
 im\_set\_display\_mode, 3-112  
 im\_set\_follow\_cursor, 3-115  
 im\_set\_input\_mode, 3-117  
 im\_set\_keyclick, 3-119  
 im\_set\_viewport\_lock, 3-121  
 im\_set\_warm\_boot, 3-123  
 im\_sound, 3-125  
 im\_standby\_wait, 3-127  
 im\_transmit\_buffer, 3-129  
 im\_transmit\_buffer\_no\_wait, 3-131  
 im\_transmit\_buffer\_noprot, 3-132  
 im\_transmit\_byte, 3-134

im\_unlink\_comm, 3-137  
 im\_viewport\_end, 3-138  
 im\_viewport\_getxy, 3-139  
 im\_viewport\_home, 3-141  
 im\_viewport\_move, 3-142  
 im\_viewport\_page\_down, 3-145  
 im\_viewport\_page\_up, 3-146  
 im\_viewport\_setxy, 3-147  
 im\_viewport\_to\_cursor, 3-148  
 INSTALL.EXE, 2-3  
 Installing  
     Programmer's Software Kit, 2-3  
     PSK installation procedure, 2-3  
 IRL Command  
     A, 3-47  
     K, 3-51  
     N, 3-55  
     V, 3-59  
     Y, 3-64

## J

JANUS Application Simulator, 2-10, 3-3  
 JANUS reader, 1-3  
 Janus/Ada compiler, 2-4, 2-7, 2-9  
 JBIND, 2-7

## K

KEYCLICK.ADA, B-5  
 Keypad  
     im\_get\_control\_key, 3-22  
     im\_get\_keyclick, 3-32  
     im\_get\_warm\_boot, 3-42  
     im\_number\_pad\_off, 3-76  
     im\_set\_control\_key, 3-110  
     im\_set\_keyclick, 3-119  
     im\_set\_warm\_boot, 3-123  
     manual conventions, xiv  
 Keypad vs. keyboard, xiii

## L

Label  
     im\_get\_label\_symbology, 3-33  
 Libraries  
     PSK Language Libraries disk, 2-3

## ***Index***

### Library file

- IM20\_ADA.LIB, 2-4
- IM20ADAD.LIB, 2-4
- IM20ADAP.LIB, 2-4

### Library functions, 3-3

### Linker

- Microsoft, 2-4

### Linking, 2-9

## ***M***

### Mode

- Desktop, 3-31, 3-118
- im\_get\_input\_mode, 3-30
- im\_set\_input\_mode, 3-117
- Programmer, 3-30, 3-117
- Wedge, 3-30, 3-117

## ***N***

### Number pad

- im\_number\_pad\_off, 3-76
- im\_number\_pad\_on, 3-78

## ***P***

### PHIMEC.EXE, 2-12

### PHPCSTD.EXE, 2-12

### Postamble

- im\_get\_postamble, 3-36

### Preamble

- im\_get\_preamble, 3-38

### Procedure

- defined, 3-3

### Programmer mode, 3-30, 3-117

### Programming with Ada, 2-4

### Protocol

- im\_protocol\_extended\_status, 3-83
- im\_serial\_protocol\_control, 3-105

### Protocol handlers, 2-12

### PSK Language Libraries, 2-4

### PWR\_STAT.ADA, B-7

## ***R***

### Reader

- about, 1-3
- Virtual Wedge, 1-4

### Reader Services

- im\_rs\_installed, 3-103
- using function libraries, 1-5
- using software interrupts, 1-5

### Reader Wedge, 2-13

### Receive buffer

- im\_cancel\_rx\_buffer, 3-11
- im\_receive\_buffer, 3-85
- im\_receive\_buffer\_no\_wait, 3-89
- im\_receive\_buffer\_noprot, 3-93
- im\_receive\_byte, 3-97
- im\_receive\_input, 3-100

### Response file, 2-9

### Run

- caution, 1-5, 2-11, 3-3

### Run procedure, 2-11

### Runtime requirements, 2-12 to 2-15

### RWTSR.EXE, 2-13

## ***S***

### Sample program

- DISPMODE.ADA, B-3
- KEYCLICK.ADA, B-5
- PWR\_STAT.ADA, B-7
- XCOMM.ADA, B-9

### Simulator, 2-10, 3-3

### Software interrupts, 1-6

### Source code, 2-4

### Specific runtime requirements, 2-14, 2-15

### Standby

- im\_standby\_wait, 3-127

### Status codes

- bit values, A-3
- listed by subsystem, A-22
- listed numerically, A-4
- macros, 2-16

### Subsystem

- Beep, A-36
- Communication, A-32, A-33
- Configuration management, A-24, A-25
- Decodes, A-28, A-29
- Display, A-42
- Event logger, A-38
- Intermec library, A-37
- Keyboard, A-39

Status codes *continued*

## Subsystem

- Keypad, A-41
- Power management, A-34
- Reader services, A-23
- Reader Wedge, A-30, A-31
- Scanner, A-27
- System configuration, A-40
- Timer, A-35

**T**

## Transmit buffer

- im\_cancel\_tx\_buffer, 3-12
- im\_transmit\_buffer, 3-129
- im\_transmit\_buffer\_no\_wait, 3-131
- im\_transmit\_buffer\_noprot, 3-132
- im\_transmit\_byte, 3-134

**V**

## Viewport

- im\_cursor\_to\_viewport, 3-15
- im\_get\_follow\_cursor, 3-29
- im\_get\_viewport\_lock, 3-40
- im\_set\_follow\_cursor, 3-115
- im\_set\_viewport\_lock, 3-121
- im\_viewport\_end, 3-138
- im\_viewport\_getxy, 3-139
- im\_viewport\_home, 3-141
- im\_viewport\_move, 3-142
- im\_viewport\_page\_down, 3-145
- im\_viewport\_page\_up, 3-146
- im\_viewport\_setxy, 3-147
- im\_viewport\_to\_cursor, 3-148

## Virtual Wedge, 1-4

**W**

## Warm boot, 3-123

- im\_get\_warm\_boot, 3-42

## Wedge mode, 3-30, 3-117

**X**

## XCOMM.ADA, B-9

