

# Reference Manual

P/N 063191-001

# JANUS<sup>®</sup> PSK for Basic, Version 2.1

 **ntermec**

A **UNOVA** Company

Intermec® Corporation  
6001 36th Avenue West  
P.O. Box 4280  
Everett, WA 98203-9280

U.S. technical and service support: 1-800-755-5505  
U.S. media supplies ordering information: 1-800-227-9947

Canadian technical and service support: 1-800-688-7043  
Canadian media supplies ordering information: 1-800-268-6936

Outside U.S. and Canada: Contact your local Intermec service supplier.

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Intermec manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Information and specifications in this manual are subject to change without notice.

© 1995 by Intermec Corporation  
All Rights Reserved

The word Intermec, the Intermec logo, JANUS, IRL, Duratherm, Virtual Wedge, and CrossBar are trademarks of Intermec Corporation.

Throughout this manual, trademarked names may be used. Rather than put a trademark (™) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

## ***Contributors***

Author	Beryl Doane
Editor	Craig Thompson
Technical Illustrator	John Bickley
Technical Reviewers	Simon Chow Roy Chrisop Roy Law Jack Lin Yong-Qin Lu Clyde Wilson

### ***Manual Change Record***

This page records the changes to this manual.

Version	Date	Description of Change
001	7/95	Original publication as part number 063191.  This manual was previously the QuickBasic chapter in the <i>JANUS Programmer's Software Kit Reference Manual</i> , P/N 062133. That book now covers only C/C++, and this book covers both QuickBasic and Visual Basic library functions for PSK v2.1.

# Contents

**Before You Begin** *xiii*  
    *Warranty Information* *xiii*  
    *Cautions* *xiii*  
    *About This Manual* *xiv*  
    *Other Intermec Manuals* *xvii*

## 1

---

### **Getting Started**

**What Your JANUS Reader Can Do** 1-3  
**Virtual Wedge** 1-4  
**Reader Services** 1-5  
    *Function Libraries* 1-6  
    *Software Interrupts* 1-6  
**Installing the Programmer's Software Kit** 1-8

## 2

---

### **QuickBasic Library**

**Building a Program Using Microsoft QuickBasic** 2-3  
    *Building the QuickBasic Sample Program* 2-4  
    *Building Your Own QuickBasic Program* 2-6  
**Debugging With JANUS Application Simulator** 2-7  
**Runtime Requirements** 2-8  
    *Protocol Handlers* 2-8  
    *Reader Wedge* 2-9  
    *Specific Functions With Runtime Requirements* 2-10  
**Unsupported QuickBasic Functions** 2-11  
**Certified QuickBasic Language Functions** 2-12

## Contents

### **QuickBasic Functions 2-15**

*QuickBasic Functions Listed by Category 2-16*

*imApplBreakStatus 2-18*

*imBacklightOff 2-20*

*imBacklightOn 2-21*

*imBacklightToggle 2-22*

*imCancelRxBuffer 2-23*

*imCancelTxBuffer 2-26*

*imCommand 2-28*

*imCursorToViewport 2-30*

*imDecreaseContrast 2-31*

*imGetConfigInfo 2-33*

*imGetContrast 2-34*

*imGetControlKey 2-36*

*imGetDisplayMode 2-37*

*imGetDisplayType 2-39*

*imGetFollowCursor 2-40*

*imGetInputMode 2-41*

*imGetKeyclick 2-43*

*imGetLabelSymbology 2-44*

*imGetLength 2-45*

*imGetPostamble 2-46*

*imGetPreamble 2-47*

*imGetViewportLock 2-48*

*imGetWarmBoot 2-50*

*imIncreaseContrast 2-51*

*imInputStatus 2-53*

*imIrlA 2-55*

*imIrlK 2-60*

*imIrlN 2-64*

*imIrlV 2-69*

*imIrlY 2-73*

*imLinkComm 2-76*

*imMessage 2-78*

*imNumberPadOff 2-79*

*imNumberPadOn 2-80*



<i>imPowerStatus</i>	2-82
<i>imProtocolExtendedStatus</i>	2-84
<i>imReceiveBuffer</i>	2-87
<i>imReceiveBufferNoprot</i>	2-89
<i>imReceiveBufferNoWait</i>	2-92
<i>imReceiveByte</i>	2-95
<i>imReceiveInput</i>	2-97
<i>imRsInstalled</i>	2-100
<i>imRxCheckStatus</i>	2-101
<i>imSerialProtocolControl</i>	2-102
<i>imSetContrast</i>	2-105
<i>imSetControlKey</i>	2-107
<i>imSetDisplayMode</i>	2-108
<i>imSetFollowCursor</i>	2-113
<i>imSetInputMode</i>	2-114
<i>imSetKeyclick</i>	2-116
<i>imSetViewportLock</i>	2-117
<i>imSetWarmBoot</i>	2-118
<i>imSound</i>	2-119
<i>imStandbyWait</i>	2-121
<i>imTransmitBuffer</i>	2-122
<i>imTransmitBufferNoWait</i>	2-124
<i>imTransmitBufferNoprot</i>	2-126
<i>imTransmitByte</i>	2-128
<i>imUnlinkComm</i>	2-130
<i>imViewportEnd</i>	2-131
<i>imViewportGetxy</i>	2-132
<i>imViewportHome</i>	2-133
<i>imViewportMove</i>	2-134
<i>imViewportPageDown</i>	2-136
<i>imViewportPageUp</i>	2-137
<i>imViewportSetxy</i>	2-138
<i>imViewportToCursor</i>	2-140

# 3

---

## **Visual Basic Library**

### **Working With Visual Basic 3-3**

*Using Variable Addresses in Visual Basic 3-4*

*Setting Timeout Values 3-5*

*Handling Bar Code Scanner Input 3-5*

*Simulating Pressing a Key 3-5*

*Simulating Pressing the Tab Key 3-7*

*Providing Power Management Support 3-8*

### **Building a Program Using Microsoft Visual Basic 3-10**

### **Debugging With JANUS Application Simulator 3-13**

### **Runtime Requirements 3-14**

*Protocol Handlers 3-14*

*Reader Wedge 3-15*

*Specific Functions With Runtime Requirements 3-16*

### **Certified Basic Language Functions 3-17**

### **Visual Basic Functions 3-18**

*Visual Basic Functions Listed by Category 3-19*

*imApplBreakStatus 3-21*

*imBacklightOff 3-23*

*imBacklightOn 3-24*

*imBacklightToggle 3-25*

*imCancelRxBuffer 3-26*

*imCancelTxBuffer 3-28*

*imCommand 3-30*

*imCursorToViewport 3-32*

*imDecreaseContrast 3-33*

*imGetConfigInfo 3-35*

*imGetContrast 3-37*

*imGetControlKey 3-39*

*imGetDisplayMode 3-41*

*imGetDisplayType 3-43*





*imGetFollowCursor* 3-44  
*imGetInputMode* 3-45  
*imGetKeyclick* 3-47  
*imGetLabelSymbology* 3-48  
*imGetLength* 3-49  
*imGetPostamble* 3-50  
*imGetPreamble* 3-51  
*imGetViewportLock* 3-52  
*imGetWarmBoot* 3-54  
*imIncreaseContrast* 3-55  
*imInputStatus* 3-57  
*imIrlA* 3-59  
*imIrlK* 3-64  
*imIrlN* 3-68  
*imIrlV* 3-73  
*imIrlY* 3-77  
*imLinkComm* 3-80  
*imMessage* 3-82  
*imNumberPadOff* 3-83  
*imNumberPadOn* 3-84  
*imPowerStatus* 3-86  
*imProtocolExtendedStatus* 3-88  
*imReceiveBuffer* 3-91  
*imReceiveBufferNoprot* 3-94  
*imReceiveBufferNoWait* 3-97  
*imReceiveByte* 3-100  
*imReceiveInput* 3-102  
*imRsInstalled* 3-105  
*imRxCheckStatus* 3-106  
*imSerialProtocolControl* 3-107  
*imSetContrast* 3-110  
*imSetControlKey* 3-112  
*imSetDisplayMode* 3-113  
*imSetFollowCursor* 3-119  
*imSetInputMode* 3-120  
*imSetKeyclick* 3-122

## Contents

*imSetViewportLock* 3-123  
*imSetWarmBoot* 3-124  
*imSound* 3-125  
*imStandbyWait* 3-127  
*imTransmitBuffer* 3-128  
*imTransmitBufferNoWait* 3-130  
*imTransmitBufferNoprot* 3-132  
*imTransmitByte* 3-134  
*imUnlinkComm* 3-136  
*imViewportEnd* 3-137  
*imViewportGetxy* 3-138  
*imViewportHome* 3-139  
*imViewportMove* 3-140  
*imViewportPageDown* 3-142  
*imViewportPageUp* 3-143  
*imViewportSetxy* 3-144  
*imViewportToCursor* 3-146



---

## Status Codes

**Status Code Bit Values** A-3

**Status Codes Listed Numerically** A-4

**Status Codes Listed by Subsystem** A-22

*Subsystem 0100 RS (Reader Services)* A-23  
*Subsystem 0200 CM (Configuration Management)* A-24  
*Subsystem 0300 SC (Scanner)* A-27  
*Subsystem 0400 DC (Decodes)* A-28  
*Subsystem 0500 RW (Reader Wedge)* A-30  
*Subsystem 0600 CU (Communication)* A-32  
*Subsystem 0800 PM (Power Management)* A-34  
*Subsystem 0A00 TM (Timer)* A-35  
*Subsystem 0B00 BP (Beep)* A-36  
*Subsystem 0E00 IM (Intermec Library)* A-37  
*Subsystem 0F00 LG (Event Logger)* A-38

*Contents*



*Subsystem 1000 KB (Keyboard Buffer) A-39*  
*Subsystem 1100 SS (System Configuration) A-40*  
*Subsystem 1200 KP (Keypad Services) A-41*  
*Subsystem 1300 DP (Display) A-42*

*Index I-3*



## Before You Begin

---

This section introduces you to standard warranty provisions, safety precautions, warnings and cautions, document formatting conventions, and sources of additional product information.

---

### **Warranty Information**

To receive a copy of the standard warranty provision for this product, contact your local Intermec sales organization. In the U.S. call (800) 755-5505, and in Canada call (800) 688-7043. Otherwise, refer to the Worldwide Sales & Service list shipped with this manual for the address and telephone number of your Intermec sales organization.

---

### **Cautions**

The cautions in this manual use the following format.



#### **Caution**

***A caution alerts you to an operating procedure, practice, condition, or statement that must be strictly observed to prevent equipment damage or destruction, or corruption or loss of data.***

#### **Conseil**

***Une précaution vous alerte d'une procédure de fonctionnement, d'une méthode, d'un état ou d'un rapport qui doit être strictement respecté pour empêcher l'endommagement ou la destruction de l'équipement, ou l'altération ou la perte de données.***

---

## About This Manual

This manual is part of the JANUS Programmer's Software Kit manual set. It describes the special features and methods needed for programming the JANUS family of PC-compatible readers. If you plan to write programs in QuickBasic or Visual Basic for MS-DOS, the information in this manual is very valuable.

If you plan to write programs in C/C++, refer to the *JANUS Programmer's Software Kit for C/C++ Reference Manual*, Part No. 062133.

If you plan to write programs in Ada, refer to the *JANUS Programmer's Software Kit for Ada Reference Manual*, Part No. 062038.

If you plan to write programs using the Interactive Reader Language (IRL), refer to the *IRL Programming Reference Manual*, Part No. 048609, and your JANUS user's manual for programming guidelines.

## Organization

The *JANUS Programmer's Software Kit for Basic Reference Manual* is divided into three chapters and one appendix as described below:

Chapter	What You Will Find
1	<i>Getting Started</i> This chapter describes the capabilities of and programming methods for the JANUS readers. It also explains how to install the Programmer's Software Kit Language Libraries disk that is provided with this manual.
2	<i>QuickBasic Language Support</i> This chapter describes how to write QuickBasic applications using the Programmer's Software Kit (PSK) library functions.
3	<i>Visual Basic Language Support</i> This chapter describes how to write Visual Basic applications using the PSK library functions.
<i>Appendix A</i>	<i>Status Codes</i> This appendix lists status codes that are returned by the PSK functions.



## ***Terms and Conventions***

- A *reader* is the JANUS 2010, 2020, or 2050 PC-compatible bar code reader.
- An *operator* is anyone who runs applications on the reader.
- A *programmer* is anyone who writes applications for the reader.
- A *normal PC* is assumed to be a DOS-based PC/AT-compatible 386, with a hard disk, 14-inch monitor, full-size keyboard, floppy disk drives, and at least two communications ports.
- *Reader services* are the functional abilities that distinguish the JANUS readers from a normal PC. For example, the reader's ability to decode bar code data as if it came from a PC keyboard is a typical reader service.
- *Software interrupts* are the synchronous triggering of interrupts used for application program interfaces.
- *Library functions* are the Intermec-specific functions provided in the language libraries you use to invoke various reader services.
- *PSK* means the Programmer's Software Kit and refers to the language libraries and the associated manuals.
- The *Programmer's Software Kit Language Libraries* is the disk shipped with this manual. It contains sample programs and library functions for interfacing with the reader.
- The *keypad* is the custom JANUS keyboard. Throughout this manual, specific references to the JANUS keyboard use the term *keypad*.
- The *keyboard* buffer is the machine-level buffer that stores key presses and scanned labels. Throughout this manual, specific references to this buffer and its status flags use the term *keyboard*.

### ***Keypad Input***

- Keys that you press on the keypad are emphasized in **bold**. For example, "press **Enter**" means you press the key labeled "Enter" on the reader keypad.
- All key names use first-letter capitalization. For example:
  - Ctrl** = Control key
  - Enter** = Enter key
  - F3** = F3 key

## *Before You Begin*

- When you are required to press and release a series of keys in order, the keys are listed in order with no connectors. For example, to enter the uppercase character A, press **Shift A**. To enter this character, you press and release the **Shift** key, and then press the key marked **A**.
- When you are required to press more than one key at the same time, the keys are connected by a dash in the text. For example, press **Ctrl-Alt-Del** to perform a warm boot on a standard PC. When the keys are connected by a dash, it is important that you press and hold the keys in the order they are listed in the text.

### *Commands*

- DOS commands are printed in Courier, exactly as you must type them. For example:

```
COPY INTERMEC.* E:\
```

- Code examples are printed in 8-point Courier. For example:

```
if(step != 0) level = step;    // use step value if provided
if(level >= 31) level = 0;    // keep level within bounds
```

### *Other Conventions*

- *Italic type* identifies a syntax parameter where it is defined in text. Italic type is also used to indicate references to other manuals and to indicate important terminology.
- Hexadecimal numbers in text are followed by an uppercase H. For example, 03 hex is shown as 03H.
- Hexadecimal numbers in C language code segments begin with 0x. For example, AX\_REG = 0x5300.





---

## ***Other Intermec Manuals***

You may need additional information for working with the PSK in a data collection system. To order additional manuals, contact your local Intermec representative or distributor.

The following publications contain useful information for programming the JANUS family of PC-compatible readers:

<b>Manual</b>	<b>Intermec Part No.</b>
<i>JANUS PSK for C/C++ Reference Manual</i>	062133
<i>JANUS PSK for Ada Reference Manual</i>	062038
<i>JANUS 2010 Hand-Held Computer User's Manual</i>	058426
<i>JANUS 2020 Hand-Held Computer User's Manual</i>	059951
<i>JANUS 2050 Vehicle Mount Unit User's Guide</i>	062874
<i>JANUS Application Simulator User's Manual</i>	062778
<i>IRL Programming Reference Manual</i>	048609
<i>Data Communications Reference Manual</i>	044737
<i>The Bar Code Book</i>	051241
<i>DCM for OS/2 Manual Kit</i>	057433
<i>DCM for HP-UX Manual Kit</i>	062223
<i>DCM for SCO Manual Kit</i>	062765

For additional programming information, see the software development kit manuals provided with your language.

**Note:** *The Programmer's Software Kit Language Libraries disk accompanying this manual includes a file called README.TXT. This file contains updates to this document and other important notes.*



**1**


***Getting Started***



*This chapter briefly describes the programming methods and capabilities that apply to the JANUS family of readers and explains how to install the PSK.*

## ***What Your JANUS Reader Can Do***

---



Your JANUS reader is a portable, programmable bar code reader and a 386-based computer in one. Each reader has the Intermec controlled BIOS and Microsoft ROM DOS 5.0. The reader behaves and functions like a normal PC with 640K of memory, with these exceptions:

- The JANUS 2010 and 2020 are hand-held, with a small LCD display, custom keyboard, and either a port for a bar code input device or a built-in scanner.
- The JANUS 2050 is mounted to a vehicle, such as a forklift, and has a monochrome CGA display, custom keyboard, built-in RF, and a port for a bar code input device.
- The operating system and protocol support programs reduce the memory available for your application to about 450K.

You can run batch programs and copy, name, or move files in the same manner as you would with any normal PC. The only difference is that the JANUS reader has ROM and RAM drives and a PC card drive.

You can also run DOS-based programs on the reader the same as you can on a PC. When you do, the reader behaves like a PC, but has the advantage of accepting bar code input as if it came from the keypad. If you are an experienced PC programmer, you have already written programs that will run on the reader.

## ***Virtual Wedge***

---

The Virtual Wedge feature of the reader allows application programs to receive decoded bar codes from the keyboard buffer. The Virtual Wedge makes the reader functionally equivalent to a reader wedge connected to a PC. Bar code input is inserted into the PC keyboard buffer as if entered from the keypad. The Virtual Wedge also allows rapid porting of PC applications to the reader.

***Note:** If your PC application follows MS-DOS programming conventions, it should run correctly on the JANUS reader. Not all programming languages, especially database languages, follow these conventions. If your PC application does not follow MS-DOS programming conventions, your scanned input will be incorrect.*

Valid configuration commands and reader commands are not put into the keyboard buffer. Bar code configuration commands beginning with \$+ are tagged as configuration commands by the Virtual Wedge and sent to the configuration manager to reconfigure the reader. The command parser in the Virtual Wedge software recognizes and processes reader commands.

You can run applications that use the Virtual Wedge (instead of Intermec interrupt extensions or function libraries) on either the reader or on your PC.

## Reader Services

---

Reader services include several functions ranging in complexity from controlling the reader beeper to controlling the function of the power management software. With reader services, you can easily use bar code input from a wand or scanner by using the direct program interface to handle the functions of the reader keyboard, display, and beeper.

There are two methods for incorporating the reader services into your programs:

- Using function libraries
- Using software interrupts

You can use either one or a combination of both methods.

**Note:** Do **not** run programs that use **PSK library functions** on your PC, **unless** you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### Caution

**Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### Conseil

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**

---

## ***Function Libraries***

You can use a *supported language* and its associated function libraries to access reader services. The term *supported language* describes a language that has extensive Intermec-supplied library functions that control reader services. The supported language functions are stored in libraries contained on the Programmer's Software Kit Language Libraries disk that is provided with this manual.

At the time of printing, the list of supported languages includes:

- Borland C/C++
- Microsoft C/C++
- Microsoft Visual C/C++
- Microsoft QuickBasic
- Microsoft Visual Basic for MS-DOS
- Janus/Ada

When you write applications in one of the supported languages, link your program to the library for your chosen language by including the header files in your program, and then invoke the reader services using the language-specific reader service commands. The Intermec-specific functions are documented in Chapter 2, "QuickBasic Language Support," and Chapter 3, "Visual Basic Language Support."

Both C/C++ and Ada support are completely explained in separate manuals. For more information, refer to the following manuals:

- *JANUS PSK for C/C++ Reference Manual*, P/N 062133
- *JANUS PSK for Ada Reference Manual*, P/N 062038

---

## ***Software Interrupts***

The reader supports special software interrupts in addition to those available on a normal PC. If your programming language supports software interrupts, you can write applications that use the reader services. However, it is much easier to use the PSK library functions.

Interrupts are a very *low-level* method of controlling a computer. Programming with interrupts is more difficult than with a high-level language (such as Ada, C, or Basic).



Some of the most popular languages have built-in commands for triggering software interrupts (Microsoft C, Borland C++, and QuickBasic, for example). Languages that do not have built-in interrupt commands sometime allow you to access interrupts by embedding fragments of assembly language inside your program. There are other methods for triggering software interrupts, and you can generate software interrupts from almost any language.

For complete descriptions and examples of the software interrupts that govern reader services, see Chapter 3, “Software Interrupts,” and Appendix B, “Sample Interrupt Programs,” in the *JANUS PSK for C/C++ Reference Manual*, P/N 06213.

**Caution**

*Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.*

**Conseil**

*N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.*

## ***Installing the Programmer's Software Kit***

---

The files on the Programmer's Software Kit Language Libraries disk are distributed in several subdirectories, each corresponding to the supported language:

Subdirectory Name	Language
INTERMEC\BORLANDC	Borland C/C++
INTERMEC\MICROSFT	Microsoft C/C++ and Visual C/C++
INTERMEC\QUICKB	Microsoft QuickBasic
INTERMEC\VBDOS	Visual Basic for DOS
INTERMEC\ADA	Janus/Ada

The exact contents of the PSK Language Libraries disk is listed in the README.TXT file contained on the disk. To use the library functions, install the correct files on your computer. You can also use the DOS copy command to copy only the specific files you are sure you will need.

**Note:** *If you have an existing Intermec directory, the installation process will update any files in the existing Intermec directory with the newer version files having the same name.*

To install the library files

1. Insert the PSK Language Libraries disk into the disk drive on your PC.
2. Change to the appropriate disk drive. For example, type A:.
3. Enter the following command:

```
INSTALL dirname drive
```

where:

*dirname* is either BORLANDC, MICROSFT, QUICKB, VBDOS, or ADA, depending on which programming language you need.

*drive* is the location where you want to install the utilities library. If you omit the drive, drive C is assumed.

2

*QuickBasic Library*



*This chapter describes how to write applications in QuickBasic using the PSK library functions.*

## ***Building a Program Using Microsoft QuickBasic***

---

The PSK QuickBasic functions are designed to work with the Microsoft BCOM45.LIB QuickBasic library. When writing your programs, use standard QuickBasic programming techniques.

The following procedures shows you how to compile and link a QuickBasic program that uses the QuickBasic library functions you installed from the PSK disk. In the first procedure, you will use one of the example programs. In the second procedure, you compile and link your own program.

Keep the following tips in mind when you build QuickBasic programs:

- Refer to your QuickBasic user's guide for information on using BC.EXE and LINK.EXE.
- Both C and QuickBasic use the BC.EXE and LINK.EXE commands. If you have C and QuickBasic installed, run these command from the QuickBasic directory or make sure that your QuickBasic directory comes before your C directory in your path.
- You must build a standalone executable program.

---

## ***Building the QuickBasic Sample Program***

The following procedure uses the sample program file RCVINPUT.BAS. The source file (\*.BAS), object file (\*.OBJ), and executable file (\*.EXE) all have the same filename.

To build the RCVINPUT.BAS sample program

1. When you installed the PSK, the following files were copied into \INTERMEC\QUICKB. Create a new subdirectory and copy these files into it:

RCVINPUT.BAS	Sample program demonstrating imReceiveInput
IM20BAS1.BI	Include file for PSK functions

2. In the same subdirectory, create a response file, RCVINPUT.RSP, for linking. The response file consists of the following four lines:

```
RCVINPUT.OBJ
RCVINPUT
(a blank line)
C:\INTERMEC\QUICKB\LIB\IM20_BAS.LIB C:\QB45\BCOM45.LIB
```

where:

the first line lists the program file and its path.

the second line lists only the executable filename with no extension.

the third line is left blank.

the fourth line lists the library files, including their path.

3. Compile the sample program from DOS:

```
BC /T /O RCVINPUT.BAS, RCVINPUT, NUL.LST
```

where:

/T /O builds a standalone object file to use with BCOM45.LIB.

4. Link the sample program from the DOS prompt:

```
LINK /NOE @RCVINPUT.RSP
```

where:

/NOE searches the object files for public symbols that may be redefined in your program.

5. Copy RCVINPUT.EXE to your JANUS reader and run the program. This sample program will prompt for input from either the keypad, the scanner, or COM1.

#### *Handling a Linker Error Message*

You may get a linker error message when you link the QuickBasic program. If you receive the following error message, your program has more segments than the default (128):

```
fatal error L1049: too many segments
```

You need to increase the number of segments and link again.

#### To set the number of segments

- Enter the following command from the DOS prompt:

```
LINK /SEG:nnn /NOE @programe.RSP
```

where: *nnn* is a number between 1 and 16,375.

---

## ***Building Your Own QuickBasic Program***

In the following procedure, *progname* is the name of your program file without an extension. Your source file (\*.BAS), object file (\*.OBJ), and executable file (\*.EXE) all have the same filename.

To build a program using QuickBasic

1. Change to the directory containing your program file, *progname*.BAS.
2. Create a response file, *progname*.RSP, for linking. The response file consists of the following four lines:

```
progname.OBJ  
progname  
(a blank line)  
C:\INTERMEC\QUICKB\LIB\IM20_BAS.LIB C:\QB45\BCOM45.LIB
```

where:

the first line lists the program file and its path.

the second line lists only the executable filename with no extension.

the third line is left blank.

the fourth line lists the library files, including their path.

3. Compile the program from DOS:

```
BC /T /O progname.BAS, progname, NUL.LST
```

where:

/T /O builds a standalone object file to use with BCOM45.LIB.

*progname* is your program name and the name for the object file, \*.OBJ.

4. Link the program from the DOS prompt using the response file:

```
LINK /NOE @progname.rsp
```

where:

/NOE searches the object files for public symbols that may be redefined in your program.

5. Copy your program, *progname*.EXE, to your JANUS reader and run the program.



### *Handling a Linker Error Message*

You may get a linker error message when you link the QuickBasic program. If you receive the following error message, your program has more segments than the default (128):

```
fatal error L1049: too many segments
```

You need to increase the number of segments and link again.

To set the number of segments

- Enter the following command from the DOS prompt:

```
LINK /SEG:nnn /NOE @programe.RSP
```

where: *nnn* is a number between 1 and 16,375.

## ***Debugging With JANUS Application Simulator***

---

The JANUS Application Simulator is a terminate-and-stay resident (TSR) program that you use to run JANUS applications on a PC. Without the Simulator, you cannot run JANUS applications on your PC. Whenever you start a program that uses PSK library functions, the program checks for a JANUS reader and for the JANUS Simulator. If you attempt to run a JANUS program on a PC without the Simulator, you get an error message.

The Simulator captures the JANUS functions and interrupts to make the PC mimic a JANUS reader. For more information on the Simulator, refer to the *JANUS Application Simulator User's Manual*, Part No. 062778.

To debug a JANUS application with the Simulator

1. Start the Simulator from the DOS prompt by entering this command:

```
janussim
```

2. Start QuickBasic.
3. Follow the debugging instructions provided with QuickBasic.

## ***Runtime Requirements***

---

For some library functions to work properly, you must install and run specific software components at program execution time. For example, if the reader is using a communications port and you want to use Intermec protocols, you must load a protocol handler. Because protocol handlers use a lot of memory, they are not automatically loaded for you. Other functions require the Reader Wedge.

---

### ***Protocol Handlers***

You use the Intermec protocol handler (PHIMEC.EXE) when the reader is connected with other Intermec devices. PHIMEC.EXE works with User-Defined, Point-to-Point, Polling Mode D, and Multi-Drop protocols.

You use the PC standard protocol handler (PHPCSTD.EXE) when the reader is connected to devices that use PC standard protocol. PHPCSTD.EXE provides low-level communication abilities and protocol services at the DOS level for non-communication software. It also provides byte-by-byte transfer.

If your reader is a radio frequency (RF) unit, RFPH.EXE is automatically loaded.

For more information on protocol handlers, refer to your JANUS user's manual.

To install a protocol handler on the reader

- From the DOS prompt, enter the following command:

```
handler n
```

where:

*handler* is either PHIMEC or PHPCSTD.

*n* is the number of the communications port.

When your application is finished, the protocol handler TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the protocol handler TSR by adding the unload command as the last line of the batch file that launches your application.

#### To unload a protocol handler on the reader

- From the DOS prompt, enter the following command:

```
unload handler n
```

where:

*handler* is the installed handler (PHIMEC or PHPCSTD).

*n* is the number of the communications port.

---

### ***Reader Wedge***

Some functions, such as `imReceiveInput`, allow the reader to receive input from multiple sources and process the input depending on the source. You must load the Reader Wedge (RWTSR.EXE) TSR to use these functions.

When your application is finished, the Reader Wedge TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the Reader Wedge TSR by adding the unload command as the last line of the batch file that launches your application.

#### To load the Reader Wedge TSR on the reader

- From the DOS prompt, enter the following command:

```
RWTSR
```

#### To unload the Reader Wedge TSR on the reader

- From the DOS prompt, enter the following command:

```
RWTSR -D
```

---

## ***Specific Functions With Runtime Requirements***

The following table lists the PSK functions that have runtime requirements.

---

### ***Specific Runtime Requirements***

<b>This Function</b>	<b>Requires</b>
imCancelRxBuffer	Protocol Handler
imCancelTxBuffer	Protocol Handler
imCommand	Reader Wedge
imGetInputMode	Reader Wedge
imGetLabelSymbology	Reader Wedge
imGetLength	Reader Wedge
imInputStatus	Reader Wedge
imIrlA	Reader Wedge
imIrlK	Reader Wedge
imIrlN	Reader Wedge
imIrlV	Reader Wedge If data is from a communications port, use a Protocol Handler and imLinkComm.
imIrlY	Reader Wedge Protocol Handler Use imLinkComm.
imLinkComm	Reader Wedge Protocol Handler
imReceiveBuffer	Protocol Handler Will not work if linked.
imReceiveBufferNoprot	Protocol Handler Will not work if linked.
imReceiveBufferNoWait	Protocol Handler Will not work if linked.
imReceiveByte	Protocol Handler You must install PHPCSTD. Will not work if linked.
imReceiveInput	Reader Wedge If data is from a communications port, use a Protocol Handler and imLinkComm.

---

*Specific Runtime Requirements (continued)*

<b>This Function</b>	<b>Requires</b>
imRxCheckStatus	Protocol Handler
imSerialProtocolControl	imLinkComm
imSetDisplayMode	Reader Wedge
imSetInputMode	Reader Wedge
imStandbyWait	Reader Wedge
imTransmitBuffer	Protocol Handler
imTransmitBufferNoprot	Protocol Handler
imTransmitBufferNoWait	Protocol Handler
imTransmitByte	Protocol Handler You must install PHPCSTD.
imUnlinkComm	Reader Wedge Protocol Handler

---

## ***Unsupported QuickBasic Functions***

---

Your JANUS reader does not support these QuickBasic light pen and joystick functions:

ON PEN GOSUB    ON STRIG GOSUB  
 PEN            PEN ON/OFF/STOP  
 STICK        STICKSTRIG  
 STRIG ON/OFF/STOP

Your JANUS reader does not support these QuickBasic file functions:

LOCK        UNLOCK

## ***Certified QuickBasic Language Functions***

---

Because of the large number of functions in the QuickBasic language, not all functions are known to work correctly when used with the Intermec family of PC-compatible readers. Many of these have been tested, however, and are known to operate on the reader the same way as on a PC. These tested functions are listed below.

**Note:** For a list of QuickBasic functions that are compatible with Visual Basic, see your Visual Basic manual.

---

### ***Tested QuickBasic Functions***

SDYNAMIC Metacommand	COLOR Statement	DEFLNG Statement
SSTATIC Metacommand	COM Statement	DEFSNG Statement
ABS Function	COMMON Statement	DEFSTR Statement
ABSOLUTE Keyword	CONST Statement	DIM Statement
AND Operator	COS Function	DO...LOOP Statement
ANY Keyword	CSNG Function	DOUBLE Keyword
APPEND Keyword	CSRLIN Function	DRAW Statement
AS Keyword	CVD Function	ELSE Keyword
ASC Function	CVSMBF Function	ELSEIF Keyword
ATN Function	CVDMBF Function	END Statement
BASE Keyword	CVI Function	ENVIRON Statement
Basic Character Set	CVL Function	ENVIRON\$ Function
BEEP Statement	CVS Function	EOF Function
BINARY Keyword	DATA Statement	EQV Operator
BLOAD Statement	Data Type Keywords	ERASE Statement
Boolean Operators	DATES\$ Function	ERDEV Function
BSAVE Statement	DATES\$ Statement	ERDEV\$ Function
CALL ABSOLUTE Statement	DECLARE Statement	ERL Function
CALL Statement	DEF FN Statement	ERR Function
CASE Keyword	DEF SEG Statement	ERROR Statement
CDBL Function	DEFDBL Statement	EXIT Statement
CHAIN Statement	DEFINT Statement	EXP Function

---

*Tested QuickBasic Functions (continued)*

FIELD Statement	LINE (Graphics) Statement	ON Keyword
FILEATTR Function	LINE INPUT Statement	ON PLAY Statement
FILES Statement	LIST Keyword	ON TIMER Statement
FIX Function	LOC Function	ON...GOSUB Statement
FOR...NEXT Statement	LOCATE Statement	ON...GOTO Statement
FRE Function	LOF Function	OPEN Statement
FREEFILE Function	LOG Function	OPTION BASE Statement
FUNCTION Statement	LONG Keyword	OR Operator
GET (File I/O) Statement	LOOP Keyword	OUT Statement
GET (Graphics) Statement	LPOS Function	OUTPUT Keyword
GOSUB Statement	LPRINT Statement	PAINT Statement
GOTO Statement	LPRINT USING Statement	PEEK Function
HEX\$ Function	LSET Statement	PLAY (Event Trapping) Statements
IF...THEN...ELSE Statement	LTRIMS\$ Function	PLAY (Music) Statement
IMP Operator	MID\$ Function	PLAY Function
INKEY\$ Function	MKD\$ Function	PMAP Function
INP Function	MKDIR Statement	POINT Function
INPUT Statement	MKDMBF\$ Function	POKE Statement
INPUT\$ Function	MKI\$ Function	POS Function
INSTR Function	MKL\$ Function	PRINT Statement
INT Function	MKS\$ Function	PRINT USING Statement
INTEGER Keyword	MKSMBF\$ Function	PSET Statement
IS Keyword	MOD Operator	PUT (File I/O) Statement
KEY (Assignment) Statement	NAME Statement	PUT (Graphics) Statement
KEY (Event Trapping) Statement	NEXT Keyword	RANDOM Keyword
KILL Statement	NOT Operator	RANDOMIZE Statement
LBOUND Function	OCT\$ Function	READ Statement
LCASE\$ Function	OFF Keyword	REDIM Statement
LEFT\$ Function	ON COM Statement	REM Statement
LEN Function	ON ERROR Statement	RESET Statement
LET Statement	ON KEY Statement	RESTORE Statement

---

*Tested QuickBasic Functions (continued)*

RESUME Statement	SYSTEM Statement
RETURN Statement	TAB Function
RIGHT\$ Function	TAN Function
RMDIR Statement	THEN Keyword
RND Function	TIMES Function
RSET Statement	TIMES\$ Statement
RTRIM\$ Function	TIMER Function
RUN Statement	TIMER Statements
SCREEN Function	TO Keyword
SCREEN Statement	TROFF Statement
SEEK Function	TRON Statement
SEEK Statement	TYPE Statement
SELECT CASE Statement	UBOUND Function
SGN Function	UCASE\$ Function
SHARED Statement	UNTIL Keyword
SHELL Statement	USING Keyword
SIN Function	VAL Function
SINGLE Keyword	VARPTR Function
SLEEP Statement	VARPTR\$ Function
SOUND Statement	VARSEG Function
SPACE\$ Function	VIEW PRINT Statement
SPC Function	VIEW Statement
SQR Function	WAIT Statement
STATIC Statement	WHILE...WEND Statement
STEP Keyword	WINDOW Statement
STOP Statement	WRITE Statement
STR\$ Function	XOR Operator
STRING Keyword	
STRING\$ Function	
SUB Statement	
SWAP Statement	



## QuickBasic Functions

---

The following pages list the QuickBasic functions available in the PSK, along with notes on syntax and examples of how to use each function.

**Note:** Do **not** run programs that use **PSK library functions** on your PC, **unless** you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### Caution

**Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### Conseil

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**

---

## **QuickBasic Functions Listed by Category**

### **Communications**

imCancelRxBuffer, 2-23  
imCancelTxBuffer, 2-26  
imLinkComm, 2-76  
imProtocolExtendedStatus, 2-84  
imReceiveBuffer, 2-87  
imReceiveBufferNoprot, 2-89  
imReceiveBufferNoWait, 2-92  
imReceiveByte, 2-95  
imRxCheckStatus, 2-101  
imSerialProtocolControl, 2-102  
imTransmitBuffer, 2-122  
imTransmitBufferNoprot, 2-126  
imTransmitBufferNoWait, 2-124  
imTransmitByte, 2-128  
imUnlinkComm, 2-130

### **Display**

imBacklightOff, 2-20  
imBacklightOn, 2-21  
imBacklightToggle, 2-22  
imDecreaseContrast, 2-31  
imGetContrast, 2-34  
imGetDisplayMode, 2-37  
imGetDisplayType, 2-39  
imGetFollowCursor, 2-40  
imIncreaseContrast, 2-51  
imSetContrast, 2-105  
imSetDisplayMode, 2-108  
imSetFollowCursor, 2-113

### **Input**

imGetInputMode, 2-41  
imGetLabelSymbology, 2-44  
imGetLength, 2-45  
imGetPostamble, 2-46  
imGetPreamble, 2-47  
imInputStatus, 2-53  
imReceiveByte, 2-95  
imReceiveInput, 2-97  
imSetInputMode, 2-114

### **Irl**

imIrlA, 2-55  
imIrlK, 2-60  
imIrlN, 2-64  
imIrlV, 2-69  
imIrlY, 2-73

### **Keypad**

imGetControlKey, 2-36  
imGetKeyclick, 2-43  
imGetWarmBoot, 2-50  
imNumberPadOff, 2-79  
imNumberPadOn, 2-80  
imSetControlKey, 2-107  
imSetKeyclick, 2-116  
imSetWarmBoot, 2-118

### **Program Control**

imApplBreakStatus, 2-18  
imStandbyWait, 2-121

### **Sound**

imSound, 2-119

### **System**

imCommand, 2-28  
imGetConfigInfo, 2-33  
imMessage, 2-78  
imPowerStatus, 2-82  
imRsInstalled, 2-100

### **Viewport**

imCursorToViewport, 2-30  
imGetViewportLock, 2-48  
imSetViewportLock, 2-117  
imViewportEnd, 2-131  
imViewportGetxy, 2-132  
imViewportHome, 2-133  
imViewportMove, 2-134  
imViewportPageDown, 2-136  
imViewportPageUp, 2-137  
imViewportSetxy, 2-138  
imViewportToCursor, 2-140

---

## ***imApplBreakStatus***

**Purpose:** This function checks whether the application break sequence has been pressed. All PSK functions are terminated when the application break sequence is keyed in.

Place calls to this function at strategic locations in your program to detect when a user wants to break out of a loop. Your program can determine what action to take when the break sequence is detected.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imApplBreakStatus% CDECL  
    (BreakStatus AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *BreakStatus* parameter returns a nonzero value if the break status bit is set and zero if it is not set.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The *BreakStatus* flag is reset each time the routine is called. Because this function is also called during the input routines provided in the library, you should check the return code from input functions for the hex value 8515H. This value indicates that the input function has terminated because the application break sequence was entered. In this case, *BreakStatus* is cleared by the input function's call to *imApplBreakStatus*.

To enter an application break sequence

1. Press  $\text{\textcircled{I/O}}$  to turn off the reader.
2. Press  $\text{\textcircled{F3}}$  -  $\text{\textcircled{2}}$  -  $\blacktriangleleft$  at the same time.
3. Press  $\text{\textcircled{1}}$ . This sets the reader's application break bit.
4. Press  $\text{\textcircled{I/O}}$  to turn on the reader.

---

**Example**

```
'***** imApplBreakStatus *****
REM $INCLUDE: 'im20bas1.bi'

' Initializing Variables
Brk% = 0
Temp$ = ""

' Clear the screen
CLS

' Press the following sequence to set the application break on:
'   I/O key (Turn OFF the reader)
'   F3+2+LeftArrow (Press F3, 2, and left arrow at the same time)
'   1 (Press the 1 key to set application break bit)
'   I/O key (Turn the reader ON)

WHILE Temp$ <> "q"

' Check the application break status
status% = imApplBreakStatus(Brk%)

IF Brk% THEN
    PRINT "App Brk is ON"
ELSE
    PRINT "App Brk is OFF"
END IF

PRINT
PRINT "Press any key to continue, "
PRINT "'q' for quit: "
PRINT
PRINT
Temp$ = INPUT$(1)
WEND
END
```

---

## ***imBacklightOff***

**Purpose:** This function turns the display backlight off. Turn the backlight off to prolong the reader's battery life.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imBacklightOff CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1 second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** imBacklightOn, imBacklightToggle

---

### ***Example***

```
'***** imBacklightOff *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Backlight off  
    CALL imBacklightOff  
    PRINT "Backlight off"  
END
```

---

## ***imBacklightOn***

**Purpose:** This function turns the display backlight on to illuminate the reader display in dimly lit environments.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imBacklightOn CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1 second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** imBacklightOff, imBacklightToggle

---

### ***Example***

```
'***** imBacklightOn *****  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Backlight on  
    CALL imBacklightOn  
    PRINT "Backlight on "  
END
```

---

## ***imBacklightToggle***

**Purpose:** This function toggles the display backlight ON and OFF.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imBacklightToggle CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1 second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** imBacklightOn, imBacklightOff

---

### ***Example***

```
'***** imBacklightToggle *****  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Backlight toggle  
    CALL imBacklightToggle  
    PRINT "Backlight switched on/off "  
END
```



---

## *imCancelRxBuffer*

**Purpose:** This function clears the receive buffer of the designated communications port.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imCancelRxBuffer% CDECL
    (BYVAL PortID AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1
imCom2    COM2, scanner port (2010 and 2050)
imCom4    COM4 (RF only)
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

If there is no input pending to receive, this function returns 4602H (no client).

**Notes:** You must install a protocol handler to use this function.

**See Also:** imReceiveBufferNoWait, imReceiveBufferNoprot

---

### *Example*

```
***** imCancelRxBuffer *****
REM $INCLUDE: 'im20bas1.bi'

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Data buffer structure for receive/transmit again and noprot
DIM farcomBuffStruct AS imFarComDataStruct

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

DIM done AS INTEGER

' The difference between imReceiveBufferNoWait and the ReceiveBufferNoprot
' is that the user must set up the imReceiveBufferNoWait comm
' struct and pend on the results. Whereas, in the Noprot receive, the
' user sets up the length of the buffer, points at that buffer and
```

### *imCancelRxBuffer – QuickBasic*

```
' sends it off and returns. There is no pending on this level for the
' imReceiveBufferNoprot routine

' Phimec protocol handler must be installed to run this routine

' Get the receive environment ready
' Call Intermec function
status%= imCancelRxBuffer(imCom1)

' Zero out string
str3 = STRING$(buffsize, CHR$(0))

' Set up communication buffer structure
farcomBuffStruct.command = imPhReceive
farcomBuffStruct.protocolMode = imNoProtocol
farcomBuffStruct.eomChar = CHR$(13) 'CR for terminating char
farcomBuffStruct.userLength = buffsize
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffsetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolXferStatus = imCuInuse
farcomBuffStruct.CommLength = 0

done = FALSE

' Call Intermec function
status%= imReceiveBufferNoWait(ImCom1, farcomBuffStruct)
PRINT "Func1= ", HEX$(status%)

' Loop until first character in buffer is a 'Q' or Esc is pressed
DO
,
' Check for receive errors:
' Print the error status

IF status%= imIserror THEN
PRINT "Rx Again err = ", HEX$(status%)
done = FALSE
ELSE
' Keyboard char
temp$ = " "
' Get the receive data
PRINT "Input chars"
PRINT "Enter 'Q'"
PRINT "or Esc to exit"

' Check to see if any characters are in buffer
DO WHILE farcomBuffStruct.protocolXferStatus = imCuInuse AND temp$ <> CHR$(27)
' Pick up any keypad input
temp$ = INKEY$
LOOP

PRINT "Comm done"
' Print the input string
PRINT str3

' Update buffer for next block then call imRxCheckStatus to
' get protocol handler to reset status.

farcomBuffStruct.command = imPhRecvAgain
farcomBuffStruct.protocolXferStatus = imCuInuse
farcomBuffStruct.commLength = 0

status%= imRxCheckStatus(ImCom1)
```

```
END IF

' Quit if first char in buffer is a 'Q' or a 'q'
' or Esc has been pressed
IF UCASE$(LEFT$(str3, 1)) = "Q" OR temp$ = CHR$(27) THEN
    done = TRUE
ELSE
    ' Zero out string and loop
    str3 = STRING$(buffsize, CHR$(0))
ENDIF

LOOP WHILE done = FALSE

' Release resources
status%= imCancelRxBuffer(ImCom1)
END
```

---

## ***imCancelTxBuffer***

**Purpose:** This function clears the contents of the transmit buffer for a designated communications port, stops transmission in progress, and resets the communications port.

Use this function with Polling Mode D to clear out the buffer. Other protocols clear the buffer automatically.

You can also use this function to clear a busy port.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imCancelTxBuffer% CDECL  
    (BYVAL PortID AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** *imTransmitBufferNoWait*, *imTransmitBufferNoprot*, *imTransmitBuffer*

---

### ***Example***

```
***** imCancelTxBuffer *****  
REM $INCLUDE: 'im20bas1.bi'  
  
' Define communication status messages  
CONST imCuSuccess = 1536  
CONST imInuse = -31230  
  
' Data buffer size must be at least 256 bytes  
CONST bufsize = 300  
  
' Data buffer structure for receive/transmit again and noprot  
DIM farcomBuffStruct AS imParComDataStruct  
  
' Define fixed length strings of 300 bytes (256 is minimum string buffer)
```

```
DIM str3 AS STRING * bufsize 'fixed length string
DIM done AS INTEGER

' PHIMEC protocol handler must be installed to run this routine
' Get the transmit environment ready
status%= imCancelTxBuffer(ImCom1)

' Make a null terminated string to transmit
str3 = "Hi There" + CHR$(0)

' Set up comm buffer parameters
farcomBuffStruct.command = imPhTransmit
farcomBuffStruct.protocolXferStatus = imInuse
' Get length not including the null terminator
farcomBuffStruct.userLength = INSTR(str3, CHR$(0)) - 1
farcomBuffStruct.commLength = 0
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffsetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolMode = imNoProtocol
' Terminator is null character
farcomBuffStruct.eomChar = CHR$(0)

' Call Intermec routine
status%= imTransmitBufferNoWait(ImCom1, farcomBuffStruct)

PRINT "Status = ", HEX$(status%)

IF status% = imCuSuccess THEN
' Wait for data transfer to complete
DO WHILE farcomBuffStruct.protocolXferStatus = imInuse AND INKEY$ <> CHR$(27)
LOOP

PRINT "Buffer transmitted"
ELSE
PRINT "Buffer not sent"
END IF

' Release resources
status%= imCancelTxBuffer(ImCom1)
END
```

---

## ***imCommand***

**Purpose:** This function modifies the reader's configuration. For example, you can use the function to set a specific communications port's baud rate.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION ImCommand% CDECL  
    (BYVAL Command AS INTEGER,  
     BYVAL CommandLength AS INTEGER)
```

**IN Parameters:** The *Command* parameter is a reader command string. The command string may include more than one reader command. For example, the command string `%.1$+BV9` turns on the backlight and raises the beep volume.

Reader commands are listed in your JANUS user's manual.

The *CommandLength* parameter is the length of the reader command string.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** For more information on using reader commands, see your JANUS user's manual.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** None.

---

**Example**

```
'***** imCommand *****
' $INCLUDE: 'im20bas1.bi'

CLS          ' Clear the screen

str1$ = "$+DJ7"
str2$ = "$+DJ0"
str3$ = "$+DJ3"

PRINT "Set high contrast"
status% = imCommand(SADD(str1$), LEN(str1$))
status% = imStandbyWait(2000)          ' Wait two seconds

PRINT "Set low contrast"
status% = imCommand(SADD(str2$), LEN(str2$))
status% = imStandbyWait(2000)          ' Wait two seconds

PRINT "Set normal contrast"
status% = imCommand(SADD(str3$), LEN(str3$))
status% = imStandbyWait(2000)          ' Wait two seconds

PRINT "Wait status >>";HEX$(status%)
imMessage(status%)
END
```

---

## ***imCursorToViewport***

**Purpose:** This function moves the cursor to the center of the current viewport. Since the viewport can move around with or without the cursor, you can use this function to recenter the cursor.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imCursorToViewport CDECL ( )

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imViewportEnd, imViewportHome,  
imViewportPageDown, imViewportPageUp,  
imViewportToCursor, imViewportMove

---

### ***Example***

```
'***** imCursorToViewport*****  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Call cursor to viewport  
    imCursorToViewport  
END
```



---

## ***imDecreaseContrast***

**Purpose:** This function decreases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast (0 to 31), where 0 is very light, and 31 is very dark.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imDecreaseContrast% CDECL ()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The 0 to 31 scale fine tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `imSetContrast` and `imGetContrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `imIncreaseContrast` and `imDecreaseContrast`. The following table compares the two scales.

This Value on Scale 0 to 7	Equates to This Value on Scale 0 to 31	Contrast Level
0	10	Very light
1	12	
2	14	
3	16	
4	18	
5	20	
6	22	Very dark
7	24	

This function has no effect on the JANUS 2050.

**See Also:** `imIncreaseContrast`, `imSetContrast`, `imGetContrast`

## *imDecreaseContrast – QuickBasic*

---

### **Example**

```
'***** imDecreaseContrast *****
REM $INCLUDE: 'im20bas1.bi'

PRINT "imDecreaseContrast"
' Call Intermec function
status% = imDecreaseContrast
'Pause for keypad input
temp$ = INPUT$(1)

PRINT "imDecreaseContrast"
' Call Intermec function
status% = imDecreaseContrast
END
```

---

## imGetConfigInfo

**Purpose:** This function retrieves the current reader configuration information string and its length.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imGetConfigInfo% CDECL ( )
    (conString AS STRING
     length AS INTEGER)
```

**IN/OUT Parameters:** The *conString* parameter is the configuration information string. The first two characters specify the type of configuration information returned.

For example, to get the beep duration setting, pass in “BD” for *conString*. The function returns BD and the current configuration for beep duration.

The *length* parameter is the length of the configuration information string.

For a list of the configuration commands, see your JANUS user’s manual.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function differs from *imCommand* in that you only pass the two-character command identifier. The *imCommand* function passes an entire command string.

**See Also:** *imCommand*

---

### Example

```
***** imGetConfigInfo *****
REM $INCLUDE: 'im20bas1.bi'

DIM outstr AS STRING *300

outstr = STRING$(300, CHR$(0))
outstr$ = "BV" + CHR$(0)

PRINT "ImGetConfigInfo example: "
status% = imGetConfigInfo(VARPTR(outstr), count%)

PRINT "Beep Volume: "; outstr
PRINT "Length: "; count%
PRINT "Status: "; HEX$(status%)
END
```

---

## ***imGetContrast***

**Purpose:** This function gets the reader's LCD display contrast level. There are eight levels of contrast (0 to 7) from very light to very dark, which are the most frequently used contrast settings.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetContrast% CDECL  
    (DisplayContrastLevel AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *DisplayContrastLevel* parameter is a number from 0 to 7 or is one of these constants defined in IM20LIB.H:

<code>imMinContrast</code>	<code>0</code>	Minimum contrast
<code>imMaxContrast</code>	<code>1</code>	Maximum contrast

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The functions `imSetContrast` and `imGetContrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `imIncreaseContrast` and `imDecreaseContrast`. The following table compares the two scales.

This Value on Scale 0 to 7	Equates to This Value on Scale 0 to 31	Contrast Level
0	10	Very light
1	12	
2	14	
3	16	
4	18	
5	20	
6	22	Very dark
7	24	

This function has no effect on the JANUS 2050.

**See Also:** `imSetContrast`, `imDecreaseContrast`, `imIncreaseContrast`

---

**Example**

```
'***** imGetContrast *****  
REM $INCLUDE: 'im20bas1.bi'  
  
  ' Get contrast  
  status% = imGetContrast (level%)  
  PRINT "Get Contrast status = ", HEX$(status%)  
  PRINT "Contrast level =", level%  
END
```

---

## ***imGetControlKey***

**Purpose:** You can enable or disable the **Ctrl** key. This procedure retrieves the current setting.

When you disable this keycode, none of the key combinations that use the **Ctrl** key will work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetControlKey% CDECL  
    (ControlKey AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *ControlKey* parameter is one of these constants:

imEnable	Ctrl key is enabled
imDisable	Ctrl key is disabled

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** imSetControlKey

---

### ***Example***

```
'***** imGetControlKey *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
status% = imSetControlKey(imEnable)  
PRINT "Enabling <CTRL>"  
status% = imGetControlKey(ctrlKey%)  
IF ctrlKey% = imEnable THEN  
    PRINT "<CTRL> enabled"  
ELSE  
    PRINT "<CTRL> disabled"  
END IF  
INPUT "Test it>>",response$  
status% = imSetControlKey(imDisable)  
PRINT "Disabling <CTRL>"  
status% = imGetControlKey(ctrlKey%)  
IF ctrlKey% = imDisable THEN  
    PRINT "<CTRL> disabled"  
END IF  
status% = imSetControlKey(imEnable)  
PRINT "Enabling <CTRL>"  
END
```

---

## *imGetDisplayMode*

**Purpose:** This function gets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imGetDisplayMode% CDECL
    (SizeMode AS INTEGER,
     VideoMode AS INTEGER,
     ScrollMode AS INTEGER,
     CharHt AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *SizeMode* parameter is one of these constants:

<i>imSizeMode80X25</i>	80 x 25 text mode
<i>imSizeMode40X25</i>	40 x 25 text mode (2010 and 2020)
<i>imSizeMode20X16</i>	20 x 16 text mode (2010 and 2020)
<i>imSizeMode20X8</i>	20 x 8 text mode (2010 and 2020)
<i>imSizeMode10X16</i>	10 x 16 text mode (2010 and 2020)
<i>imSizeMode10X8</i>	10 x 8 text mode (2010 and 2020)

The *VideoMode* parameter is only significant if the *SizeMode* parameter is *imSizeMode80X25*. The standard BIOS goes up to *VideoMode* 13H. The reader only supports up to *VideoMode* 6.

The *VideoMode* parameter is one of these constants:

<i>imStdVideoMode0</i>	40 x 25 (use for double-wide character)
<i>imStdVideoMode1</i>	40 x 25 (use for double-wide character)
<i>imStdVideoMode2</i>	80 x 25
<i>imStdVideoMode3</i>	80 x 25
<i>imStdVideoMode4</i>	300 x 200 2-color
<i>imStdVideoMode5</i>	300 x 200 monochrome
<i>imStdVideoMode6</i>	640 x 200 2-color (2050)

## *imGetDisplayMode* – QuickBasic

The *ScrollMode* parameter is only significant if the *SizeMode* parameter is *imSizeMode80X25*. The *ScrollMode* parameter is one of these constants:

<i>imLcdScrollAt25</i>	Scroll at line 25
<i>imLcdScrollAt16</i>	Scroll at line 16 (2010 and 2020)
<i>imLcdScrollAt13</i>	Scroll at line 13 (2050 and Double-height)
<i>imLcdScrollAt8</i>	Scroll at line 8 (2010 and 2020)

The *CharHt* parameter is only significant if the *SizeMode* parameter is *imSizeMode80X25*. The *CharHt* parameter is one of these constants:

<i>imStandardCharHeight</i>	Standard-height characters
<i>imDoubleCharHeight</i>	Double-height characters

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *imSetDisplayMode*

---

### Example

```
'***** imGetDisplayMode *****  
REM $INCLUDE: 'im20bas1.bi'  
  
' Get Display Mode  
status% = imGetDisplayMode (dpSize%, dpVideo%, dpScroll%, dpCharHt%)  
PRINT "Status = ", HEX$(status%)  
PRINT "Get modes"  
PRINT "Size = ", dpSize%  
PRINT "Video = ", dpVideo%  
PRINT "Scroll = ", dpScroll%  
PRINT "CharHt = ", dpCharHt%  
END
```



---

## *imGetDisplayType*

**Purpose:** This function gets the hardware display type, either standard JANUS reader or JANUS 2050.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imGetDisplayType% CDECL
    (*type AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *type* parameter is one of these constants:

IMLCD20X16	Standard JANUS display
IMCRT80X25	JANUS 2050 display

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imGetDisplayMode, imSetDisplayMode

---

### *Example*

```
***** imGetDisplayType *****
REM $INCLUDE: 'im20bas1.bi'

PRINT "imGetDisplayType example: "

status% = imGetDisplayType(displayType%)

IF displayType% = imLCD20X16 THEN
    PRINT "Display type is Standard JANUS display"
ELSE
    PRINT "Display type is JANUS 2050 display"
ENDIF

PRINT "Status: "; HEX$(status%)
END
```

---

## ***imGetFollowCursor***

**Purpose:** When the display is in 80 x 25 mode, the viewport follows the cursor as it moves. The follow-the-cursor feature can be enabled or disabled. This function retrieves the current setting.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetFollowCursor% CDECL  
    (FollowCursor AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *FollowCursor* parameter is one of these constants:

<code>imEnable</code>	Follow-the-cursor mode is enabled
<code>imDisable</code>	Follow-the-cursor mode is disabled

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** `imSetFollowCursor`, `imCursorToViewport`, `imViewportToCursor`

---

### ***Example***

```
'***** imGetFollowCursor *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
status% = imGetFollowCursor(FollowCursor%)  
PRINT "Follow is ";followCursor%  
  
status% = imSetFollowCursor(imDisable)  
status% = imGetFollowCursor(FollowCursor%)  
PRINT "Follow is ";followCursor%  
  
status% = imSetFollowCursor(imEnable)  
status% = imGetFollowCursor(FollowCursor%)  
PRINT "Follow is ";FollowCursor%  
END
```

---

## *imGetInputMode*

**Purpose:** This function reports the current mode of the input manager. The different modes affect how the reader interprets and stores input.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetInputMode% CDECL ( )
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** The mode returned by this function is one of these constants:

imWedge	Wedge mode
imProgrammer	Programmer mode
imDesktop	Desktop mode

**Notes:** There are three different reader input modes: Wedge, Programmer, and Desktop. These different modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label input goes into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. This mode should be used when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader's power management capabilities. You might notice reduced battery life when in this mode compared to being in either programmer mode or desktop mode. For more information on power management, see Chapter 3, "Advanced Programming," in the *JANUS PSK for C/C++ Reference Manual*.

**Programmer Mode** Keypad input is echoed to the screen and terminates when you press **Enter**. Reader commands are executed as well as saved. Use this mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in programmer mode.

### *imGetInputMode – QuickBasic*

**Desktop Mode** The application is responsible for retrieving and displaying input. Keypad entry terminates when you press each key. Use this mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes of keyboard flags (**Shift, Ctrl, Alt**).

For more information about reader input modes, see Chapter 3, “Advanced Programming,” in the *JANUS PSK for C/C++ Reference Manual*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:**           imSetInputMode

---

#### **Example**

```
'***** imGetInputMode *****'  
' $INCLUDE: 'im20bas1.bi'  
  
CLS           ' Clear the screen  
PRINT "Setting imProgrammer"  
imSetInputMode(imProgrammer)  
inputMode% = imGetInputMode  
IF inputMode% = imProgrammer THEN  
    PRINT "Set to imProgrammer"  
ELSEIF inputMode% = imDesktop THEN  
    PRINT "Set to imDesktop"  
ELSEIF inputMode% = imWedge THEN  
    PRINT "Set to imWedge"  
ELSE  
    PRINT "Mode error"  
END IF  
imSetInputMode(imWedge)  
END
```

---

## *imGetKeyclick*

**Purpose:** You can configure the reader to emit a click each time a key is pressed. This function returns the current setting (enabled or disabled) of the keyclick.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imGetKeyclick% CDECL
    (KeyClick AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *KeyClick* parameter is one of these constants:

imEnable	Keyclick is enabled
imDisable	Keyclick is disabled

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imSetKeyclick

---

### *Example*

```
'***** imGetKeyclick *****
REM $INCLUDE: 'im20bas1.bi'

status% = imSetKeyclick(imDisable)
PRINT "Disabling keyclick"
Status% = imGetKeyclick(ctrlKey%)
IF ctrlKey% = imEnable THEN
    PRINT "Keyclick enabled"
ELSE
    PRINT "Keyclick disabled"
END IF
INPUT "Test it>>",response$
PRINT response$
status% = imSetKeyclick(imEnable)
PRINT "Enabling keyclick"
INPUT "Test it>>",response$
END
```

---

## ***imGetLabelSymbology***

**Purpose:** This function gets the symbology, such as Code 39, from the most recently scanned label. Call this function after receiving the data using `imReceiveInput`.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetLabelSymbology% CDECL  
    (Symbology AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *Symbology* parameter is one of these constants:

<code>imUnknownDecode</code>	Unknown bar code
<code>imCODABAR</code>	Codebar bar code
<code>imCode11</code>	Code 11 bar code
<code>imCode16k</code>	Code 16K bar code
<code>imCode39</code>	Code 39 bar code
<code>imCode49</code>	Code 93 bar code
<code>imCode93</code>	Code 49 bar code
<code>imCode128</code>	Code 128 bar code
<code>imI2Of5</code>	Interleaved 2 of 5
<code>imMSI</code>	MSI bar code
<code>imPLESSEY</code>	Plessey bar code
<code>imUPC</code>	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imReceiveInput`

---

### ***Example***

See example for `imReceiveInput`.

---

## imGetLength

**Purpose:** This function returns the length of the string received from the designated source by the most recent imReceiveInput function.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetLength% CDECL  
    (Source AS INTEGER)
```

**IN Parameters:** The *Source* parameter is one of these constants:

imLabelSelect	Label selected
imKeyboardSelect	Keypad selected
imCom1Select	COM1 selected
imCom2Select	COM2, scanner port selected (2010 and 2050)
imCom4Select	COM4 selected (RF only)

**OUT Parameters:** None.

**Return Value:** This function returns the length of the last input string read from the designated source.

**Notes:** For this function, all COM input is considered to be from the same source. For example, if you call im\_receive\_input with imCom1Select and again with imCom4Select, then a call to im\_get\_length with a source of imCom1Select returns the length of the message received from COM4 because that was the last message read from a communications port.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** imReceiveInput

---

### Example

See example for imReceiveInput.

---

## ***imGetPostamble***

**Purpose:** This function retrieves the current postamble string and its length.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetPostamble% CDECL  
    (BYVAL postString AS INTERGER  
     length AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *postString* parameter is the postamble string.

The *length* parameter is the length of the postamble string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You can set the postamble with IC.EXE, with the imCommand function and \$+AE command, or by scanning a postamble. Refer to your JANUS user's manual for more information on configuring a postamble.

**See Also:** imGetPreamble, imGetConfigInfo

---

### ***Example***

```
'***** imGetPostamble *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
DIM outstr AS STRING *300  
  
outstr = STRING$(300, CHR$(0))  
  
PRINT "imGetPostamble example: "  
  
status% = imGetPostamble(VARPTR(outstr), count%)  
  
PRINT "Postamble String: "; outstr  
PRINT "Postamble Length: "; count%  
PRINT "Status: "; HEX$(status%)  
END
```



---

## *imGetPreamble*

**Purpose:** This function retrieves the current preamble string and its length.

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imGetPreamble% CDECL
    (BYVAL preambleString AS INTERGER
     length AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *preambleString* parameter is the preamble string.

The *length* parameter is the length of the preamble string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You can set the preamble with IC.EXE, with the imCommand function and \$+AE command, or by scanning a preamble. Refer to your JANUS user’s manual for more information on configuring a preamble.

**See Also:** imGetPostamble, imGetConfigInfo

---

### *Example*

```
***** imGetPreamble *****
REM $INCLUDE: 'im20bas1.bi'

DIM outstr AS STRING *300

outstr = STRING$(300, CHR$(0))

PRINT "imGetPreamble example: "

status% = imGetPreamble(VARPTR(outstr), count%)

PRINT "Preamble String: "; outstr
PRINT "Preamble Length: "; count%
PRINT "Status: "; HEX$(status%)
END
```

---

## ***imGetViewportLock***

**Purpose:** This function retrieves the current setting of the viewport lock. When the display is in 80 x 25 mode, you can use the viewport in virtual display mode unless the currently running application program restricts it. The application program may require the viewport to be locked or unlocked.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetViewportLock% CDECL  
    (VpLock AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *VpLock* parameter is one of these constants:

<code>imEnable</code>	Viewport is locked
<code>imDisable</code>	Viewport is unlocked

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The display must be in 80 x 25 mode (see `imSetDisplayMode`) to use this function.

This function has no effect on the JANUS 2050.

When the viewport is "locked," the viewport movement keys do not move the viewport. The viewport can still move if follow-the-cursor mode is enabled.

**See Also:** `imSetViewportLock`, `imSetDisplayMode`, `imGetDisplayMode`, `imGetFollowCursor`, `imSetFollowCursor`

---

**Example**

```
'***** imGetViewportLock *****  
REM $INCLUDE: 'im20bas1.bi'  
  
status% = imGetViewportLock(viewportLock%)  
PRINT "Viewport is ";viewportLock%  
  
status% = imSetViewportLock(imDisable)  
status% = imGetViewportLock(viewportLock%)  
PRINT "Viewport is ";viewportLock%  
  
status% = imSetViewportLock(imEnable)  
status% = imGetViewportLock(viewportLock%)  
PRINT "Viewport is ";viewportLock%  
END
```

---

## ***imGetWarmBoot***

**Purpose:** This function retrieves the current setting of the warm boot status. You can enable or disable the **Ctrl-Alt-Del** warm boot key sequence. When disabled, pressing the **Ctrl-Alt-Del** key sequence does not reboot the reader.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imGetWarmBoot% CDECL  
    (WarmBoot AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *WarmBoot* parameter is one of these constants:

imEnable	<b>Ctrl-Alt-Del</b> warm boot is enabled
imDisable	<b>Ctrl-Alt-Del</b> warm boot is disabled

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** imSetWarmBoot

---

### ***Example***

```
***** imGetWarmBoot *****  
REM $INCLUDE: 'im20bas1.bi'  
  
status% = imSetWarmBoot(imDisable)  
PRINT "Disabling <BOOT>"  
status% = imGetWarmBoot(ctrlKey%)  
IF ctrlKey% = imEnable THEN  
    PRINT "<BOOT> enabled"  
ELSE  
    PRINT "<BOOT> disabled"  
END IF  
INPUT "Test it1>>",response$  
status% = imSetWarmBoot(imEnable)  
PRINT "Enabling <BOOT>"  
INPUT "Test it1>>",response$  
END
```

---

## ***imIncreaseContrast***

**Purpose:** This function increases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast, where 0 is very light, and 31 is very dark.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imIncreaseContrast% CDECL ()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The 0 to 31 scale fine tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table compares the two scales.

This Value on Scale 0 to 7	Equates to This Value on Scale 0 to 31	Contrast Level
0	10	Very light
1	12	
2	14	
3	16	
4	18	
5	20	
6	22	Very dark
7	24	

This function has no effect on the JANUS 2050.

**See Also:** `imGetContrast`, `imDecreaseContrast`, `imSetContrast`

## *imIncreaseContrast – QuickBasic*

---

### **Example**

```
'***** imIncreaseContrast *****  
REM $INCLUDE: 'im20bas1.bi'  
  
    PRINT "imIncreaseContrast"  
    ' Call Intermec function  
    status% = imIncreaseContrast  
    ' Pause for keypad input  
    temp$ = INPUT$(1)  
  
    PRINT "imIncreaseContrast"  
    ' Call Intermec function  
    status% = imIncreaseContrast  
END
```

---

## ***imInputStatus***

**Purpose:** This function checks to see if any input buffers have data and returns the buffer identification.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imInputStatus% CDECL ()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** The buffers checked correspond to these constants:

<code>imNoSelect</code>	No input buffer selected
<code>imLabelSelect</code>	Label selected
<code>imKeyboardSelect</code>	Keypad selected
<code>imCom1Select</code>	COM1 selected
<code>imCom2Select</code>	COM2, scanner port selected (2010 and 2050)
<code>imCom4Select</code>	COM4 selected (RF only)
<code>imAllSelect</code>	All input containers are selected

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imReceiveInput`

## *imInputStatus – QuickBasic*

---

### **Example**

```
'***** imInputStatus *****
REM $INCLUDE: 'im20bas1.bi'

DIM str AS STRING * 300
DIM buffer AS STRING * 300

status% = imLinkComm(imCom1, VARPTR(str), LEN(str))

WHILE temp$ <> "q"
  CLS
  str = STRING$(300, CHR$(0))
  inputstat% = 0
  statbreak$ = ""

  PRINT "Getting Input Stat"
  WHILE inputstat% = 0 AND statbreak$ <> "q"
    statbreak$ = INKEY$
    inputstat% = imInputStatus
  WEND
  PRINT "Input status: "; inputstat%
  PRINT
  PRINT "Getting Data"

  status% = imReceiveInput(inputstat%, 20000, source%, VARPTR(buffer))

  PRINT "Receive status: "; HEX$(status%)
  PRINT "Source Input: "; source%
  PRINT "Output is: "
  PRINT buffer
  PRINT
  PRINT "press q to quit"
  temp$ = INPUT$(1)
WEND

status% = imUnlinkComm(imCom1)
END
```



---

## ***imIrlA***

**Purpose:** This function receives input from bar code labels or the keypad in the same manner as the IRL ASCII input command A. This function returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command A, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION ImIrlA% CDECL
    (BYVAL Timeout AS LONG,
     TestTable AS INTEGER,
     BYVAL MaskString AS INTEGER,
     BYVAL PwStringPTR AS INTEGER,
     CmdCount AS INTEGER,
     Symbology AS INTEGER)
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *TestTable*. The *TestTable* parameter must be a matrix of the following form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

*imlrlA – QuickBasic*

The *a* position in the matrix is one of the following:

<code>imNoLength</code>	Accept data of any length
<code>imLength</code>	Accept data with a specific length
<code>imRange</code>	Accept data within a length range

If `imLength` is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If `imRange` is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {`imNoLength,0,0,0`}.

The *MaskString* parameter sets up a data mask that received data must match. *MaskString* accepts a string of constants or wildcard characters. For example, use the string `### - #####` to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

<code>#</code>	Numeric
<code>@</code>	Alpha
<code>?</code>	Alphanumeric printable
<code>NULL (CHR\$(0))</code>	No mask

**OUT Parameters:** You must allocate at least 256 bytes to the *PwString* parameter.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

The *Symbology* parameter is one of these constants:

imUnknownDecode	Unknown bar code
imCODABAR	Codebar bar code
imCode11	Code 11 bar code
imCode16k	Code 16K bar code
imCode39	Code 39 bar code
imCode49	Code 93 bar code
imCode93	Code 49 bar code
imCode128	Code 128 bar code
imI2Of5	Interleaved 2 of 5
imMSI	MSI bar code
imPLESSEY	Plessey bar code
imUPC	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Set the reader to programmer mode using `imSetInputMode` before using this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlK`, `imIrlN`, `imIrlV`, `imIrlY`, `imSetDisplayMode`, `imSetInputMode`

## *imIrlA – QuickBasic*

---

### **Example**

```
'***** imIrlA *****
' $INCLUDE: 'im20bas1.bi'

DIM LengthTable(imNumIrlLengths) AS imLengthSpec

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS          ' Clear the screen

    imSetInputMode(imProgrammer)

    Timeout = 10000      ' Set timeout to 10 seconds

    ' The data mask takes precedence over other options.
    ' If no data mask is wanted, just set it to CHR$(0)
    ' This example would be for a Social Security number

    ' DataMask$ = "###-##-####" + CHR$(0) ' Null terminate string
    DataMask$ = CHR$(0)          ' No data mask

    ' This example shows how to set 3 lengths and 1 range.  Input would
    ' need to be of length 3, 5, 7, or 11 through 15 characters.

    LengthTable(1).entry = imLength
    LengthTable(1).min   = 0
    LengthTable(1).max   = 0
    LengthTable(1).match = 3

    LengthTable(2).entry = imLength
    LengthTable(2).min   = 0
    LengthTable(2).max   = 0
    LengthTable(2).match = 5

    LengthTable(3).entry = imLength
    LengthTable(3).min   = 0
    LengthTable(3).max   = 0
    LengthTable(3).match = 7

    LengthTable(4).entry = imRange
    LengthTable(4).min   = 11
    LengthTable(4).max   = 15
    LengthTable(4).match = 0

    LengthTable(5).entry = imNoLength      ' Just a placeholder
    LengthTable(5).min   = 0
    LengthTable(5).max   = 0
    LengthTable(5).match = 0

    ' This table would be used if the user wanted to enter data of any length.
    '
    ' LengthTable(1).entry = imNoLength
    ' LengthTable(1).min   = 0
    ' LengthTable(1).max   = 0
    ' LengthTable(1).match = 0
    '
    ' LengthTable(2).entry = imNoLength
    ' LengthTable(2).min   = 0
    ' LengthTable(2).max   = 0
    ' LengthTable(2).match = 0
```

```
' LengthTable(3).entry = imNoLength
' LengthTable(3).min   = 0
' LengthTable(3).max   = 0
' LengthTable(3).match = 0
'
' LengthTable(4).entry = imNoLength
' LengthTable(4).min   = 0
' LengthTable(4).max   = 0
' LengthTable(4).match = 0
'
' LengthTable(5).entry = imNoLength
' LengthTable(5).min   = 0
' LengthTable(5).max   = 0
' LengthTable(5).match = 0

PRINT "Input>>";

status% = imIrlA(TimeOut, LengthTable(1).entry, SADD(DataMask$), VARPTR(inString),
cmdCount%, Symbology%)

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>" ;LEFT$(inString, charCounter%)

imSetInputMode(imWedge)
END
```

---

## ***imIrlK***

**Purpose:** This function receives input from the keypad in any format in the same manner as the IRL ASCII input command K. This function returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command K, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION ImIrlK% CDECL  
    (BYVAL Timeout AS LONG,  
     TestTable AS INTEGER,  
     BYVAL MaskString AS INTEGER,  
     BYVAL PwStringPTR AS INTEGER,  
     CmdCount AS INTEGER)
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *TestTable*. The *TestTable* parameter must be a matrix of the following form:

```
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},
```

The *a* position in the matrix is one of the following:

imNoLength	Accept data of any length
imLength	Accept data of a specific length
imRange	Accept data within a length range

If *imLength* is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If *imRange* is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {imNoLength,0,0,0}.

The *MaskString* parameter sets up a data mask that received data must match. *MaskString* can accept a string of constants or wildcard characters. For example, use the string ### - ##### to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

#	Numeric
@	Alpha
?	Alphanumeric printable
NULL (CHR\$(0))	No mask

**OUT Parameters:** You must allocate at least 256 bytes to the *PwString* parameter.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to programmer mode with the *imSetInputMode* function to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

## *imIrlK – QuickBasic*

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlN`, `imIrlV`, `imIrlY`, `imSetDisplayMode`, `imSetInputMode`

---

### *Example*

```
'***** imIrlK *****
' $INCLUDE: 'im20bas1.bi'

DIM LengthTable(imNumIrlLengths) AS imLengthSpec

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS          ' Clear the screen

imSetInputMode(imProgrammer)

TimeOut = 10000      ' Set timeout to 10 seconds

' The data mask takes precedence over other options.
' If no data mask is wanted, just set it to CHR$(0)
' This example would be for a Social Security number

' DataMask$ = "###-##-####" + CHR$(0) ' Null terminate string
DataMask$ = CHR$(0)          ' No data mask

' This example shows how to set 3 lengths and 1 range. Input would
' need to be of length 3, 5, 7, or 11 through 15 characters.

LengthTable(1).entry = imLength
LengthTable(1).min   = 0
LengthTable(1).max   = 0
LengthTable(1).match = 3

LengthTable(2).entry = imLength
LengthTable(2).min   = 0
LengthTable(2).max   = 0
LengthTable(2).match = 5

LengthTable(3).entry = imLength
LengthTable(3).min   = 0
LengthTable(3).max   = 0
LengthTable(3).match = 7

LengthTable(4).entry = imRange
LengthTable(4).min   = 11
LengthTable(4).max   = 15
LengthTable(4).match = 0

LengthTable(5).entry = imNoLength      ' Just a placeholder
LengthTable(5).min   = 0
LengthTable(5).max   = 0
LengthTable(5).match = 0
```



```
PRINT "Input>>";

status% = imIrkK(Timeout, LengthTable(1).entry, SADD(DataMask$), VARPTR(inString),
cmdCount%)

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>" ;LEFT$(inString,charCounter%)

imSetInputMode(imWedge)

END
```

---

## ***imIrlN***

**Purpose:** The *imIrlN* function receives numeric input from the keypad or a label in the same manner as the IRL numeric input command N. Nonnumeric data is ignored.

This function clears any data that might be in the keyboard or label buffers before the function was called, edits reader commands from input, and displays input data. For more information on IRL and command N, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION ImIrlN% CDECL  
    (BYVAL Timeout AS LONG,  
     TestTable AS INTEGER,  
     BYVAL PwStringPTR AS INTEGER,  
     CmdCount AS INTEGER,  
     Symbology AS INTEGER)
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
<i>imZeroTimeout</i>	No wait
<i>imInfiniteTimeout</i>	Wait forever

If *imInfiniteTimeout* is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *TestTable*. The *TestTable* parameter must be a matrix of the following form:

*{a, b, c, d},*  
*{a, b, c, d},*  
*{a, b, c, d},*  
*{a, b, c, d},*  
*{a, b, c, d},*

The *a* position in the matrix is one of the following:

<i>imNoLength</i>	Accept data of any length
<i>imLength</i>	Accept data of a specific length
<i>imRange</i>	Accept data within a length range

If *imLength* is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If *imRange* is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Any unused table entries must be set to *{imNoLength,0,0,0}*.

**OUT Parameters:** You must allocate at least 256 bytes to the *PwString* parameter.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

*imIrlN – QuickBasic*

The *Symbology* parameter is one of these constants:

imUnknownDecode	Unknown bar code
imCODABAR	Codebar bar code
imCode11	Code 11 bar code
imCode16k	Code 16K bar code
imCode39	Code 39 bar code
imCode49	Code 93 bar code
imCode93	Code 49 bar code
imCode128	Code 128 bar code
imI2Of5	Interleaved 2 of 5
imMSI	MSI bar code
imPLESSEY	Plessey bar code
imUPC	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to programmer mode with the `imSetInputMode` function to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlK`, `imIrlV`, `imIrlY`, `imSetInputMode`

**Example**

```

***** imIrlN *****
' $INCLUDE: 'im20bas1.bi'

DIM LengthTable(imNumIrlLengths) AS imLengthSpec

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS          ' Clear the screen

    imSetInputMode(imProgrammer)

    Timeout = 10000      ' Set timeout to 10 seconds

' This example shows how to set 3 lengths and 1 range.  Input would
' need to be of length 3, 5, 7, or 11 through 15 characters.

    LengthTable(1).entry = imLength
    LengthTable(1).min   = 0
    LengthTable(1).max   = 0
    LengthTable(1).match = 3

    LengthTable(2).entry = imLength
    LengthTable(2).min   = 0
    LengthTable(2).max   = 0
    LengthTable(2).match = 5

    LengthTable(3).entry = imLength
    LengthTable(3).min   = 0
    LengthTable(3).max   = 0
    LengthTable(3).match = 7

    LengthTable(4).entry = imRange
    LengthTable(4).min   = 11
    LengthTable(4).max   = 15
    LengthTable(4).match = 0

    LengthTable(5).entry = imNoLength      ' Just a placeholder
    LengthTable(5).min   = 0
    LengthTable(5).max   = 0
    LengthTable(5).match = 0

' This table would be used if the user wanted to enter data of any length.
'
' LengthTable(1).entry = imNoLength
' LengthTable(1).min   = 0
' LengthTable(1).max   = 0
' LengthTable(1).match = 0
'
' LengthTable(2).entry = imNoLength
' LengthTable(2).min   = 0
' LengthTable(2).max   = 0
' LengthTable(2).match = 0
'
' LengthTable(3).entry = imNoLength
' LengthTable(3).min   = 0
' LengthTable(3).max   = 0
' LengthTable(3).match = 0
'

```

## *imIrlN – QuickBasic*

```
' LengthTable(4).entry = imNoLength
' LengthTable(4).min   = 0
' LengthTable(4).max   = 0
' LengthTable(4).match = 0
'
' LengthTable(5).entry = imNoLength
' LengthTable(5).min   = 0
' LengthTable(5).max   = 0
' LengthTable(5).match = 0

PRINT "Input>>";

status% = imIrlN(TimeOut, LengthTable(1).entry, VARPTR(inString), cmdCount%,
Symbology%)

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>" ; LEFT$(inString, charCounter%)

imSetInputMode(imWedge)
END
```

---

## ***imIrlV***

**Purpose:** This function receives input from any specified source in the same manner as the IRL universal input command V. For more information on IRL and command V, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION ImIrlV% CDECL
    (BYVAL Timeout AS LONG,
    BYVAL Edit AS INTEGER,
    BYVAL Beeper AS INTEGER,
    BYVAL Display AS INTEGER,
    BYVAL Source AS INTEGER,
    BYVAL PwStringPTR AS INTEGER,
    CmdCount AS INTEGER,
    Symbology AS INTEGER)
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

The *Edit* parameter determines whether the Reader Wedge parses reader commands. Use one of these constants:

imDisable	Disable reader command parsing
imEnable	Enable reader command parsing

If *Edit* is imDisabled, reader commands are treated as data.

*imIrlV – QuickBasic*

The *Beeper* parameter determines whether the IRL V command beeps or not when data is entered. Use one of these constants:

imAppliBeep	Application controls the beep
imWedgeBeep	Beeps each time data is entered

The *Display* parameter determines if the data is displayed when it is entered. Use one of these constants:

imDisable	Disable display of data
imEnable	Enable display of data

**IN/OUT  
Parameters:**

The *Source* parameter determines which input sources are allowed. When the IRL V command returns, *Source* indicates where the data came from. When both keypad and label inputs are enabled, the *Source* always returns keypad. It is possible for keyed and scanned data to be intermixed.

If you have both the keypad and scanner enabled, and you want to know where the data came from, first check the symbology:

- If the symbology is imUnknownDecode, then the data is from the keypad.
- If the symbology is another value (such as imCode39), then some or all of the data came from the scanner.

The *Source* parameter is one of these constants:

imNoSelect	No source
imLabelSelect	Label
imKeyboardSelect	Keypad
imCom1Select	COM1
imCom2Select	COM2, scanner port selected (2010 and 2050)
imCom4Select	COM4 (RF only)
imAllSelect	All sources are designated

**OUT Parameters:** The *PwString* parameter is the returned string containing the IRL commands and must have at least 256 bytes allocated.

The *CmdCount* is 0 unless an abort command is passed in the string.



The *Symbology* parameter is one of these constants:

imUnknownDecode	Unknown bar code
imCODABAR	Codebar bar code
imCode11	Code 11 bar code
imCode16k	Code 16K bar code
imCode39	Code 39 bar code
imCode49	Code 93 bar code
imCode93	Code 49 bar code
imCode128	Code 128 bar code
imI2Of5	Interleaved 2 of 5
imMSI	MSI bar code
imPLESSEY	Plessey bar code
imUPC	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to programmer mode with the `imSetInputMode` function to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

To receive data from a communications port, you must install a protocol handler.

Use the `imLinkComm` function to establish a link between the Reader Wedge and a communications port, and use the `imUnlinkComm` function to remove the link.

Data is automatically cleared from both the scanner and the keypad buffers but not from any communications port buffer.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlK`, `imIrlN`, `imIrlY`, `imSetInputMode`

## *imIrlV – QuickBasic*

---

### **Example**

```
'***** imIrlV *****
' $INCLUDE: 'im20bas1.bi'

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS                                ' Clear the screen

imSetInputMode(imProgrammer)

TimeOut = 10000                    ' Set timeout to 10 seconds

source% = imKeyboardSelect + imLabelSelect

editMode = imEnable                ' Edit for reader commands

beepMode = imWedgeBeep            ' Wedge does the beeping

dispMode = imEnable                ' Display the input as it is entered

PRINT "Input>>";

status% = imIrlV(TimeOut, editMode, beepMode, dispMode, source%, VARPTR(inString),
cmdCount%, Symbology%)

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>";LEFT$(inString,charCounter%)

IF Symbology% > imUnknownDecode THEN
    PRINT "From Label"
    IF Symbology% = imCode39 THEN
        PRINT "Code 39"
    ELSE
        PRINT "Another symbology"
    END IF
ELSEIF source% = imKeyboardSelect THEN
    PRINT "From Keypad"
ELSEIF source% = imCom1Select THEN
    PRINT "From Com 1"
ELSEIF source% = imCom4Select THEN
    PRINT "From Com 4"
ELSE
    PRINT "Unknown Source"
END IF

imSetInputMode(imWedge)
END
```

---

## ***imIrlY***

**Purpose:** This function receives input from a designated communications port. in the same manner as the IRL ASCII input command Y.

This function receives a single block, not an entire file. This function always clears input from the host and edits reader commands from input. Unlike the other IRL instructions, the data is not automatically displayed. For more information on IRL and command Y, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imIrlY% CDECL
    (BYVAL Timeout AS LONG,
    BYVAL PortID AS INTEGER,
    BYVAL (SADD(EomChar$)) AS INTEGER,
    BYVAL Protocol AS INTEGER,
    BYVAL (SADD(InString$)) AS INTEGER,
    CmdCount AS INTEGER)
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If *imInfiniteTimeout* is selected, the function will not return until the end of message character has been received.

The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *EomChar* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

The *Protocol* parameter is one of these constants:

<code>imNoChange</code>	Keep the current protocol
<code>imProtocolOff</code>	Turn the protocol OFF
<code>imProtocolOn</code>	Turn the protocol ON
<code>imNewTermChar</code>	Use the new termination character

The *Protocol* parameter affects how incoming messages are received:

- If `imNoChange` is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If `imProtocolOff` is specified, the incoming data is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.
- If `imProtocolOn` is specified, the incoming message is terminated with the end of message character of the active protocol.
- If `imNewTermChar` is specified, `imProtocolOff` is assumed and the new end of message character specified in the parameter list is used.

**OUT Parameters:** You must allocate at least 256 bytes to the *InString* parameter.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to programmer mode with the `imSetInputMode` function to use this function.

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

You must install a protocol handler to use this function.

The receive buffers are cleared whenever the protocol is turned ON or OFF. To change the termination character (or to not change the setting at all), use `imNewTermChar` or `imNoChange` instead of toggling the protocol.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlK`, `imIrlN`, `imIrlV`, `imSetDisplayMode`, `imSetInputMode`

---

### Example

```

'***** imIrlY *****
' $INCLUDE: 'im20bas1.bi'

CONST bufsize = 300
DIM inString AS STRING * bufsize
DIM comString AS STRING * bufsize

CLS          ' Clear the screen
imSetInputMode(imProgrammer)
ImLinkCom% = imLinkComm(imCom1, VARPTR(comString), bufsize)
Timeout = 10000      ' Set timeout to 10 seconds

' eomChar$ = CHR$(0) ' No termination character
eomChar$ = CHR$(13) ' Termination character is CR

PRINT "Send Data>>";

' status% = imIrlY(Timeout, imCom1, SADD(eomChar$), imProtocolOn, VARPTR(inString),
cmdCount%)
status% = imIrlY(Timeout, imCom1, SADD(eomChar$), imProtocolOff, VARPTR(inString),
cmdCount%)

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>";LEFT$(inString,charCounter%)

ImLinkCom% = imUnlinkComm(imCom1)


imSetInputMode(imWedge)
END

```

## imLinkComm

**Purpose:** This function establishes a link between the Reader Wedge function and a designated communications port. The following figure lists the different modes and the functions to use when linked or unlinked.

### Linking Specific Modes and Functions



AIT-24

**Syntax:**

```

REM $INCLUDE: 'im20bas1.bi'
FUNCTION ImLinkComm% CDECL
    (BYVAL PortID AS INTEGER,
    BYVAL Buffer AS INTEGER,
    BYVAL BufferSize AS INTEGER)
    
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1 COM1  
imCom2 COM2, scanner port (2010 and 2050)  
imCom4 COM4 (RF only)

The *Buffer* parameter is a pointer to a memory area used by the Reader Wedge. Your application should not use this buffer.

The *BufferSize* parameter is the number of bytes to allocate for the buffer array (maximum is 300 bytes).

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Use this function if you want to receive data with the Reader Wedge input function imIrlY or use the communications port with imReceiveInput and imIrlV.

This function needs to be called only once.

You must unlink at the end of your application.

You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** imUnlinkComm, imReceiveInput, imIrlV, imIrlY

---

### Example

See example for imReceiveInput, imIrlY, and imSerialProtocolControl.

---

## *imMessage*

**Purpose:** This function displays the error message associated with a specific status code returned by an Intermec function. These status codes are listed in Appendix A.

Use this function to display additional information about status codes during application development.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
SUB imMessage% CDECL  
    (BYVAL StatusCode AS INTEGER)
```

**IN Parameters:** The *StatusCode* parameter is a standard status code returned from various PSK functions.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** The status message is displayed at the current cursor location without any formatting.

---

### *Example*

```
'***** imMessage *****'  
' $INCLUDE: 'im20bas1.bi'  
  
CLS          ' Clear the screen  
str1$ = "$+DJ3"  
PRINT "Set normal contrast"  
status% = imCommand(SADD(str1$), LEN(str1$))  
PRINT "Command status >>";HEX$(status%)  
    imMessage(status%)  
END
```



---

## ***imNumberPadOff***

**Purpose:** This function disables the number pad feature. When the number pad is disabled, the numeric keys function the same as the 1 through + keys above the “QWERTY” keys on a normal PC keyboard.

When the number pad is disabled, you cannot type characters from the extended ASCII character set or use the number pad to move the cursor. For more information, refer to your JANUS user’s manual.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
FUNCTION imNumberPadOff% CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imNumberPadOn

---

### ***Example***

```
'***** imNumberPadOff *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
' Initializing Variables  
NumberPadTest$ = ""  
Temp$ = ""  
CLS  
  
status% = imNumberPadOff  
  
PRINT  
PRINT "Test number pad off"  
PRINT "<ENTER> when done: "  
INPUT NumberPadTest$  
PRINT  
PRINT "Press any key to quit."  
INPUT Temp$  
END
```

---

## ***imNumberPadOn***

**Purpose:** This function enables the reader's number pad. When enabled, the number pad functions the same way as the 10-key number pad on a standard PC keyboard. The numeric keys then provide cursor movement and editing keys, numbers, and access to the extended ASCII character set.

When you enable the number pad, you also turn the **Num Lock** key off or on. When **Num Lock** is on, the number pad keys produce only numbers or extended ASCII characters with the same scan codes as the numeric keypad on a PC. The numeric keys always generate the same ASCII characters for numbers, but the scan codes depend on the status of the number pad and **Num Lock**.

When **Num Lock** is off, the number pad keys move the cursor (**Home**) or edit text (**Del**). Refer to your JANUS user's manual for more information on the number pad.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imNumberPadOn% CDECL  
    (BYVAL NumLock AS INTEGER)
```

**IN Parameters:** The *NumLock* parameter indicates whether the **Num Lock** key is ON or OFF. Use one of these constants:

imNumlockOn	Enable the number pad with Num Lock ON
imNumlockOff	Disable the number pad with Num Lock OFF

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** imNumberPadOff

---

**Example**

```
'***** imNumberPadOn *****
REM $INCLUDE: 'im20bas1.bi'

' Initializing Variables
NumberPadTest$ = ""
Temp$ = ""
CLS

status% = imNumberPadOn(imNumlockOff)
PRINT "numpad enable NL OFF"
PRINT "<ENTER> when done: "
INPUT NumberPadTest$
PRINT

status% = imNumberPadOn(imNumlockOn)
PRINT
PRINT "numpd enable NL ON"
PRINT "<ENTER> when done: "
INPUT NumberPadTest$
PRINT

PRINT "Press any key to quit."
INPUT Temp$
END
```

---

## ***imPowerStatus***

**Purpose:** This function returns the line status, battery status, backup status, and percentage of remaining battery life.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imPowerStatus% CDECL  
    (LineStatus AS INTEGER,  
     BatteryStatus AS INTEGER,  
     BackupStatus AS INTEGER,  
     FuelGauge AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *LineStatus* parameter returns one of these constants:

<code>imAclineNotConnected</code>	AC line is not connected
<code>imAclineConnected</code>	AC line is connected
<code>imUnknownAcline</code>	AC line status is unknown

The *BatteryStatus* parameter returns one of these constants:

<code>imHighBat</code>	Battery charge is high
<code>imLowBat</code>	Battery charge is low
<code>imCriticalBat</code>	Battery charge is critical
<code>imChargingBat</code>	Battery is charging now
<code>imUnknownBat</code>	Battery condition is unknown

The *BackupStatus* parameter returns one of these constants:

<code>imBackupOk</code>	Backup battery is OK
<code>imBackupLow</code>	Backup battery is low

The *FuelGauge* parameter returns one of these constants:

0–100	% of full charge in increments of 10%
255	Unknown

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

---

**Example**

```
'***** imPowerStatus *****  
REM $INCLUDE: 'im20bas1.bi'  
  
PRINT "imPowerStatus"  
  
acLine% = -1  
battery% = -1  
backup% = -1  
fuel% = -1  
status% = -1  
  
status% = imPowerStatus(acLine%, battery%, backup%, fuel%)  
  
PRINT "ACLine = ", HEX$(acLine%)  
PRINT "battery = ", HEX$(battery%)  
PRINT "backup = ", HEX$(backup%)  
PRINT "fuel = ", HEX$(fuel%)  
PRINT "status = ", HEX$(status%)  
END
```

---

## ***imProtocolExtendedStatus***

**Purpose:** This function gets the protocol extended status from the designated communications port. You allocate the protocol status buffer or radio frequency (RF) status buffer, and then `imProtocolExtendedStatus` returns the status and setup in hexadecimal values.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imProtocolExtendedStatus% CDECL  
    (BYVAL PortID AS INTEGER,  
     SEG StatusBuffer AS imCommStatusBufferS)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *StatusBuffer* parameter is a far pointer to a buffer structure. Use one of these constants:

```
imCommStatusBufferS (as shown in the syntax above)  
imCommStatusBufferRF
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imReceiveBufferNoWait`, `imTransmitBufferNoWait`

**Example**

```

'***** imProtocolExtendedStatus *****
REM $INCLUDE: 'im20bas1.bi'

'Extend status protocol buffer
DIM statusBuffer AS imCommStatusBufferS

'Initialize status buffer

' Note: Must assign StatusStrVersion as below to return proper
' status
statusBuffer.StatusStructureVersion = CHR$(StatusStrVersion)
statusBuffer.HandlerVer = STRING$(LEN(statusBuffer.HandlerVer), CHR$(0))
statusBuffer.HandlerType = 0
statusBuffer.Specific.BaudRate = 0
statusBuffer.Specific.Parity = CHR$(0)
statusBuffer.Specific.StopBits = CHR$(0)
statusBuffer.Specific.DataBits = CHR$(0)
statusBuffer.Specific.ModemStatus = CHR$(0)
statusBuffer.Specific.PortStatus = CHR$(0)
statusBuffer.Specific.ActiveProt = 0
statusBuffer.Specific.LrcEnabled = CHR$(0)
statusBuffer.Specific.IntercharDelay = 0
statusBuffer.Specific.TurnaroundDelay = 0
statusBuffer.Specific.ReceiveTimeout = 0
statusBuffer.Specific.TransmitTimeout = 0
statusBuffer.Specific.PolChar = CHR$(0)
statusBuffer.Specific.SelChar = CHR$(0)
statusBuffer.Specific.ResChar = CHR$(0)
statusBuffer.Specific.regChar = CHR$(0)
statusBuffer.Specific.affChar = CHR$(0)
statusBuffer.Specific.negChar = CHR$(0)
statusBuffer.Specific.somChar = CHR$(0)
statusBuffer.Specific.txeomLen = CHR$(0)
statusBuffer.Specific.txeomChar1 = CHR$(0)
statusBuffer.Specific.txeomChar2 = CHR$(0)
statusBuffer.Specific.rxeomLen = CHR$(0)
statusBuffer.Specific.rxeomChar1 = CHR$(0)
statusBuffer.Specific.rxeomChar2 = CHR$(0)
statusBuffer.Specific.flowCtrl = CHR$(0)
statusBuffer.Specific.MultiDropAddr = CHR$(0)
statusBuffer.Specific.MultiDropEnabled = CHR$(0)
statusBuffer.Specific.EofLength = 0
statusBuffer.Specific.EofChar = CHR$(0)
statusBuffer.Specific.HaveRecvClientBuffer = 0
statusBuffer.Specific.HaveXmitClientBuffer = 0
statusBuffer.Specific.ProtocolMode = 0

' Call Intermec routine
status% = imProtocolExtendedStatus(ImCom1, statusBuffer)

' Function call return status
PRINT "Extd Prot Stat"
PRINT HEX$(status%)

temp$ = INPUT$(1)
CLS
LOCATE 1,1

' Print first page of status info
PRINT "Extd Status,Pglof3"
PRINT "Strut Ver = ", ASC(statusBuffer.StatusStructureVersion)

```

## *imProtocolExtendedStatus – QuickBasic*

```
PRINT "Hd Ver = ", statusBuffer.HandlerVer
PRINT "Hd Type = ", statusBuffer.HandlerType
PRINT "Baud = ", statusBuffer.Specific.BaudRate
PRINT "Parity = ", ASC(statusBuffer.Specific.Parity)
PRINT "Stop = ", ASC(statusBuffer.Specific.StopBits)
PRINT "Data = ", ASC(statusBuffer.Specific.DataBits)
PRINT "Modem = ", ASC(statusBuffer.Specific.ModemStatus)
PRINT "Port stat = ", ASC(statusBuffer.Specific.PortStatus)
PRINT "Ate prot = ", statusBuffer.Specific.ActiveProt
PRINT "Lrc enble = ", ASC(statusBuffer.Specific.LrcEnabled)
PRINT "Itc dely = ", statusBuffer.Specific.IntercharDelay
PRINT "Trnd dely = ", statusBuffer.Specific.TurnaroundDelay
PRINT "RX tmeout = ", statusBuffer.Specific.ReceiveTimeout
PRINT "Xt tmeout = ", statusBuffer.Specific.TransmitTimeout

' Pause between screens
PRINT "Any key to cont"
temp$ = INPUT$(1)
CLS
LOCATE 1,1

PRINT "Extd Status,Pg2of3"
' Print third page of status info
PRINT "Pol char = ", ASC(statusBuffer.Specific.PolChar)
PRINT "Sel char = ", ASC(statusBuffer.Specific.SelChar)
PRINT "Res char = ", ASC(statusBuffer.Specific.ResChar)
PRINT "Req char = ", ASC(statusBuffer.Specific.reqChar)
PRINT "Aff char = ", ASC(statusBuffer.Specific.affChar)
PRINT "Neg char = ", ASC(statusBuffer.Specific.negChar)
PRINT "Som char = ", ASC(statusBuffer.Specific.somChar)
PRINT "Tx len = ", ASC(statusBuffer.Specific.txcomLen)
PRINT "Txchar 1 = ", ASC(statusBuffer.Specific.txcomChar1)
PRINT "Txchar 2 = ", ASC(statusBuffer.Specific.txcomChar2)
PRINT "Rxlen = ", ASC(statusBuffer.Specific.rxcomLen)
PRINT "Rxchar 1 = ", ASC(statusBuffer.Specific.rxcomChar1)
PRINT "Rx char 2 = ", ASC(statusBuffer.Specific.rxcomChar2)
PRINT "Flow ctrl = ", ASC(statusBuffer.Specific.flowCtrl)

' Pause between screens
PRINT "Any key to cont"
temp$ = INPUT$(1)

CLS
LOCATE 1,1

PRINT "Extd Status,Pg3of3"
' Print second page of status info
PRINT "Mul addr = ", ASC(statusBuffer.Specific.MultiDropAddr)
PRINT "Mul enble = ", ASC(statusBuffer.Specific.MultiDropEnabled)
PRINT "EOF len = ", statusBuffer.Specific.EofLength
PRINT "EOF char = ", ASC(statusBuffer.Specific.EofChar)
PRINT "Recv clt = ", statusBuffer.Specific.HaveRecvClientBuffer
PRINT "Xmit clt = ", statusBuffer.Specific.HaveXmitClientBuffer
PRINT "Prot mode = ", statusBuffer.Specific.ProtocolMode
END
```



---

## *imReceiveBuffer*

**Purpose:** This function receives the contents of a data buffer from a designated communications port.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imReceiveBuffer% CDECL  
    (BYVAL PortID AS INTEGER,  
     BYVAL UserLength AS INTEGER,  
     BYVAL DataBuffer AS INTEGER,  
     BYVAL Timeout AS INTEGER,  
     CommLength AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *UserLength* parameter is the maximum number of bytes to receive and must be at least 256 bytes.

The *DataBuffer* parameter is a far pointer to the array where you want to place the received data. This buffer must hold at least 256 bytes.

The *Timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select *imInfiniteTimeout*, the function will not return until the end of message character has been received.

### *imReceiveBuffer – QuickBasic*

**OUT Parameters:** The *CommLength* is the actual number of bytes received upon completion of the call.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function does not return a parameter value until an end of message, a buffer is full, a timeout, or an error occurs.

You must install a protocol handler to use this function.

**See Also:** *imReceiveBufferNoWait*, *imReceiveBufferNoprot*, *imCancelRxBuffer*, *imRxCheckStatus*

---

### **Example**

```
***** imReceiveBuffer *****
' Note: You must have reader services and a communication protocol handler installed
' to enable send/receive buffer functions.
' Run these TSR's at DOS prompt before running these tests:
'   rservice
'   PHIMEC 1 ( 1 is COM1)      Must be run with Phimec protocol

REM $INCLUDE: 'im20bas1.bi'

CONST bufsize = 300           ' Data buffer must be at least 256 bytes

DIM str1 AS STRING * bufsize  ' Fixed length strings of 300 bytes

DIM commLength AS INTEGER     ' Actual length returned by imReceiveBuffer

PRINT "imReceiveBuffer"
PRINT "Phimec protocol"
PRINT "Default - 9600 E 7 1"
' Quit with <CR><LF> sequence
PRINT "Ctrl JM to quit"
PRINT "(<CR><LF>)"

' Init the string
str1 = STRING$(bufsize, CHR$(0))

' Call Intermec function
status% = imReceiveBuffer(imCom1, LEN(str1), VARPTR(str1), 10000, commLength)

' Print results
PRINT str1

' Print return status(s)
PRINT
PRINT "Actual len = ", commLength
PRINT "status = ", HEX$(status%)

END
```

---

## *imReceiveBufferNoprot*

**Purpose:** This function receives a text string from the designated port without using the active protocol. Only the PHIMEC.EXE protocol handler supports this function, which is often used to receive a host initialization string before beginning transmission.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imReceiveBufferNoprot% CDECL
    (BYVAL PortID AS INTEGER,
    BYVAL UserLength AS INTEGER,
    BYVAL DataBuffer AS INTEGER,
    BYVAL Timeout AS INTEGER,
    BYVAL EomChar AS INTEGER,
    CommLength AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1
imCom2    COM2, scanner port (2010 and 2050)
imCom4    COM4 (RF only)
```

The *UserLength* parameter is the maximum number of bytes you can receive and must be at least 256 bytes.

The *DataBuffer* parameter is a far pointer to the data array where you want to place the received data. This buffer must hold at least 256 bytes.

The *Timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

```
0 to 65,534 ms    Numeric range
imZeroTimeout    No wait
imInfiniteTimeout Wait forever.
```

## *imReceiveBufferNoprot – QuickBasic*

If *imInfiniteTimeout* is selected, the function will not return until the end of message character has been received.

The *EomChar* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any character.

**OUT Parameters:** The *CommLength* parameter returns the actual number of bytes received.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install the PHIMEC.EXE protocol handler to use this function.

The difference between this function and *imReceiveBufferNoWait* is that when *imReceiveBufferNoprot* returns from the function call, the data has been read, the timeout has expired, or an error was encountered. When you call *imReceiveBufferNoWait*, program execution continues without checking for received data or errors.

**See Also:** *imReceiveBufferNoWait*, *imCancelRxBuffer*, *imRxCheckStatus*

---

### **Example**

```
***** imReceiveBufferNoprot *****
REM $INCLUDE: 'im20bas1.bi'

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

' Actual length returned by imReceiveBuffer
DIM commLength AS INTEGER
DIM eomChar AS INTEGER

DIM done AS INTEGER

PRINT "imReceiveBufferNoprot"

' Get the receive environment ready
status%= imCancelRxBuffer(ImCom1)

' Zero out string
str3 = STRING$(bufsize, CHR$(0))

' Define carriage return as end of message character
eomChar = 13 '<CR>
```

```
PRINT "Input chars"
PRINT " Press Enter to end"

' Call the Intermec function
status%= imReceiveBufferNoprot(ImCom1, buffsize, VARPTR(str3), 10000, eomChar,
commLength)

PRINT "Status = ", HEX$(status%)

' Print results
PRINT str3
PRINT "Actual len", commLength

' Release resources
status%= imCancelRxBuffer(ImCom1)
END
```

---

## ***imReceiveBufferNoWait***

**Purpose:** This function receives data from the designated communications port and places the data into a user-defined record. It differs from `imReceiveBuffer` in that the programmer must set up the data record and monitor the transfer status until transmission is complete. This function runs in the background after it is initiated; no checks are made.

Use this function when receiving multiple buffer transmissions in conjunction with `imRxCheckStatus`.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imReceiveBufferNoWait% CDECL  
    (BYVAL PortID AS INTEGER,  
     SEG DataStruct AS imFarComDataStruct)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *DataStruct* parameter is a far pointer to the data array for the received data. This buffer must hold at least 256 bytes.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must build and maintain a *DataStruct* of the type `imFarComDataStruct` as described in `IM20BAS1.BI`.

You must periodically check the `protocolXferStatus` element in the `imComDataBuffer` record to see if all the data has been received. When `protocolXferStatus` is no longer code 8602H (communications port in use), all data is received.

You must install a protocol handler to use this function.

This function differs from imReceiveBufferNoprot in that program execution continues after imReceiveBufferNoWait is called. When imReceiveBufferNoprot returns from a function call, the data has been read, the timeout has expired, or an error was encountered.

**See Also:** imReceiveBufferNoprot, imCancelRxBuffer, imRxCheckStatus

---

### Example

```
'***** imReceiveBufferNoWait *****
REM $INCLUDE: 'im20bas1.bi'

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Data buffer structure for receive/transmit again and noprot
DIM farcomBuffStruct AS imFarComDataStruct

' Extend status protocol buffer
DIM statusBuffer AS imStatusBuffer

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

DIM done AS INTEGER

' The difference between imReceiveBufferNoWait and the imReceiveBufferNoprot
' is that the user must set up the imReceiveBufferNoWait comm
' struct and pend on the results. Whereas, in the Noprot receive, the
' user sets up the length of the buffer, points at that buffer and
' sends it off and returns. There is no pending on this level for the
' imReceiveBufferNoprot routine

' Phimec protocol handler must be installed to run this routine

PRINT "imReceiveBufferNoWait"

' Get the receive environment ready
status%= imCancelRxBuffer(imCom1)

' Zero out string
str3 = STRING$(bufsize, CHR$(0))

' Set up communication buffer structure
farcomBuffStruct.command = imPhReceive
farcomBuffStruct.protocolMode = imNoProtocol
farcomBuffStruct.eomChar = CHR$(13) 'CR for terminating char
farcomBuffStruct.userLength = bufsize
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffSetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolXferStatus = imCuInuse
farcomBuffStruct.CommLength = 0

done = FALSE

' Call Intermec function
status%= imReceiveBufferNoWait(ImCom1, farcomBuffStruct)
```

### *imReceiveBufferNoWait – QuickBasic*

```
PRINT "Func1= ", HEX$(status%)

' Loop until first character in buffer is a 'Q' or Esc is pressed
DO
    ' Check for receive errors:
    ' Print the error status

    IF status%= imIserror THEN
        PRINT "Rx Again err = ", HEX$(status%)
        done = FALSE
    ELSE
        ' Keyboard char
        temp$ = " "
        ' Get the receive data
        PRINT "Input chars"
        PRINT "Enter 'Q'"
        PRINT "or Esc to exit"

        ' Check to see if any characters are in buffer
        DO WHILE farcomBuffStruct.protocolXferStatus = imCuInuse AND temp$ <> CHR$(27)
            ' Pick up any keypad input
            temp$ = INKEY$
        LOOP

        PRINT "Comm done"
        ' Print the input string
        PRINT str3

        ' Update buffer for next block then call imRxCheckStatus to
        ' get protocol handler to reset status.

        farcomBuffStruct.command = imPhRecvAgain
        farcomBuffStruct.protocolXferStatus = imCuInuse
        farcomBuffStruct.commLength = 0

        status%= imRxCheckStatus(ImCom1)
    END IF

    ' Quit if first char in buffer is a 'Q' or a 'q'
    ' or Esc has been pressed
    IF UCASE$(LEFT$(str3, 1)) = "Q" OR temp$ = CHR$(27) THEN
        done = TRUE
    ELSE
        ' Zero out string and loop
        str3 = STRING$(buffsize, CHR$(0))
    ENDIF
LOOP WHILE done = FALSE

' Release resources
status%= imCancelRxBuffer(ImCom1)
END
```



---

## ***imReceiveByte***

**Purpose:** This function receives one byte of data through the designated communications port. This function is identical to MS-DOS INT 14H service 02H.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imReceiveByte% CDECL  
    (BYVAL PortID AS INTEGER,  
     ReceiveByte AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

**OUT Parameters:** The *ReceiveByte* parameter is a pointer to the byte received from the communications port.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

If you are using PHIMEC.EXE and want to receive a single byte, use *imReceiveBuffer* with a buffer length of one instead of the *imReceiveByte* function.

**See Also:** *imTransmitByte*

## *imReceiveByte – QuickBasic*

---

### **Example**

```
'***** imReceiveByte *****
REM $INCLUDE: 'im20bas1.bi'

DIM instring AS STRING * 1

PRINT "imReceiveByte"
' If the Mode command is used, DO NOT install the Phpcstd protocol
' If the Phpcstd protocol is installed DO NOT use the Mode command

' Set up comm port
SHELL "MODE COM1:9600 E 7 1"

' Init JANUS keyboard key press buffer
keystre$ = ""
PRINT "Press Esc to exit"

' Get COM1 input and print to screen
DO

    ' Call Intermec function
    status% = imReceiveByte (imCom1, VARPTR(instring))
    PRINT USING "!"; instring;
    keystre$ = INKEY$
' Loop until Esc is pressed
LOOP UNTIL keystre$ = CHR$(27) OR instring = CHR$(27)

PRINT "status = ", HEX$(status%)
END
```

---

## imReceiveInput

**Purpose:** This function gets input from the source and places it into the received buffer. You can use the imGetLength function after this function to get the input length.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imReceiveInput% CDECL
    (BYVAL Allowed AS INTEGER,
    BYVAL Timeout AS LONG,
    Source AS INTEGER,
    (SADD (Received$)) AS INTEGER)
```

**IN Parameters:** The *Allowed* parameter defines the available input source and is one or more of these constants:

imLabelSelect	Label selected
imKeyboardSelect	Keypad selected
imCom1Select	COM1 selected
imCom2Select	COM2, scanner port selected (2010 and 2050)
imCom4Select	COM4 selected (RF only)
imAllSelect	All sources are selected

The *Timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

*imReceiveInput – QuickBasic*

**OUT Parameters:** The *Source* parameter specifies the actual input source and is one of these constants:

imNoSelect	No selection made
imLabelSelect	Label selected
imKeyboardSelect	Keypad selected
imCom1Select	COM1 selected
imCom2Select	COM2, scanner port selected (2010 and 2050)
imCom4Select	COM4 selected (RF only)

The *Received* parameter is the variable where the data is placed.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** If input from more than one source is received before this function is called, the first available input is returned in this order: label, keypad, COM1, COM2, and COM4.

If you are using a communications port, you must install a protocol handler and call *imLinkComm*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** *imGetLength*, *imGetLabelSymbology*, *imLinkComm*

**Example**

```

'***** imReceiveInput *****
' $INCLUDE: 'im20bas1.bi'

CONST bufsize = 300
DIM  inString AS STRING * bufsize
DIM  comString AS STRING * bufsize

CLS          ' Clear the screen
imSetInputMode(imProgrammer)
ImLinkCom% = imLinkComm(imCom1, VARPTR(comString), bufsize)

FOR I% = 1 TO 3
  PRINT "Enter>>";

  status% = imReceiveInput(ImAllSelect,imInfiniteTimeout,source%,VARPTR(inString))
  PRINT          ' Add a blank line

  IF source% = ImKeypadSelect THEN

    PRINT "From Keypad"

  ELSEIF source% = imLabelSelect THEN

    PRINT "From Label"
    status% = imGetLabelSymbology(symbology%)

    IF symbology% = imCode39 THEN
      PRINT "Code 39"
    ELSE
      PRINT "Another code"
    ENDIF

  ELSEIF source% = imCom1Select THEN

    PRINT "From Serial"

  ELSE

    PRINT "Unknown source"

  END IF

  ' Get length of received data
  length% = imGetLength(source%)

  ' Print data received.  If the string is printed without doing the
  ' LEFT$, the entire 300 byte fixed-length string will be printed.

  PRINT "Recvd>>";LEFT$(inString,length%)

NEXT I%

ImLinkCom% = imUnlinkComm(imCom1)

imSetInputMode(ImWedge)
END

```

---

## ***imRsInstalled***

**Purpose:** This function determines whether or not the reader services (RSERVICE.EXE) program is installed.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
FUNCTION imRsInstalled% CDECL ( )

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

---

### ***Example***

```
'***** imRsInstalled *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
  ' Call the Intermec function  
  status% = imRsInstalled  
  PRINT "status = ", HEX$(status%)  
  
  IF status% = imRsAllSuccess THEN  
    PRINT "Rservice installed"  
  ELSE  
    PRINT "Rservice not installed"  
  END IF  
END
```

---

## ***imRxCheckStatus***

**Purpose:** This function directs the active protocol handler to check the communications port buffer status variable to determine if the application program has accepted the previous data. Use this function with the `imReceiveBufferNoWait` function to receive multiple buffers.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imRxCheckStatus% CDECL  
    (BYVAL PortID AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

<code>imCom1</code>	COM1
<code>imCom2</code>	COM2, scanner port (2010 and 2050)
<code>imCom4</code>	COM4 (RF only)

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** `imReceiveBufferNoWait`

---

### ***Example***

See example for `imReceiveBufferNoWait`.

---

## ***imSerialProtocolControl***

**Purpose:** This function controls the protocol mode for a designated communications port and determines whether the receive mode is with or without protocol according to the input parameter. Any change clears the input buffer and resets the reader command parser.

Use this function to set protocol when connected to a communications port. The return value indicates a success if the port is currently linked to the Virtual Wedge. If the port is not currently linked to the Virtual Wedge, the function returns an error.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imSerialProtocolControl% CDECL  
    (BYVAL PortID AS INTEGER,  
     BYVAL ProtocolSwitch AS INTEGER,  
     BYVAL EomChar AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *ProtocolSwitch* parameter affects how incoming messages are received and is one of these constants:

```
imNoChange    Keep the current protocol  
imProtocolOff  Turn the protocol OFF  
imProtocolOn   Turn the protocol ON  
imNewTermChar Use the new termination character
```

The *ProtocolSwitch* affects all incoming messages as follows:

- If *imNoChange* is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If *imProtocolOff* is specified, the incoming message is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.



- If `imProtocolOn` is specified, the incoming message is terminated with the end of message character of the active protocol.
- If `imNewTermChar` is specified, `imProtocolOff` is assumed and the new end of message character specified in the parameter list is used.

The *EomChar* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Requires `imLinkComm`.

The receive buffers are cleared whenever the protocol is turned ON or OFF. To change the termination character (or to not change the setting at all), use `imNewTermChar` or `imNoChange` instead of toggling the protocol.

**See Also:** `imLinkComm`

## *imSerialProtocolControl – QuickBasic*

---

### **Example**

```
'***** imSerialProtocolControl *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
CLS  
  
DIM linkBuffer AS STRING * 300  
DIM inputBuffer AS STRING * 300  
DIM eomChar AS INTEGER  
eomChar = 13  
timeout% = 10000  
source% = 0  
  
linkBuffer = STRING$(300, CHR$(0))  
inputBuffer = STRING$(300, CHR$(0))  
  
CALL imSetInputMode(imProgrammer)  
  
status% = imLinkComm(imCom1, VARPTR(linkBuffer), LEN(linkBuffer))  
  
' Turn on the protocol  
status% = imSerialProtocolControl(imCom1, imProtocolOn, eomChar)  
  
' Get data from com 1  
PRINT "Waiting for data"  
WHILE source% <> 1  
    inputBuffer = STRING$(300, CHR$(0))  
    status% = imReceiveInput(imCom1Select, timeout%, source%, VARPTR(inputBuffer))  
WEND  
  
PRINT "Message is:"  
PRINT inputBuffer  
  
status% = imUnLinkComm(imCom1)  
  
CALL imSetInputMode(imWedge)  
  
PRINT "Press any key"  
temp$ = INPUT$(1)  
END
```

---

## ***imSetContrast***

**Purpose:** This function sets the reader's LCD display contrast level. There are eight levels of contrast (0 to 7) from very light to very dark, which are the most frequently used contrast settings.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imSetContrast% CDECL
    (BYVAL DisplayContrastLevel AS INTEGER)
```

**IN Parameters:** The *DisplayContrastLevel* parameter is one of these constants:

imMinContrast	Level 0
imAveContrast	Level 4
imMaxContrast	Level 7

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The functions *imSetContrast* and *imGetContrast* use a scale of 0 to 7 that is related to the scale of 0 to 31 used by *imIncreaseContrast* and *imDecreaseContrast*. The following table compares the two scales.

This Value on Scale 0 to 7	Equates to This Value on Scale 0 to 31	Contrast Level
0	10	Very light
1	12	
2	14	
3	16	
4	18	
5	20	
6	22	Very dark
7	24	

This function has no effect on the JANUS 2050.

**See Also:** *imGetContrast*, *imDecreaseContrast*, *imIncreaseContrast*

## *imSetContrast – QuickBasic*

---

### **Example**

```
'***** imSetContrast *****  
REM $INCLUDE: 'im20bas1.bi'  
  
' Set contrast  
  ' Prompt for contrast level to set  
PRINT "Enter Contrast(0-7)"  
  INPUT "Level = ", level%  
  status% = imSetContrast (level%)  
  PRINT "Set Contrast status =", HEX$(status%)  
END
```

---

## ***imSetControlKey***

**Purpose:** This function enables or disables the **Ctrl** key setting. When disabled, none of the key combinations that use the **Ctrl** key work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imSetControlKey% CDECL  
    (BYVAL ControlKey AS INTEGER)
```

**IN Parameters:** The *ControlKey* parameter is one of these constants:

<code>imEnable</code>	Enable the <b>Ctrl</b> key
<code>imDisable</code>	Disable the <b>Ctrl</b> key

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imGetControlKey`

---

### ***Example***

See example for `imGetControlKey`.

---

## ***imSetDisplayMode***

**Purpose:** This function sets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imSetDisplayMode% CDECL  
    (BYVAL SizeMode AS INTEGER,  
     BYVAL VideoMode AS INTEGER,  
     BYVAL ScrollMode AS INTEGER,  
     BYVAL CharHt AS INTEGER)
```

**IN Parameters:** The *SizeMode* parameter is one of these constants:

<code>imSizeMode80X25</code>	80 x 25 text mode
<code>imSizeMode40X25</code>	40 x 25 text mode (2010 and 2020)
<code>imSizeMode 20X16</code>	20 x 16 text mode (2010 and 2020)
<code>imSizeMode 20X8</code>	20 x 8 text mode (2010 and 2020)
<code>imSizeMode 10X16</code>	10 x 16 text mode (2010 and 2020)
<code>imSizeMode 10X8</code>	10 x 8 text mode (2010 and 2020)

The *VideoMode* parameter is only significant if the *SizeMode* parameter is `imSizeMode80X25`. The standard BIOS goes up to *VideoMode* 13H, but the JANUS readers only support up to *VideoMode* 6.

The *VideoMode* parameter is one of these constants:

<code>imStdVideoMode0</code>	40 x 25 (use for double-wide characters)
<code>imStdVideoMode1</code>	40 x 25 (use for double-wide characters)
<code>imStdVideoMode2</code>	80 x 25
<code>imStdVideoMode3</code>	80 x 25
<code>imStdVideoMode4</code>	300 x 200 2-color
<code>imStdVideoMode5</code>	300 x 200 monochrome
<code>imStdVideoMode6</code>	640 x 200 2-color (2050)

The *ScrollMode* parameter is only significant if the size mode parameter is *imSizeMode80X25*. The *ScrollMode* parameter is one of these constants:

<i>imLcdScrollAt25</i>	Scroll at line 25
<i>imLcdScrollAt16</i>	Scroll at line 16 (2010 and 2020)
<i>imLcdScrollAt13</i>	Scroll at line 13 (2050)
<i>imLcdScrollAt8</i>	Scroll at line 8 (2010 and 2020)
<i>imMaxScrollMode</i>	Maximum number of scroll lines

The *CharHt* parameter is only significant if the *SizeMode* parameter is *imSizeMode80X25*. The *CharHt* parameter is one of these constants:

<i>imStandardCharHeight</i>	Standard-height characters
<i>imDoubleCharHeight</i>	Double-height characters

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Changing display modes clears the screen.

The IRL input commands do not display correctly when the display is in 80 x 25 mode and the cursor has scrolled off the display. To alleviate this problem, set the display mode to one of the other modes, such as 20 x 16.

The mode does not change if there are conflicting parameters, such as trying to set the *VideoMode* to 16 lines and the *ScrollMode* at line 8.

If you want to use one of the graphics modes, use the appropriate function call provided by your programming language.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** *imGetDisplayMode*, *imSetFollowCursor*

## *imSetDisplayMode – QuickBasic*

---

### **Example 1**

```
'***** imSetDisplayMode *****
REM $INCLUDE: 'im20bas1.bi'

status% = imSetDisplayMode(imSizeMode20X16,VideoMode%,ScrollMode%,CharHt%)
status% = imGetDisplayMode(SizeMode%,VideoMode%,ScrollMode%,CharHt%)
print "Size   =";SizeMode%
print "Video  =";VideoMode%
print "Scroll =";srollMode%
print "CharHt =";CharHt%
input "Waiting>>",response$

status% = imSetDisplayMode(imSizeMode20X8,VideoMode%,ScrollMode%,CharHt%)
status% = imGetDisplayMode(SizeMode%,VideoMode%,ScrollMode%,CharHt%)
print "Size   =";SizeMode%
print "Video  =";VideoMode%
print "Scroll =";srollMode%
print "CharHt =";CharHt%
input "Waiting>>",response$
END
```

---

### **Example 2**

```
'*****
' FILE NAME:   setdisp.bas
' DESCRIPTION: Tests various display configurations
'
'*****
' The PSK keeps track of display information through the normal BIOS
' calls. Basic, however, uses its own set of interrupts. This results
' in the reader wedge getting out of synch with standard basic print and
' input statements if a display size other than 80x25 or 40x25 is used.
'
' If one of the other display modes is desired, the application needs to
' display data by using INT 10H instead of the normal basic print
' statements. This is an example of how to do this. Note that this also
' applies to printing a prompt with the input statement.
'
' The command line to compile this program is:
'   bc/o setdisp.bas
'
' The response file for linking would be:
'   setdisp.obj im20bas.obj
'   setdisp
'   (blank line)
'   im20_bas.lib vbdos.lib vbdcl10.lib
'
' RWTSR must be loaded for this program to execute.
'*****

' $INCLUDE: 'im20bas1.bi'
' $INCLUDE: 'vbdos.bi'

declare sub PrintString (TextString$)
dim shared inRegs as RegType, outRegs AS RegType

CONST bufsize = 300
DIM inString AS STRING * bufsize
cls
```



```

status% = imGetDisplayMode(SizeModeTmp%,videoModeTmp%,scrollModeTmp%,charHtTmp%)
'
' Instead of:
'   print "Size   =" ;sizeModeTmp%
'   print "Video  =" ;videoModeTmp%
'   print "Scroll =" ;srollModeTmp%
'   print "CharHt =" ;charHtTmp%
'   input "Waiting>>",response$
'
' use:
PrintString "Size   ="
PrintString STR$(sizeModeTmp%)
PrintString "\nVideo ="
PrintString STR$(videoModeTmp%)
PrintString "\nScroll ="
PrintString STR$(scrollModeTmp%)
PrintString "\nCharHt ="
PrintString STR$(charHtTmp%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect,imInfiniteTimeout,source%,VARPTR(inString))
cls

status% = imSetDisplayMode(imSizeMode20X16,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(SizeMode%,videoMode%,scrollMode%,charHt%)
PrintString "Size   ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect,imInfiniteTimeout,source%,VARPTR(inString))
cls

status% = imSetDisplayMode(imSizeMode20X8,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(SizeMode%,videoMode%,scrollMode%,charHt%)
PrintString "Size   ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect,imInfiniteTimeout,source%,VARPTR(inString))
cls

status% = imSetDisplayMode(imSizeMode10X16,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(SizeMode%,videoMode%,scrollMode%,charHt%)
PrintString "Size   ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll="
PrintString STR$(scrollMode%)
PrintString "\nCharHt="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect,imInfiniteTimeout,source%,VARPTR(inString))
cls

```

## *imSetDisplayMode – QuickBasic*

```
status% = imSetDisplayMode(imSizeModel0X8,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(SizeMode%,videoMode%,scrollMode%,charHt%)
PrintString "Size ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll="
PrintString STR$(scrollMode%)
PrintString "\nCharHt="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect,imInfiniteTimeout,source%,VARPTR(inString))
cls

status% = imSetDisplayMode(sizeModeTmp%,videoModeTmp%,scrollModeTmp%,charHtTmp%)
status% = imGetDisplayMode(SizeMode%,videoMode%,scrollMode%,charHt%)
PrintString "Size ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect,imInfiniteTimeout,source%,VARPTR(inString))
END

' *****
' Prints a string using INT 10H
' Prints a newline when "\n" is found
' *****

SUB PrintString(TextString$)
  Length% = LEN(TextString$)
  FOR I% = 1 to Length%
    IF ASC(MID$(TextString$, I%, 1)) = 92 AND ASC(MID$(TextString$, I%+1, 1)) = 110
    THEN
      inRegs.ax = &HE0D      ' Print CR
      inRegs.bx = &H0
      INTERRUPT &H10, inRegs, outRegs

      inRegs.ax = &HE0A      ' Print LF
      inRegs.bx = &H0
      INTERRUPT &H10, inRegs, outRegs
      I% = I% + 1
    ELSE
      inRegs.ax = &HE00 + ASC(MID$(TextString$, I%, 1))
      inRegs.bx = &H0
      INTERRUPT &H10, inRegs, outRegs
    END IF
  NEXT
END SUB

' *****
' END OF FILE: setdisp.bas
' COPYRIGHT (c) 1994 INTERMEC CORPORATION, ALL RIGHTS RESERVED
```

---

## ***imSetFollowCursor***

**Purpose:** When the display is in 80 x 25 mode, the viewport follows the cursor as it moves. This function enables or disables the follow-the-cursor feature.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imSetFollowCursor% CDECL
    (BYVAL FollowCursor AS INTEGER)
```

**IN Parameters:** The *FollowCursor* parameter is one of these constants:

imEnable	Enable follow-the-cursor mode
imDisable	Disable follow-the-cursor mode

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The display must be in 80 x 25 mode for this function to work correctly.

This function has no effect on the JANUS 2050.

**See Also:** imGetFollowCursor

---

### ***Example***

```
'***** imSetFollowCursor *****'
REM $INCLUDE: 'im20bas1.bi'

status% = imGetFollowCursor(followCursor%)
PRINT "Follow is ";followCursor%

status% = imSetFollowCursor(imDisable)
status% = imGetFollowCursor(followCursor%)
PRINT "Follow is ";followCursor%

status% = imSetFollowCursor(imEnable)
status% = imGetFollowCursor(followCursor%)
PRINT "Follow is ";followCursor%
END
```

---

## ***imSetInputMode***

**Purpose:** This function clears the input buffers and sets the input manager to one of three modes: Wedge, Programmer, or Desktop.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
SUB imSetInputMode CDECL  
    (BYVAL Mode AS INTEGER)
```

**IN Parameters:** The *Mode* parameter is one of these constants:

<code>imWedge</code>	Wedge mode
<code>imProgrammer</code>	Programmer mode
<code>imDesktop</code>	Desktop mode

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

There are three different reader input modes: wedge, programmer, and desktop. These modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label input goes into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. This mode should be used when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader’s power management capabilities. You will probably notice reduced battery life when in this mode compared to being in either programmer or desktop mode. For more information on power management, see Chapter 3, “Advanced Programming,” in the *JANUS PSK for C/C++ Reference Manual*.

**Programmer Mode** Inputs are echoed to the screen. Reader commands are executed as well as saved. Use this mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in programmer mode.

**Desktop Mode** The application is responsible for retrieving and displaying input. Use this mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes of keyboard flags (**Shift**, **Ctrl**, **Alt**).

Upon exiting the program, set the input mode to *imWedge* so that DOS will work as expected.

For more information about reader input modes, see Chapter 3, “Advanced Programming,” in the *JANUS PSK for C/C++ Reference Manual*.

**See Also:** *imGetInputMode*, *imReceiveInput*

---

**Example**

See example for *imGetInputMode* and *imReceiveInput*.

---

## ***imSetKeyclick***

**Purpose:** Each time you press a key, the reader can emit a click. This function enables or disables the keyclick.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imSetKeyclick% CDECL  
    (BYVAL KeyClick AS INTEGER)
```

**IN Parameters:** The *KeyClick* parameter is one of these constants:

<code>imEnable</code>	Enable the keyclick
<code>imDisable</code>	Disable the keyclick

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imGetKeyclick`

---

### ***Example***

See example for `imGetKeyclick`.

---

## ***imSetViewportLock***

**Purpose:** This function enables or disables the keys that move the viewport.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imSetViewportLock% CDECL  
    (BYVAL VpLock AS INTEGER)
```

**IN Parameters:** The *VpLock* parameter is one of these constants:

<code>imEnable</code>	Lock the viewport
<code>imDisable</code>	Unlock the viewport

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The display must be in 80 x 25 mode for this function to work correctly.

This function controls whether the viewport moves (unlocked) or does not move (locked) when the viewport movement keys are pressed.

This function has no effect on the JANUS 2050.

**See Also:** `imGetViewportLock`, `imSetFollowCursor`

---

### ***Example***

See example for `imGetViewportLock`.

---

## ***imSetWarmBoot***

**Purpose:** This function enables or disables the **Ctrl-Alt-Del** warm boot key sequence. When disabled, the **Ctrl-Alt-Del** key sequence does not reboot the reader.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imSetWarmBoot% CDECL  
    (BYVAL WarmBoot AS INTEGER)
```

**IN Parameters:** The *WarmBoot* parameter is one of these constants:

imEnable	Enable <b>Ctrl-Alt-Del</b> warm boot
imDisable	Disable <b>Ctrl-Alt-Del</b> warm boot

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** imGetWarmBoot

---

### ***Example***

```
'***** imSetWarmBoot *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
status% = imSetWarmBoot(imDisable)  
PRINT "Disabling <BOOT>"  
status% = imGetWarmBoot(ctrlKey%)  
IF ctrlKey% = imEnable THEN  
    PRINT "<BOOT> enabled"  
ELSE  
    PRINT "<BOOT> disabled"  
END IF  
INPUT "Test it1>>",response$  
  
status% = imSetWarmBoot(imEnable)  
PRINT "Enabling <BOOT>"  
INPUT "Test it1>>",response$  
END
```



---

## ***imSound***

**Purpose:** This function generates a beep of specified pitch and duration. For example, use a soft beep for library use, a loud beep for manufacturing use, or a unique beep to distinguish between other readers.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'
FUNCTION imSound% CDECL
    (BYVAL Pitch AS INTEGER,
    BYVAL Duration AS INTEGER,
    BYVAL Volume AS INTEGER)
```

**IN Parameters:** The *Pitch* parameter is the frequency of the beep you want the reader to make. The numeric range for *Pitch* is from 20 to 20,000 Hz. You can also use one of these constants:

```
imHighPitch      2400 Hz
imLowPitch       1200 Hz
imVeryLowPitch   600 Hz
```

The *Duration* parameter is the length of the beep. The numeric range for *Duration* is from 1 to 65,000 ms. You can also use one of these constants:

```
imBeepDuration   50 ms
imClickDuration   4 ms
```

The *Volume* parameter is one of these constants:

```
imOffVolume      Volume is off
imQuietVolume    Volume is quiet
imNormalVolume   Volume is normal
imLoudVolume     Volume is loud
imExtraLoudVolume Volume is extra loud
imCurrentVolume  Volume is the current volume
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

## *imSound – QuickBasic*

---

### **Example**

```
'***** imSound *****
REM $INCLUDE: 'im20bas1.bi'

RESTORE
duration% = 0
pitch%    = -1
volume%   = imCurrentVolume

' Play a song
' Read data and play song until end of data
DO WHILE pitch% <> 0
  'Read in pitch and duration
  READ pitch%, duration%

  ' Call the Intermec function
  status% = imSound(pitch%, duration%, volume%)
LOOP
PRINT "status = ", HEX$(status%)

' Sound data
DATA 523, 500, 392, 500, 440, 500, 330, 500, 349, 500, 330, 250
DATA 296, 250, 262, 1000, 0 ,0

' Enumeration of notes and frequencies
' C0 = 262, D0 = 296, E0 = 330, F0 = 349, G0 = 392, A0 = 440, B0 = 494,
' C1 = 523, D1 = 587, E1 = 659, F1 = 698, G1 = 784, A1 = 880, B1 = 988,
' EIGHTH = 125, QUARTER = 250, HALF = 500, WHOLE = 1000, END = 0
' Above sound DATA
' C1, HALF, G0, HALF, A0, HALF, E0, HALF, F0, HALF, E0, QUARTER,
' D0, QUARTER, C0, WHOLE, END
END
```

---

## ***imStandbyWait***

**Purpose:** This function requests that reader services wait in standby mode for a specific period of time. You can use this function to suspend the reader for a length of time to save the battery power.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION ImStandbyWait% CDECL  
    (BYVAL Timeout AS LONG)
```

**IN Parameters:** The *Timeout* parameter is the amount of time to wait in standby mode. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select imInfiniteTimeout, the function will not return until the end of message character has been received.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** None.

---

### ***Example***

See example for imCommand.

---

## ***imTransmitBuffer***

**Purpose:** This function transmits the contents of a data buffer through a designated communications port. This function continues operating until the buffer transmission is complete or until an error status is detected.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imTransmitBuffer% CDECL  
    (BYVAL PortID AS INTEGER,  
     BYVAL UserLength AS INTEGER,  
     BYVAL DataBuffer AS INTEGER,  
     BYVAL Timeout AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *UserLength* parameter is the length of the data string that you want to transmit.

The *DataBuffer* parameter is a far pointer to the data array that you want to transmit.

The *Timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select imInfiniteTimeout, the function will not return until the end of message character has been received.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** imReceiveBuffer, imTransmitBufferNoWait, imTransmitBufferNoprot

---

### Example

```

***** imTransmitBuffer *****
'   Note: Must have reader services and comm protocol handler installed
'   to enable send/receive buffer functions
'   Run these TSR's at DOS prompt before running these tests:
'       rservice
'       phimec 1 ( 1 is COM1)

      REM $INCLUDE: 'im20bas1.bi'

' Must be run with Phimec protocol installed

PRINT "imTransmitBuffer"

outstr$ = "Hi There"

' Call Intermec function
status% = imTransmitBuffer (imCom1, LEN(outstr$), SADD(outstr$), 1000)

PRINT "com = ", imCom1
PRINT "str = ", outstr$
PRINT "len = ", LEN(outstr$)
PRINT "status = ", HEX$(status%)
END

```

---

## ***imTransmitBufferNoWait***

**Purpose:** This function transmits the contents of a buffer and passes control back to its client.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imTransmitBufferNoWait% CDECL  
    (BYVAL PortID AS INTEGER,  
    SEG DataStruct AS imFarComDataStruct)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *DataStruct* parameter is a far pointer to the data array that you want to transmit.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

This function differs from *imTransmitBuffer* in that the client must set the buffer structure and monitor the buffer status until transmission is complete.

Use this function for multiple buffer transmissions in conjunction with checking the status in *DataStruct*.

You must build and maintain a *DataStruct* of the type *imFarComDataStruct* as described in *IM20BAS1.BI*.

**See Also:** *imTransmitBufferNoprot*, *imCancelTxBuffer*

**Example**

```

'***** imTransmitBufferNoWait *****
REM $INCLUDE: 'im20bas1.bi'

' Define communication status messages
CONST imCuSuccess = 1536
CONST imInuse = -31230

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Data buffer structure for receive/transmit again and noprot
DIM farcomBuffStruct AS imFarComDataStruct

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

' PHIMEC protocol handler must be installed to run this routine
PRINT "imTransmitBufferNoWait"

' Get the transmit environment ready
status%= imCancelTxBuffer(ImCom1)

' Make a null terminated string to transmit
str3 = "Hi There" + CHR$(0)

' Set up comm buffer parameters
farcomBuffStruct.command = imPhTransmit
farcomBuffStruct.protocolXferStatus = imInuse
' Get length not including the null terminator
farcomBuffStruct.userLength = INSTR(str3, CHR$(0)) - 1
farcomBuffStruct.commLength = 0
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffsetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolMode = imNoProtocol
' Terminator is null character
farcomBuffStruct.eomChar = CHR$(0)

' Call Intermec routine
status%= imTransmitBufferNoWait(ImCom1, farcomBuffStruct)
PRINT "Status = ", HEX$(status%)

IF status% = imCuSuccess THEN
' Wait for data transfer to complete
DO WHILE farcomBuffStruct.protocolXferStatus = imInuse AND INKEY$ <> CHR$(27)
LOOP

PRINT "Buffer transmitted"
ELSE
PRINT "Buffer not sent"
END IF

' Release resources
status%= imCancelTxBuffer(ImCom1)
END

```

---

## ***imTransmitBufferNoprot***

**Purpose:** This function transmits a buffer without protocol and sends only the specified number of characters.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imTransmitBufferNoprot% CDECL  
    (BYVAL PortID AS INTEGER,  
     BYVAL UserLength AS INTEGER,  
     BYVAL DataBuffer AS INTEGER,  
     BYVAL Timeout AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *UserLength* parameter is the maximum number of bytes to be transmitted.

The *DataBuffer* parameter is a far pointer to the data array that you want to transmit.

The *Timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 65,534 ms	Numeric range
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select imInfiniteTimeout, the function will not return until the end of message character has been received.

**OUT Parameters:** None.



**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler other than PHPCSTD.EXE to use this function.

If an existing transmit client is linked to the host, you must issue a cancel command first.

**See Also:** imTransmitBufferNoWait, imCancelTxBuffer, imTransmitBuffer

---

### Example

```
'***** imTransmitBufferNoprot *****
REM $INCLUDE: 'im20bas1.bi'

PRINT "Transmit Noprot"

' Get the transmit environment ready
status%= imCancelTxBuffer(ImCom1)

' Define transmit string
temp$ = "Intermec"

' Call Intermec routine
status%= imTransmitBufferNoprot(ImCom1, LEN(temp$), SADD(temp$), 1000)
PRINT
PRINT "Status = ", HEX$(status%)

' Check for success
IF status% < 16384 AND status% > 0 THEN
PRINT "Buffer transmitted"
ELSE
PRINT "Buffer not sent"
END IF

' Release resources
status%= imCancelTxBuffer(ImCom1)
END
```

---

## ***imTransmitByte***

**Purpose:** This function transmits one byte of data out through a designated communications port. This function is identical to MS-DOS INT 14H Service 01H.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imTransmitByte% CDECL  
    (BYVAL PortID AS INTEGER,  
     BYVAL TransmitByte AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *TransmitByte* parameter is the byte of data to transmit.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

Intermec recommends using *imTransmitBuffer* (with a *UserLength* of one) instead of using this function.

You can use this function for an acknowledgment.

**See Also:** *imReceiveByte*, *imTransmitBuffer*

---

**Example**

```
'***** imTransmitByte *****
REM $INCLUDE: 'im20bas1.bi'

PRINT "imTransmitByte"
' If the Mode command is used, DO NOT install the Phpcstd protocol
' If the Phpcstd protocol is installed DO NOT use the mode command

' Set up comm port
SHELL "MODE COM1:9600 E 7 1"

' Get keypad char and transmit to COM1
DO
  outstr$ = INKEY$
  IF outstr$ <> "" THEN
    ' Call Intermec function
    status% = imTransmitByte (imCom1, SADD(outstr$))
    PRINT USING "!"; outstr$;
  END IF
' Loop until Esc is pressed
LOOP UNTIL outstr$ = CHR$(27)

PRINT "status = ", HEX$(status%)
PRINT "Press any key"
PRINT " to continue"
END
```

---

## ***imUnlinkComm***

**Purpose:** This function removes the link between the Reader Wedge function and a designated communications port. After this function executes, the Reader Wedge is not notified of receive buffer functions.

You only need to use this procedure one time, at the end of your program.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION ImUnLinkComm% CDECL  
    (BYVAL PortID AS INTEGER)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imLinkComm`

---

### ***Example***

See example for `imReceiveInput`, `imIrlY`, and `imSerialProtocolControl`.

---

## ***imViewportEnd***

**Purpose:** This function sets the viewport to the lower right corner (end) of the virtual display.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imViewportEnd CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportHome, imViewportPageDown, imViewportPageUp, imViewportToCursor, imViewportMove

---

### ***Example***

```
!***** imViewportEnd *****  
REM $INCLUDE: 'im20bas1.bi'  
  
! Set viewport to lower right corner  
imViewportEnd  
SLEEP 5  
END
```

---

## ***imViewportGetxy***

**Purpose:** This function retrieves the column and row of the upper left corner of the viewport.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imViewportGetxy% CDECL  
    (Row AS INTEGER,  
     Column AS INTEGER)
```

**IN Parameters:** None.

**OUT Parameters:** The *Row* parameter returns the row value (Y-coordinate) of the viewport.

The *Column* parameter returns the column value (X-coordinate) of the viewport.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function is valid only when the display is in 80 x 25 mode.

This function has no effect on the JANUS 2050.

**See Also:** *imViewportSetxy*, *imViewportMove*, *imViewportPageUp*, *imViewportPageDown*, *imViewportToCursor*, *imViewportEnd*, *imViewportHome*

---

### ***Example***

```
'***** imViewportGetxy *****'  
REM $INCLUDE: 'im20bas1.bi'  
row% = 3  
col% = 3  
status% = imViewportSetxy(row%,col%)  
print "Row =";row%  
print "Col =";col%  
input "Waiting>>",response$  
status% = imViewportGetxy(row%,col%)  
print "Row =";row%  
print "Col =";col%  
END
```

---

## *imViewportHome*

**Purpose:** This function sets the viewport to the upper left corner (home) of the virtual display.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imViewportHome CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportEnd, imViewportPageDown, imViewportPageUp, imViewportToCursor, imViewportMove

---

### *Example*

```
!***** imViewportHome *****  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Home  
    imViewportHome  
    SLEEP 5  
END
```

---

## ***imViewportMove***

**Purpose:** This function moves the viewport the specified distance and direction.

**Syntax:**

```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imViewportMove% CDECL  
    (BYVAL Direction AS INTEGER,  
    BYVAL Distance AS INTEGER,  
    Row AS INTEGER,  
    Column AS INTEGER)
```

**IN Parameters:** The *Direction* parameter is one of these constants:

<code>imViewportLeft</code>	Move left
<code>imViewportRight</code>	Move right
<code>imViewportUp</code>	Move up
<code>imViewportDown</code>	Move down

The *Distance* parameter indicates the number of units to move the viewport and is either a numeric value between 1 and 70 or is `imDefaultDistance`.

If the distance parameter is `imDefaultDistance`, the default step size is used.

The distance moved is a configurable parameter. For more information on configuring the viewport, see your JANUS user's manual.

**OUT Parameters:** The *Row* parameter returns the row number to which the viewport has moved.

The *Column* parameter returns the column number to which the viewport has moved.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The (*Row*, *Column*) pair represents the upper left corner of the viewport being displayed.

The minimum value for both the *Row* and *Column* is (0,0), which is the upper left corner of the virtual window. The maximum value is determined by the video mode and the number of lines and columns displayed.



For example, for the normal video mode 3 (80 x 25 display) with a 20 x 16 display size, the maximum value of *Row* is 9 (25 minus 16) and the maximum value of *Column* is 60 (80 minus 20).

The *Row* and *Column* viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *Row* and *Column*.

This function has no effect on the JANUS 2050.

**See Also:** imViewportEnd, imViewportHome, imViewportPageDown, imViewportPageUp, imViewportToCursor, imCursorToViewport

---

### Example

```
'***** imViewportMove *****'
REM $INCLUDE: 'im20bas1.bi'

' Viewport move
' Prompt for direction, distance

INPUT "Enter direction ", direction%
INPUT "Enter distance ", distance%

status% = imViewportMove (direction%, distance%, dpRow%, dpColumn%)
PRINT "RVP move status = "
PRINT " ", HEX$(status%)
PRINT "Row ", dpRow%
PRINT "Col ", dpColumn%
SLEEP 5

END
```

---

## ***imViewportPageDown***

**Purpose:** This function moves the viewport down one viewport length.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imViewportPageDown CDECL ( )

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportEnd, imViewportHome,  
imViewportPageUp, imViewportToCursor, imViewportMove

---

### ***Example***

```
'***** imViewportPageDown *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Down one viewport length  
    imViewportPageDown  
    SLEEP 5  
END
```

---

## ***imViewportPageUp***

- Purpose:** This function moves the viewport up one viewport length.
- Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imViewportPageUp CDECL ( )
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** None.
- Notes:** This function has no effect on the JANUS 2050.
- See Also:** imCursorToViewport, imViewportEnd, imViewportHome,  
imViewportPageDown, imViewportToCursor, imViewportMove

---

### ***Example***

```
***** imViewportPageUp *****  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Up one viewport length  
    imViewportPageUp  
    SLEEP 5  
END
```

---

## ***imViewportSetxy***

- Purpose:** This function sets the viewport row and column to a specific value when moving between two screens.
- Syntax:**
- ```
REM $INCLUDE: 'im20bas1.bi'  
FUNCTION imViewportSetxy% CDECL  
    (Row AS INTEGER,  
     Column AS INTEGER)
```
- IN/OUT Parameters:** The *Row* parameter sets the row value (Y-coordinate) of the viewport.  
The *Column* parameter sets the column value (X-coordinate) of the viewport.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** The (*Row*, *Column*) pair represents the upper left corner of the viewport being displayed.
- The minimum value for both the *Row* and *Column* is (0,0), which is the upper left corner of the virtual window. The maximum value is determined by the video mode and the number of lines and columns displayed.
- For example, for the normal video mode 3 (80 x 25 display) with a 20 x 16 display size, the maximum value of *Row* is 9 (25 minus 16) and the maximum value of *Column* is 60 (80 minus 20).
- The *Row* and *Column* viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *Row* and *Column*.
- This function has no effect on the JANUS 2050.
- See Also:** *imViewportMove*

---

**Example**

```
'***** imViewportSetxy *****  
REM $INCLUDE: 'im20bas1.bi'  
  
' Viewport Set X and Y coordinates  
' Prompt for row and col  
  
INPUT "Enter row ", dpRow%  
INPUT "Enter column ", dpColumn%  
status% = imViewportSetxy (dpRow%, dpColumn%)  
temp$ = INPUT$(1)  
PRINT "VP Set XY status ="  
PRINT " ", HEX$(status%)  
SLEEP 5  
END
```

---

## ***imViewportToCursor***

**Purpose:** This function centers the viewport around the cursor.

**Syntax:** REM \$INCLUDE: 'im20bas1.bi'  
SUB imViewportToCursor CDECL ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** When the cursor is not displayed, use this function to move the viewport to the cursor.

This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportEnd, imViewportHome, imViewportPageDown, imViewportMove

---

### ***Example***

```
'***** imViewportToCursor *****'  
REM $INCLUDE: 'im20bas1.bi'  
  
    ' Call viewport to cursor  
    imViewportToCursor  
    SLEEP 5  
END
```

**3**

***Visual Basic Library***





*This chapter describes how to write applications in Visual Basic using the PSK library functions.*

## ***Working With Visual Basic***

---

The PSK Visual Basic functions are derived from the C and QuickBasic language functions. Visual Basic and QuickBasic are very similar, but the following differences affect how you write your programs:

**Variable Addresses** Visual Basic works more like C/C++ than like QuickBasic in the way that it stores variables. Because Visual Basic uses far pointers, you compile your Visual Basic programs with IM20VBAS.BI. “Using Variable Addresses in Visual Basic” later in this section explains how Visual Basic passes variable addresses.

**Integers for *Timeout* Parameters** All of the Visual Basic functions that pass a *Timeout* parameter pass it as an integer. In most cases, this convention causes no problem. However, as an integer, *Timeout* must be less than 32,768. “Setting Timeout Values” later in this section provides a solution for using larger values.

**Scanner Input** Because Visual Basic is event driven, your application may need to handle events that the JANUS reader or Visual Basic does not recognize. For example, if your application uses a form that receives input from the bar code scanner, you need to provide a method for triggering a keyboard event. “Handling Bar Code Scanner Input” later in this section provides one possible solution.

**Power Management** For the JANUS power management software to go to low-power mode, the keyboard buffer must be polled more frequently than Visual Basic polls it. You need to provide a method for increasing the number of keyboard polls if you want the reader to shut off when it is inactive. “Providing Power Management Support” later in this section provides one possible solution.

---

## ***Using Variable Addresses in Visual Basic***

Visual Basic uses far pointers for many variables, while QuickBasic uses only near pointers. Some of the QuickBasic library functions may work with short Visual Basic programs, but functions that pass variable parameters do not usually work as expected. To avoid problems, use the Visual Basic functions and the include file IM20VBAS.BI. Link your program with IM20\_BAS.LIB.

The function declarations in IM20VBAS.BI use both the address segment and offset (where appropriate) to pass variables. The rule of thumb is to use SSEGADD() for variable length strings and to use both VARPTR() and VARSEG() for fixed length strings, integers, and arrays.

The order of VARPTR() and VARSEG() is important. The example in the *Visual Basic for DOS Reference Manual* for VARPTR states the following:

Because CDECL puts things on the stack from right to left, place the offset VARPTR(xxx) first in the list, followed by the segment VARSEG(xxx) (where xxx is the variable).

For example:

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imGetControlKey% (VARPTR(CtrlKey%),
    VARSEG(CtrlKey%))
    '* more statements *
FUNCTION ImCommand%(SSEGADD(Command$), Length%)
```

---

## Setting Timeout Values

Many of the Visual Basic functions pass a *Timeout* parameter. In each case, *Timeout* is an integer and must be less than 32,768. Your application may require larger values up to the maximum of 65,536.

To use a timeout value greater than 32,767

1. Convert the number to a negative number (*nnnnn* - 65536) and declare a constant for this negative value.

```
CONST im40000 = 40000 - 65536
```

2. Use the constant in the parameter list. The result is passed correctly to the function in IM20\_BAS.LIB.

```
status% = imStandbyWait(im40000)
```

---

## Handling Bar Code Scanner Input

When the JANUS reader operates in Wedge mode (the default mode), data from the scanner is placed in the keyboard buffer. However, a Visual Basic form waits for a keyboard event before checking the keyboard buffer for data. Scanned data remains in the buffer until a key is pressed or until another event triggers Visual Basic to inspect the keyboard buffer.

Additionally, if your form has more than one control, your application can simulate pressing **Tab** to move to the next control in the form.

### Simulating Pressing a Key

One method of getting past the key press limitation is to put a timer in the form and set the time interval to 100 ms. In Example 1 below, the sample timer routine toggles the **Num Lock** key twice. Visual Basic interprets the toggle as a key press and retrieves the scanned data from the keyboard buffer.

In the timer routine, there are two tests to determine if there is data in the keyboard buffer. First, the keyboard buffer status is checked by calling INTERRUPT &H16. If there is data in the keyboard buffer, the output register flag Z is not set. The sample segment performs a logical AND with the register flags to test for data. If data is present, then `outregs.flags` does not contain 40H and the result is zero (0).

Next, the program checks to see if the focus is a text box. If it is, then the **Num Lock** key is toggled twice.

---

**Example 1: Checking for Scanned Input and Power Management**

```
SUB Timer1_Timer ()
'* Checking for Scanned Input and Power Management
'* This subroutine checks the keyboard buffer status to activate power management
'* and to check for scanned data. The Power Management software requires checking
'* the status 4 times.
'* If there is data in keyboard buffer, check to see if a text box has focus.

inregs.ax = &H1100
INTERRUPT &H16, inregs, outregs 'Check extended keyboard status register
inregs.ax = &H1100
INTERRUPT &H16, inregs, outregs 'Check ext keyboard status register
inregs.ax = &H1100
INTERRUPT &H16, inregs, outregs 'Check ext keyboard status register
inregs.ax = &H1100
INTERRUPT &H16, inregs, outregs 'Check ext keyboard status register

charAvailable% = outregs.flags AND &H40 'Bitwise AND checks Status in Z flag
' set = no key press or no data in buffer
IF charAvailable% = 0 THEN 'If data present, is focus on text box?
  IF TYPEOF SCREEN.ActiveControl IS TextBox THEN

    DEF SEG = 0 'Set segment to low memory
    POKE &H417, PEEK(&H417) XOR &H20 'Toggle Num Lock active
    DEF SEG 'Restore segment

    inregs.ax = &H1100
    INTERRUPT &H16, inregs, outregs 'Check extended keyboard status

    DEF SEG = 0 'Set segment to low memory
    POKE &H417, PEEK(&H417) XOR &H20 'Restore Num Lock to what it was
    DEF SEG 'Restore segment

    inregs.ax = &H1100
    INTERRUPT &H16, inregs, outregs 'Check ext keyboard status

  END IF
ENDIF
END SUB
```

The next sample program demonstrates how to move the focus from the active text box to another text box when a carriage return is scanned or when the **Enter** key is pressed. If any other data is scanned or another key is pressed, the data is changed to all uppercase.

---

**Example 2: Moving to the Next Text Box After Receiving a Carriage Return**

```
SUB txtText1_KeyPress (KeyAscii)
  IF KeyAscii = 13 THEN
    txtText2.SETFOCUS
  ELSE
    C$ = CHR$(KeyAscii)           'Convert ASCII keycode to character
    KeyAscii = ASC(UCASE$(C$))   'Convert character to uppercase
  END IF
END SUB
```

### **Simulating Pressing the Tab Key**

Visual Basic moves the focus from one control to the next when the **Tab** key is pressed. When you are scanning bar code labels, you can configure the reader to add a Tab character <HT> to the end of the data to automatically move to the next control.

You must also configure the reader to send the correct key code for <HT>. By default, the reader interprets the <HT> character as **Ctrl-I** (1709 hex), but Visual Basic requires 0F09 hex for the **Tab** key.

Use this method and the timer routine from “Simulating Pressing a Key” to use the scanner with your Visual Basic applications.

#### **To configure the postamble**

1. Use the Postamble configuration command (AE) to set the postamble to a single horizontal tab character <HT>. For more information, see your JANUS user’s manual.
2. Modify the keycode lookup table entry for the horizontal tab <HT>.

#### To temporarily change the Tab keycode

- Use the Key Code Look-Up Table configuration command (WM) to change the keycode lookup table. Set the <HT> key to 0F09 hex.

This change is temporary. Rebooting the reader resets the look-up table to the default settings. For more information, see your JANUS user's manual.

#### To change the Tab keycode and save the setting

1. Use IC.EXE to set the keycode for the horizontal tab <HT>.
2. From the Op menu, select Key Codes.
3. Select Redefine.
4. For the character to redefine, press **Ctrl-I**. The code <HT> is displayed.
5. For the new key code, type **0f09**. The "f" can be uppercase or lowercase.
6. Press **Enter**.
7. Save the configuration and exit Configuration Manager. For more information, see your JANUS user's manual.

---

## ***Providing Power Management Support***

The JANUS reader power management software monitors keypad activity to determine if the reader can be put into suspend mode. If it detects that the keyboard buffer is being polled on a regular basis, and no other activity is detected, it assumes that the reader is inactive. If the inactive state continues for longer than the configured setting, then the power management software turns off the reader to preserve battery life. The default Configuration Management setting is 1 minute.

Because Visual Basic is event-driven, the keyboard buffer is not automatically monitored. The power management software never detects the inactive state, and the reader never shuts off. Your program must check the keyboard buffer status four times to simulate keyboard monitoring.

The timer subroutine that follows checks the keyboard buffer status four times. If the keyboard buffer status changes, then the power management software does nothing. If there is no change for the fourth check, then the power management software knows that the reader is inactive.

---

**Example 3: Checking Keyboard Status for Power Management**

```
SUB Timer1_Timer ()
' * This subroutine checks the keyboard buffer status to activate power management
' * and to check for scanned data. The Power Management software requires checking
' * the status 4 times. If there is data in keyboard buffer, process it.

    inregs.ax = &H1100
    INTERRUPT &H16, inregs, outregs,    'Check extended keyboard status register

    inregs.ax = &H1100
    INTERRUPT &H16, inregs, outregs,    'Check extended keyboard status register

    inregs.ax = &H1100
    INTERRUPT &H16, inregs, outregs,    'Check extended keyboard status register

    inregs.ax = &H1100
    INTERRUPT &H16, inregs, outregs,    'Check extended keyboard status register

    charAvailable% = outregs.flags AND &H40    'Bitwise AND to check Status in Z flag
  'set = no key press or no data in buffer
    IF charAvailable% = 0 THEN                'If data present, do something
' *
' * Insert your code here.
' * See previous example "Checking for Scanned Input and Power Management"
' *
        ENDIF
    END SUB
```

## **Building a Program Using Microsoft Visual Basic**

This section shows you how to write, compile, and link a Visual Basic for DOS program that uses the Visual Basic library functions you installed from the PSK disk.

Keep the following tips in mind when you build your Visual Basic programs:

- Visual Basic cannot compile and link with external libraries. You must compile and link your program from the DOS command line.
- Refer to your Visual Basic user's guide for information on using BC.EXE and LINK.EXE.
- Both C and Visual Basic use the BC.EXE and LINK.EXE commands. If you have C and Visual Basic installed and want to compile and link from the command line, run these commands from the Visual Basic directory or make sure that your Visual Basic directory comes before your C directory in your path.
- You must build a standalone executable program.

In the following procedure, *progrname* is the name of your program file without an extension. In a short program, your source file (*progrname.BAS*), object file (*progrname.OBJ*), and executable file (*progrname.EXE*) all have the same filename.

Most Visual Basic applications use several types of source files: *progrname.BAS*, *progrname.FRM*, *progrname.BI*, *progrname.MAK*, and *progrname.TXT*. Your application may have more than one file of a particular type. For more information, refer to your Visual Basic manual.



**To build your program using Visual Basic for DOS**

1. Start Visual Basic from DOS with the library (/L) switch:

```
vbdos /L
```

2. Create and edit your program.
3. Exit Visual Basic.
4. At the DOS prompt, change to the directory containing your program source files.
5. Compile each \*.BAS and \*.FRM module from DOS, one at a time:

```
BC /T /O /C:512 progname.BAS, progname, NUL.LST
```

where:

**/T /O** builds a standalone object file.

**/C:512** sets the buffer size for receiving remote data. The maximum size is 32,767 bytes.

**progname** is your program or module name and the name for the object file, \*.OBJ.

6. Create a response file, *progname.RSP*, for linking. The response file consists of the following four lines:

```
prognam1.OBJ prognam2.OBJ prognam3.OBJ
progname
(a blank line)
C:\INTERMEC\VBDOS\LIB\IM20_BAS.LIB C:\VBDOS\VBDCL10.LIB +
C:\VBDOS\VBDOS.LIB
```

where:

the first line lists all the object files from Step 5 and the im20bas.obj file, including their path.

the second line lists only the executable filename with no extension.

the third line is left blank.

the fourth line lists the library files, including their paths.

If any line has more than 255 characters, type a + (plus) to indicate a continuation and continue typing paths and filenames on the next line.

7. Link the program from the DOS prompt using the response file:

```
LINK /NOE @prognam.rsp
```

where: /NOE searches the object files for public symbols that may be redefined in your program.

8. Copy your program, *prognam*.EXE, to your JANUS reader and run the program.

#### *Handling a Linker Error Message*

You may get a linker error message when you link the Visual Basic program. If you receive the following error message, your program has more segments than the default (128):

```
fatal error L1049: too many segments
```

You need to increase the number of segments and link again.

#### To set the number of segments

- Enter the following command from the DOS prompt:

```
LINK /SEG:nnn /NOE @prognam.RSP
```

where: *nnn* is a number between 1 and 16,375.

## ***Debugging With JANUS Application Simulator***

---

The JANUS Application Simulator is a terminate-and-stay resident (TSR) program that you use to run JANUS applications on a PC. Without the Simulator, you cannot run JANUS applications on your PC. Whenever you start a program that uses PSK library functions, the program checks for a JANUS reader and for the JANUS Simulator. If you attempt to run a JANUS program on a PC without the Simulator, you get an error message.

The Simulator captures the JANUS functions and interrupts to make the PC mimic a JANUS reader. For more information on the Simulator, refer to the *JANUS Application Simulator User's Manual*, Part No. 062778.

To debug a JANUS application with the Simulator

1. Start the Simulator from the DOS prompt by entering this command:  
`janussim`
2. Start Visual Basic.
3. Follow the debugging instructions provided with Visual Basic.

## ***Runtime Requirements***

---

For some library functions to work properly, you must install and run specific software components at program execution time. For example, if the reader is using a communications port and you want to use Intermec protocols, you must load a protocol handler. Because protocol handlers use a lot of memory, they are not automatically loaded for you. Other functions require the Reader Wedge.

---

### ***Protocol Handlers***

You use the Intermec protocol handler (PHIMEC.EXE) when the reader is connected with other Intermec devices. PHIMEC.EXE works with User-Defined, Point-to-Point, Polling Mode D, and Multi-Drop protocols.

You use the PC standard protocol handler (PHPCSTD.EXE) when the reader is connected to devices that use PC standard protocol. PHPCSTD.EXE provides low-level communication abilities and protocol services at the DOS level for non-communication software. It also provides byte-by-byte transfer.

If your reader is a radio frequency (RF) unit, RFPH.EXE is automatically loaded.

For more information on protocol handlers, refer to your JANUS user's manual.

To install a protocol handler on the reader

- From the DOS prompt, enter the following command:

```
handler n
```

where:

*handler* is either PHIMEC or PHPCSTD.

*n* is the number of the communications port.

When your application is finished, the protocol handler TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the protocol handler TSR by adding the unload command as the last line of the batch file that launches your application.

**To unload a protocol handler on the reader**

- From the DOS prompt, enter the following command:

```
unload handler n
```

where:

*handler* is the installed handler (PHIMEC or PHPCSTD).

*n* is the number of the communications port.

---

***Reader Wedge***

Some functions, such as `imReceiveInput`, allow the reader to receive input from multiple sources and process the input depending on the source. You must load the Reader Wedge (RWTSR.EXE) TSR to use these functions.

When your application is finished, the Reader Wedge TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the Reader Wedge TSR by adding the unload command as the last line of the batch file that launches your application.

**To load the Reader Wedge TSR on the reader**

- From the DOS prompt, enter the following command:

```
RWTSR
```

**To unload the Reader Wedge TSR on the reader**

- From the DOS prompt, enter the following command:

```
RWTSR -D
```

---

## ***Specific Functions With Runtime Requirements***

The following table lists the PSK functions that have runtime requirements.

---

### ***Specific Runtime Requirements***

| <b>This Function</b>  | <b>Requires</b>                                                                               |
|-----------------------|-----------------------------------------------------------------------------------------------|
| imCancelRxBuffer      | Protocol Handler                                                                              |
| imCancelTxBuffer      | Protocol Handler                                                                              |
| imCommand             | Reader Wedge                                                                                  |
| imGetInputMode        | Reader Wedge                                                                                  |
| imGetLabelSymbology   | Reader Wedge                                                                                  |
| imGetLength           | Reader Wedge                                                                                  |
| imInputStatus         | Reader Wedge                                                                                  |
| imIrlA                | Reader Wedge                                                                                  |
| imIrlK                | Reader Wedge                                                                                  |
| imIrlN                | Reader Wedge                                                                                  |
| imIrlV                | Reader Wedge<br>If data is from a communications port, use a Protocol Handler and imLinkComm. |
| imIrlY                | Reader Wedge<br>Protocol Handler<br>Use imLinkComm.                                           |
| imLinkComm            | Reader Wedge<br>Protocol Handler                                                              |
| imReceiveBuffer       | Protocol Handler<br>Will not work if linked.                                                  |
| imReceiveBufferNoprot | Protocol Handler<br>Will not work if linked.                                                  |
| imReceiveBufferNoWait | Protocol Handler<br>Will not work if linked.                                                  |
| imReceiveByte         | Protocol Handler<br>You must install PHPCSTD. Will not work if linked.                        |
| imReceiveInput        | Reader Wedge<br>If data is from a communications port, use a Protocol Handler and imLinkComm. |

---

*Specific Runtime Requirements (continued)*

| <b>This Function</b>    | <b>Requires</b>                               |
|-------------------------|-----------------------------------------------|
| imRxCheckStatus         | Protocol Handler                              |
| imSerialProtocolControl | imLinkComm                                    |
| imSetDisplayMode        | Reader Wedge                                  |
| imSetInputMode          | Reader Wedge                                  |
| imStandbyWait           | Reader Wedge                                  |
| imTransmitBuffer        | Protocol Handler                              |
| imTransmitBufferNoprot  | Protocol Handler                              |
| imTransmitBufferNoWait  | Protocol Handler                              |
| imTransmitByte          | Protocol Handler<br>You must install PHPCSTD. |
| imUnlinkComm            | Reader Wedge<br>Protocol Handler              |

---

## ***Certified Basic Language Functions***

---

The Visual Basic PSK functions are derived from the QuickBasic and C/C++ functions. For a complete list of tested QuickBasic functions, see “Certified QuickBasic Language Functions” in Chapter 2. Refer to your Visual Basic reference manual for a list of QuickBasic functions that Visual Basic does not support.

## Visual Basic Functions

---

The following pages list the Basic functions available in the PSK, along with notes on syntax and examples of how to use each function.

**Note:** Do **not** run programs that use **PSK library functions** on your PC, **unless** you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### Caution

**Do not run programs that use Intermec-specific interrupt extensions on your PC, unless you have the JANUS Application Simulator installed. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### Conseil

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC, à moins que JANUS Application Simulator soit installé. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**



---

## Visual Basic Functions Listed by Category

### Communications

- imCancelRxBuffer, 3-26
- imCancelTxBuffer, 3-28
- imLinkComm, 3-80
- imProtocolExtendedStatus, 3-88
- imReceiveBuffer, 3-91
- imReceiveBufferNoprot, 3-94
- imReceiveBufferNoWait, 3-97
- imReceiveByte, 3-100
- imRxCheckStatus, 3-106
- imSerialProtocolControl, 3-107
- imTransmitBuffer, 3-128
- imTransmitBufferNoprot, 3-132
- imTransmitBufferNoWait, 3-130
- imTransmitByte, 3-134
- imUnlinkComm, 3-136

### Display

- imBacklightOff, 3-23
- imBacklightOn, 3-24
- imBacklightToggle, 3-25
- imDecreaseContrast, 3-33
- imGetContrast, 3-37
- imGetDisplayMode, 3-41
- imGetDisplayType, 3-43
- imGetFollowCursor, 3-44
- imIncreaseContrast, 3-55
- imSetContrast, 3-110
- imSetDisplayMode, 3-113
- imSetFollowCursor, 3-119

### Input

- imGetInputMode, 3-45
- imGetLabelSymbology, 3-48
- imGetLength, 3-49
- imGetPostamble, 3-50
- imGetPreamble, 3-51
- imInputStatus, 3-57
- imReceiveByte, 3-100
- imReceiveInput, 3-102
- imSetInputMode, 3-120

### Irl

- imIrlA, 3-59
- imIrlK, 3-64
- imIrlN, 3-68
- imIrlV, 3-73
- imIrlY, 3-77

### Keypad

- imGetKeyclick, 3-47
- imGetWarmBoot, 3-54
- imNumberPadOff, 3-83
- imNumberPadOn, 3-84
- imSetControlKey, 3-112
- imSetKeyclick, 3-122
- imSetWarmBoot, 3-124

### Program control

- imApplBreakStatus, 3-21
- imStandbyWait, 3-127

## ***Sound***

imSound, 3-125

## ***System***

imCommand, 3-30

imGetConfigInfo, 3-35

imMessage, 3-82

imPowerStatus, 3-86

imRsInstalled, 3-105

## ***Viewport***

imGetViewportLock, 3-52

imCursorToViewport, 3-32

imSetViewportLock, 3-123

imViewportEnd, 3-137

imViewportGetxy, 3-138

imViewportHome, 3-139

imViewportMove, 3-140

imViewportPageDown, 3-142

imViewportPageUp, 3-143

imViewportSetxy, 3-144

---

## imApplBreakStatus

**Purpose:** This function checks whether the application break sequence has been pressed. All PSK functions are terminated when the application break sequence is keyed in.

Place calls to this function at strategic locations in your program to detect when a user wants to break out of a loop. Your program can determine what action to take when the break sequence is detected.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imApplBreakStatus%  
    (VARPTR(BreakStatus), VARSEG(BreakStatus))
```

**IN Parameters:** None.

**OUT Parameters:** The *BreakStatus* parameter returns a nonzero value if the break status bit is set and zero if it is not set.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The *BreakStatus* flag is reset each time the routine is called. Because this function is also called during the input routines provided in the library, you should check the return code from input functions for the hex value 8515H. This value indicates that the input function has terminated because the application break sequence was entered. In this case, *BreakStatus* is cleared by the input function’s call to imApplBreakStatus.

To enter an application break sequence

1. Press  $\text{I/O}$  to turn off the reader.
2. Press  $\text{F3}$  -  $\text{2}$  -  $\blacktriangleleft$  at the same time.
3. Press  $\text{1}$ . This sets the reader’s application break bit.
4. Press  $\text{I/O}$  to turn on the reader.

## *imApplBreakStatus – Visual Basic*

---

### **Example**

```
'***** imApplBreakStatus *****
REM $INCLUDE: 'im20vbas.bi'

' Initializing Variables
Brk% = 0
Temp$ = ""

' Clear the screen
CLS

' Press the following sequence to set the application break on:
' I/O key (Turn OFF the reader)
' F3+2+LeftArrow (Press F3, 2, and left arrow at the same time)
' 1 (Press the 1 key to set application break bit)
' I/O key (Turn the reader ON)

WHILE Temp$ <> "q"

' Check the application break status
status% = imApplBreakStatus (VARPTR(Brk%), VARSEG(Brk%))

IF Brk% THEN
    PRINT "App Brk is ON"
ELSE
    PRINT "App Brk is OFF"
END IF

PRINT
PRINT "Press any key to continue, "
PRINT "'q' for quit: "
PRINT
PRINT
Temp$ = INPUT$(1)
WEND
END
```

---

## *imBacklightOff*

**Purpose:** This function turns the display backlight off. Turn the backlight off to prolong the reader's battery life.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imBacklightOff()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1 second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** imBacklightOn, imBacklightToggle

---

### *Example*

```
'***** imBacklightOff *****  
REM $INCLUDE: 'im20vbas.bi'  
  
    ' Backlight off  
    CALL imBacklightOff  
    PRINT "Backlight off"  
END
```

---

## ***imBacklightOn***

**Purpose:** This function turns the display backlight on to illuminate the reader display in dimly lit environments.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imBacklightOn()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1 second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** imBacklightOff, imBacklightToggle

---

### ***Example***

```
'***** imBacklightOn *****  
REM $INCLUDE: 'im20vbas.bi'  
  
    ' Backlight on  
    CALL imBacklightOn  
    PRINT "Backlight on "  
END
```

---

## ***imBacklightToggle***

**Purpose:** This function toggles the display backlight ON and OFF.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imBacklightToggle()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1 second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** imBacklightOn, imBacklightOff

---

### ***Example***

```
'***** imBacklightToggle *****  
REM $INCLUDE: 'im20vbas.bi'  
  
    ' Backlight toggle  
    CALL imBacklightToggle  
    PRINT "Backlight switched on/off "  
END
```

---

## ***imCancelRxBuffer***

**Purpose:** This function clears the receive buffer of the designated communications port.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
FUNCTION imCancelRxBuffer%(PortID)

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1 COM1  
imCom2 COM2, scanner port (2010 and 2050)  
imCom4 COM4 (RF only)

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

If there is no input pending to receive, this function returns 4602H (no client).

**Notes:** You must install a protocol handler to use this function.

**See Also:** imReceiveBufferNoWait, imReceiveBufferNoprot

---

### ***Example***

```
'***** imCancelRxBuffer *****'  
REM $INCLUDE: 'im20vbas.bi'  
  
CONST bufsize = 300 ' Data buffer must be at least 256 bytes  
DIM farcomBuffStruct AS imFarComDataStruct ' Data buffer structure  
DIM str3 AS STRING * bufsize ' Fixed length strings of 300 bytes  
DIM done  
  
' The difference between imReceiveBufferNoWait and the ReceiveBufferNoprot  
' is that the user must set up the imReceiveBufferNoWait comm  
' struct and pend on the results. Whereas, in the Noprot receive, the  
' user sets up the length of the buffer, points at that buffer and  
' sends it off and returns. There is no pending on this level for the  
' imReceiveBufferNoprot routine  
  
' Phimec protocol handler must be installed to run this routine  
  
' Get the receive environment ready  
status%= imCancelRxBuffer(imCom1)
```



```

' Zero out string
str3 = STRING$(buffsize, CHR$(0))
' Set up communication buffer structure
farcomBuffStruct.command = imPhReceive
farcomBuffStruct.protocolMode = imNoProtocol
farcomBuffStruct.eomChar = CHR$(13) 'CR for terminating char
farcomBuffStruct.userLength = buffsize
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffSetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolXferStatus = imCuInuse
farcomBuffStruct.CommLength = 0

done = FALSE

' Call Intermec function
status%= imReceiveBufferNoWait(ImCom1,
    VARPTR(farcomBuffStruct), VARSEG(farcomBuffStruct))
PRINT "Func1= ", HEX$(status%)

' Loop until first character in buffer is a 'Q' or Esc is pressed
DO
    ' Check for receive errors:
    ' Print the error status
    IF status%= imIserror THEN
        PRINT "Rx Again err = ", HEX$(status%)
        done = FALSE
    ELSE
        ' Keyboard char
        temp$ = " "
        ' Get the receive data
        PRINT "Input chars"
        PRINT "Enter 'Q'"
        PRINT "or Esc to exit"

        ' Check to see if any characters are in buffer
        DO WHILE farcomBuffStruct.protocolXferStatus = imCuInuse AND temp$ <> CHR$(27)
            temp$ = INKEY$ ' Pick up any keypad input
        LOOP

        PRINT "Comm done"
        PRINT str3 ' Print the input string

        ' Update buffer for next block then call imRxCheckStatus to
        ' get protocol handler to reset status.
        farcomBuffStruct.command = imPhRecvAgain
        farcomBuffStruct.protocolXferStatus = imCuInuse
        farcomBuffStruct.commLength = 0
        status%= imRxCheckStatus(ImCom1)
    END IF

    ' Quit if first char in buffer is a 'Q' or a 'q'
    ' or Esc has been pressed
    IF UCASE$(LEFT$(str3, 1)) = "Q" OR temp$ = CHR$(27) THEN
        done = TRUE
    ELSE
        ' Zero out string and loop
        str3 = STRING$(buffsize, CHR$(0))
    ENDIF
LOOP WHILE done = FALSE
' Release resources
status%= imCancelRxBuffer(ImCom1)
END

```

---

## ***imCancelTxBuffer***

**Purpose:** This function clears the contents of the transmit buffer for a designated communications port, stops transmission in progress, and resets the communications port.

Use this function with Polling Mode D to clear out the buffer. Other protocols clear the buffer automatically.

You can also use this function to clear a busy port.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imCancelTxBuffer%(PortID)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** `imTransmitBufferNoWait`, `imTransmitBufferNoprot`, `imTransmitBuffer`

**Example**

```

***** imCancelTxBuffer *****
REM $INCLUDE: 'im20vbas.bi'

' PHIMEC protocol handler must be installed to run this routine
' Define communication status messages
CONST imCuSuccess = 1536
CONST imInuse = -31230

CONST bufsize = 300          ' Data buffer must be at least 256 bytes

' Data buffer structure for receive/transmit again and noprot
DIM farcomBuffStruct AS imFarComDataStruct

DIM str3 AS STRING * bufsize  'fixed length string of 300 bytes

DIM done

' Get the transmit environment ready
status%= imCancelTxBuffer(ImCom1)

' Make a null terminated string to transmit
str3 = "Hi There" + CHR$(0)

' Set up comm buffer parameters
farcomBuffStruct.command = imPhTransmit
farcomBuffStruct.protocolXferStatus = imInuse
' Get length not including the null terminator
farcomBuffStruct.userLength = INSTR(str3, CHR$(0)) - 1
farcomBuffStruct.commLength = 0
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffsetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolMode = imNoProtocol
' Terminator is null character
farcomBuffStruct.eomChar = CHR$(0)

' Call Intermec routine
status%= imTransmitBufferNoWait(ImCom1,
    VARPTR(farcomBuffStruct), VARSEG(farcomBuffStruct))

PRINT "Status = ", HEX$(status%)

IF status% = imCuSuccess THEN
    ' Wait for data transfer to complete
    DO WHILE farcomBuffStruct.protocolXferStatus = imInuse AND INKEY$ <> CHR$(27)
        LOOP

    PRINT "Buffer transmitted"
ELSE
    PRINT "Buffer not sent"
END IF

' Release resources
status%= imCancelTxBuffer(ImCom1)
END

```

---

## ***imCommand***

**Purpose:** This function modifies the reader's configuration. For example, you can use the function to set a specific communications port's baud rate.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION ImCommand%(SSEGADD(Command), Length)
```

**IN Parameters:** The *Command* parameter is a reader command string. The command string may include more than one reader command. For example, the command string `%.1$+BV9` turns on the backlight and raises the beep volume.

Reader commands are listed in your JANUS user's manual.

The *Length* parameter is the length of the reader command string.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** For more information on using reader commands, see your JANUS user's manual.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** None.

---

**Example**

```
'***** imCommand *****  
' $INCLUDE: 'im20vbas.bi'  
  
CLS          ' Clear the screen  
  
str1$ = "$+DJ7"  
str2$ = "$+DJ0"  
str3$ = "$+DJ3"  
  
PRINT "Set high contrast"  
status% = imCommand(SSEGADD(str1$), LEN(str1$))  
status% = imStandbyWait(2000)          ' Wait two seconds  
  
PRINT "Set low contrast"  
status% = imCommand(SSEGADD(str2$), LEN(str2$))  
status% = imStandbyWait(2000)          ' Wait two seconds  
  
PRINT "Set normal contrast"  
status% = imCommand(SSEGADD(str3$), LEN(str3$))  
status% = imStandbyWait(2000)          ' Wait two seconds  
  
PRINT "Wait status >>";HEX$(status%)  
imMessage(status%)  
END
```

---

## ***imCursorToViewport***

**Purpose:** This function moves the cursor to the center of the current viewport. Since the viewport can move around with or without the cursor, you can use this function to recenter the cursor.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imCursorToViewport()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imViewportEnd, imViewportHome,  
imViewportPageDown, imViewportPageUp,  
imViewportToCursor, imViewportMove

---

### ***Example***

```
'***** imCursorToViewport*****  
REM $INCLUDE: 'im20vbas.bi'  
  
    ' Call cursor to viewport  
    imCursorToViewport  
END
```

---

## ***imDecreaseContrast***

**Purpose:** This function decreases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast (0 to 31), where 0 is very light, and 31 is very dark.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imDecreaseContrast()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The 0 to 31 scale fine tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table compares the two scales.

| This Value on<br>Scale 0 to 7 | Equates to This Value on<br>Scale 0 to 31 | Contrast<br>Level |
|-------------------------------|-------------------------------------------|-------------------|
| 0                             | 10                                        | Very light        |
| 1                             | 12                                        |                   |
| 2                             | 14                                        |                   |
| 3                             | 16                                        |                   |
| 4                             | 18                                        |                   |
| 5                             | 20                                        |                   |
| 6                             | 22                                        | Very dark         |
| 7                             | 24                                        |                   |

This function has no effect on the JANUS 2050.

**See Also:** `imIncreaseContrast`, `imSetContrast`, `imGetContrast`

## *imDecreaseContrast – Visual Basic*

---

### **Example**

```
'***** imDecreaseContrast *****  
REM $INCLUDE: 'im20vbas.bi'  
  
    PRINT "imDecreaseContrast"  
    ' Call Intermec function  
    status% = imDecreaseContrast  
    'Pause for keypad input  
    temp$ = INPUT$(1)  
  
    PRINT "imDecreaseContrast"  
    ' Call Intermec function  
    status% = imDecreaseContrast  
END
```



---

## ***imGetConfigInfo***

**Purpose:** This function retrieves the current reader configuration information string and its length.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetConfigInfo%  
    (VARPTR(conString), VARSEG(conString),  
    VARPTR(length), VARSEG(length))
```

**IN/OUT Parameters:** The *conString* parameter is the configuration information string. The first two characters specify the type of configuration information returned.

For example, to get the beep duration setting, pass in “BD” for *conString*. The function returns BD and the current configuration for beep duration.

The *length* parameter is the length of the configuration information string.

For a list of the configuration commands, see your JANUS user’s manual.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function differs from imCommand in that you only pass the two-character command identifier. The imCommand function passes an entire command string.

**See Also:** imCommand

## *imGetConfigInfo – Visual Basic*

---

### **Example**

```
'***** imGetConfigInfo *****  
REM $INCLUDE: 'im20vbas.bi'  
  
DIM outstr AS STRING *300  
  
outstr = STRING$(300, CHR$(0))  
outstr$ = "BV" + CHR$(0)  
  
PRINT "ImGetConfigInfo example: "  
  
status% = imGetConfigInfo(VARPTR(outstr), VARSEG(outstr),  
    VARPTR(count%), VARSEG(count%))  
  
PRINT "Beep Volume: "; outstr  
PRINT "Length: "; count%  
PRINT "Status: "; HEX$(status%)  
END
```

---

## ***imGetContrast***

**Purpose:** This function gets the reader's LCD display contrast level. There are eight levels of contrast (0 to 7) from very light to very dark, which are the most frequently used contrast settings.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imGetContrast%
    (VARPTR(DispContLevel), VARSEG(DispContLevel))
```

**IN Parameters:** None.

**OUT Parameters:** The *DispContLevel* parameter is a number from 0 to 7 or is one of these constants:

|               |   |                  |
|---------------|---|------------------|
| imMinContrast | 0 | Minimum contrast |
| imMaxContrast | 1 | Maximum contrast |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The functions *im\_set\_contrast* and *im\_get\_contrast* use a scale of 0 to 7 that is related to the scale of 0 to 31 used by *im\_increase\_contrast* and *im\_decrease\_contrast*. The following table compares the two scales.

| This Value on<br>Scale 0 to 7 | Equates to This Value on<br>Scale 0 to 31 | Contrast<br>Level |
|-------------------------------|-------------------------------------------|-------------------|
| 0                             | 10                                        | Very light        |
| 1                             | 12                                        |                   |
| 2                             | 14                                        |                   |
| 3                             | 16                                        |                   |
| 4                             | 18                                        |                   |
| 5                             | 20                                        |                   |
| 6                             | 22                                        | Very dark         |
| 7                             | 24                                        |                   |

This function has no effect on the JANUS 2050.

**See Also:** *imSetContrast*, *imDecreaseContrast*, *imIncreaseContrast*

## *imGetContrast – Visual Basic*

---

### **Example**

```
'***** imGetContrast *****  
REM $INCLUDE: 'im20vbas.bi'  
  
' Get contrast  
  status% = imGetContrast (VARPTR(level%), VARSEG(level%))  
  PRINT "Get Contrast status = ", HEX$(status%)  
  PRINT "Contrast level =", level%  
END
```

---

## ***imGetControlKey***

**Purpose:** You can enable or disable the **Ctrl** key. This procedure retrieves the current setting.

When you disable this keycode, none of the key combinations that use the **Ctrl** key will work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetControlKey%  
    (VARPTR(ControlKey), VARSEG(ControlKey))
```

**IN Parameters:** None.

**OUT Parameters:** The *ControlKey* parameter is one of these constants:

|           |                      |
|-----------|----------------------|
| imEnable  | Ctrl key is enabled  |
| imDisable | Ctrl key is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imSetControlKey

## *imGetControlKey – Visual Basic*

---

### **Example**

```
'***** imGetControlKey *****  
REM $INCLUDE: 'im20vbas.bi'  
  
status% = imSetControlKey(imEnable)  
PRINT "Enabling <CTRL>"  
status% = imGetControlKey(VARPTR(ctrlKey%), VARSEG(ctrlKey%))  
IF ctrlKey% = imEnable THEN  
    PRINT "<CTRL> enabled"  
ELSE  
    PRINT "<CTRL> disabled"  
END IF  
INPUT "Test it>>",response$  
status% = imSetControlKey(imDisable)  
PRINT "Disabling <CTRL>"  
status% = imGetControlKey(VARPTR(ctrlKey%), VARSEG(ctrlKey%))  
IF ctrlKey% = imDisable THEN  
    PRINT "<CTRL> disabled"  
END IF  
status% = imSetControlKey(imEnable)  
PRINT "Enabling <CTRL>"  
END
```

---

## imGetDisplayMode

**Purpose:** This function gets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imGetDisplayMode%
    (VARPTR(SizeMode), VARSEG(SizeMode),
    VARPTR(VideoMode), VARSEG(VideoMode),
    VARPTR(ScrollMode), VARSEG(ScrollMode),
    VARPTR(CharHt), VARSEG(CharHt))
```

**IN Parameters:** None.

**OUT Parameters:** The *SizeMode* parameter is required and is one of these constants:

|                 |                                   |
|-----------------|-----------------------------------|
| imSizeMode80X25 | 80 x 25 text mode                 |
| imSizeMode40X25 | 40 x 25 text mode (2010 and 2020) |
| imSizeMode20X16 | 20 x 16 text mode (2010 and 2020) |
| imSizeMode20X8  | 20 x 8 text mode (2010 and 2020)  |
| imSizeMode10X16 | 10 x 16 text mode (2010 and 2020) |
| imSizeMode10X8  | 10 x 8 text mode (2010 and 2020)  |

If imSizeMode80X25 is set, you also need to set the video mode, scroll mode, and character height.

If any other *SizeMode* is set, the other parameters are automatically set.

The *VideoMode* parameter requires imSizeMode80X25. The standard PC BIOS supports up to video mode 13H. The reader only supports up to video mode 6. You can also set video modes 0 through 3 with IC.EXE.

The *VideoMode* parameter is one of these constants:

|                 |                                         |
|-----------------|-----------------------------------------|
| imStdVideoMode0 | 40 x 25 (use for double-wide character) |
| imStdVideoMode1 | 40 x 25 (use for double-wide character) |
| imStdVideoMode2 | 80 x 25                                 |
| imStdVideoMode3 | 80 x 25                                 |
| imStdVideoMode4 | 300 x 200 2-color                       |
| imStdVideoMode5 | 300 x 200 monochrome                    |
| imStdVideoMode6 | 640 x 200 2-color (2050)                |

## *imGetDisplayMode* – Visual Basic

The *ScrollMode* parameter requires *imSizeMode80X25* and is one of these constants:

|                        |                                            |
|------------------------|--------------------------------------------|
| <i>imLcdScrollAt25</i> | Scroll at line 25                          |
| <i>imLcdScrollAt16</i> | Scroll at line 16 (2010 and 2020)          |
| <i>imLcdScrollAt13</i> | Scroll at line 13 (2050 and double-height) |
| <i>imLcdScrollAt8</i>  | Scroll at line 8 (2010 and 2020)           |

The *CharHt* parameter requires *imSizeMode80X25* and is one of these constants:

|                             |                                                                                   |
|-----------------------------|-----------------------------------------------------------------------------------|
| <i>imStandardCharHeight</i> | Standard-height characters, applies to all scroll modes except line 8 and line 13 |
| <i>imDoubleCharHeight</i>   | Double-height characters, applies only to scroll at line 8 and line 13            |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** *imSetDisplayMode*

---

### **Example**

```
'***** imGetDisplayMode *****
REM $INCLUDE: 'im20vbas.bi'

' Get Display Mode
status% = imGetDisplayMode (VARPTR(dpSize%), VARSEG(dpSize%),
    VARPTR(dpVideo%), VARSEG(dpVideo%),
    VARPTR(dpScroll%), VARSEG(dpScroll%),
    VARPTR(dpCharHt%), VARSEG(dpCharHt%))
PRINT "Status = ", HEX$(status%)
PRINT "Get modes"
PRINT "Size = ", dpSize%
PRINT "Video = ", dpVideo%
PRINT "Scroll = ", dpScroll%
PRINT "CharHt = ", dpCharHt%
END
```



---

## *imGetDisplayType*

**Purpose:** This function gets the hardware display type, either standard JANUS reader or JANUS 2050.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetDisplayType%  
    (VARPTR(type), VARSEG(type))
```

**IN Parameters:** None.

**OUT Parameters:** The *type* parameter is one of these constants:

|            |                        |
|------------|------------------------|
| IMLCD20X16 | Standard JANUS display |
| IMCRT80X25 | JANUS 2050 display     |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imGetDisplayMode, imSetDisplayMode

---

### *Example*

```
REM $INCLUDE: 'im20vbas.bi'  
PRINT "imGetDisplayType example: "  
status% = imGetDisplayType(VARPTR(displayType%), VARSEG(displayType%))  
IF displayType% = imLCD20X16 THEN  
    PRINT "Display type is Standard JANUS display"  
ELSE  
    PRINT "Display type is JANUS 2050 display"  
ENDIF  
PRINT "Status: "; HEX$(status%)  
END
```

---

## ***imGetFollowCursor***

**Purpose:** When the display is in 80 x 25 mode, the viewport follows the cursor as it moves. The follow-the-cursor feature can be enabled or disabled. This function retrieves the current setting.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetFollowCursor%  
    (VARPTR(FolCursor%), VARSEG (FolCursor%))
```

**IN Parameters:** None.

**OUT Parameters:** The *FolCursor%* parameter is one of these constants:

|                  |                                    |
|------------------|------------------------------------|
| <i>imEnable</i>  | Follow-the-cursor mode is enabled  |
| <i>imDisable</i> | Follow-the-cursor mode is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** *imSetFollowCursor*, *imCursorToViewport*, *imViewportToCursor*

---

### ***Example***

```
'***** imGetFollowCursor *****'  
REM $INCLUDE: 'im20vbas.bi'  
  
status% = imGetFollowCursor(VARPTR(FollowCursor%), VARSEG(FollowCursor%))  
PRINT "Follow is ";followCursor%  
  
status% = imSetFollowCursor(imDisable)  
status% = imGetFollowCursor(VARPTR(FollowCursor%), VARSEG(FollowCursor%))  
PRINT "Follow is ";followCursor%  
  
status% = imSetFollowCursor(imEnable)  
status% = imGetFollowCursor(VARPTR(FollowCursor%), VARSEG(FollowCursor%))  
PRINT "Follow is ";FollowCursor%  
END
```

---

## *imGetInputMode*

**Purpose:** This function reports the current mode of the input manager. The different modes affect how the reader interprets and stores input.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetInputMode%()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** The mode returned by this function is one of these constants:

|              |                 |
|--------------|-----------------|
| imWedge      | Wedge mode      |
| imProgrammer | Programmer mode |
| imDesktop    | Desktop mode    |

**Notes:** There are three different reader input modes: Wedge, Programmer, and Desktop. These different modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label input goes into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. Use Wedge mode when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader's power management capabilities. You might notice reduced battery life when in this mode compared to being in either Programmer mode or Desktop mode. For more information on power management, see Chapter 3, "Advanced Programming," in the *JANUS PSK for C/C++ Reference Manual*.

**Programmer Mode** Keypad input is echoed to the screen and terminates when you press **Enter**. Reader commands are executed and saved. Use this mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in Programmer mode.

## *imGetInputMode – Visual Basic*

**Desktop Mode** The application is responsible for retrieving and displaying input. Keypad entry terminates when you press each key. Use this mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes of keyboard flags (**Shift, Ctrl, Alt**).

For more information about reader input modes, see Chapter 3, “Advanced Programming,” in the *JANUS PSK for C/C++ Reference Manual*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:**           imSetInputMode

---

### **Example**

```
'***** imGetInputMode *****  
' $INCLUDE: 'im20vbas.bi'  
  
CLS           ' Clear the screen  
PRINT "Setting imProgrammer"  
imSetInputMode(imProgrammer)  
inputMode% = imGetInputMode  
IF inputMode% = imProgrammer THEN  
    PRINT "Set to imProgrammer"  
ELSEIF inputMode% = imDesktop THEN  
    PRINT "Set to imDesktop"  
ELSEIF inputMode% = imWedge THEN  
    PRINT "Set to imWedge"  
ELSE  
    PRINT "Mode error"  
END IF  
imSetInputMode(imWedge)  
END
```

---

## imGetKeyclick

**Purpose:** You can configure the reader to emit a click each time a key is pressed. This function returns the current setting (enabled or disabled) of the keyclick.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imGetKeyclick%
    (VARPTR(KeyClick), VARSEG(KeyClick))
```

**IN Parameters:** None.

**OUT Parameters:** The *KeyClick* parameter is one of these constants:

|           |                      |
|-----------|----------------------|
| imEnable  | Keyclick is enabled  |
| imDisable | Keyclick is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imSetKeyclick

---

### Example

```
***** imGetKeyclick *****
REM $INCLUDE: 'im20vbas.bi'

status% = imSetKeyclick(imDisable)
PRINT "Disabling keyclick"
Status% = imGetKeyclick(VARPTR(ctrlKey%), VARSEG(ctrlKey%))
IF ctrlKey% = imEnable THEN
    PRINT "Keyclick enabled"
ELSE
    PRINT "Keyclick disabled"
END IF
INPUT "Test it>>",response$
PRINT response$
status% = imSetKeyclick(imEnable)
PRINT "Enabling keyclick"
INPUT "Test it>>",response$
END
```

---

## ***imGetLabelSymbology***

**Purpose:** This function gets the symbology, such as Code 39, from the most recently scanned label. Call this function after receiving the data using `imReceiveInput`.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetLabelSymbology%  
    (VARPTR(Symb), VARSEG(Symb))
```

**IN Parameters:** None.

**OUT Parameters:** The *Symb* parameter is one of these constants:

|                              |                        |
|------------------------------|------------------------|
| <code>imUnknownDecode</code> | Unknown bar code       |
| <code>imCODABAR</code>       | Codebar bar code       |
| <code>imCode11</code>        | Code 11 bar code       |
| <code>imCode16k</code>       | Code 16K bar code      |
| <code>imCode39</code>        | Code 39 bar code       |
| <code>imCode49</code>        | Code 93 bar code       |
| <code>imCode93</code>        | Code 49 bar code       |
| <code>imCode128</code>       | Code 128 bar code      |
| <code>imI2Of5</code>         | Interleaved 2 of 5     |
| <code>imMSI</code>           | MSI bar code           |
| <code>imPLESSEY</code>       | Plessey bar code       |
| <code>imUPC</code>           | Universal Product code |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imReceiveInput`

---

### ***Example***

See example for `imReceiveInput`.

---

## *imGetLength*

**Purpose:** This function returns the length of the string received from the designated source by the most recent `imReceiveInput` function.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetLength%(Source)
```

**IN Parameters:** The *Source* parameter is one of these constants:

|                               |                                             |
|-------------------------------|---------------------------------------------|
| <code>imLabelSelect</code>    | Label selected                              |
| <code>imKeyboardSelect</code> | Keypad selected                             |
| <code>imCom1Select</code>     | COM1 selected                               |
| <code>imCom2Select</code>     | COM2, scanner port selected (2010 and 2050) |
| <code>imCom4Select</code>     | COM4 selected (RF only)                     |

**OUT Parameters:** None.

**Return Value:** This function returns the length of the last input string read from the designated source.

**Notes:** For this function, all COM input is considered to be from the same source. For example, if you call `im_receive_input` with `imCom1Select` and again with `imCom4Select`, then a call to `im_get_length` with a source of `imCom1Select` returns the length of the message received from COM4 because that was the last message read from a communications port.

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imReceiveInput`

---

### *Example*

See example for `imReceiveInput`.

---

## ***imGetPostamble***

- Purpose:** This function retrieves the current postamble string and its length.
- Syntax:**
- ```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetPostamble%  
    (VARPTR(postString), VARSEG(postString)  
    VARPTR(Length), VARSEG(Length))
```
- IN Parameters:** None.
- OUT Parameters:** The *postString* parameter is the postamble string.  
  
The *Length* parameter is the length of the postamble string.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”
- Notes:** You can set the postamble with IC.EXE, with the imCommand function and \$+AE command, or by scanning a postamble. Refer to your JANUS user’s manual for more information on configuring a postamble.
- See Also:** imGetPreamble, imGetConfigInfo

---

### ***Example***

```
***** imGetPostamble *****  
REM $INCLUDE: 'im20vbas.bi'  
  
DIM outstr AS STRING *300  
  
outstr = STRING$(300, CHR$(0))  
  
PRINT "imGetPostamble example: "  
  
status% = imGetPostamble(VARPTR(outstr), VARSEG(outstr), VARPTR(count%) VARSEG(count%))  
  
PRINT "Postamble String: "; outstr  
PRINT "Postamble Length: "; count%  
PRINT "Status: "; HEX$(status%)  
END
```



---

## imGetPreamble

**Purpose:** This function retrieves the current preamble string and its length.

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imGetPreamble%
    (VARPTR(preambleStr), VARSEG(preambleStr)
    VARPTR(Length), VARSEG(Length))
```

**IN Parameters:** None.

**OUT Parameters:** The *preambleStr* parameter is the preamble string.

The *Length* parameter is the length of the preamble string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You can set the preamble with IC.EXE, with the imCommand function and \$+AE command, or by scanning a preamble. Refer to your JANUS user’s manual for more information on configuring a preamble.

**See Also:** imGetPostamble, imGetConfigInfo

---

### Example

```
***** imGetPreamble *****
REM $INCLUDE: 'im20vbas.bi'

DIM outstr AS STRING *300

outstr = STRING$(300, CHR$(0))

PRINT "imGetPreamble example: "

status% = imGetPreamble(VARPTR(outstr), VARSEG(outstr), VARPTR(count%),VARSEG(count%))

PRINT "Preamble String: "; outstr
PRINT "Preamble Length: "; count%
PRINT "Status: "; HEX$(status%)
END
```

---

## ***imGetViewportLock***

**Purpose:** This function retrieves the current setting of the viewport lock. When the display is in 80 x 25 mode, you can use the viewport in virtual display mode unless the currently running application program restricts it. The application program may require the viewport to be locked or unlocked.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetViewportLock%  
    (VARPTR(VpLock), VARSEG(VpLock))
```

**IN Parameters:** None.

**OUT Parameters:** The *VpLock* parameter is one of these constants:

imEnable	Viewport is locked
imDisable	Viewport is unlocked

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The display must be in 80 x 25 mode (see *imSetDisplayMode*) to use this function.

This function has no effect on the JANUS 2050.

When the viewport is “locked,” the viewport movement keys do not move the viewport. The viewport can still move if follow-the-cursor mode is enabled.

**See Also:** *imSetViewportLock*, *imSetDisplayMode*, *imGetDisplayMode*, *imGetFollowCursor*, *imSetFollowCursor*

---

**Example**

```
'***** imGetViewportLock *****  
REM $INCLUDE: 'im20vbas.bi'  
  
status% = imGetViewportLock(VARPTR(viewportLock%), VARSEG(viewportLock%))  
PRINT "Viewport is ";viewportLock%  
  
status% = imSetViewportLock(imDisable)  
status% = imGetViewportLock(VARPTR(viewportLock%), VARSEG(viewportLock%))  
PRINT "Viewport is ";viewportLock%  
  
status% = imSetViewportLock(imEnable)  
status% = imGetViewportLock(VARPTR(viewportLock%), VARSEG(viewportLock%))  
PRINT "Viewport is ";viewportLock%  
END
```

---

## ***imGetWarmBoot***

**Purpose:** This function retrieves the current setting of the warm boot status. You can enable or disable the **Ctrl-Alt-Del** warm boot key sequence. When disabled, pressing the **Ctrl-Alt-Del** key sequence does not reboot the reader.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imGetWarmBoot%  
    (VARPTR(WarmBoot), VARSEG(WarmBoot))
```

**IN Parameters:** None.

**OUT Parameters:** The *WarmBoot* parameter is one of these constants:

imEnable	<b>Ctrl-Alt-Del</b> warm boot is enabled
imDisable	<b>Ctrl-Alt-Del</b> warm boot is disabled

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** imSetWarmBoot

---

### ***Example***

```
***** imGetWarmBoot *****  
REM $INCLUDE: 'im20vbas.bi'  
  
status% = imSetWarmBoot(imDisable)  
PRINT "Disabling <BOOT>"  
status% = imGetWarmBoot(VARPTR(ctrlKey%), VARSEG(ctrlKey%))  
IF ctrlKey% = imEnable THEN  
    PRINT "<BOOT> enabled"  
ELSE  
    PRINT "<BOOT> disabled"  
END IF  
INPUT "Test it1>>",response$  
status% = imSetWarmBoot(imEnable)  
PRINT "Enabling <BOOT>"  
INPUT "Test it1>>",response$  
END
```

---

## ***imIncreaseContrast***

**Purpose:** This function increases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast, where 0 is very light, and 31 is very dark.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imIncreaseContrast%()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The 0 to 31 scale fine tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table compares the two scales.

This Value on Scale 0 to 7	Equates to This Value on Scale 0 to 31	Contrast Level
0	10	Very light
1	12	
2	14	
3	16	
4	18	
5	20	
6	22	Very dark
7	24	

This function has no effect on the JANUS 2050.

**See Also:** `imGetContrast`, `imDecreaseContrast`, `imSetContrast`

## *imIncreaseContrast – Visual Basic*

---

### **Example**

```
'***** imIncreaseContrast *****  
REM $INCLUDE: 'im20vbas.bi'  
  
    PRINT "imIncreaseContrast"  
    ' Call Intermec function  
    status% = imIncreaseContrast  
    ' Pause for keypad input  
    temp$ = INPUT$(1)  
  
    PRINT "imIncreaseContrast"  
    ' Call Intermec function  
    status% = imIncreaseContrast  
END
```

---

## ***imInputStatus***

**Purpose:** This function checks to see if any input buffers have data and returns the buffer identification.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imInputStatus%()
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** The buffers checked correspond to these constants:

<code>imNoSelect</code>	No input buffer selected
<code>imLabelSelect</code>	Label selected
<code>imKeyboardSelect</code>	Keypad selected
<code>imCom1Select</code>	COM1 selected
<code>imCom2Select</code>	COM2, scanner port selected (2010 and 2050)
<code>imCom4Select</code>	COM4 selected (RF only)
<code>imAllSelect</code>	All input buffers are selected

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imReceiveInput`

## *imInputStatus – Visual Basic*

---

### **Example**

```
'***** imInputStatus *****
REM $INCLUDE: 'im20vbas.bi'

DIM str AS STRING * 300
DIM buffer AS STRING * 300

status% = imLinkComm(imCom1, VARPTR(str),VARSEG(str), LEN(str))

WHILE temp$ <> "q"
  CLS
  str = STRING$(300, CHR$(0))
  inputstat% = 0
  statbreak$ = ""

  PRINT "Getting Input Stat"
  WHILE inputstat% = 0 AND statbreak$ <> "q"
    statbreak$ = INKEY$
    inputstat% = imInputStatus
  WEND
  PRINT "Input status: "; inputstat%
  PRINT
  PRINT "Getting Data"

  status% = imReceiveInput(inputstat%, 20000, source%, VARPTR(buffer))

  PRINT "Receive status: "; HEX$(status%)
  PRINT "Source Input: "; source%
  PRINT "Output is: "
  PRINT buffer
  PRINT
  PRINT "press q to quit"
  temp$ = INPUT$(1)
WEND

status% = imUnlinkComm(imCom1)
END
```



---

## ***imIrlA***

**Purpose:** This function receives input from bar code labels or the keypad in the same manner as the IRL ASCII input command A. This function returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command A, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION ImIrlA%
    (Timeout,
     VARPTR(TestTable), VARSEG(TestTable),
     SSEGADD(MaskString),
     VARPTR(InString), VARSEG(InString),
     VARPTR(CmdCount), VARSEG(CmdCount)
     VARPTR(Symb), VARSEG(Symb))
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is an integer or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you use imInfiniteTimeout, the function does not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *TestTable*. The *TestTable* parameter must be a matrix of the following form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

*imlrlA – Visual Basic*

*{a, b, c, d}*,

The *a* position in the matrix is one of the following:

<i>imNoLength</i>	Accept data of any length
<i>imLength</i>	Accept data with a specific length
<i>imRange</i>	Accept data within a length range

If *imLength* is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If *imRange* is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to *{imNoLength,0,0,0}*.

The *MaskString* parameter sets up a data mask that received data must match. *MaskString* accepts a string of constants or wildcard characters. For example, use the string *### - ####* to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

#	Numeric
@	Alpha
?	Alphanumeric printable
NULL (CHR\$(0))	No mask

**OUT Parameters:** The *InString* parameter is the input string. You must allocate at least 256 bytes for *InString*.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

The *Symb* parameter is one of these constants:

imUnknownDecode	Unknown bar code
imCODABAR	Codebar bar code
imCode11	Code 11 bar code
imCode16k	Code 16K bar code
imCode39	Code 39 bar code
imCode49	Code 93 bar code
imCode93	Code 49 bar code
imCode128	Code 128 bar code
imI2Of5	Interleaved 2 of 5
imMSI	MSI bar code
imPLESSEY	Plessey bar code
imUPC	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with `imSetInputMode`.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlK`, `imIrlN`, `imIrlV`, `imIrlY`, `imSetDisplayMode`, `imSetInputMode`

## *imIrlA – Visual Basic*

---

### **Example**

```
'***** imIrlA *****
' $INCLUDE: 'im20vbas.bi'

DIM LengthTable(imNumIrlLengths) AS imLengthSpec

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS          ' Clear the screen

    imSetInputMode(imProgrammer)

    Timeout = 10000      ' Set timeout to 10 seconds

    ' The data mask takes precedence over other options.
    ' If no data mask is wanted, just set it to CHR$(0)
    ' This example would be for a Social Security number

    ' DataMask$ = "###-##-####" + CHR$(0) ' Null terminate string
    DataMask$ = CHR$(0)          ' No data mask

    ' This example shows how to set 3 lengths and 1 range. Input would
    ' need to be of length 3, 5, 7, or 11 through 15 characters.

    LengthTable(1).entry = imLength
    LengthTable(1).min   = 0
    LengthTable(1).max   = 0
    LengthTable(1).match = 3

    LengthTable(2).entry = imLength
    LengthTable(2).min   = 0
    LengthTable(2).max   = 0
    LengthTable(2).match = 5

    LengthTable(3).entry = imLength
    LengthTable(3).min   = 0
    LengthTable(3).max   = 0
    LengthTable(3).match = 7

    LengthTable(4).entry = imRange
    LengthTable(4).min   = 11
    LengthTable(4).max   = 15
    LengthTable(4).match = 0

    LengthTable(5).entry = imNoLength      ' Just a placeholder
    LengthTable(5).min   = 0
    LengthTable(5).max   = 0
    LengthTable(5).match = 0

    ' This table would be used if the user wanted to enter data of any length.
    '
    ' LengthTable(1).entry = imNoLength
    ' LengthTable(1).min   = 0
    ' LengthTable(1).max   = 0
    ' LengthTable(1).match = 0
    '
    ' LengthTable(2).entry = imNoLength
    ' LengthTable(2).min   = 0
    ' LengthTable(2).max   = 0
    ' LengthTable(2).match = 0
```

```
' LengthTable(3).entry = imNoLength
' LengthTable(3).min = 0
' LengthTable(3).max = 0
' LengthTable(3).match = 0
'
' LengthTable(4).entry = imNoLength
' LengthTable(4).min = 0
' LengthTable(4).max = 0
' LengthTable(4).match = 0
'
' LengthTable(5).entry = imNoLength
' LengthTable(5).min = 0
' LengthTable(5).max = 0
' LengthTable(5).match = 0

PRINT "Input>>";

status% = imIrlA(TimeOut,
  (VARPTR(LengthTable(1).entry), VARSEG(LengthTable(1).entry), SSEGADD(DataMask$),
  VARPTR(inString), VARSEG(inString), VARPTR(cmdCount%), VARSEG(cmdCount%),
  VARPTR(Symbology%) VARSEG(Symbology%))

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value returned in this example would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
  charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>" ; LEFT$(inString, charCounter%)

imSetInputMode(imWedge)
END
```

---

## ***imIrlK***

**Purpose:** This function receives input from the keypad in any format in the same manner as the IRL ASCII input command K. This function returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command K, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION ImIrlK%  
    (Timeout,  
     VARPTR(TestTable), VARSEG(TestTable),  
     MaskString,  
     VARPTR(InString), VARSEG(InString),  
     VARPTR(CmdCount), VARSEG(CmdCount))
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *TestTable*. The *TestTable* parameter must be a matrix of the following form:

```
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},
```

The *a* position in the matrix is one of the following:

imNoLength	Accept data of any length
imLength	Accept data of a specific length
imRange	Accept data within a length range

If *imLength* is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If *imRange* is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {imNoLength,0,0,0}.

The *MaskString* parameter sets up a data mask that received data must match. *MaskString* can accept a string of constants or wildcard characters. For example, use the string ### - ##### to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

#	Numeric
@	Alpha
?	Alphanumeric printable
NULL (CHR\$(0))	No mask

**OUT Parameters:** The *InString* parameter is the input string. You must allocate at least 256 bytes for *InString*.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with *imSetInputMode*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

## *imIrlK – Visual Basic*

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlN`, `imIrlV`, `imIrlY`, `imSetDisplayMode`, `imSetInputMode`

---

### **Example**

```
'***** imIrlK *****
' $INCLUDE: 'im20vbas.bi'

DIM LengthTable(imNumIrlLengths) AS imLengthSpec

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS          ' Clear the screen

    imSetInputMode(imProgrammer)

    Timeout = 10000      ' Set timeout to 10 seconds

    ' The data mask takes precedence over other options.
    ' If no data mask is wanted, just set it to CHR$(0)
    ' This example would be for a Social Security number

    ' DataMask$ = "###-##-####" + CHR$(0) ' Null terminate string
    DataMask$ = CHR$(0)                ' No data mask

    ' This example shows how to set 3 lengths and 1 range. Input would
    ' need to be of length 3, 5, 7, or 11 through 15 characters.

    LengthTable(1).entry = imLength
    LengthTable(1).min   = 0
    LengthTable(1).max   = 0
    LengthTable(1).match = 3

    LengthTable(2).entry = imLength
    LengthTable(2).min   = 0
    LengthTable(2).max   = 0
    LengthTable(2).match = 5

    LengthTable(3).entry = imLength
    LengthTable(3).min   = 0
    LengthTable(3).max   = 0
    LengthTable(3).match = 7

    LengthTable(4).entry = imRange
    LengthTable(4).min   = 11
    LengthTable(4).max   = 15
    LengthTable(4).match = 0

    LengthTable(5).entry = imNoLength      ' Just a placeholder
    LengthTable(5).min   = 0
    LengthTable(5).max   = 0
    LengthTable(5).match = 0
```



```
PRINT "Input>>";

status% = (TimeOut,
           (VARPTR(LengthTable(1).entry), VARSEG(LengthTable(1).entry), SSEGADD(DataMask$),
           VARPTR(inString), VARSEG(inString), VARPTR(cmdCount%),VARSEG(cmdCount%))

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>" ;LEFT$(inString,charCounter%)

imSetInputMode(imWedge)
END
```

---

## ***imIrlN***

**Purpose:** The *imIrlN* function receives numeric input from the keypad or a label in the same manner as the IRL numeric input command N. Nonnumeric data is ignored.

This function clears any data that might be in the keyboard or label buffers before the function was called, edits reader commands from input, and displays input data. For more information on IRL and command N, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION ImIrlN%  
    (Timeout,  
    VARPTR(TestTable), VARSEG(TestTable),  
    VARPTR(InString), VARSEG(InString),  
    VARPTR(CmdCount), VARSEG(CmdCount)  
    VARPTR(Symb), VARSEG(Symb))
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
<i>imZeroTimeout</i>	No wait
<i>imInfiniteTimeout</i>	Wait forever

If *imInfiniteTimeout* is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *TestTable*. The *TestTable* parameter must be a matrix of the following form:

```
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},  
{a, b, c, d},
```

The *a* position in the matrix is one of the following:

imNoLength	Accept data of any length
imLength	Accept data of a specific length
imRange	Accept data within a length range

If *imLength* is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If *imRange* is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Any unused table entries must be set to {imNoLength,0,0,0}.

**OUT Parameters:** The *InString* parameter is the input string. You must allocate at least 256 bytes for *InString*.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

*imIrlN – Visual Basic*

The *Symb* parameter is one of these constants:

imUnknownDecode	Unknown bar code
imCODABAR	Codebar bar code
imCode11	Code 11 bar code
imCode16k	Code 16K bar code
imCode39	Code 39 bar code
imCode49	Code 93 bar code
imCode93	Code 49 bar code
imCode128	Code 128 bar code
imI2Of5	Interleaved 2 of 5
imMSI	MSI bar code
imPLESSEY	Plessey bar code
imUPC	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with `imSetInputMode`.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlK`, `imIrlV`, `imIrlY`, `imSetInputMode`

---

**Example**

```
***** imIrlN *****
' $INCLUDE: 'im20vbas.bi'

DIM LengthTable(imNumIrlLengths) AS imLengthSpec

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS          ' Clear the screen

    imSetInputMode(imProgrammer)

    Timeout = 10000      ' Set timeout to 10 seconds

' This example shows how to set 3 lengths and 1 range.  Input would
' need to be of length 3, 5, 7, or 11 through 15 characters.

    LengthTable(1).entry = imLength
    LengthTable(1).min   = 0
    LengthTable(1).max   = 0
    LengthTable(1).match = 3

    LengthTable(2).entry = imLength
    LengthTable(2).min   = 0
    LengthTable(2).max   = 0
    LengthTable(2).match = 5

    LengthTable(3).entry = imLength
    LengthTable(3).min   = 0
    LengthTable(3).max   = 0
    LengthTable(3).match = 7

    LengthTable(4).entry = imRange
    LengthTable(4).min   = 11
    LengthTable(4).max   = 15
    LengthTable(4).match = 0

    LengthTable(5).entry = imNoLength      ' Just a placeholder
    LengthTable(5).min   = 0
    LengthTable(5).max   = 0
    LengthTable(5).match = 0

' This table would be used if the user wanted to enter data of any length.
'
' LengthTable(1).entry = imNoLength
' LengthTable(1).min   = 0
' LengthTable(1).max   = 0
' LengthTable(1).match = 0
'
' LengthTable(2).entry = imNoLength
' LengthTable(2).min   = 0
' LengthTable(2).max   = 0
' LengthTable(2).match = 0
'
' LengthTable(3).entry = imNoLength
' LengthTable(3).min   = 0
' LengthTable(3).max   = 0
' LengthTable(3).match = 0
'
```

### *imIrlN – Visual Basic*

```
' LengthTable(4).entry = imNoLength
' LengthTable(4).min = 0
' LengthTable(4).max = 0
' LengthTable(4).match = 0
'
' LengthTable(5).entry = imNoLength
' LengthTable(5).min = 0
' LengthTable(5).max = 0
' LengthTable(5).match = 0

PRINT "Input>>";

status% = imIrlN(Timeout,
    (VARPTR(LengthTable(1).entry), VARSEG(LengthTable(1).entry),
    VARPTR(inString), VARSEG(inString), VARPTR(cmdCount%), VARSEG(cmdCount%),
    VARPTR(Symbology%) VARSEG(Symbology%))

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>" ; LEFT$(inString, charCounter%)

imSetInputMode(imWedge)
END
```

---

## ***imIrlV***

**Purpose:** This function receives input from any specified source in the same manner as the IRL universal input command V. For more information on IRL and command V, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION ImIrlV%
    (Timeout, Edit, Beeper, Display,
    VARPTR(Source), VARSEG(Source),
    VARPTR(InString), VARSEG(InString),
    VARPTR(CmdCount), VARSEG(CmdCount),
    VARPTR(Symb), VARSEG(Symb))
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If *imInfiniteTimeout* is selected, the function will not return until the end of message character has been received.

If *imInfiniteTimeout* is selected, the function will not return until the end of message character has been received.

The *Edit* parameter determines whether the Reader Wedge parses reader commands. Use one of these constants:

imDisable	Disable reader command parsing
imEnable	Enable reader command parsing

If *Edit* is *imDisabled*, reader commands are treated as data.

*imIrlV – Visual Basic*

The *Beeper* parameter determines whether the IRL V command beeps or not when data is entered. Use one of these constants:

imAppliBeep	Application controls the beep
imWedgeBeep	Beeps each time data is entered

The *Display* parameter determines if the data is displayed when it is entered. Use one of these constants:

imDisable	Disable display of data
imEnable	Enable display of data

**IN/OUT  
Parameters:**

The *Source* parameter determines which input sources are allowed. When the IRL V command returns, *Source* indicates where the data came from. When both keypad and label inputs are allowed, the *Source* always returns keypad because it is possible for keyed and scanned data to be intermixed (not likely, but possible).

If you have both the keypad and scanner enabled, and you want to know where the data came from, first check the symbology:

- If the symbology is imUnknownDecode, then the data is from the keypad.
- If the symbology is one of the other values (such as imCode39), then some or all of the data came from the scanner.

The *Source* parameter is one of these constants:

imNoSelect	No source
imLabelSelect	Label
imKeyboardSelect	Keypad
imCom1Select	COM1
imCom2Select	COM2, scanner port selected (2010 and 2050)
imCom4Select	COM4 (RF only)
imAllSelect	All sources are designated

**OUT Parameters:** The *InString* parameter is the input string. You must allocate at least 256 bytes for *InString*.

The *CmdCount* is 0 unless an abort command is passed in the string.



The *Symb* parameter is one of these constants:

imUnknownDecode	Unknown bar code
imCODABAR	Codebar bar code
imCode11	Code 11 bar code
imCode16k	Code 16K bar code
imCode39	Code 39 bar code
imCode49	Code 93 bar code
imCode93	Code 49 bar code
imCode128	Code 128 bar code
imI2Of5	Interleaved 2 of 5
imMSI	MSI bar code
imPLESSEY	Plessey bar code
imUPC	Universal Product code

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with `imSetInputMode`.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

To receive data from a communications port, you must install a protocol handler.

Use the `imLinkComm` function to establish a link between the Reader Wedge and a communications port, and use the `imUnlinkComm` function to remove the link.

Data is automatically cleared from both the scanner and the keypad buffers but not from any communications port buffer.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlK`, `imIrlN`, `imIrlY`, `imSetInputMode`

## *imIrlV – Visual Basic*

---

### **Example**

```
'***** imIrlV *****
' $INCLUDE: 'im20vbas.bi'

CONST bufsize = 300
DIM inString AS STRING * bufsize

CLS                                ' Clear the screen

imSetInputMode(imProgrammer)

TimeOut = 10000                    ' Set timeout to 10 seconds

source% = imKeyboardSelect + imLabelSelect

editMode = imEnable                ' Edit for reader commands

beepMode = imWedgeBeep            ' Wedge does the beeping

dispMode = imEnable                ' Display the input as it is entered

PRINT "Input>>";

status% = imIrlV(TimeOut, editMode beepMode, dispMode,
    VARPTR(source), VARSEG(source%), VARPTR(inString), VARSEG(inString),
    VARPTR(cmdCount%), VARSEG(cmdCount%), VARPTR(Symbology%), VARSEG(Symbology%))

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but since
' this is a fixed-length string, the value returned in this example would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
    charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1

PRINT
PRINT "Recvd>>";LEFT$(inString,charCounter%)

IF Symbology% > imUnknownDecode THEN
    PRINT "From Label"
    IF Symbology% = imCode39 THEN
        PRINT "Code 39"
    ELSE
        PRINT "Another symbology"
    END IF
ELSEIF source% = imKeyboardSelect THEN
    PRINT "From Keypad"
ELSEIF source% = imCom1Select THEN
    PRINT "From Com 1"
ELSEIF source% = imCom4Select THEN
    PRINT "From Com 4"
ELSE
    PRINT "Unknown Source"
END IF

imSetInputMode(imWedge)
END
```

---

## ***imIrlY***

**Purpose:** This function receives input from a designated communications port. in the same manner as the IRL ASCII input command Y.

This function receives a single block, not an entire file. This function always clears input from the host and edits reader commands from input. Unlike the other IRL instructions, the data is not automatically displayed. For more information on IRL and command Y, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imIrlY%
    (Timeout, PortID, SSEGADD(EomChar$), Protocol,
    VARPTR(InString$), VARSEG(InString$)
    VARPTR(CmdCount), VARSEG(CmdCount))
```

**IN Parameters:** The *Timeout* parameter is the receive input timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *EomChar* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

The *Protocol* parameter is one of these constants:

<code>imNoChange</code>	Keep the current protocol
<code>imProtocolOff</code>	Turn the protocol OFF
<code>imProtocolOn</code>	Turn the protocol ON
<code>imNewTermChar</code>	Use the new termination character

The *Protocol* parameter affects how incoming messages are received:

- If `imNoChange` is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If `imProtocolOff` is specified, the incoming data is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.
- If `imProtocolOn` is specified, the incoming message is terminated with the end of message character of the active protocol.
- If `imNewTermChar` is specified, `imProtocolOff` is assumed and the new end of message character specified in the parameter list is used.

**OUT Parameters:** The *InString* parameter is the input string. You must allocate at least 256 bytes for *InString*.

The *CmdCount* returned is 0 unless an abort command is passed in the string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with `imSetInputMode`.

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

You must install a protocol handler to use this function.

The receive buffers are cleared whenever the protocol is turned ON or OFF. To change the termination character (or to not change the setting at all), use `imNewTermChar` or `imNoChange` instead of toggling the protocol.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `imSetDisplayMode`.

**See Also:** `imIrlA`, `imIrlK`, `imIrlN`, `imIrlV`, `imSetDisplayMode`, `imSetInputMode`

---

### Example

```

'***** imIrlY *****
' $INCLUDE: 'im20vbas.bi'

CONST bufsize = 300
DIM inString AS STRING * bufsize
DIM comString AS STRING * bufsize

CLS          ' Clear the screen
imSetInputMode(imProgrammer)
ImLinkCom% = imLinkComm(imCom1, VARPTR(comString), VARSEG(comString), LEN(str))
Timeout = 10000      ' Set timeout to 10 seconds

' eomChar$ = CHR$(0) ' No termination character
eomChar$ = CHR$(13) ' Termination character is CR

PRINT "Send Data>>";

' status% = imIrlY(Timeout, imCom1, SSEGADD(eomChar$), imProtocolOn,
  VARPTR(inString), , VARSEG(inString),
  VARPTR(cmdCount%), VARSEG(cmdCount%))
status% = imIrlY(Timeout, imCom1, SSEGADD(eomChar$), imProtocolOff,
  VARPTR(inString), , VARSEG(inString),
  VARPTR(cmdCount%), VARSEG(cmdCount%))

' This will get the length of the returned string by looking for the first
' null. Doing a LEN function will return the length of the string, but
' since this is a fixed-length string, the value that would be returned
' (in this example) would be 300.

charCounter% = 1

WHILE MID$(inString, charCounter%, 1) > CHR$(0)
  charCounter% = charCounter% + 1
WEND

charCounter% = charCounter% - 1
PRINT
PRINT "Recvd>>";LEFT$(inString, charCounter%)


ImLinkCom% = imUnlinkComm(imCom1)
imSetInputMode(imWedge)
END

```

## imLinkComm

**Purpose:** This function establishes a link between the Reader Wedge function and a designated communications port. The following figure lists the different modes and the functions to use when linked or unlinked.

### Linking Specific Modes and Functions



AIT-43

**Syntax:**

```

REM $INCLUDE: 'im20vbas.bi'
FUNCTION ImLinkComm%
    (PortID,
    VARPTR(Buffer), VARSEG(Buffer),
    BufferSize)
    
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1 COM1  
imCom2 COM2, scanner port (2010 and 2050)  
imCom4 COM4 (RF only)

The *Buffer* parameter is a pointer to a memory area used by the Reader Wedge. Your application should not use this buffer.

The *BufferSize* parameter is the number of bytes to allocate for the buffer array (suggested size is 300 bytes).

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Use this function if you want to receive data with the Reader Wedge input function imIrlY or use the communications port with imReceiveInput and imIrlV.

This function needs to be called only once.

You must unlink at the end of your application.

You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** imUnlinkComm, imReceiveInput, imIrlV, imIrlY

---

### Example

See example for imReceiveInput, imIrlY, and imSerialProtocolControl.

---

## ***imMessage***

**Purpose:** This function displays the error message associated with a specific status code returned by an Intermec function. These status codes are listed in Appendix A.

Use this function to display additional information about status codes during application development.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imMessage%(*StatusCode* )

**IN Parameters:** The *StatusCode* parameter is a standard status code returned from various PSK functions.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** The status message is displayed at the current cursor location without any formatting.

---

### ***Example***

```
'***** imMessage *****'  
' $INCLUDE: 'im20vbas.bi'  
  
CLS          ' Clear the screen  
str1$ = "$+DJ3"  
PRINT "Set normal contrast"  
status% = imCommand(SSEGADD(str1$), LEN(str1$))  
PRINT "Command status >>" ; HEX$(status%)  
          imMessage(status%)  
END
```



---

## ***imNumberPadOff***

**Purpose:** This function disables the number pad feature. When the number pad is disabled, the numeric keys function the same as the 1 through + keys above the “QWERTY” keys on a normal PC keyboard.

When the number pad is disabled, you cannot type characters from the extended ASCII character set or use the number pad to move the cursor. For more information, refer to your JANUS user’s manual.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
FUNCTION imNumberPadOff%()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** imNumberPadOn

---

### ***Example***

```
'***** imNumberPadOff *****'  
REM $INCLUDE: 'im20vbas.bi'  
  
' Initializing Variables  
NumberPadTest$ = ""  
Temp$ = ""  
CLS  
  
status% = imNumberPadOff  
  
PRINT  
PRINT "Test number pad off"  
PRINT "<ENTER> when done: "  
INPUT NumberPadTest$  
PRINT  
PRINT "Press any key to quit."  
INPUT Temp$  
END
```

---

## ***imNumberPadOn***

**Purpose:** This function enables the reader's number pad. When enabled, the number pad functions the same way as the 10-key number pad on a standard PC keyboard. The numeric keys then provide cursor movement and editing keys, numbers, and access to the extended ASCII character set.

When you enable the number pad, you also turn the **Num Lock** key off or on. When **Num Lock** is on, the number pad keys produce only numbers or extended ASCII characters with the same scan codes as the numeric keypad on a PC. The numeric keys always generate the same ASCII characters for numbers, but the scan codes depend on the status of the number pad and **Num Lock**.

When **Num Lock** is off, the number pad keys move the cursor (**Home**) or edit text (**Del**). Refer to your JANUS user's manual for more information on the number pad.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imNumberPadOn%(NumLock)
```

**IN Parameters:** The *NumLock* parameter indicates whether the **Num Lock** key is ON or OFF. Use one of these constants:

<code>imNumlockOn</code>	Enable the number pad with Num Lock ON
<code>imNumlockOff</code>	Disable the number pad with Num Lock OFF

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** `imNumberPadOff`

---

**Example**

```
'***** imNumberPadOn *****
REM $INCLUDE: 'im20vbas.bi'

' Initializing Variables
NumberPadTest$ = ""
Temp$ = ""
CLS

status% = imNumberPadOn(imNumlockOff)
PRINT "numpad enable NL OFF"
PRINT "<ENTER> when done: "
INPUT NumberPadTest$
PRINT

status% = imNumberPadOn(imNumlockOn)
PRINT
PRINT "numpd enable NL ON"
PRINT "<ENTER> when done: "
INPUT NumberPadTest$
PRINT

PRINT "Press any key to quit."
INPUT Temp$
END
```

---

## ***imPowerStatus***

**Purpose:** This function returns the line status, battery status, backup status, and percentage of remaining battery life.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imPowerStatus%  
    (VARPTR(LineStatus), VARSEG(LineStatus)  
    VARPTR(BatteryStatus), VARSEG(BatteryStatus)  
    VARPTR(BackupStatus), VARSEG(BackupStatus)  
    VARPTR(FuelGauge), VARSEG(FuelGauge))
```

**IN Parameters:** None.

**OUT Parameters:** The *LineStatus* parameter returns one of these constants:

<code>imAclineNotConnected</code>	AC line is not connected
<code>imAclineConnected</code>	AC line is connected
<code>imUnknownAcline</code>	AC line status is unknown

The *BatteryStatus* parameter returns one of these constants:

<code>imHighBat</code>	Battery charge is high
<code>imLowBat</code>	Battery charge is low
<code>imCriticalBat</code>	Battery charge is critical
<code>imChargingBat</code>	Battery is charging now
<code>imUnknownBat</code>	Battery condition is unknown

The *BackupStatus* parameter returns one of these constants:

<code>imBackupOk</code>	Backup battery is OK
<code>imBackupLow</code>	Backup battery is low

The *FuelGauge* parameter returns one of these constants:

0–100	% of full charge in increments of 10%
255	Unknown

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

---

**Example**

```
'***** imPowerStatus *****'  
REM $INCLUDE: 'im20vbas.bi'  
  
PRINT "imPowerStatus"  
  
acLine% = -1  
battery% = -1  
backup% = -1  
fuel% = -1  
status% = -1  
  
status% = imPowerStatus(VARPTR(acLine%), VARSEG(acLine%),  
    VARPTR(battery%), VARSEG(battery%), VARPTR(backup%), VARSEG(backup%),  
    VARPTR(fuel%), VARSEG(fuel%))  
  
PRINT "ACLine = ", HEX$(acLine%)  
PRINT "battery = ", HEX$(battery%)  
PRINT "backup = ", HEX$(backup%)  
PRINT "fuel = ", HEX$(fuel%)  
PRINT "status = ", HEX$(status%)  
END
```

---

## ***imProtocolExtendedStatus***

**Purpose:** This function gets the protocol extended status from the designated communications port. You allocate the protocol status buffer or radio frequency (RF) status buffer, and then `imProtocolExtendedStatus` returns the status and setup in hexadecimal values.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imProtocolExtendedStatus%  
    ( PortID ,  
      VARPTR(StatusBuffer) , VARSEG(StatusBuffer))
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *StatusBuffer* parameter is a far pointer to a buffer structure. Use one of these constants:

```
imCommStatusBufferS (as shown in the syntax above)  
imCommStatusBufferRF
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imReceiveBufferNoWait`, `imTransmitBufferNoWait`

**Example**

```

'***** imProtocolExtendedStatus *****
REM $INCLUDE: 'im20vbas.bi'

'Extend status protocol buffer
DIM statusBuffer AS imCommStatusBufferS

'Initialize status buffer

' Note: Must assign StatusStrVersion as below to return proper
' status
statusBuffer.StatusStructureVersion = CHR$(StatusStrVersion)
statusBuffer.HandlerVer = STRING$(LEN(statusBuffer.HandlerVer), CHR$(0))
statusBuffer.HandlerType = 0
statusBuffer.Specific.BaudRate = 0
statusBuffer.Specific.Parity = CHR$(0)
statusBuffer.Specific.StopBits = CHR$(0)
statusBuffer.Specific.DataBits = CHR$(0)
statusBuffer.Specific.ModemStatus = CHR$(0)
statusBuffer.Specific.PortStatus = CHR$(0)
statusBuffer.Specific.ActiveProt = 0
statusBuffer.Specific.LrcEnabled = CHR$(0)
statusBuffer.Specific.IntercharDelay = 0
statusBuffer.Specific.TurnaroundDelay = 0
statusBuffer.Specific.ReceiveTimeout = 0
statusBuffer.Specific.TransmitTimeout = 0
statusBuffer.Specific.PolChar = CHR$(0)
statusBuffer.Specific.SelChar = CHR$(0)
statusBuffer.Specific.ResChar = CHR$(0)
statusBuffer.Specific.regChar = CHR$(0)
statusBuffer.Specific.affChar = CHR$(0)
statusBuffer.Specific.negChar = CHR$(0)
statusBuffer.Specific.somChar = CHR$(0)
statusBuffer.Specific.txeomLen = CHR$(0)
statusBuffer.Specific.txeomChar1 = CHR$(0)
statusBuffer.Specific.txeomChar2 = CHR$(0)
statusBuffer.Specific.rxeomLen = CHR$(0)
statusBuffer.Specific.rxeomChar1 = CHR$(0)
statusBuffer.Specific.rxeomChar2 = CHR$(0)
statusBuffer.Specific.flowCtrl = CHR$(0)
statusBuffer.Specific.MultiDropAddr = CHR$(0)
statusBuffer.Specific.MultiDropEnabled = CHR$(0)
statusBuffer.Specific.EofLength = 0
statusBuffer.Specific.EofChar = CHR$(0)
statusBuffer.Specific.HaveRecvClientBuffer = 0
statusBuffer.Specific.HaveXmitClientBuffer = 0
statusBuffer.Specific.ProtocolMode = 0

' Call Intermec routine
status% = imProtocolExtendedStatus(ImCom1, VARPTR(statusBuffer), VARSEG(statusBuffer))

' Function call return status
PRINT "Extd Prot Stat"
PRINT HEX$(status%)

temp$ = INPUT$(1)
CLS
LOCATE 1,1

' Print first page of status info
PRINT "Extd Status,Pglof3"
PRINT "Strut Ver = ", ASC(statusBuffer.StatusStructureVersion)

```

### *imProtocolExtendedStatus – Visual Basic*

```
PRINT "Hd Ver = ", statusBuffer.HandlerVer
PRINT "Hd Type = ", statusBuffer.HandlerType
PRINT "Baud = ", statusBuffer.Specific.BaudRate
PRINT "Parity = ", ASC(statusBuffer.Specific.Parity)
PRINT "Stop = ", ASC(statusBuffer.Specific.StopBits)
PRINT "Data = ", ASC(statusBuffer.Specific.DataBits)
PRINT "Modem = ", ASC(statusBuffer.Specific.ModemStatus)
PRINT "Port stat = ", ASC(statusBuffer.Specific.PortStatus)
PRINT "Ate prot = ", statusBuffer.Specific.ActiveProt
PRINT "Lrc enble = ", ASC(statusBuffer.Specific.LrcEnabled)
PRINT "Itc dely = ", statusBuffer.Specific.IntercharDelay
PRINT "Trnd dely = ", statusBuffer.Specific.TurnaroundDelay
PRINT "RX tmeout = ", statusBuffer.Specific.ReceiveTimeout
PRINT "Xt tmeout = ", statusBuffer.Specific.TransmitTimeout

' Pause between screens
PRINT "Any key to cont"
temp$ = INPUT$(1)
CLS
LOCATE 1,1

PRINT "Extd Status,Pg2of3"
' Print third page of status info
PRINT "Pol char = ", ASC(statusBuffer.Specific.PolChar)
PRINT "Sel char = ", ASC(statusBuffer.Specific.SelChar)
PRINT "Res char = ", ASC(statusBuffer.Specific.ResChar)
PRINT "Req char = ", ASC(statusBuffer.Specific.reqChar)
PRINT "Aff char = ", ASC(statusBuffer.Specific.affChar)
PRINT "Neg char = ", ASC(statusBuffer.Specific.negChar)
PRINT "Som char = ", ASC(statusBuffer.Specific.somChar)
PRINT "Tx len = ", ASC(statusBuffer.Specific.txcomLen)
PRINT "Txchar 1 = ", ASC(statusBuffer.Specific.txcomChar1)
PRINT "Txchar 2 = ", ASC(statusBuffer.Specific.txcomChar2)
PRINT "Rxlen = ", ASC(statusBuffer.Specific.rxcomLen)
PRINT "Rxchar 1 = ", ASC(statusBuffer.Specific.rxcomChar1)
PRINT "Rx char 2 = ", ASC(statusBuffer.Specific.rxcomChar2)
PRINT "Flow ctrl = ", ASC(statusBuffer.Specific.flowCtrl)

' Pause between screens
PRINT "Any key to cont"
temp$ = INPUT$(1)

CLS
LOCATE 1,1

PRINT "Extd Status,Pg3of3"
' Print second page of status info
PRINT "Mul addr = ", ASC(statusBuffer.Specific.MultiDropAddr)
PRINT "Mul enble = ", ASC(statusBuffer.Specific.MultiDropEnabled)
PRINT "EOF len = ", statusBuffer.Specific.EofLength
PRINT "EOF char = ", ASC(statusBuffer.Specific.EofChar)
PRINT "Recv clt = ", statusBuffer.Specific.HaveRecvClientBuffer
PRINT "Xmit clt = ", statusBuffer.Specific.HaveXmitClientBuffer
PRINT "Prot mode = ", statusBuffer.Specific.ProtocolMode
END
```



---

## *imReceiveBuffer*

**Purpose:** This function receives the contents of a data buffer from a designated communications port.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imReceiveBuffer%
    (PortID,
     UserLength,
     VARPTR(DataBuffer), VARSEG(DataBuffer)
     Timeout,
     VARPTR(CommLength), VARSEG(CommLength))
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1
imCom2    COM2, scanner port (2010 and 2050)
imCom4    COM4 (RF only)
```

The *UserLength* parameter is the maximum number of bytes to receive and must be at least 256 bytes.

The *DataBuffer* parameter is a far pointer to the array where you want to place the received data. This buffer must hold at least 256 bytes.

The *Timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

```
0 to 32,767 ms      Integer range
32,768 to 65,534 ms See "Setting Timeout Values" in this chapter.
imZeroTimeout      No wait
imInfiniteTimeout  Wait forever
```

If you select *imInfiniteTimeout*, the function will not return until the end of message character has been received.

## *imReceiveBuffer – Visual Basic*

**OUT Parameters:** The *CommLength* is the actual number of bytes received upon completion of the call.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function does not return a parameter value until an end of message, a buffer is full, a timeout, or an error occurs.

You must install a protocol handler to use this function.

**See Also:** `imReceiveBufferNoWait`, `imReceiveBufferNoprot`, `imCancelRxBuffer`, `imRxCheckStatus`

---

### *Example*

```
***** imReceiveBuffer *****
' Note: You must have reader services and a communication protocol handler installed
' to enable send/receive buffer functions.
' Run these TSR's at DOS prompt before running these tests:
'   rservice
'   PHIMEC 1 ( 1 is COM1)

REM $INCLUDE: 'im20vbas.bi'

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str1 AS STRING * bufsize

' Actual length returned by imReceiveBuffer
DIM commLength

' Must be run with Phimec protocol installed
PRINT "imReceiveBuffer"
PRINT "Phimec protocol"
PRINT "Default - 9600 E 7 1"
' Quit with <CR><LF> sequence
PRINT "Ctrl JM to quit"
PRINT "(<CR><LF>)"

' Init the string
str1 = STRING$(bufsize, CHR$(0))

' Call Intermec function
status% = imReceiveBuffer(imCom1, LEN(str1), VARPTR(str1), VARSEG(str1), 10000,
    VARPTR(commLength), VARSEG(commLength))

' Print results
PRINT str1

' Print return status(s)
PRINT
```

```
PRINT "Actual len = ", commlength  
PRINT "status = ", HEX$(status%)  
END
```

---

## ***imReceiveBufferNoprot***

**Purpose:** This function receives a text string from the designated port without using the active protocol. Only the PHIMEC.EXE protocol handler supports this function, which is often used to receive a host initialization string before beginning transmission.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imReceiveBufferNoprot%  
    (PortID ,  
     UserLength ,  
     VARPTR(DataBuffer) , VARSEG(DataBuffer)  
     Timeout ,  
     EomChar ,  
     VARPTR(CommLength) , VARSEG(CommLength) )
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *UserLength* parameter is the maximum number of bytes you can receive and must be at least 256 bytes.

The *DataBuffer* parameter is a far pointer to the data array where you want to place the received data. This buffer must hold at least 256 bytes.

The *Timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See “Setting Timeout Values” in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If imInfiniteTimeout is selected, the function will not return until the end of message character has been received.

The *EomChar* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any character.

**OUT Parameters:** The *CommLength* parameter returns the actual number of bytes received.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install the PHIMEC.EXE protocol handler to use this function.

The difference between this function and imReceiveBufferNoWait is that when imReceiveBufferNoprot returns from the function call, the data has been read, the timeout has expired, or an error was encountered. When you call imReceiveBufferNoWait, program execution continues without checking for received data or errors.

**See Also:** imReceiveBufferNoWait, imCancelRxBuffer, imRxCheckStatus

---

### Example

```

'***** imReceiveBufferNoprot *****
REM $INCLUDE: 'im20vbas.bi'

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

' Actual length returned by imReceiveBuffer
DIM commLength
DIM eomChar

DIM done

```

### *imReceiveBufferNoprot – Visual Basic*

```
PRINT "imReceiveBufferNoprot"

' Get the receive environment ready
status%= imCancelRxBuffer(ImCom1)

' Zero out string
str3 = STRING$(buffsize, CHR$(0))

' Define carriage return as end of message character
eomChar = 13 '<CR>'

PRINT "Input chars"
PRINT " Press Enter to end"

' Call the Intermec function
status%= imReceiveBufferNoprot(ImCom1, buffsize, VARPTR(str3), VARSEG(str3), 10000,
    eomChar, VARPTR(commLength), VARSEG(commLength))

PRINT "Status = ", HEX$(status%)

' Print results
PRINT str3
PRINT "Actual len", commLength

' Release resources
status%= imCancelRxBuffer(ImCom1)
END
```

---

## ***imReceiveBufferNoWait***

**Purpose:** This function receives data from the designated communications port and places the data into a user-defined record. It differs from `imReceiveBuffer` in that the programmer must set up the data record and monitor the transfer status until transmission is complete. This function runs in the background after it is initiated; no checks are made.

Use this function when receiving multiple buffer transmissions in conjunction with `imRxCheckStatus`.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imReceiveBufferNoWait%
    (PortID ,
     VARPTR(DataStruct), VARSEG(DataStruct))
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1
imCom2    COM2, scanner port (2010 and 2050)
imCom4    COM4 (RF only)
```

The *DataStruct* parameter is a far pointer to the data array for the received data. This buffer must hold at least 256 bytes.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must build and maintain a *DataStruct* of the type `imFarComDataStruct` as described in `IM20VBAS.BI`.

You must periodically check the `protocolXferStatus` element in the `ImComDataBuffer` record to see if all the data has been received. When `protocolXferStatus` is no longer code `8602H` (communications port in use), all data is received.

You must install a protocol handler to use this function.

## *imReceiveBufferNoWait – Visual Basic*

This function differs from `imReceiveBufferNoprot` in that program execution continues after `imReceiveBufferNoWait` is called. When `imReceiveBufferNoprot` returns from a function call, the data has been read, the timeout has expired, or an error was encountered.

**See Also:** `imReceiveBufferNoprot`, `imCancelRxBuffer`, `imRxCheckStatus`

---

### *Example*

```
'***** imReceiveBufferNoWait *****
REM $INCLUDE: 'im20vbas.bi'

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Data buffer structure for receive/transmit again and noprot
DIM farcomBuffStruct AS imFarComDataStruct

' Extend status protocol buffer
DIM statusBuffer AS imStatusBuffer

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

DIM done

' The difference between imReceiveBufferNoWait and the imReceiveBufferNoprot
' is that the user must set up the imReceiveBufferNoWait comm
' struct and pend on the results. Whereas, in the Noprot receive, the
' user sets up the length of the buffer, points at that buffer and
' sends it off and returns. There is no pending on this level for the
' imReceiveBufferNoprot routine

' Phimec protocol handler must be installed to run this routine

PRINT "imReceiveBufferNoWait"

' Get the receive environment ready
status%= imCancelRxBuffer(imCom1)

' Zero out string
str3 = STRING$(bufsize, CHR$(0))

' Set up communication buffer structure
farcomBuffStruct.command = imPhReceive
farcomBuffStruct.protocolMode = imNoProtocol
farcomBuffStruct.eomChar = CHR$(13) 'CR for terminating char
farcomBuffStruct.userLength = bufsize
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffSetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolXferStatus = imCuInuse
farcomBuffStruct.CommLength = 0

done = FALSE

' Call Intermec function
status%= imReceiveBufferNoWait(ImCom1,
```



```

    VARPTR(farcomBuffStruct), VARSEG(farcomBuffStruct))
PRINT "Func1= ", HEX$(status%)

' Loop until first character in buffer is a 'Q' or Esc is pressed
DO
    ' Check for receive errors:
    ' Print the error status

    IF status% = imIserror THEN
        PRINT "Rx Again err = ", HEX$(status%)
        done = FALSE
    ELSE
        ' Keyboard char
        temp$ = " "
        ' Get the receive data
        PRINT "Input chars"
        PRINT "Enter 'Q'"
        PRINT "or Esc to exit"

        ' Check to see if any characters are in buffer
        DO WHILE farcomBuffStruct.protocolXferStatus = imCuInuse AND temp$ <> CHR$(27)
            ' Pick up any keypad input
            temp$ = INKEY$
        LOOP

        PRINT "Comm done"
        ' Print the input string
        PRINT str3

        ' Update buffer for next block then call imRxCheckStatus to
        ' get protocol handler to reset status.

        farcomBuffStruct.command = imPhRecvAgain
        farcomBuffStruct.protocolXferStatus = imCuInuse
        farcomBuffStruct.commLength = 0

        status% = imRxCheckStatus(ImCom1)
    END IF

    ' Quit if first char in buffer is a 'Q' or a 'q'
    ' or Esc has been pressed
    IF UCASE$(LEFT$(str3, 1)) = "Q" OR temp$ = CHR$(27) THEN
        done = TRUE
    ELSE
        ' Zero out string and loop
        str3 = STRING$(buffsize, CHR$(0))
    ENDIF
LOOP WHILE done = FALSE

' Release resources
status% = imCancelRxBuffer(ImCom1)
END

```

---

## ***imReceiveByte***

**Purpose:** This function receives one byte of data through the designated communications port. This function is identical to MS-DOS INT 14H service 02H.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imReceiveByte%  
    (PortID,  
    VARPTR(ReceiveByte ), VARSEG(ReceiveByte))
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

**OUT Parameters:** The *ReceiveByte* parameter is a pointer to the byte received from the communications port.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

If you are using PHIMEC.EXE and want to receive a single byte, use *imReceiveBuffer* with a buffer length of one instead of the *imReceiveByte* function.

**See Also:** *imTransmitByte*

---

**Example**

```
'***** imReceiveByte *****
REM $INCLUDE: 'im20vbas.bi'

DIM instring AS STRING * 1

PRINT "imReceiveByte"
' If the Mode command is used, DO NOT install the Phpcstd protocol
' If the Phpcstd protocol is installed DO NOT use the Mode command

' Set up comm port
SHELL "MODE COM1:9600 E 7 1"

' Init JANUS keyboard key press buffer
keystre$ = ""
PRINT "Press Esc to exit"

' Get COM1 input and print to screen
DO

    ' Call Intermec function
    status% = imReceiveByte (imCom1, VARPTR(instring), VARSEG(instring))
    PRINT USING "!"; instring;
    keystre$ = INKEY$
' Loop until Esc is pressed
LOOP UNTIL keystre$ = CHR$(27) OR instring = CHR$(27)

PRINT "status = ", HEX$(status%)
END
```

---

## ***imReceiveInput***

**Purpose:** This function gets input from the source and places it into the received buffer. You can use the `imGetLength` function after this function to get the input length.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imReceiveInput%  
    ( Allowed ,  
      Timeout ,  
      VARPTR(Source), VARSEG(Source),  
      VARPTR(Received$) VARSEG(Received$))
```

**IN Parameters:** The *Allowed* parameter defines the available input source and is one or more of these constants:

<code>imLabelSelect</code>	Label selected
<code>imKeyboardSelect</code>	Keypad selected
<code>imCom1Select</code>	COM1 selected
<code>imCom2Select</code>	COM2, scanner port selected (2010 and 2050)
<code>imCom4Select</code>	COM4 selected (RF only)
<code>imAllSelect</code>	All sources are selected

The *Timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
<code>imZeroTimeout</code>	No wait
<code>imInfiniteTimeout</code>	Wait forever

If `imInfiniteTimeout` is selected, the function will not return until the end of message character has been received.

**OUT Parameters:** The *Source* parameter specifies the actual input source and is one of these constants:

<code>imNoSelect</code>	No selection made
<code>imLabelSelect</code>	Label selected
<code>imKeyboardSelect</code>	Keypad selected
<code>imCom1Select</code>	COM1 selected
<code>imCom2Select</code>	COM2, scanner port selected (2010 and 2050)
<code>imCom4Select</code>	COM4 selected (RF only)

The *Received* parameter is the variable where the data is placed.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** If input from more than one source is received before this function is called, the first available input is returned in this order: label, keypad, COM1, COM2, and COM4.

If you are using a communications port, you must install a protocol handler and call `imLinkComm`.

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imGetLength`, `imGetLabelSymbology`, `imLinkComm`

## *imReceiveInput – Visual Basic*

---

### **Example**

```
'***** imReceiveInput *****
' $INCLUDE: 'im20vbas.bi'

CONST bufsize = 300
DIM inString AS STRING * bufsize
DIM comString AS STRING * bufsize

CLS          ' Clear the screen
imSetInputMode(imProgrammer)
ImLinkCom% = imLinkComm(imCom1, VARPTR(comString), VARSEG(comString), bufsize)

FOR I% = 1 TO 3
  PRINT "Enter>>";

  status% = imReceiveInput(ImAllSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%), VARPTR(inString), VARSEG(inString))
  PRINT          ' Add a blank line

  IF source% = ImKeyboardSelect THEN
    PRINT "From Keypad"
  ELSEIF source% = imLabelSelect THEN
    PRINT "From Label"
    status% = imGetLabelSymbology (VARPTR(symbology%), VASEG(symbology%))
    IF symbology% = imCode39 THEN
      PRINT "Code 39"
    ELSE
      PRINT "Another code"
    ENDIF
  ELSEIF source% = imCom1Select THEN
    PRINT "From Serial"
  ELSE
    PRINT "Unknown source"
  END IF

  ' Get length of received data
  length% = imGetLength(source%)

  ' Print data received.  If the string is printed without doing the
  ' LEFT$, the entire 300 byte fixed-length string will be printed.

  PRINT "Recvd>>";LEFT$(inString,length%)

NEXT I%
ImLinkCom% = imUnlinkComm(imCom1)
imSetInputMode(ImWedge)

END
```

---

## ***imRsInstalled***

- Purpose:** This function determines whether or not the reader services (RSERVICE.EXE) program is installed.
- Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
FUNCTION imRsInstalled%()
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

---

### ***Example***

```
'***** imRsInstalled *****'  
REM $INCLUDE: 'im20vbas.bi'  
  
  ' Call the Intermec function  
  status% = imRsInstalled  
  PRINT "status = ", HEX$(status%)  
  
  IF status% = imRsAllSuccess THEN  
    PRINT "Rservice installed"  
  ELSE  
    PRINT "Rservice not installed"  
  END IF  
END
```

---

## ***imRxCheckStatus***

**Purpose:** This function directs the active protocol handler to check the communications port buffer status variable to determine if the application program has accepted the previous data. Use this function with the `imReceiveBufferNoWait` function to receive multiple buffers.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imRxCheckStatus%(PortID)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

<code>imCom1</code>	COM1
<code>imCom2</code>	COM2, scanner port (2010 and 2050)
<code>imCom4</code>	COM4 (RF only)

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** `imReceiveBufferNoWait`

---

### ***Example***

See example for `imReceiveBufferNoWait`.



---

## imSerialProtocolControl

**Purpose:** This function controls the protocol mode for a designated communications port and determines whether the receive mode is with or without protocol according to the input parameter. Any change clears the input buffer and resets the reader command parser.

Use this function to set protocol when connected to a communications port. The return value indicates a success if the port is currently linked to the Virtual Wedge. If the port is not currently linked to the Virtual Wedge, the function returns an error.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imSerialProtocolControl%  
    (PortID, ProtocolSwitch, EomChar)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

The *ProtocolSwitch* parameter affects how incoming messages are received and is one of these constants:

```
imNoChange    Keep the current protocol  
imProtocolOff  Turn the protocol OFF  
imProtocolOn   Turn the protocol ON  
imNewTermChar Use the new termination character
```

The *ProtocolSwitch* affects all incoming messages as follows:

- If *imNoChange* is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If *imProtocolOff* is specified, the incoming message is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.

### *imSerialProtocolControl – Visual Basic*

- If `imProtocolOn` is specified, the incoming message is terminated with the end of message character of the active protocol.
- If `imNewTermChar` is specified, `imProtocolOff` is assumed and the new end of message character specified in the parameter list is used.

The *EomChar* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Requires `imLinkComm`.

The receive buffers are cleared whenever the protocol is turned ON or OFF. To change the termination character (or to not change the setting at all), use `imNewTermChar` or `imNoChange` instead of toggling the protocol.

**See Also:** `imLinkComm`

---

**Example**

```
'***** imSerialProtocolControl *****
REM $INCLUDE: 'im20vbas.bi'

CLS

DIM linkBuffer AS STRING * 300
DIM inputBuffer AS STRING * 300
DIM eomChar
eomChar = 13
timeout% = 10000
source% = 0

linkBuffer = STRING$(300, CHR$(0))
inputBuffer = STRING$(300, CHR$(0))

CALL imSetInputMode(imProgrammer)

status% = imLinkComm(imCom1, VARPTR(linkBuffer), LEN(linkBuffer))

' Turn on the protocol
status% = imSerialProtocolControl(imCom1, imProtocolOn, eomChar)

' Get data from com 1
PRINT "Waiting for data"
WHILE source% <> 1
    inputBuffer = STRING$(300, CHR$(0))
    status% = imReceiveInput(imCom1Select, timeout%, source%, VARPTR(inputBuffer))
WEND

PRINT "Message is:"
PRINT inputBuffer

status% = imUnLinkComm(imCom1)

CALL imSetInputMode(imWedge)

PRINT "Press any key"
temp$ = INPUT$(1)
END
```

---

## ***imSetContrast***

**Purpose:** This function sets the reader's LCD display contrast level. There are eight levels of contrast (0 to 7) from very light to very dark, which are the most frequently used contrast settings.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imSetContrast%(DisplayContrastLevel)
```

**IN Parameters:** The *DisplayContrastLevel* parameter is one of these constants:

<code>imMinContrast</code>	Level 0
<code>imAveContrast</code>	Level 4
<code>imMaxContrast</code>	Level 7

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table compares the two scales.

This Value on Scale 0 to 7	Equates to This Value on Scale 0 to 31	Contrast Level
0	10	Very light
1	12	
2	14	
3	16	
4	18	
5	20	
6	22	
7	24	Very dark

This function has no effect on the JANUS 2050.

**See Also:** `imGetContrast`, `imDecreaseContrast`, `imIncreaseContrast`

---

**Example**

```
'***** imSetContrast *****  
REM $INCLUDE: 'im20vbas.bi'  
  
' Set contrast  
  ' Prompt for contrast level to set  
PRINT "Enter Contrast(0-7)"  
  INPUT "Level = ", level%  
  status% = imSetContrast (level%)  
  PRINT "Set Contrast status =", HEX$(status%)  
END
```

---

## ***imSetControlKey***

**Purpose:** This function enables or disables the **Ctrl** key setting. When disabled, none of the key combinations that use the **Ctrl** key work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imSetControlKey%(ControlKey)
```

**IN Parameters:** The *ControlKey* parameter is one of these constants:

<code>imEnable</code>	Enable the <b>Ctrl</b> key
<code>imDisable</code>	Disable the <b>Ctrl</b> key

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imGetControlKey`

---

### ***Example***

See example for `imGetControlKey`.

---

## *imSetDisplayMode*

**Purpose:** This function sets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imSetDisplayMode%
    ( SizeMode, VideoMode, ScrollMode, CharHt )
```

**IN Parameters:** The *SizeMode* parameter is required and is one of these constants:

imSizeMode80X25	80 x 25 text mode
imSizeMode40X25	40 x 25 text mode (2010 and 2020)
imSizeMode 20X16	20 x 16 text mode (2010 and 2020)
imSizeMode 20X8	20 x 8 text mode (2010 and 2020)
imSizeMode 10X16	10 x 16 text mode (2010 and 2020)
imSizeMode 10X8	10 x 8 text mode (2010 and 2020)

If imSizeMode80X25 is set, you also need to set the video mode, scroll mode, and character height.

If any other *SizeMode* is set, the video mode, scroll mode, and character height are automatically set.

The *VideoMode* parameter requires imSizeMode80X25. The standard PC BIOS supports up to video mode 13H. The reader only supports up to video mode 6. You can also set video modes 0 through 3 with IC.EXE.

The *VideoMode* parameter is one of these constants:

imStdVideoMode0	40 x 25 (use for double-wide characters)
imStdVideoMode1	40 x 25 (use for double-wide characters)
imStdVideoMode2	80 x 25
imStdVideoMode3	80 x 25
imStdVideoMode4	300 x 200 2-color
imStdVideoMode5	300 x 200 monochrome
imStdVideoMode6	640 x 200 2-color (2050)

## *imSetDisplayMode* – Visual Basic

The *ScrollMode* requires *imSizeMode80X25* and is one of these constants:

<i>imLcdScrollAt25</i>	Scroll at line 25
<i>imLcdScrollAt16</i>	Scroll at line 16 (2010 and 2020)
<i>imLcdScrollAt13</i>	Scroll at line 13 (2050 and double-height)
<i>imLcdScrollAt8</i>	Scroll at line 8 (2010 and 2020)
<i>imMaxScrollMode</i>	Maximum number of scroll lines

The *CharHt* parameter requires *imSizeMode80X25* and is one of these constants:

<i>imStandardCharHeight</i>	Standard-height characters, applies to all scroll modes except line 8 and line 13
<i>imDoubleCharHeight</i>	Double-height characters, applies only to scroll at line 8 and line 13

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** Changing display modes clears the screen.

The IRL input commands do not display correctly when the display is in 80 x 25 mode and the cursor has scrolled off the display. To alleviate this problem, set the display mode to one of the other modes, such as 20 x 16.

The mode does not change if there are conflicting parameters, such as trying to set the *VideoMode* to 16 lines and the *ScrollMode* at line 8.

If you want to use one of the graphics modes, use the appropriate function call provided by your programming language.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** *imGetDisplayMode*, *imSetFollowCursor*



**Example 1**

```

'***** imSetDisplayMode *****
REM $INCLUDE: 'im20vbas.bi'

status% = imSetDisplayMode(imSizeMode20X16,VideoMode%,ScrollMode%,CharHt%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
print "Size   =";SizeMode%
print "Video  =";VideoMode%
print "Scroll =";srollMode%
print "CharHt =";CharHt%
input "Waiting>>",response$

status% = imSetDisplayMode(imSizeMode20X8,VideoMode%,ScrollMode%,CharHt%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
print "Size   =";SizeMode%
print "Video  =";VideoMode%
print "Scroll =";srollMode%
print "CharHt =";CharHt%
input "Waiting>>",response$
END

```

**Example 2**

```

'*****
' FILE NAME:   setdisp.bas
' DESCRIPTION: Tests various display configurations
'*****
' The PSK keeps track of display information through the normal BIOS
' calls. Basic, however, uses its own set of interrupts. This results
' in the reader wedge getting out of synch with standard basic print and
' input statements if a display size other than 80x25 or 40x25 is used.
'
' If one of the other display modes is desired, the application needs to
' display data by using INT 10H instead of the normal basic print
' statements. This is an example of how to do this. Note that this also
' applies to printing a prompt with the input statement.
'
' RWTSR must be loaded for this program to execute.
'*****

' $INCLUDE: 'im20vbas.bi'
' $INCLUDE: 'vbdos.bi'

declare sub PrintString (TextString$)
dim shared inRegs as RegType, outRegs AS RegType

CONST bufsize = 300
DIM inString AS STRING * bufsize
cls
status% = imGetDisplayMode(SizeModeTmp%,videoModeTmp%,scrollModeTmp%,charHtTmp%)

' Instead of:
' print "Size   =";sizeModeTmp%
' print "Video  =";videoModeTmp%
' print "Scroll =";srollModeTmp%

```

## *imSetDisplayMode – Visual Basic*

```
'      print "CharHt =" ;charHtTmp%
'      input "Waiting>>",response$
'
'
'      use:
PrintString "Size   ="
PrintString STR$(sizeModeTmp%)
PrintString "\nVideo ="
PrintString STR$(videoModeTmp%)
PrintString "\nScroll ="
PrintString STR$(scrollModeTmp%)
PrintString "\nCharHt ="
PrintString STR$(charHtTmp%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%),VARPTR(inString), VARSEG(inString))
cls

status% = imSetDisplayMode(imSizeMode20X16,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
PrintString "Size   ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%),VARPTR(inString), VARSEG(inString))
cls

status% = imSetDisplayMode(imSizeMode20X8,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
PrintString "Size   ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%),VARPTR(inString), VARSEG(inString))
cls

status% = imSetDisplayMode(imSizeModel0X16,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
PrintString "Size   ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString STR$(charHt%)
```

```

PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%),VARPTR(inString), VARSEG(inString)
cls

status% = imSetDisplayMode(imSizeModel0X8,videoMode%,scrollMode%,charHt%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
PrintString "Size ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll="
PrintString STR$(scrollMode%)
PrintString "\nCharHt="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%),VARPTR(inString), VARSEG(inString)
cls

status% = imSetDisplayMode(sizeModeTmp%,videoModeTmp%,scrollModeTmp%,charHtTmp%)
status% = imGetDisplayMode(VARPTR(SizeMode%), VARSEG(SizeMode%),
    VARPTR(VideoMode%), VARSEG(VideoMode%), VARPTR(ScrollMode%), VARSEG(ScrollMode%),
    VARPTR(CharHt%), VARSEG(CharHt%))
PrintString "Size ="
PrintString STR$(sizeMode%)
PrintString "\nVideo ="
PrintString STR$(videoMode%)
PrintString "\nScroll ="
PrintString STR$(scrollMode%)
PrintString "\nCharHt ="
PrintString STR$(charHt%)
PrintString "\nWaiting>"
status% = imReceiveInput(ImKeyboardSelect, imInfiniteTimeout,
    VARPTR(source%), VARSEG(source%),VARPTR(inString), VARSEG(inString)
END

' *****
' Prints a string using INT 10H
' Prints a newline when "\n" is found
' *****

SUB PrintString(TextString$)
    Length% = LEN(TextString$)
    FOR I% = 1 to Length%
        IF ASC(MID$(TextString$, I%, 1)) = 92 AND ASC(MID$(TextString$, I%+1, 1)) = 110
            THEN
                inRegs.ax = &HE0D      ' Print CR
                inRegs.bx = &H0
                INTERRUPT &H10, inRegs, outRegs

                inRegs.ax = &HE0A      ' Print LF
                inRegs.bx = &H0
                INTERRUPT &H10, inRegs, outRegs
                I% = I% + 1
            ELSE
                inRegs.ax = &HE00 + ASC(MID$(TextString$, I%, 1))
                inRegs.bx = &H0
                INTERRUPT &H10, inRegs, outRegs
            END IF
    END IF

```

*imSetDisplayMode – Visual Basic*

```
    NEXT  
END SUB
```

```
' *****  
' END OF FILE: setdisp.bas  
' COPYRIGHT (c) 1995 INTERMEC CORPORATION, ALL RIGHTS RESERVED
```

---

## ***imSetFollowCursor***

**Purpose:** When the display is in 80 x 25 mode, the viewport follows the cursor as it moves. This function enables or disables the follow-the-cursor feature.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
FUNCTION imSetFollowCursor%(*FollowCursor*)

**IN Parameters:** The *FollowCursor* parameter is one of these constants:

imEnable	Enable follow-the-cursor mode
imDisable	Disable follow-the-cursor mode

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The display must be in 80 x 25 mode for this function to work correctly.

This function has no effect on the JANUS 2050.

**See Also:** imGetFollowCursor

---

### ***Example***

```

***** imSetFollowCursor *****
REM $INCLUDE: 'im20vbas.bi'

status% = imGetFollowCursor(followCursor%)
PRINT "Follow is ";followCursor%

status% = imSetFollowCursor(imDisable)
status% = imGetFollowCursor(followCursor%)
PRINT "Follow is ";followCursor%

status% = imSetFollowCursor(imEnable)
status% = imGetFollowCursor(followCursor%)
PRINT "Follow is ";followCursor%
END

```

---

## ***imSetInputMode***

**Purpose:** This function clears the input buffers and sets the input manager to one of three modes: Wedge, Programmer, or Desktop.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
SUB imSetInputMode(Mode)
```

**IN Parameters:** The *Mode* parameter is one of these constants:

<code>imWedge</code>	Wedge mode
<code>imProgrammer</code>	Programmer mode
<code>imDesktop</code>	Desktop mode

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

There are three different reader input modes: Wedge, Programmer, and Desktop. These modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label input goes into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. This mode should be used when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader’s power management capabilities. You will probably notice reduced battery life when in this mode compared to being in either programmer or desktop mode. For more information on power management, see Chapter 3, “Advanced Programming,” in the *JANUS PSK for C/C++ Reference Manual*.

**Programmer Mode** Inputs are echoed to the screen. Reader commands are executed as well as saved. Use this mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in Programmer mode.

**Desktop Mode** The application is responsible for retrieving and displaying input. Use this mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes of keyboard flags (**Shift**, **Ctrl**, **Alt**).

Upon exiting the program, set the input mode to `imWedge` so that DOS will work as expected.

For more information about reader input modes, see “Reader Input Modes,” in Chapter 3, “Advanced Programming,” in the *JANUS PSK for C/C++ Reference Manual*.

**See Also:** `imGetInputMode`, `imReceiveInput`

---

**Example**

See example for `imGetInputMode` and `imReceiveInput`.

---

## ***imSetKeyclick***

**Purpose:** Each time you press a key, the reader can emit a click. This function enables or disables the keyclick.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imSetKeyclick%(KeyClick)
```

**IN Parameters:** The *KeyClick* parameter is one of these constants:

<code>imEnable</code>	Enable the keyclick
<code>imDisable</code>	Disable the keyclick

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imGetKeyclick`

---

### ***Example***

See example for `imGetKeyclick`.



---

## ***imSetViewportLock***

**Purpose:** This function enables or disables the keys that move the viewport.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imSetViewportLock%(VpLock)
```

**IN Parameters:** The *VpLock* parameter is one of these constants:

<code>imEnable</code>	Lock the viewport
<code>imDisable</code>	Unlock the viewport

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** The display must be in 80 x 25 mode for this function to work correctly.

This function controls whether the viewport moves (unlocked) or does not move (locked) when the viewport movement keys are pressed.

This function has no effect on the JANUS 2050.

**See Also:** `imGetViewportLock`, `imSetFollowCursor`

---

### ***Example***

See example for `imGetViewportLock`.

---

## ***imSetWarmBoot***

**Purpose:** This function enables or disables the **Ctrl-Alt-Del** warm boot key sequence. When disabled, the **Ctrl-Alt-Del** key sequence does not reboot the reader.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imSetWarmBoot%  
    ( WarmBoot )
```

**IN Parameters:** The *WarmBoot* parameter is one of these constants:

<code>imEnable</code>	Enable <b>Ctrl-Alt-Del</b> warm boot
<code>imDisable</code>	Disable <b>Ctrl-Alt-Del</b> warm boot

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `imGetWarmBoot`

---

### ***Example***

```
!***** imSetWarmBoot *****  
REM $INCLUDE: 'im20vbas.bi'  
  
status% = imSetWarmBoot(imDisable)  
PRINT "Disabling <BOOT>"  
status% = imGetWarmBoot (VARPTR(ctrlKey%), VARSEG(ctrlKey%))  
IF ctrlKey% = imEnable THEN  
    PRINT "<BOOT> enabled"  
ELSE  
    PRINT "<BOOT> disabled"  
END IF  
INPUT "Test it1>>",response$  
  
status% = imSetWarmBoot(imEnable)  
PRINT "Enabling <BOOT>"  
INPUT "Test it1>>",response$  
END
```

---

## ***imSound***

**Purpose:** This function generates a beep of specified pitch and duration. For example, use a soft beep for library use, a loud beep for manufacturing use, or a unique beep to distinguish between other readers.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'
FUNCTION imSound%
    (Pitch, Duration, Volume)
```

**IN Parameters:** The *Pitch* parameter is the frequency of the beep you want the reader to make. The numeric range for *Pitch* is from 20 to 20,000 Hz. You can also use one of these constants:

imHighPitch	2400 Hz
imLowPitch	1200 Hz
imVeryLowPitch	600 Hz

The *Duration* parameter is the length of the beep. The numeric range for *Duration* is from 1 to 65,000 ms. You can also use one of these constants:

1 to 32,767 ms	Integer range
32,768 to 65,534 ms	See “Setting Timeout Values” in this chapter.
imBeepDuration	50 ms
imClickDuration	4 ms

The *Volume* parameter is one of these constants:

imOffVolume	Volume is off
imQuietVolume	Volume is quiet
imNormalVolume	Volume is normal
imLoudVolume	Volume is loud
imExtraLoudVolume	Volume is extra loud
imCurrentVolume	Volume is the current volume

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

## *imSound – Visual Basic*

---

### **Example**

```
'***** imSound *****
REM $INCLUDE: 'im20vbas.bi'

RESTORE
duration% = 0
pitch%    = -1
volume%   = imCurrentVolume

' Play a song
' Read data and play song until end of data
DO WHILE pitch% <> 0
  'Read in pitch and duration
  READ pitch%, duration%

  ' Call the Intermec function
  status% = imSound(pitch%, duration%, volume%)
LOOP
PRINT "status = ", HEX$(status%)

' Sound data
DATA 523, 500, 392, 500, 440, 500, 330, 500, 349, 500, 330, 250
DATA 296, 250, 262, 1000, 0 ,0

' Enumeration of notes and frequencies
' C0 = 262, D0 = 296, E0 = 330, F0 = 349, G0 = 392, A0 = 440, B0 = 494,
' C1 = 523, D1 = 587, E1 = 659, F1 = 698, G1 = 784, A1 = 880, B1 = 988,
' EIGHTH = 125, QUARTER = 250, HALF = 500, WHOLE = 1000, END = 0
' Above sound DATA
' C1, HALF, G0, HALF, A0, HALF, E0, HALF, F0, HALF, E0, QUARTER,
' D0, QUARTER, C0, WHOLE, END
END
```

---

## ***imStandbyWait***

**Purpose:** This function requests that reader services wait in standby mode for a specific period of time. You can use this function to suspend the reader for a length of time to save the battery power.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION ImStandbyWait%(Timeout)
```

**IN Parameters:** The *Timeout* parameter is the amount of time to wait in standby mode. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select imInfiniteTimeout, the function will not return until the end of message character has been received.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** None.

---

### ***Example***

See example for imCommand.

---

## ***imTransmitBuffer***

**Purpose:** This function transmits the contents of a data buffer through a designated communications port. This function continues operating until the buffer transmission is complete or until an error status is detected.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imTransmitBuffer%  
    (PortID,  
     UserLength ,  
     SSEGADD(DataBuffer) ,  
     Timeout)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *UserLength* parameter is the length of the data string that you want to transmit.

The *DataBuffer* parameter is a far pointer to the data array that you want to transmit.

The *Timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select imInfiniteTimeout, the function will not return until the end of message character has been received.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

**See Also:** imReceiveBuffer, imTransmitBufferNoWait, imTransmitBufferNoprot

---

### Example

```
***** imTransmitBuffer *****
'   Note: Must have reader services and comm protocol handler installed
'   to enable send/receive buffer functions
'   Run these TSR's at DOS prompt before running these tests:
'       rservice
'       phimec 1 ( 1 is COM1)

      REM $INCLUDE: 'im20vbas.bi'

' Must be run with Phimec protocol installed

PRINT "imTransmitBuffer"

outstr$ = "Hi There"

' Call Intermec function
status% = imTransmitBuffer (imCom1, LEN(outstr$), SSEGADD(outstr$), 1000)

PRINT "com = ", imCom1
PRINT "str = ", outstr$
PRINT "len = ", LEN(outstr$)
PRINT "status = ", HEX$(status%)
END
```

---

## ***imTransmitBufferNoWait***

**Purpose:** This function transmits the contents of a buffer and passes control back to its client.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imTransmitBufferNoWait%  
    (PortID,  
     VARPTR(DataStruct), VARPTR(DataStruct))
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *DataStruct* parameter is a far pointer to the data array that you want to transmit.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

This function differs from *imTransmitBuffer* in that the client must set the buffer structure and monitor the buffer status until transmission is complete.

Use this function for multiple buffer transmissions in conjunction with checking the status in *DataStruct*.

You must build and maintain a *DataStruct* of the type *imFarComDataStruct* as described in *IM20VBAS.BI*.

**See Also:** *imTransmitBufferNoprot*, *imCancelTxBuffer*



**Example**

```

'***** imTransmitBufferNoWait *****
REM $INCLUDE: 'im20vbas.bi'

' Define communication status messages
CONST imCuSuccess = 1536
CONST imInuse = -31230

' Data buffer size must be at least 256 bytes
CONST bufsize = 300

' Data buffer structure for receive/transmit again and noprot
DIM farcomBuffStruct AS imFarComDataStruct

' Define fixed length strings of 300 bytes (256 is minimum string buffer)
DIM str3 AS STRING * bufsize 'fixed length string

' PHIMEC protocol handler must be installed to run this routine
PRINT "imTransmitBufferNoWait"

' Get the transmit environment ready
status%= imCancelTxBuffer(ImCom1)

' Make a null terminated string to transmit
str3 = "Hi There" + CHR$(0)

' Set up comm buffer parameters
farcomBuffStruct.command = imPhTransmit
farcomBuffStruct.protocolXferStatus = imInuse
' Get length not including the null terminator
farcomBuffStruct.userLength = INSTR(str3, CHR$(0)) - 1
farcomBuffStruct.commLength = 0
farcomBuffStruct.SegDataPtr = VARSEG(str3)
farcomBuffStruct.OffsetDataPtr = VARPTR(str3)
farcomBuffStruct.protocolMode = imNoProtocol
' Terminator is null character
farcomBuffStruct.eomChar = CHR$(0)

' Call Intermec routine
status%= imTransmitBufferNoWait(ImCom1, (VARPTR(farcomBuffStruct),
    (VARSEG(farcomBuffStruct)))
PRINT "Status = ", HEX$(status%)

IF status% = imCuSuccess THEN
' Wait for data transfer to complete
DO WHILE farcomBuffStruct.protocolXferStatus = imInuse AND INKEY$ <> CHR$(27)
LOOP

PRINT "Buffer transmitted"
ELSE
PRINT "Buffer not sent"
END IF

' Release resources
status%= imCancelTxBuffer(ImCom1)
END

```

---

## ***imTransmitBufferNoprot***

**Purpose:** This function transmits a buffer without protocol and sends only the specified number of characters.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imTransmitBufferNoprot%  
    (PortID,  
     UserLength,  
     SSEGADD(DataBuffer),  
     Timeout)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

imCom1	COM1
imCom2	COM2, scanner port (2010 and 2050)
imCom4	COM4 (RF only)

The *UserLength* parameter is the maximum number of bytes to be transmitted.

The *DataBuffer* parameter is a far pointer to the data array that you want to transmit.

The *Timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *Timeout* parameter is a number or one of these constants:

0 to 32,767 ms	Integer range
32,768 to 65,534 ms	See "Setting Timeout Values" in this chapter.
imZeroTimeout	No wait
imInfiniteTimeout	Wait forever

If you select imInfiniteTimeout, the function will not return until the end of message character has been received.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler other than PHPCSTD.EXE to use this function.

If an existing transmit client is linked to the host, you must issue a cancel command first.

**See Also:** imTransmitBufferNoWait, imCancelTxBuffer, imTransmitBuffer

---

### Example

```
'***** imTransmitBufferNoprot *****  
REM $INCLUDE: 'im20vbas.bi'  
  
PRINT "Transmit Noprot"  
  
' Get the transmit environment ready  
status%= imCancelTxBuffer(ImCom1)  
  
' Define transmit string  
temp$ = "Intermec"  
  
' Call Intermec routine  
status%= imTransmitBufferNoprot(ImCom1, LEN(temp$), SSEGADD(temp$), 1000)  
PRINT  
PRINT "Status = ", HEX$(status%)  
  
' Check for success  
IF status% < 16384 AND status% > 0 THEN  
PRINT "Buffer transmitted"  
ELSE  
PRINT "Buffer not sent"  
END IF  
  
' Release resources  
status%= imCancelTxBuffer(ImCom1)  
END
```

---

## ***imTransmitByte***

**Purpose:** This function transmits one byte of data out through a designated communications port. This function is identical to MS-DOS INT 14H Service 01H.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imTransmitByte%  
    (PortID, TransmitByte)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

<i>imCom1</i>	COM1
<i>imCom2</i>	COM2, scanner port (2010 and 2050)
<i>imCom4</i>	COM4 (RF only)

The *TransmitByte* parameter is the byte of data to transmit.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

Intermec recommends using *imTransmitBuffer* (with a *UserLength* of one) instead of using this function.

You can use this function for an acknowledgment.

**See Also:** *imReceiveByte*, *imTransmitBuffer*

---

**Example**

```
'***** imTransmitByte *****
REM $INCLUDE: 'im20vbas.bi'

PRINT "imTransmitByte"
' If the Mode command is used, DO NOT install the Phpcstd protocol
' If the Phpcstd protocol is installed DO NOT use the mode command

' Set up comm port
SHELL "MODE COM1:9600 E 7 1"

' Get keypad char and transmit to COM1
DO
  outstr$ = INKEY$
  IF outstr$ <> "" THEN
    ' Call Intermec function
    status% = imTransmitByte (imCom1, SADD(outstr$))
    PRINT USING "!"; outstr$;
  END IF
' Loop until Esc is pressed
LOOP UNTIL outstr$ = CHR$(27)

PRINT "status = ", HEX$(status%)
PRINT "Press any key"
PRINT " to continue"
END
```

---

## ***imUnlinkComm***

**Purpose:** This function removes the link between the Reader Wedge function and a designated communications port. After this function executes, the Reader Wedge is not notified of receive buffer functions.

You only need to use this procedure one time, at the end of your program.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION ImUnLinkComm%(PortID)
```

**IN Parameters:** The *PortID* parameter identifies the communications port as follows:

```
imCom1    COM1  
imCom2    COM2, scanner port (2010 and 2050)  
imCom4    COM4 (RF only)
```

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** `imLinkComm`

---

### ***Example***

See example for `imReceiveInput`, `imIrlY`, and `imSerialProtocolControl`.

---

## ***imViewportEnd***

**Purpose:** This function sets the viewport to the lower right corner (end) of the virtual display.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imViewportEnd ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportHome, imViewportPageDown, imViewportPageUp, imViewportToCursor, imViewportMove

---

### ***Example***

```
!***** imViewportEnd *****  
REM $INCLUDE: 'im20vbas.bi'  
  
! Set viewport to lower right corner  
imViewportEnd  
SLEEP 5  
END
```

---

## ***imViewportGetxy***

**Purpose:** This function retrieves the column and row of the upper left corner of the viewport.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imViewportGetxy%  
    (VARPTR(Row), VARSEG(Row),  
     VARPTR(Column), VARSEG(Column))
```

**IN Parameters:** None.

**OUT Parameters:** The *Row* parameter returns the row value (Y-coordinate) of the viewport.

The *Column* parameter returns the column value (X-coordinate) of the viewport.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** This function is valid only when the display is in 80 x 25 mode.

This function has no effect on the JANUS 2050.

**See Also:** *imViewportSetxy*, *imViewportMove*, *imViewportPageUp*, *imViewportPageDown*, *imViewportToCursor*, *imViewportEnd*, *imViewportHome*

---

### ***Example***

```
***** imViewportGetxy *****  
REM $INCLUDE: 'im20vbas.bi'  
row% = 3  
col% = 3  
status% = imViewportSetxy(VARPTR(row%), VARSEG(row%), VARPTR(col%), VARSEG(col%))  
print "Row =";row%  
print "Col =";col%  
input "Waiting>>",response$  
status% = imViewportGetxy(VARPTR(row%), VARSEG(row%), VARPTR(col%), VARSEG(col%))  
print "Row =";row%  
print "Col =";col%  
END
```



---

## ***imViewportHome***

**Purpose:** This function sets the viewport to the upper left corner (home) of the virtual display.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imViewportHome ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportEnd, imViewportPageDown, imViewportPageUp, imViewportToCursor, imViewportMove

---

### ***Example***

```
!***** imViewportHome *****  
REM $INCLUDE: 'im20vbas.bi'  
  
! Home  
imViewportHome  
SLEEP 5  
END
```

---

## ***imViewportMove***

**Purpose:** This function moves the viewport the specified distance and direction.

**Syntax:**

```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imViewportMove%  
    (Direction,  
     Distance,  
     VARPTR(Row), VARSEG(Row),  
     VARPTR(Column), VARSEG(Column))
```

**IN Parameters:** The *Direction* parameter is one of these constants:

imViewportLeft	Move left
imViewportRight	Move right
imViewportUp	Move up
imViewportDown	Move down

The *Distance* parameter indicates the number of units to move the viewport and is either a numeric value between 1 and 70 or is imDefaultDistance.

If the distance parameter is imDefaultDistance, the default step size is used.

The distance moved is a configurable parameter. For more information on configuring the viewport, see your JANUS user's manual.

**OUT Parameters:** The *Row* parameter returns the row number to which the viewport has moved.

The *Column* parameter returns the column number to which the viewport has moved.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The (*Row*, *Column*) pair represents the upper left corner of the viewport being displayed.

The minimum value for both the *Row* and *Column* is (0,0), which is the upper left corner of the virtual window. The maximum value is determined by the video mode and the number of lines and columns displayed.

For example, for the normal video mode 3 (80 x 25 display) with a 20 x 16 display size, the maximum value of *Row* is 9 (25 minus 16) and the maximum value of *Column* is 60 (80 minus 20).

The *Row* and *Column* viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *Row* and *Column*.

This function has no effect on the JANUS 2050.

**See Also:** imViewportEnd, imViewportHome, imViewportPageDown, imViewportPageUp, imViewportToCursor, imCursorToViewport

---

### Example

```
'***** imViewportMove *****
REM $INCLUDE: 'im20vbas.bi'

' Viewport move
' Prompt for direction, distance

INPUT "Enter direction ", direction%
INPUT "Enter distance ",distance%

status% = imViewportMove (direction%, distance%, VARPTR(dpRow%), VARSEG(dpRow%),
    VARPTR(dpColumn%), VARSEG(dpColumn%))
PRINT "RVP move status = "
PRINT " ", HEX$(status%)
PRINT "Row ", dpRow%
PRINT "Col ", dpColumn%
SLEEP 5
END
```

---

## ***imViewportPageDown***

**Purpose:** This function moves the viewport down one viewport length.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imViewportPageDown ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportEnd, imViewportHome,  
imViewportPageUp, imViewportToCursor, imViewportMove

---

### ***Example***

```
***** imViewportPageDown *****
REM $INCLUDE: 'im20vbas.bi'

    ' Down one viewport length
    imViewportPageDown
    SLEEP 5
END
```

---

## ***imViewportPageUp***

- Purpose:** This function moves the viewport up one viewport length.
- Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imViewportPageUp ()
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** None.
- Notes:** This function has no effect on the JANUS 2050.
- See Also:** imCursorToViewport, imViewportEnd, imViewportHome,  
imViewportPageDown, imViewportToCursor, imViewportMove

---

### ***Example***

```
***** imViewportPageUp *****  
REM $INCLUDE: 'im20vbas.bi'  
  
    ' Up one viewport length  
    imViewportPageUp  
    SLEEP 5  
END
```

---

## ***imViewportSetxy***

- Purpose:** This function sets the viewport row and column to a specific value when moving between two screens.
- Syntax:**
- ```
REM $INCLUDE: 'im20vbas.bi'  
FUNCTION imViewportSetxy%  
    (VARPTR(Row), VARSEG(Row),  
    VARPTR(Column), VARSEG(Column))
```
- IN/OUT Parameters:** The *Row* parameter sets the row value (Y-coordinate) of the viewport.  
The *Column* parameter sets the column value (X-coordinate) of the viewport.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** The (*Row*, *Column*) pair represents the upper left corner of the viewport being displayed.
- The minimum value for both the *Row* and *Column* is (0,0), which is the upper left corner of the virtual window. The maximum value is determined by the video mode and the number of lines and columns displayed.
- For example, for the normal video mode 3 (80 x 25 display) with a 20 x 16 display size, the maximum value of *Row* is 9 (25 minus 16) and the maximum value of *Column* is 60 (80 minus 20).
- The *Row* and *Column* viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *Row* and *Column*.
- This function has no effect on the JANUS 2050.
- See Also:** *imViewportMove*

---

**Example**

```
'***** imViewportSetxy *****  
REM $INCLUDE: 'im20vbas.bi'  
  
' Viewport Set X and Y coordinates  
' Prompt for row and col  
  
INPUT "Enter row ", dpRow%  
INPUT "Enter column ", dpColumn%  
status% = imViewportSetxy (VARPTR(dpRow%), VARSEG(dpRow%),  
    VARPTR(dpColumn%), VARSEG(dpColumn%))  
temp$ = INPUT$(1)  
PRINT "VP Set XY status ="  
PRINT " ", HEX$(status%)  
SLEEP 5  
END
```

---

## ***imViewportToCursor***

**Purpose:** This function centers the viewport around the cursor.

**Syntax:** REM \$INCLUDE: 'im20vbas.bi'  
SUB imViewportToCursor ()

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** When the cursor is not displayed, use this function to move the viewport to the cursor.

This function has no effect on the JANUS 2050.

**See Also:** imCursorToViewport, imViewportEnd, imViewportHome, imViewportPageDown, imViewportMove

---

### ***Example***

```
'***** imViewportToCursor *****'  
REM $INCLUDE: 'im20vbas.bi'  
  
    ' Call viewport to cursor  
    imViewportToCursor  
    SLEEP 5  
END
```





## ***Appendix A: Status Codes***



*This appendix lists the status code hex values and error messages. Use the tables in this appendix to look up the meaning of a specific status code.*

## **Status Code Bit Values**

---

Most of the PSK functions return status codes. You can use the codes to test for error conditions that your application will act upon.

Each status code is a 16-bit word structured as follows:

|    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 15 | 14 | 13 | 12 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| s  | s  | f  | f  | f  | f | f | m | m | m | m | m | m | m | m |

JPSK.002

where:

*s* is severity code: 00 = Success  
 10 = Error  
 01 = Warning  
 11 = Fatal

*f* is the subsystem code, explained later in this appendix.

*m* is the message code that identifies the error or warning condition.

The status codes are IM\_USHORT (unsigned short) values.

The tables in this appendix list the hex value of the message codes.

## ***Status Codes Listed Numerically***

---

The following table lists the return codes and the error message text provided by `im_message` and `imMessage`. For each message, there is an associated status return code, subsystem, and severity.

Some messages are abbreviated to fit the display and to save memory on the JANUS reader. The table includes an easy-to-read version of the abbreviated messages.

---

### *Status Codes and Error Messages Listed in Numerical Order*

| Hex Code | Severity | Subsystem | Reader Message and Description                               |
|----------|----------|-----------|--------------------------------------------------------------|
| 0000     | Good     | NO        | Request successful                                           |
| 0001     | Good     | NO        | Prohibited                                                   |
| 0100     | Good     | RS        | Rservice request success<br>Reader services successful       |
| 0103     | Good     | RS        | Rservice resume success<br>Reader services resume successful |
| 0200     | Good     | CM        | Request success<br>Request successful                        |
| 0201     | Good     | CM        | Read End Of Record<br>End of record reached                  |
| 0202     | Good     | CM        | Read End Of File<br>End of file reached                      |
| 0300     | Good     | SC        | Scan success<br>Scan successful                              |
| 0400     | Good     | DC        | Success<br>Successful command                                |
| 0401     | Good     | DC        | Symbology already enabled<br>Symbology is already enabled    |
| 0402     | Good     | DC        | Symbology not enabled<br>Symbology is not enabled            |
| 040A     | Good     | DC        | Good decode<br>Successful decode                             |
| 040B     | Good     | DC        | Intermediate row re-read<br>Intermediate row reread          |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                   |
|----------|----------|-----------|--------------------------------------------------------------------------------------------------|
| 040C     | Good     | DC        | Intermediate decoded<br>Intermediate raw decoded                                                 |
| 0421     | Good     | DC        | Default command symbology                                                                        |
| 0422     | Good     | DC        | Mixed ASCII format                                                                               |
| 0500     | Good     | RW        | RW success<br>Reader Wedge successful                                                            |
| 0505     | Good     | RW        | No rdr cmds parsed<br>No reader commands parsed                                                  |
| 0506     | Good     | RW        | Valid rdr cmds parsed<br>Valid reader commands parsed                                            |
| 0509     | Good     | RW        | Accumulating rdr cmd<br>Accumulating reader command                                              |
| 050A     | Good     | RW        | Rdr cmd override<br>Reader command override                                                      |
| 050B     | Good     | RW        | Rdr cmd enter accum<br>Reader command enter accumulation                                         |
| 050C     | Good     | RW        | Rdr cmd exit accum<br>Reader command exit accumulation                                           |
| 050D     | Good     | RW        | Accumulate multi-read labels<br>Accumulating multiread labels                                    |
| 0510     | Good     | RW        | ENTER rdr cmd parsed<br>An Enter reader command was parsed                                       |
| 0513     | Good     | RW        | Protected field rdr cmd parsed<br>Protected field was parsed                                     |
| 0517     | Good     | RW        | Keycode label parsed<br>Keycode label was parsed                                                 |
| 0518     | Good     | RW        | Isolated ENTER cmd parsed<br>An isolated Enter command was parsed                                |
| 0519     | Good     | RW        | Good rdr cmd on exit accum<br>A reader command was parsed successfully on exit from accumulation |
| 051A     | Good     | RW        | Good rdr cmd on ENTER<br>A reader command was parsed successfully when Enter was parsed          |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                              |
|----------|----------|-----------|-----------------------------------------------------------------------------|
| 051C     | Good     | RW        | Enter accum parsed<br>An Enter Accumulate has been parsed when accumulating |
| 051D     | Good     | RW        | Exit multi-read<br>A label terminating a multiple-read sequence was scanned |
| 051E     | Good     | RW        | Enter multi-read<br>A label beginning a multiple-read sequence was scanned  |
| 0521     | Good     | RW        | No comms status<br>No communications status to report                       |
| 0525     | Good     | RW        | Rdr cmds parsed<br>Reader commands forwarded to the application were parsed |
| 0600     | Good     | CU        | Comm success<br>Communications operation success                            |
| 0601     | Good     | CU        | Comm Buff done<br>Communications buffer done                                |
| 0800     | Good     | PM        | PM success<br>Power management successful                                   |
| 0A00     | Good     | TM        | Timer success<br>Timer operation successful                                 |
| 0B00     | Good     | BP        | Beep success<br>Beeper call successful                                      |
| 0E00     | Good     | IM        | String Extract Complete                                                     |
| 0E01     | Good     | IM        | String Append complete                                                      |
| 0E02     | Good     | IM        | Search string found                                                         |
| 0E03     | Good     | IM        | String Copy complete                                                        |
| 0E04     | Good     | IM        | Operation success<br>Successful operation                                   |
| 0F00     | Good     | LG        | Successful operation                                                        |
| 1000     | Good     | KB        | Expanded keypad success<br>Expanded keyboard buffer successful              |
| 100A     | Good     | KB        | Expanded buffer enabled                                                     |
| 100B     | Good     | KB        | Expanded buffer disabled                                                    |
| 1100     | Good     | SS        | System Config success<br>System configuration successful                    |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                               |
|----------|----------|-----------|----------------------------------------------------------------------------------------------|
| 1200     | Good     | KP        | Keypad success<br>Successful keypad operation                                                |
| 1300     | Good     | DP        | Display success<br>Successful display operation                                              |
| 1A00     | Good     | EX        | Execution success<br>Transaction successful                                                  |
| 1A01     | Good     | EX        | ACK received<br>Transaction successful, ACK received                                         |
| 1A10     | Good     | EX        | Data received<br>Received host message on Read operation                                     |
| 4200     | Warning  | CM        | Not all config items copied<br>Not all configuration items copied                            |
| 4201     | Warning  | CM        | Rdr Cmd terminated config cmd<br>Reader command terminated configuration command string      |
| 4202     | Warning  | CM        | Client should not be notified                                                                |
| 4502     | Warning  | RW        | Input timeout                                                                                |
| 4503     | Warning  | RW        | No input data                                                                                |
| 450E     | Warning  | RW        | The app should be notified<br>The application should be notified                             |
| 4529     | Warning  | RW        | Input from source other than requested<br>Input from source is other than the ones requested |
| 452A     | Warning  | RW        | RWTSR already loaded                                                                         |
| 4600     | Warning  | CU        | Warning buff canceled<br>Buffer canceled                                                     |
| 4601     | Warning  | CU        | Comm Timeout warning<br>Communication timeout                                                |
| 4602     | Warning  | CU        | Comm had no client to cancel<br>Communication had no client to cancel                        |
| 4603     | Warning  | CU        | Comm Util no PH for config<br>No protocol handler to configure                               |
| 4604     | Warning  | CU        | Prot handler not loaded<br>Protocol handler is not yet loaded                                |
| 4605     | Warning  | CU        | Prot handler already receiving<br>Protocol handler is already receiving                      |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                     |
|----------|----------|-----------|------------------------------------------------------------------------------------|
| 4606     | Warning  | CU        | PH not active for link request<br>Protocol handler is not active for link request  |
| 4A00     | Warning  | TM        | Timer not active<br>Timer not currently active                                     |
| 5001     | Warning  | KB        | Expanded buffer installed<br>Expanded keyboard buffer installed or disabled        |
| 5201     | Warning  | KP        | Backdoor Comms failed<br>Backdoor communications failure                           |
| 5A02     | Warning  | EX        | NAK received<br>Transaction failed, NAK received                                   |
| 5A07     | Warning  | EX        | No more log records<br>Standby file is empty                                       |
| 5A11     | Warning  | EX        | Received data truncated<br>Data was truncated                                      |
| 5A12     | Warning  | EX        | Fields overflow<br>Too many fields                                                 |
| 5A20     | Warning  | EX        | Record logged<br>Record stored in standby file successfully                        |
| 5A21     | Warning  | EX        | Logged but upload error<br>Record stored in standby file, but upload standby error |
| 8100     | Error    | RS        | Rservice invalid request code<br>Invalid function code received                    |
| 8101     | Error    | RS        | Rservice not installed<br>Reader services is not installed                         |
| 8102     | Error    | RS        | Rservice resume failed<br>Reader services resume failed                            |
| 8103     | Error    | RS        | Rservice or App out of date<br>Reader services or application is out of date       |
| 8104     | Error    | RS        | RWTSR not connected<br>Reader Wedge TSR is not installed                           |
| 8200     | Error    | CM        | Invalid Object                                                                     |
| 8201     | Error    | CM        | Invalid subfunction                                                                |
| 8202     | Error    | CM        | Invalid Param length<br>Invalid parameter length                                   |



---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                      |
|----------|----------|-----------|-------------------------------------------------------------------------------------|
| 8203     | Error    | CM        | Invalid Param val<br>Invalid parameter value                                        |
| 8204     | Error    | CM        | Invalid Param 1 value<br>Invalid first parameter value                              |
| 8205     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and no check digit)   |
| 8206     | Error    | CM        | Invalid param 2 value<br>Invalid second parameter value                             |
| 8207     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and full ASCII)       |
| 8208     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and mixed full ASCII) |
| 8209     | Error    | CM        | Invalid Param 3 value<br>Invalid third parameter value                              |
| 820A     | Error    | CM        | Invalid Codabar cfg<br>Invalid Codabar configuration (ABC and discard start/stop)   |
| 820B     | Error    | CM        | Protocol not loaded                                                                 |
| 820C     | Error    | CM        | Invalid comm or protcl<br>Invalid port or protocol specified                        |
| 820D     | Error    | CM        | No end quote<br>No ending quote found                                               |
| 820E     | Error    | CM        | No dbl quote<br>No double quote (might be missing an opening quote)                 |
| 820F     | Error    | CM        | Invalid parser state                                                                |
| 8210     | Error    | CM        | Invalid config cmd<br>Invalid configuration command                                 |
| 8211     | Error    | CM        | Client returned err<br>Client deemed configuration command invalid                  |
| 8212     | Error    | CM        | Invalid beep duration                                                               |
| 8213     | Error    | CM        | Invalid beep freq<br>Invalid beep frequency                                         |
| 8214     | Error    | CM        | Invalid beep vol<br>Invalid beep volume                                             |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                       |
|----------|----------|-----------|------------------------------------------------------------------------------------------------------|
| 8215     | Error    | CM        | Beep vol alrdy off<br>Beep volume already off                                                        |
| 8216     | Error    | CM        | Beep vol alrdy on<br>Beep volume already on                                                          |
| 8217     | Error    | CM        | Invalid beep specifier<br>Invalid beep specifier (must be "L" or "H")                                |
| 8218     | Error    | CM        | Inappropriate protcl<br>Inappropriate configuration for the current protocol                         |
| 8219     | Error    | CM        | BIOS rejected set config<br>BIOS rejected the set configuration command                              |
| 821A     | Error    | CM        | Bld string too small<br>Configuration command string object is too small                             |
| 821B     | Error    | CM        | Invalid Build cmd<br>Configuration ID is invalid                                                     |
| 821C     | Error    | CM        | Invalid Build param<br>Invalid build parameter                                                       |
| 821D     | Error    | CM        | No Build Func<br>No build function                                                                   |
| 821E     | Error    | CM        | No more build entries                                                                                |
| 821F     | Error    | CM        | No more WM bld entries<br>No more build entries in wedge lookup table                                |
| 8220     | Error    | CM        | No more WM bld entries<br>No more build entries in wedge lookup table for "build next" WM<br>command |
| 8221     | Error    | CM        | No LUM key entries<br>No entries found in the LUM key table                                          |
| 8222     | Error    | CM        | WM entry not found<br>No match in lookup table for specified character                               |
| 8223     | Error    | CM        | Invalid Temp config<br>At least one parameter rejected by client (see JANUS.ERR)                     |
| 8224     | Error    | CM        | Config Item not found<br>Configuration item is not found                                             |
| 8225     | Error    | CM        | File Open err<br>File open error                                                                     |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                       |
|----------|----------|-----------|------------------------------------------------------------------------------------------------------|
| 8226     | Error    | CM        | File Write err<br>File write error                                                                   |
| 8227     | Error    | CM        | File Read err<br>File read error                                                                     |
| 8228     | Error    | CM        | Read record too large<br>Record too large to read                                                    |
| 8229     | Error    | CM        | Invalid Hex Char in esc seq<br>Invalid hex character found in the escape sequence                    |
| 822A     | Error    | CM        | Invalid esc sequence<br>Invalid escape sequence                                                      |
| 822B     | Error    | CM        | Read file not opened<br>Read attempted on a file that was not opened                                 |
| 822C     | Error    | CM        | Write file not opened<br>Write attempted on a file that was not opened                               |
| 822D     | Error    | CM        | File close op fail<br>File close operation failed                                                    |
| 822E     | Error    | CM        | Attempt close non-open file<br>Attempt made to close a file that was not opened                      |
| 822F     | Error    | CM        | Invalid default config<br>Invalid default configuration                                              |
| 8230     | Error    | CM        | RF back not installd<br>RF back is not installed                                                     |
| 8231     | Error    | CM        | RF driver not installd<br>RF protocol handler is not installed                                       |
| 8232     | Error    | CM        | Path (IMPATH) not found<br>Path specified by IMPATH is not found                                     |
| 8233     | Error    | CM        | Bld BIOS val out of range<br>BIOS returned an invalid value during build                             |
| 8234     | Error    | CM        | Config Item not allowed by Prot<br>Configuration item is not allowed for the selected protocol       |
| 8235     | Error    | CM        | Config Item value out of range<br>Configuration item value is out of range for the selected protocol |
| 8236     | Error    | CM        | Invalid 4th param value<br>Invalid fourth parameter value                                            |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                       |
|----------|----------|-----------|--------------------------------------------------------------------------------------|
| 8237     | Error    | CM        | Invalid 5th param value<br>Invalid fifth parameter value                             |
| 8238     | Error    | CM        | Invalid 6th param value<br>Invalid sixth parameter value                             |
| 8239     | Error    | CM        | Can't open JANUS.ERR<br>Unable to open JANUS.ERR file                                |
| 823A     | Error    | CM        | Radio.cfg has invalid checksum<br>File checksum is invalid                           |
| 823B     | Error    | CM        | Invalid RF freq in RF config<br>Invalid RF frequency specified                       |
| 823C     | Error    | CM        | Invalid RF channel in RF config<br>Invalid channel specified                         |
| 823D     | Error    | CM        | CM_ENCODED_RF_DATA_S != CM_NUM_RF_CHANNELS<br>Structure mismatch                     |
| 823E     | Error    | CM        | Allowed RF channels after unallowed channel<br>Specified RF channel is not allowed   |
| 823F     | Error    | CM        | Ping cmd not allowed here<br>Ping command not allowed here                           |
| 8240     | Error    | CM        | Ping cmd not xmitted, prot busy<br>Ping command not transmitted (protocol busy)      |
| 8241     | Error    | CM        | Missing end of config cmd<br>Missing end of configuration command                    |
| 8242     | Error    | CM        | RF freq doesn't match RF back type<br>RF frequency does not match the RF back        |
| 8243     | Error    | CM        | Can't read RF back config data<br>Unable to read configuration data from the RF back |
| 8244     | Error    | CM        | Unallowed video display mode<br>Video display mode is not allowed                    |
| 8245     | Error    | CM        | Cmd source not allowed<br>Command source is not allowed                              |
| 8246     | Error    | CM        | Invalid 7th param value<br>Invalid seventh parameter value                           |
| 8300     | Error    | SC        | Scanner load err<br>Scanner load error                                               |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                |
|----------|----------|-----------|-------------------------------------------------------------------------------|
| 8301     | Error    | SC        | Insufficient timers<br>Not enough timers for the scanner to initialize        |
| 8302     | Error    | SC        | Insufficient memory<br>Insufficient memory for the scanner to initialize      |
| 8303     | Error    | SC        | IPM connect failed<br>Scanner not connected to power management               |
| 8304     | Error    | SC        | Invalid Laser Timeout<br>Invalid laser timeout configuration                  |
| 8305     | Error    | SC        | Counts obj integrity failed<br>Count object integrity check failed            |
| 8306     | Error    | SC        | Scanner vector table corrupt                                                  |
| 8402     | Error    | DC        | Autodiscrim table full<br>Autodiscrimination table full                       |
| 8403     | Error    | DC        | Insufficient resources for decode                                             |
| 8404     | Error    | DC        | Decode init failure<br>Decode initialization failure due to scanner           |
| 8405     | Error    | DC        | No scanner<br>Decode initialization failure - no scanner present              |
| 8406     | Error    | DC        | Invalid decodes cmd<br>Invalid decodes command                                |
| 8407     | Error    | DC        | Symbology out of range<br>Invalid symbology specified                         |
| 840D     | Error    | DC        | Can't decode scan<br>Unable to decode scan                                    |
| 840E     | Error    | DC        | Missing start/stop<br>Missing start/stop character                            |
| 840F     | Error    | DC        | Too few counts to decode                                                      |
| 8410     | Error    | DC        | Invalid char<br>Invalid character found                                       |
| 8411     | Error    | DC        | Invalid acceleration                                                          |
| 8412     | Error    | DC        | Insufficient chars for valid label<br>Insufficient characters for valid label |
| 8413     | Error    | DC        | Invalid check digit                                                           |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                                 |
|----------|----------|-----------|----------------------------------------------------------------------------------------------------------------|
| 8414     | Error    | DC        | Output string too short                                                                                        |
| 8415     | Error    | DC        | No leading margin                                                                                              |
| 8416     | Error    | DC        | Invalid start/stop                                                                                             |
| 8417     | Error    | DC        | Attempted decode past end of buffer<br>Attempted decode past end of buffer (not enough counts for whole label) |
| 8418     | Error    | DC        | No trailing margin                                                                                             |
| 8419     | Error    | DC        | Invalid UPC supplemental                                                                                       |
| 841A     | Error    | DC        | Invalid parity                                                                                                 |
| 841B     | Error    | DC        | Guard char missing<br>Guard character missing                                                                  |
| 841C     | Error    | DC        | Invalid row number                                                                                             |
| 841D     | Error    | DC        | Unable to scale counts                                                                                         |
| 841E     | Error    | DC        | Invalid 2 of 5 label                                                                                           |
| 841F     | Error    | DC        | Invalid 2 of 5 length                                                                                          |
| 8420     | Error    | DC        | 2 of 5 label length exceeds maximum                                                                            |
| 8423     | Error    | DC        | No valid label region found                                                                                    |
| 8424     | Error    | DC        | Ink spread exceeded threshold                                                                                  |
| 8425     | Error    | DC        | Denominator of expression zero<br>Denominator of an expression is zero (divide by zero attempted)              |
| 8426     | Error    | DC        | ASCII conversion failed<br>Conversion to ASCII of full label failed                                            |
| 8501     | Error    | RW        | Input request err<br>Input request error                                                                       |
| 8504     | Error    | RW        | Illegal RW mode<br>Illegal reader commands parsed                                                              |
| 8507     | Error    | RW        | Rdr cmd parsing err<br>Reader commands parsing error                                                           |
| 8508     | Error    | RW        | Invalid config<br>Invalid configuration                                                                        |
| 850F     | Error    | RW        | Error in rdr cmd edit<br>Error in reader command edit                                                          |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                                                                                |
|----------|----------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8511     | Error    | RW        | Unable to allocate memory for input                                                                                                                           |
| 8512     | Error    | RW        | Prot handler not linked<br>Protocol handler not linked                                                                                                        |
| 8514     | Error    | RW        | Rdr cmd parsing err on exit accum<br>Reader command parsing error on exit accumulation                                                                        |
| 8515     | Error    | RW        | Application break detected                                                                                                                                    |
| 8516     | Error    | RW        | Invalid Rdr Wedge request<br>Invalid Reader Wedge request                                                                                                     |
| 851B     | Error    | RW        | Rdr cmd erroneously parsed<br>A reader command was incorrectly parsed when Enter was<br>parsed                                                                |
| 851F     | Error    | RW        | Label not accepted: App not requesting input<br>Label not accepted because the scan-ahead is not enabled and the<br>application is not at an input statement. |
| 8520     | Error    | RW        | Link failed, no buffers<br>Reader Wedge link failed                                                                                                           |
| 8522     | Error    | RW        | Invalid port value for input request<br>Invalid port specified in input request                                                                               |
| 8523     | Error    | RW        | Xmit buffer busy or Comm Utility err returned<br>Communications error                                                                                         |
| 8524     | Error    | RW        | Exit Accum with Comms Error<br>Communications error from an exit accumulation command                                                                         |
| 8526     | Error    | RW        | Invalid option in RW_DO<br>Invalid port specified in input request                                                                                            |
| 8527     | Error    | RW        | No label symbology, no label input yet<br>No symbology code available                                                                                         |
| 8528     | Error    | RW        | Bad parameter                                                                                                                                                 |
| 8600     | Error    | CU        | Invalid config<br>Invalid configuration                                                                                                                       |
| 8601     | Error    | CU        | Buffer length 0 error                                                                                                                                         |
| 8602     | Error    | CU        | Comm port in use                                                                                                                                              |
| 8603     | Error    | CU        | Protocol error                                                                                                                                                |
| 8604     | Error    | CU        | Comm port error                                                                                                                                               |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                                                        |
|----------|----------|-----------|-----------------------------------------------------------------------------------------------------------------------|
| 8605     | Error    | CU        | Comm port busy                                                                                                        |
| 8606     | Error    | CU        | Service not supported<br>Communication request is not supported                                                       |
| 8607     | Error    | CU        | Prot handler already loaded<br>Protocol handler already loaded                                                        |
| 8608     | Error    | CU        | Prot buffer error<br>Protocol buffer error                                                                            |
| 8609     | Error    | CU        | Unknown service request                                                                                               |
| 860A     | Error    | CU        | No data available                                                                                                     |
| 860B     | Error    | CU        | ComUtil not loaded<br>Communications utility is not loaded                                                            |
| 860C     | Error    | CU        | Resume/Suspend failure                                                                                                |
| 860D     | Error    | CU        | INT 14 already in use<br>Communication utility INT 14 is already in use                                               |
| 860E     | Error    | CU        | Incompatible rev PH or ComUtil<br>Incompatible revision between the protocol handler and the<br>communication utility |
| 860F     | Error    | CU        | Invalid EOF char                                                                                                      |
| 8610     | Error    | CU        | Buffer must be > 256 bytes                                                                                            |
| 8611     | Error    | CU        | Prot handler not active<br>Protocol handler is not active                                                             |
| 8612     | Error    | CU        | Buff size too big                                                                                                     |
| 8613     | Error    | CU        | Re-entrant request for service                                                                                        |
| 8614     | Error    | CU        | H/W I/O error<br>Hardware I/O error                                                                                   |
| 86F0     | Error    | CU        | Non-supported Comm service<br>Non-supported communication service                                                     |
| 8821     | Error    | PM        | Cannot change state                                                                                                   |
| 8822     | Error    | PM        | State mgr invalid cmd<br>Invalid state manager command                                                                |
| 8842     | Error    | PM        | IPM interface invalid cmd<br>Invalid IPM interface command                                                            |
| 8843     | Error    | PM        | Parameter out of range                                                                                                |



---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                  |
|----------|----------|-----------|---------------------------------------------------------------------------------|
| 8844     | Error    | PM        | Semaphore max value exceeded<br>Semaphore maximum value exceeded                |
| 8A00     | Error    | TM        | Invalid timer func cod<br>Invalid timer function code                           |
| 8A01     | Error    | TM        | No free timers available                                                        |
| 8A02     | Error    | TM        | Illegal timer mode specified                                                    |
| 8A03     | Error    | TM        | Timer not allocated                                                             |
| 8A04     | Error    | TM        | Timer currently active                                                          |
| 8A05     | Error    | TM        | Invalid timer delay specified                                                   |
| 8A06     | Error    | TM        | Invalid timer id specified                                                      |
| 8A07     | Error    | TM        | Timer Resume/Suspend failure                                                    |
| 8A08     | Error    | TM        | Cannot process user request<br>Timer utility cannot safely process user request |
| 8B00     | Error    | BP        | Pitch out of range                                                              |
| 8B01     | Error    | BP        | Duration out of range                                                           |
| 8B02     | Error    | BP        | Vol out of range<br>Volume out of range                                         |
| 8B03     | Error    | BP        | Not seq or preem beep<br>Not a sequential or preemptive beep                    |
| 8B04     | Error    | BP        | Invalid battery flag                                                            |
| 8B05     | Error    | BP        | No preem timer available<br>No preemptive timer available                       |
| 8B06     | Error    | BP        | No seq timer available<br>No sequential timer available                         |
| 8B07     | Error    | BP        | Sequence empty                                                                  |
| 8B08     | Error    | BP        | Beep sequence not started                                                       |
| 8B09     | Error    | BP        | Error init beep list<br>Error initializing beep list                            |
| 8B0A     | Error    | BP        | Beep avail list empty<br>Beep available list empty                              |
| 8B0B     | Error    | BP        | Bad beep mgr reques<br>Bad beep manager request                                 |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                   |
|----------|----------|-----------|--------------------------------------------------|
| 8B0C     | Error    | BP        | Beep sequence full                               |
| 8B0D     | Error    | BP        | Beep in suspend state<br>Beeper in suspend state |
| 8B0E     | Error    | BP        | Beeper Resume/Suspend failure                    |
| 8E00     | Error    | IM        | Substring not found                              |
| 8E01     | Error    | IM        | Extract string empty                             |
| 8E02     | Error    | IM        | Extract string too long                          |
| 8E03     | Error    | IM        | Append string overflow                           |
| 8E04     | Error    | IM        | Search string not found                          |
| 8E05     | Error    | IM        | Search string empty                              |
| 8E06     | Error    | IM        | Search string too long                           |
| 8E07     | Error    | IM        | String copy too long                             |
| 8E08     | Error    | IM        | Invalid parameter                                |
| 8E09     | Error    | IM        | Hex conversion length error                      |
| 8E0A     | Error    | IM        | Hex conversion overflow                          |
| 8E0B     | Error    | IM        | Invalid binary to ASCII radix                    |
| 8E0C     | Error    | IM        | Binary to ASCII field too small                  |
| 8F00     | Error    | LG        | Event queue empty                                |
| 8F01     | Error    | LG        | Prohibited area disable                          |
| 8F02     | Error    | LG        | Reader service disable                           |
| 8F03     | Error    | LG        | Configuration management disable                 |
| 8F04     | Error    | LG        | Scanner disable                                  |
| 8F05     | Error    | LG        | Decodes disable                                  |
| 8F06     | Error    | LG        | Reader Wedge disable                             |
| 8F07     | Error    | LG        | Communications utility disable                   |
| 8F08     | Error    | LG        | Protocol handler disable                         |
| 8F09     | Error    | LG        | Power management disable                         |
| 8F0A     | Error    | LG        | BIOS disable                                     |
| 8F0B     | Error    | LG        | Timer disable                                    |
| 8F0C     | Error    | LG        | Beeper disable                                   |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                                              |
|----------|----------|-----------|---------------------------------------------------------------------------------------------|
| 8F0D     | Error    | LG        | IRL desktop disable                                                                         |
| 8F0E     | Error    | LG        | Prompting configuration disable                                                             |
| 8F0F     | Error    | LG        | Intermec library disabled                                                                   |
| 8F10     | Error    | LG        | Event logger disable                                                                        |
| 8F11     | Error    | LG        | Keyboard disable                                                                            |
| 8F12     | Error    | LG        | System configuration disable                                                                |
| 8F13     | Error    | LG        | Keypad disable                                                                              |
| 8F14     | Error    | LG        | Display disable                                                                             |
| 8F15     | Error    | LG        | Communications manager disable                                                              |
| 8F16     | Error    | LG        | Workbench disable                                                                           |
| 8F17     | Error    | LG        | Severity success disable                                                                    |
| 8F18     | Error    | LG        | Severity warning disable                                                                    |
| 8F19     | Error    | LG        | Severity error disable                                                                      |
| 8F1A     | Error    | LG        | Severity fatal disable                                                                      |
| 8F1B     | Error    | LG        | Wrong subsystem ID entered                                                                  |
| 8F1C     | Error    | LG        | Wrong severity ID entered                                                                   |
| 9002     | Error    | KB        | Can't disable not empty buffer<br>Cannot disable because buffer is not empty                |
| 9003     | Error    | KB        | Keypad buffer full<br>Keyboard buffer is full, entire string rejected                       |
| 9004     | Error    | KB        | Expanded buffer not installed<br>Expanded keyboard buffer not installed                     |
| 9005     | Error    | KB        | Invalid mode value was passed                                                               |
| 9006     | Error    | KB        | Exp buffer flush not install<br>Expanded keyboard buffer flush failed                       |
| 9007     | Error    | KB        | Undefined message                                                                           |
| 9008     | Error    | KB        | 16.B3 err:Source str > dest bufr<br>Source string exceeds source or destination buffer size |
| 9009     | Error    | KB        | 16.B3 err:Unknown str descriptor<br>String descriptor type is unknown                       |
| 900C     | Error    | KB        | Invalid option requested from int 16 B4xxh                                                  |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                                              |
|----------|----------|-----------|-----------------------------------------------------------------------------|
| 9100     | Error    | SS        | Invalid service number                                                      |
| 9101     | Error    | SS        | ASIC bit number out of range                                                |
| 9102     | Error    | SS        | Unknown ASIC I/O address                                                    |
| 9103     | Error    | SS        | Undefined message code                                                      |
| 9104     | Error    | SS        | Invalid COM Port id<br>Invalid communications port ID                       |
| 9105     | Error    | SS        | Invalid Args<br>Invalid Argument                                            |
| 9200     | Error    | KP        | Timeout mid. transaction<br>Timeout occurred in the middle of a transaction |
| 9201     | Error    | KP        | Timeout 1st transaction<br>Timeout occurred on the first transaction        |
| 9202     | Error    | KP        | Keypad busy                                                                 |
| 9203     | Error    | KP        | Forced transaction abort                                                    |
| 9204     | Error    | KP        | Failed to process command                                                   |
| 9205     | Error    | KP        | Invalid func number<br>Invalid function number                              |
| 9206     | Error    | KP        | Invalid keypad comms status<br>Invalid keypad communications status         |
| 9207     | Error    | KP        | Passed in wrong parameter                                                   |
| 9208     | Error    | KP        | BIOS returned invalid value                                                 |
| 9300     | Error    | DP        | Abs value out range<br>Absolute value out range                             |
| 9301     | Error    | DP        | Invalid display size mode                                                   |
| 9302     | Error    | DP        | Display function undefined                                                  |
| 9303     | Error    | DP        | Invalid backlight timeout value                                             |
| 9304     | Error    | DP        | Display BIOS returned an invalid status                                     |
| 9305     | Error    | DP        | Invalid viewport mode                                                       |
| 9306     | Error    | DP        | Invalid scroll mode                                                         |
| 9307     | Error    | DP        | Invalid video mode                                                          |
| 9308     | Error    | DP        | Invalid size mode                                                           |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                       |
|----------|----------|-----------|------------------------------------------------------|
| 9309     | Error    | DP        | Invalid height mode<br>Invalid character height mode |
| 9A03     | Error    | EX        | Transmit fail                                        |
| 9A04     | Error    | EX        | Receive timeout                                      |
| 9A05     | Error    | EX        | Packet header error                                  |
| 9A06     | Error    | EX        | Transaction ID missing                               |
| 9A08     | Error    | EX        | Standby file missing                                 |
| 9A09     | Error    | EX        | Standby file I/O error                               |
| 9A40     | Error    | EX        | Buffer overflow<br>Host response buffer is too small |
| 9A41     | Error    | EX        | Buffer overflow and upload standby error             |

## ***Status Codes Listed by Subsystem***

---

The status codes in the following tables are organized by subsystems. To find a particular status code, identify the subsystem by looking at bits 8 through 13 and refer to that section:

| Code | Abbrev. | Name                     |
|------|---------|--------------------------|
| 0100 | RS      | Reader Services          |
| 0200 | CM      | Configuration Management |
| 0300 | SC      | Scanner                  |
| 0400 | DC      | Decodes                  |
| 0500 | RW      | Reader Wedge             |
| 0600 | CU      | Communication            |
| 0800 | PM      | Power Management         |
| 0A00 | TM      | Timer                    |
| 0B00 | BP      | Beep                     |
| 0E00 | IM      | Intermec Library         |
| 0F00 | LG      | Event Logger             |
| 1000 | KB      | Keyboard Buffer          |
| 1100 | SS      | System Configuration     |
| 1200 | KP      | Keypad Services          |
| 1300 | DP      | Display                  |
| 1A00 | EX      | DCM Support              |



---

## ***Subsystem 0100 RS (Reader Services)***

| Hex Code | Message                                       |
|----------|-----------------------------------------------|
| 0100     | Reader service successful                     |
| 0103     | Reader services resume successful             |
| 8100     | Invalid function Hex code received            |
| 8101     | Reader services is not installed              |
| 8102     | Reader services resume failed                 |
| 8103     | Reader services or application is out of date |
| 8104     | Reader Wedge TSR is not installed             |

---

## ***Subsystem 0200 CM (Configuration Management)***

| Hex Code | Message                                                    |
|----------|------------------------------------------------------------|
| 0200     | Request successful                                         |
| 0201     | End of record encountered                                  |
| 0202     | End of file encountered                                    |
| 4200     | Not all configuration items copied                         |
| 4201     | Reader command terminated configuration command string     |
| 4292     | Client should not be notified                              |
| 8200     | Invalid object                                             |
| 8201     | Invalid subfunction                                        |
| 8202     | Invalid parameter length                                   |
| 8203     | Invalid parameter value                                    |
| 8204     | Invalid first parameter                                    |
| 8205     | Invalid Code 39 configuration (HIBC and no check digit)    |
| 8206     | Invalid second parameter                                   |
| 8207     | Invalid Code 39 configuration (HIBC and full ASCII)        |
| 8208     | Invalid Code 39 configuration (HIBC and mixed full ASCII)  |
| 8209     | Invalid third parameter                                    |
| 820A     | Invalid Codabar configuration (ABC and discard start/stop) |
| 820B     | Protocol not loaded                                        |
| 820C     | Invalid port or protocol specified                         |
| 820D     | No ending quote found                                      |
| 820E     | No double quote (might be missing an opening quote)        |
| 820F     | Invalid parser state                                       |
| 8210     | Invalid configuration command                              |
| 8211     | Client deemed configuration command invalid                |
| 8212     | Invalid beep duration                                      |
| 8213     | Invalid beep frequency                                     |
| 8214     | Invalid beep volume                                        |
| 8215     | Beep volume already off                                    |
| 8216     | Beep volume already extra loud                             |
| 8217     | Invalid beep specifier (must be "L" or "H")                |



---

*Subsystem 0200 CM (Configuration Management) (continued)*

| Hex Code | Message                                                                 |
|----------|-------------------------------------------------------------------------|
| 8218     | Inappropriate configuration for the current protocol                    |
| 8219     | BIOS rejected the set configuration command                             |
| 821A     | Configuration command string object is too small                        |
| 821B     | Configuration ID is invalid                                             |
| 821C     | Invalid build parameter                                                 |
| 821D     | No build function                                                       |
| 821E     | No more build entries                                                   |
| 821F     | No more build entries in wedge lookup table                             |
| 8220     | No more build entries in wedge lookup table for “build next” WM command |
| 8221     | No entries found in the LUM key table                                   |
| 8222     | No match in lookup table for specified character                        |
| 8223     | At least one parameter rejected by client (see JANUS.ERR)               |
| 8224     | Configuration item is not found                                         |
| 8225     | File open error                                                         |
| 8226     | File write error                                                        |
| 8227     | File read error                                                         |
| 8228     | Record too large to be read                                             |
| 8229     | Invalid hex character found in the escape sequence                      |
| 822A     | Invalid escape sequence                                                 |
| 822B     | Read attempted on a file that was not opened                            |
| 822C     | Write attempted on a file that was not opened                           |
| 822D     | File close operation failed                                             |
| 822E     | Attempt made to close a file that is not open                           |
| 822F     | Invalid default configuration                                           |
| 8230     | RF back is not installed                                                |
| 8231     | RF protocol handler is not installed                                    |
| 8232     | Path specified by IMPATH is not found                                   |
| 8233     | BIOS returned an invalid value during build                             |
| 8234     | Configuration item is not allowed for the selected protocol             |

---

*Subsystem 0200 CM (Configuration Management) (continued)*

| Hex Code | Message                                                            |
|----------|--------------------------------------------------------------------|
| 8235     | Configuration item value is out of range for the selected protocol |
| 8236     | Invalid fourth parameter value                                     |
| 8237     | Invalid fifth parameter value                                      |
| 8238     | Invalid sixth parameter value                                      |
| 8239     | Unable to open JANUS.ERR                                           |
| 823A     | File checksum invalid                                              |
| 823B     | Invalid RF frequency                                               |
| 823C     | Invalid channel is specified                                       |
| 823D     | Structure mismatch                                                 |
| 823E     | Specified RF channel is not allowed                                |
| 823F     | Ping command not allowed here                                      |
| 8240     | Ping command not transmitted (protocol busy)                       |
| 8241     | Missing end of configuration command                               |
| 8242     | RF frequency does not match the RF back type                       |
| 8243     | Unable to read configuration data from the RF back                 |
| 8244     | Video display mode is not allowed                                  |
| 8245     | Command source is not allowed                                      |



---

## ***Subsystem 0300 SC (Scanner)***

| Hex Code | Message                                           |
|----------|---------------------------------------------------|
| 0300     | Scan successful                                   |
| 8300     | Scanner load error                                |
| 8301     | Not enough timers for the scanner to initialize   |
| 8302     | Insufficient memory for the scanner to initialize |
| 8303     | Scanner cannot connect to power management        |
| 8304     | Invalid laser timeout configuration               |
| 8305     | Counts object integrity check failed              |
| 8306     | Scanner vector table is corrupt                   |

---

## ***Subsystem 0400 DC (Decodes)***

| Hex Code | Message                                                                     |
|----------|-----------------------------------------------------------------------------|
| 0400     | Successful command                                                          |
| 0401     | Symbology is already enabled                                                |
| 0402     | Symbology is not enabled                                                    |
| 040A     | Successful decode                                                           |
| 040B     | Intermediate row reread                                                     |
| 040C     | Intermediate row decoded                                                    |
| 0421     | Default command symbology                                                   |
| 0422     | Mixed ASCII format                                                          |
| 8402     | Autodiscrimination table full                                               |
| 8403     | Insufficient resources for decode                                           |
| 8404     | Decode initialization failure due to scanner                                |
| 8405     | Decode initialization failure—no scanner                                    |
| 8406     | Invalid decodes command                                                     |
| 8407     | Invalid symbology specified                                                 |
| 840D     | Unable to decode scan                                                       |
| 840E     | Missing start/stop character                                                |
| 840F     | Too few counts to decode                                                    |
| 8410     | Invalid character found                                                     |
| 8411     | Invalid acceleration                                                        |
| 8412     | Insufficient characters for valid label                                     |
| 8413     | Invalid check digit                                                         |
| 8414     | Output string too short                                                     |
| 8415     | No leading margin                                                           |
| 8416     | Invalid start/stop                                                          |
| 8417     | Attempted decode past end of buffer (not enough counts for the whole label) |
| 8418     | No trailing margin                                                          |
| 8419     | Invalid UPC supplemental                                                    |
| 841A     | Invalid parity                                                              |
| 841B     | Guard character missing                                                     |



---

*Subsystem 0400 DC (Decodes) (continued)*

| Hex Code | Message                                  |
|----------|------------------------------------------|
| 841C     | Invalid row number                       |
| 841D     | Unable to scale counts                   |
| 841E     | Invalid 2 of 5 label                     |
| 841F     | Invalid 2 of 5 length                    |
| 8420     | 2 of 5 label length exceeds maximum      |
| 8423     | No valid label region found              |
| 8424     | Ink spread exceeded threshold            |
| 8425     | Denominator of an expression is zero     |
| 8426     | Conversion to ASCII of full label failed |

---

## ***Subsystem 0500 RW (Reader Wedge)***

| Hex Code | Message                                                            |
|----------|--------------------------------------------------------------------|
| 0500     | Reader Wedge successful                                            |
| 0505     | No reader commands parsed                                          |
| 0506     | Valid reader commands parsed                                       |
| 0509     | Accumulating reader command                                        |
| 050A     | Reader command override                                            |
| 050B     | Reader command enter accumulation                                  |
| 050C     | Reader command exit accumulation                                   |
| 050D     | Accumulating multiple-read labels                                  |
| 0510     | An Enter reader command was parsed                                 |
| 0513     | Protected field has been parsed                                    |
| 0517     | Keycode label has been parsed                                      |
| 0518     | An isolated Enter command was parsed                               |
| 0519     | A successful reader command parse on exit from accumulation        |
| 051A     | A reader command has been successfully parsed when Enter is parsed |
| 051C     | An Enter Accumulate has been parsed when accumulating              |
| 051D     | A label terminating a multiple-read sequence has been scanned      |
| 051E     | A label beginning a multiple-read sequence has been scanned        |
| 0521     | No communications status to report                                 |
| 0525     | Reader commands forwarded to the application have been parsed      |
| 4502     | Input timeout                                                      |
| 4503     | No input data                                                      |
| 450E     | The application should be notified                                 |
| 4529     | Input from the source is other than the ones requested             |
| 452A     | RWTSR is already loaded                                            |
| 452B     | Prepare for reboot command received                                |
| 452C     | Cancel reboot command received                                     |
| 8501     | Input request error                                                |
| 8504     | Illegal reader commands parsed                                     |
| 8507     | Reader commands parsing error                                      |
| 8508     | Invalid configuration error                                        |

---

*Subsystem 0500 RW (Reader Wedge) (continued)*

| Hex Code | Message                                                                                               |
|----------|-------------------------------------------------------------------------------------------------------|
| 850F     | Error in reader command edit                                                                          |
| 8511     | Unable to allocate memory for input                                                                   |
| 8512     | Protocol handler is not linked                                                                        |
| 8514     | Reader command parse error on exit accumulation                                                       |
| 8515     | Application break detected                                                                            |
| 8516     | Invalid Reader Wedge request                                                                          |
| 851B     | A reader command has been erroneously parsed when Enter is parsed                                     |
| 851F     | Label not accepted because the scan-ahead is not enabled and application is not at an input statement |
| 8520     | Reader Wedge link failed                                                                              |
| 8522     | Invalid port specified in input request                                                               |
| 8523     | Communications error                                                                                  |
| 8524     | Communications error from an exit accumulation command                                                |
| 8526     | Library coding error                                                                                  |
| 8527     | No symbology code available                                                                           |
| 8528     | Bad parameter                                                                                         |

---

## ***Subsystem 0600 CU (Communications)***

| Hex Code | Message                                                                          |
|----------|----------------------------------------------------------------------------------|
| 0600     | Communication operation success                                                  |
| 0601     | Communication buffer done                                                        |
| 4600     | Buffer canceled                                                                  |
| 4601     | Communication timeout                                                            |
| 4602     | Communication had no client to cancel                                            |
| 4603     | No protocol handler to configure                                                 |
| 4604     | Protocol handler is not yet loaded                                               |
| 4605     | Protocol handler already receiving                                               |
| 4606     | Protocol handler not active for link request                                     |
| 8600     | Invalid configuration                                                            |
| 8601     | Buffer length zero error                                                         |
| 8602     | Communications port is in use                                                    |
| 8603     | Protocol error                                                                   |
| 8604     | Communications port error                                                        |
| 8605     | Communications port is busy                                                      |
| 8606     | Communication request is not supported                                           |
| 8607     | Protocol handler already loaded                                                  |
| 8608     | Protocol buffer error                                                            |
| 8609     | Unknown service request                                                          |
| 860A     | No data available                                                                |
| 860B     | Communication utility is not loaded                                              |
| 860C     | Resume/suspend failure                                                           |
| 860D     | Communication utility INT 14 is already in use                                   |
| 860E     | Incompatible revision between the protocol handler and the communication utility |
| 860F     | Invalid end of file character                                                    |
| 8610     | Buffer must be 256 bytes or greater                                              |
| 8611     | Protocol handler not active                                                      |
| 8612     | Buffer size is too big                                                           |





---

*Subsystem 0600 CU (Communications) (continued)*

| Hex Code | Message                            |
|----------|------------------------------------|
| 8613     | Reentrant request for service      |
| 8614     | Hardware I/O error                 |
| 86F0     | Nonsupported communication service |

---

## ***Subsystem 0800 PM (Power Management)***

| Hex Code | Message                       |
|----------|-------------------------------|
| 0800     | Power management success      |
| 8821     | Cannot change state           |
| 8822     | Invalid state manager command |
| 8842     | Invalid IPM interface command |
| 8843     | Parameter out of range        |
| 8844     | Semaphore maximum exceeded    |

---

## ***Subsystem 0A00 TM (Timer)***

| Hex Code | Message                                          |
|----------|--------------------------------------------------|
| 0A00     | Timer operation success                          |
| 4A00     | Timer not currently active                       |
| 8A00     | Invalid timer function code                      |
| 8A01     | No free timers available                         |
| 8A02     | Illegal timer mode specified                     |
| 8A03     | Timer not allocated                              |
| 8A04     | Timer is currently active                        |
| 8A05     | Invalid timer delay specified                    |
| 8A06     | Invalid timer ID specified                       |
| 8A07     | Timer resume/suspend failure                     |
| 8A08     | Timer utility cannot safely process user request |

## ***Subsystem 0B00 BP (Beep)***

| Hex Code | Message                               |
|----------|---------------------------------------|
| 0B00     | Beeper call success                   |
| 8B00     | Pitch out of range                    |
| 8B01     | Duration out of range                 |
| 8B02     | Volume out of range                   |
| 8B03     | Not a sequential or a preemptive beep |
| 8B04     | Invalid battery flag                  |
| 8B05     | No preemptive timer available         |
| 8B06     | No sequential timer available         |
| 8B07     | Sequence empty                        |
| 8B08     | Beep sequence not started             |
| 8B09     | Error initializing beep list          |
| 8B0A     | Beep available list empty             |
| 8B0B     | Bad beep manager request              |
| 8B0C     | Beep sequence full                    |
| 8B0D     | Beeper in suspend state               |
| 8B0E     | Beeper resume/suspend failure         |

---

## ***Subsystem 0E00 IM (Intermec Library)***

| Hex Code | Message                         |
|----------|---------------------------------|
| 0E00     | String extract complete         |
| 0E01     | String append complete          |
| 0E02     | String search found             |
| 0E03     | String copy complete            |
| 0E04     | Successful operation            |
| 8E00     | Substring not found             |
| 8E01     | String extract empty            |
| 8E02     | String extract too long         |
| 8E03     | String append overflow          |
| 8E04     | String search not found         |
| 8E05     | String search empty             |
| 8E06     | String search too long          |
| 8E07     | String copy too long            |
| 8E08     | Invalid parameter               |
| 8E09     | Hex conversion length error     |
| 8E0A     | Hex conversion overflow         |
| 8E0B     | Invalid binary to ASCII radix   |
| 8E0C     | Binary to ASCII field too small |

---

## ***Subsystem 0F00 LG (Event Logger)***

| Hex Code | Message                          |
|----------|----------------------------------|
| 0F00     | Successful logger operation      |
| 8F00     | Event queue empty                |
| 8F01     | Prohibited area disable          |
| 8F02     | Reader service disable           |
| 8F03     | Configuration management disable |
| 8F04     | Scanner disable                  |
| 8F05     | Decodes disable                  |
| 8F06     | Reader Wedge disable             |
| 8F07     | Communications utility disable   |
| 8F08     | Protocol handler disable         |
| 8F09     | Power management disable         |
| 8F0A     | BIOS disable                     |
| 8F0B     | Timer disable                    |
| 8F0C     | Beeper disable                   |
| 8F0D     | IRL desktop disable              |
| 8F0E     | Prompting configuration disable  |
| 8F0F     | Intermec library disabled        |
| 8F10     | Event logger disable             |
| 8F11     | Keyboard disable                 |
| 8F12     | System configuration disable     |
| 8F13     | Keypad disable                   |
| 8F14     | Display disable                  |
| 8F15     | Communications manager disable   |
| 8F16     | Workbench disable                |
| 8F17     | Severity success disable         |
| 8F18     | Severity warning disable         |
| 8F19     | Severity error disable           |
| 8F1A     | Severity fatal disable           |
| 8F1B     | Wrong subsystem ID entered       |
| 8F1C     | Wrong severity ID entered        |

---

## ***Subsystem 1000 KB (Keyboard Buffer)***

| Hex Code | Message                                                 |
|----------|---------------------------------------------------------|
| 1000     | Expanded keyboard buffer success                        |
| 100A     | Expanded buffer enabled                                 |
| 100B     | Expanded buffer disabled                                |
| 5001     | Expanded keyboard buffer installed or disabled          |
| 9002     | Cannot disable because buffer is not empty              |
| 9003     | Keyboard buffer is full (entire string rejected)        |
| 9004     | Expanded keyboard buffer not installed                  |
| 9005     | Invalid mode value was passed                           |
| 9006     | Expanded keyboard buffer flush not successful           |
| 9007     | Undefined message                                       |
| 9008     | Source string exceeds source or destination buffer size |
| 9009     | String descriptor type is unknown                       |
| 900C     | Invalid option requested from INT 16 B4xxh              |

---

## ***Subsystem 1100 SS (System Configuration)***

| Hex Code | Message                         |
|----------|---------------------------------|
| 1100     | System configuration successful |
| 9100     | Invalid service number          |
| 9101     | ASIC bit number is out of range |
| 9102     | Unknown ASIC I/O address        |
| 9103     | Undefined message code          |
| 9104     | Invalid communications port ID  |
| 9105     | Invalid argument                |



---

## ***Subsystem 1200 KP (Keypad Services)***

| Hex Code | Message                                         |
|----------|-------------------------------------------------|
| 1200     | Successful keypad operation                     |
| 5201     | Backdoor communications failure                 |
| 9200     | Timeout occurred in the middle of a transaction |
| 9201     | Timeout occurred on the first transaction       |
| 9202     | Keypad busy                                     |
| 9203     | Forced transaction abort                        |
| 9204     | Failed to process a command                     |
| 9205     | Invalid function number                         |
| 9206     | Invalid keypad communications status            |
| 9207     | Wrong parameter passed in                       |
| 9208     | BIOS returned an invalid value                  |

---

## ***Subsystem 1300 DP (Display)***

| Hex Code | Message                                 |
|----------|-----------------------------------------|
| 1300     | Successful display operation            |
| 9300     | Absolute value out of range             |
| 9301     | Invalid display size mode               |
| 9302     | Display function undefined              |
| 9303     | Invalid backlight timeout value         |
| 9304     | Display BIOS returned an invalid status |
| 9305     | Invalid viewport mode                   |
| 9306     | Invalid scroll mode                     |
| 9307     | Invalid video mode                      |
| 9308     | Invalid size mode                       |
| 9309     | Invalid character height mode           |



***Index***



## Index

---

### A

About This Manual, xiv  
Addressing variables, 3-3, 3-4

### B

Backlight  
  imBacklightOff, 2-20, 3-23  
  imBacklightOn, 2-21, 3-24  
  imBacklightToggle, 2-22, 3-25

Bar code input  
  Visual Basic, 3-3, 3-5 to 3-8

Battery  
  imPowerStatus, 2-82, 3-86

Beeper  
  imSound, 2-119, 3-125

Break  
  imApplBreakStatus, 2-18, 3-21

Build procedure  
  QuickBasic, 2-3 to, 2-7  
  Visual Basic, 3-10 to 3-12

### C

Carriage return  
  Visual Basic, 3-7

Caution, 1-5, 1-7, 2-15, 3-18

Certified functions  
  QuickBasic, 2-12  
  Visual Basic, 3-17

Command  
  imCommand, 2-28, 3-30

Compiler  
  QuickBasic, 2-4, 2-6  
  Visual Basic, 3-11

Configuration  
  imGetConfigInfo, 2-33, 3-35

Contrast  
  imDecreaseContrast, 2-31, 3-33  
  imGetContrast, 2-34, 3-37  
  imIncreaseContrast, 2-51, 3-55  
  imSetContrast, 2-105, 3-110

Control key  
  imGetControlKey, 2-36, 3-39  
  imSetControlKey, 2-107, 3-112

Conventions, manual, xv

Cursor  
  imCursorToViewport, 2-30, 3-32  
  imGetFollowCursor, 2-40, 3-44  
  imGetViewportLock, 2-48, 3-52  
  imSetFollowCursor, 2-113, 3-119  
  imSetViewportLock, 2-117, 3-123  
  imViewportHome, 2-133, 3-139  
  imViewportToCursor, 2-140, 3-146

### D

Debugging  
  using JANUS Application Simulator, 2-7,  
  3-13

Defined terms, xv

Desktop mode, 2-42, 2-115, 3-46, 3-121

Differences  
  Visual Basic and QuickBasic, 3-3

Disk  
  PSK, 1-8

Display modes  
  imGetDisplayMode, 2-37, 3-41  
  imSetDisplayMode, 2-108, 3-113

Display type  
  imGetDisplayType, 2-39, 3-43

## E

### Error message

- imMessage, 2-78, 3-82
- linker, 2-5, 2-7, 3-12

### Examples

- imApplBreakStatus, 2-19, 3-22
- imBacklightOff, 2-20, 3-23
- imBacklightOn, 2-21, 3-24
- imBacklightToggle, 2-22, 3-25
- imCancelRxBuffer, 2-23, 3-26
- imCancelTxBuffer, 2-26, 3-29
- imCommand, 2-29, 3-31
- imCursorToViewport, 2-30, 3-32
- imDecreaseContrast, 2-32, 3-34
- imGetConfigInfo, 2-33, 3-36
- imGetContrast, 2-35, 3-38
- imGetControlKey, 2-36, 3-40
- imGetDisplayMode, 2-38, 3-42
- imGetDisplayType, 2-39
- imGetFollowCursor, 2-40, 3-44
- imGetInputMode, 2-42, 3-46
- imGetKeyclick, 2-43, 3-47
- imGetPostamble, 2-46, 3-50
- imGetPreamble, 2-47, 3-51
- imGetViewportLock, 2-49, 3-53
- imGetWarmBoot, 2-50, 3-54
- imIncreaseContrast, 2-52, 3-56
- imInputStatus, 2-54, 3-58
- imIrlA, 2-58, 3-62
- imIrlK, 2-62, 3-66
- imIrlN, 2-67, 3-71
- imIrlV, 2-72, 3-76
- imIrlY, 2-75, 3-79
- imMessage, 2-78, 3-82
- imNumberPadOff, 2-79, 3-83
- imNumberPadOn, 2-81, 3-85
- imPowerStatus, 2-83, 3-87
- imProtocolExtendedStatus, 2-85, 3-89
- imReceiveBuffer, 2-88, 3-92
- imReceiveBufferNoprot, 2-90, 3-95
- imReceiveBufferNoWait, 2-93, 3-98
- imReceiveByte, 2-96, 3-101
- imReceiveInput, 2-99, 3-104
- imRsInstalled, 2-100, 3-105

### Examples *continued*

- imSerialProtocolControl, 2-104, 3-109
- imSetContrast, 2-106, 3-111
- imSetDisplayMode, 2-110, 3-115
- imSetFollowCursor, 2-113, 3-119
- imSetWarmBoot, 2-118, 3-124
- imSound, 2-120, 3-126
- imTransmitBuffer, 2-123, 3-129
- imTransmitBufferNoprot, 2-127, 3-133
- imTransmitBufferNoWait, 2-125, 3-131
- imTransmitByte, 2-129, 3-135
- imViewportEnd, 2-131, 3-137
- imViewportGetxy, 2-132, 3-138
- imViewportHome, 2-133, 3-139
- imViewportMove, 2-135, 3-141
- imViewportPageDown, 2-136, 3-142
- imViewportPageUp, 2-137, 3-143
- imViewportSetxy, 2-139, 3-145
- imViewportToCursor, 2-140, 3-146
- power management, 3-6, 3-9
- scanned input, 3-6
- text box, 3-7

## F

Far pointers, 3-3, 3-4

### Function libraries

supported languages, 1-6

Functions, *See also QuickBasic Functions and Visual Basic Functions*

certified QuickBasic, 2-12, 2-14

QuickBasic, 2-15 to 2-140

Visual Basic, 3-18 to 3-146

## H

Hexadecimal numbers, convention for, xvi

## I

IM20\_BAS.LIB, 3-4

IM20VBAS.BI, 3-3, 3-4

### Installing

Programmer's Software Kit, 1-8

INT 10H, 2-110

### Integer

size limits, 3-3, 3-5

Interrupts, software, 1-6

IRL command

A, 2-55, 3-59

K, 2-60, 3-64

N, 2-64, 3-68

V, 2-69, 3-73

Y, 2-73, 3-77

## J

JANUS Application Simulator, 2-7, 3-13

JANUS reader

about, 1-3

## K

Key code

changing, 3-7, 3-8

Key Code Look-Up Table, 3-8

Key press

Visual Basic, 3-5

Keyboard, using, xv

Keypad, using, xv

## L

Label

imGetLabelSymbology, 2-44, 3-48

Libraries

PSK Language Libraries disk, 1-8

Library

QuickBasic, 2-15

Visual Basic, 3-18

Link segments, 2-5, 2-7, 3-12

Linker

error message, 2-5, 2-7, 3-12

## M

Manuals, other Intermec, xvii

Mode

Desktop, 2-42, 2-115, 3-46, 3-121

imGetInputMode, 2-41, 3-45

imSetInputMode, 2-114, 3-120

Programmer, 2-41, 2-115, 3-45, 3-121

Wedge, 2-41, 2-114, 3-45, 3-120

Moving to next control

Visual Basic, 3-7, 3-8

## N

Number pad

imNumberPadOff, 2-79, 3-83

imNumberPadOn, 2-80, 3-84

## P

PHIMEC.EXE, 2-8, 3-14

PHPCSTD.EXE, 2-8, 3-14

Pointers

Visual Basic, 3-3, 3-4

Postamble

imGetPostamble, 2-46, 3-50

Visual Basic, 3-7

Power management, 3-3

Visual Basic, 3-8, 3-9

Preamble

imGetPreamble, 2-47, 3-51

Programmer mode, 2-41, 2-115, 3-45, 3-121

Protocol

imProtocolExtendedStatus, 2-84, 3-88

imSerialProtocolControl, 2-102, 3-107

Protocol handlers, 2-8, 2-9, 3-14, 3-15

## Q

QuickBasic, 2-3, 2-4, 2-5, 2-7

building a program, 2-3, 2-4, 2-5, 2-6, 2-7

certified functions, 2-12, 2-14

compiler, 2-4, 2-6

library, 2-15

unsupported features, 2-11

QuickBasic and Visual Basic differences, 3-3

QuickBasic functions

imApplBreakStatus, 2-18

imBacklightOff, 2-20

imBacklightOn, 2-21

imBacklightToggle, 2-22

imCancelRxBuffer, 2-23

imCancelTxBuffer, 2-26

imCommand, 2-28

imCursorToViewport, 2-30

imDecreaseContrast, 2-31

imGetConfigInfo, 2-33

imGetContrast, 2-34

imGetControlKey, 2-36

QuickBasic functions *continued*

- imGetDisplayMode, 2-37
- imGetDisplayType, 2-39
- imGetFollowCursor, 2-40
- imGetInputMode, 2-41
- imGetKeyclick, 2-43
- imGetLabelSymbology, 2-44
- imGetLength, 2-45
- imGetPostamble, 2-46
- imGetPreamble, 2-47
- imGetViewportLock, 2-48
- imGetWarmBoot, 2-50
- imIncreaseContrast, 2-51
- imInputStatus, 2-53
- imIrlA, 2-55
- imIrlK, 2-60
- imIrlN, 2-64
- imIrlV, 2-69
- imIrlY, 2-73
- imLinkComm, 2-76
- imMessage, 2-78
- imNumberPadOff, 2-79
- imNumberPadOn, 2-80
- imPowerStatus, 2-82
- imProtocolExtendedStatus, 2-84
- imReceiveBuffer, 2-87
- imReceiveBufferNoprot, 2-89
- imReceiveBufferNoWait, 2-92
- imReceiveByte, 2-95
- imReceiveInput, 2-97
- imRsInstalled, 2-100
- imRxCheckStatus, 2-101
- imSerialProtocolControl, 2-102
- imSetContrast, 2-105
- imSetControlKey, 2-107
- imSetDisplayMode, 2-108
- imSetFollowCursor, 2-113
- imSetInputMode, 2-114
- imSetKeyclick, 2-116
- imSetViewportLock, 2-117
- imSetWarmBoot, 2-118
- imSound, 2-119
- imStandbyWait, 2-121
- imTransmitBuffer, 2-122
- imTransmitBufferNoprot, 2-126

QuickBasic functions *continued*

- imTransmitBufferNoWait, 2-124
- imTransmitByte, 2-128
- imUnlinkComm, 2-130
- imViewportEnd, 2-131
- imViewportGetxy, 2-132
- imViewportHome, 2-133
- imViewportMove, 2-134
- imViewportPageDown, 2-136
- imViewportPageUp, 2-137
- imViewportSetxy, 2-138
- imViewportToCursor, 2-140

**R**

- .RSP file, 2-4, 2-6, 3-11
- Reader
  - about, 1-3
  - Virtual Wedge, 1-4
- Reader Services
  - imRsInstalled, 2-100, 3-105
  - using function libraries, 1-5
  - using software interrupts, 1-5
- Reader Wedge, 2-9, 3-15
- Receive buffer
  - imCancelRxBuffer, 2-23, 3-26
  - imReceiveBuffer, 2-87, 3-91
  - imReceiveBufferNoprot, 2-89, 3-94
  - imReceiveBufferNoWait, 2-92, 3-97
  - imReceiveByte, 2-95, 3-100
  - imReceiveInput, 2-97, 3-102
- Requirements
  - QuickBasic runtime, 2-8, 2-9, 2-10, 2-11
  - Visual Basic runtime, 3-14, 3-15, 3-16, 3-17
- Response file, 2-4, 2-6, 3-11
- Run
  - caution, 1-5, 1-7, 2-15, 3-18
- Runtime requirements
  - QuickBasic, 2-8, 2-9, 2-10, 2-11
  - Visual Basic, 3-14, 3-15, 3-16, 3-17
- RWTSR.EXE, 2-9, 3-15
- S**
- Scanner input, 3-3
  - Visual Basic, 3-5, 3-6, 3-7, 3-8
- setdisp.bas, 2-110, 3-115



Setting timeout values, 3-3, 3-5  
 Simulating a key press  
   Visual Basic, 3-5  
 Simulator, 2-7, 2-15, 3-13, 3-18  
 Software interrupts, 1-6  
 SSEGADD, 3-4  
 Standby

  imStandbyWait, 2-121, 3-127

Status codes, A-3  
   bit values, A-3  
   listed by subsystem, A-22  
   listed numerically, A-4  
 Subsystem  
   Beep, A-36  
   Communication, A-32  
   Configuration management, A-24  
   Decodes, A-28  
   Display, A-42  
   Event logger, A-38  
   Intermec library, A-37  
   Keyboard, A-39  
   Keypad, A-41  
   Power management, A-34  
   Reader services, A-23  
   Reader Wedge, A-30, A-31  
   Scanner, A-27  
   System configuration, A-40  
   Timer, A-35

## T

Tab key  
   Visual Basic, 3-7  
 Terms and conventions, xv  
 Text box  
   Visual Basic, 3-7  
 Timeout as integer, 3-3, 3-5  
 Transmit buffer  
   imTransmitBuffer, 2-122, 3-128  
   imTransmitBufferNoprot, 2-126, 3-132  
   imTransmitBufferNoWait, 2-124, 3-130  
   imTransmitByte, 2-128, 3-134

## U

Unsupported features  
   QuickBasic, 2-11

## V

Variable addresses  
   Visual Basic, 3-3, 3-4  
 VARPTR, 3-4  
 VARSEG, 3-4  
 Viewport  
   imCursorToViewport, 2-30, 3-32  
   imGetFollowCursor, 2-40, 3-44  
   imGetViewportLock, 2-48, 3-52  
   imViewportEnd, 2-131, 3-137  
   imViewportGetxy, 2-132, 3-138  
   imViewportHome, 2-133, 3-139  
   imViewportMove, 2-134, 3-140  
   imViewportPageDown, 2-136, 3-142  
   imViewportPageUp, 2-137, 3-143  
   imViewportSetxy, 2-138, 3-144  
   imViewportToCursor, 2-140, 3-146  
 Virtual Wedge, 1-4  
 Visual Basic, 3-6  
   about, 3-3  
   building a program, 3-10, 3-11, 3-12  
   certified functions, 3-17  
   compiler, 3-11  
   key press, 3-5  
   library, 3-18  
   moving to next control, 3-7, 3-8  
   power management, 3-8, 3-9  
   sample program, 3-6, 3-7, 3-9  
   simulating a key press, 3-5  
   Tab key, 3-7, 3-8  
   variable addresses, 3-3, 3-4  
   working with, 3-3  
 Visual Basic and QuickBasic differences, 3-3  
 Visual Basic functions  
   imApplBreakStatus, 3-21  
   imBacklightOff, 3-23  
   imBacklightOn, 3-24  
   imBacklightToggle, 3-25  
   imCancelRxBuffer, 3-26  
   imCancelTxBuffer, 3-28  
   imCommand, 3-30  
   imCursorToViewport, 3-32  
   imDecreaseContrast, 3-33  
   imGetConfigInfo, 3-35

Visual Basic functions *continued*

- imGetContrast, 3-37
- imGetControlKey, 3-39
- imGetDisplayMode, 3-41
- imGetDisplayType, 3-43
- imGetFollowCursor, 3-44
- imGetInputMode, 3-45
- imGetKeyclick, 3-47
- imGetLabelSymbology, 3-48
- imGetLength, 3-49
- imGetPostamble, 3-50
- imGetPreamble, 3-51
- imGetViewportLock, 3-52
- imGetWarmBoot, 3-54
- imIncreaseContrast, 3-55
- imInputStatus, 3-57
- imIrlA, 3-59
- imIrlK, 3-64
- imIrlN, 3-68
- imIrlV, 3-73
- imIrlY, 3-77
- imLinkComm, 3-80
- imMessage, 3-82
- imNumberPadOff, 3-83
- imNumberPadOn, 3-84
- imPowerStatus, 3-86
- imProtocolExtendedStatus, 3-88
- imReceiveBuffer, 3-91
- imReceiveBufferNoprot, 3-94
- imReceiveBufferNoWait, 3-97
- imReceiveByte, 3-100
- imReceiveInput, 3-102
- imRsInstalled, 3-105
- imRxCheckStatus, 3-106
- imSerialProtocolControl, 3-107
- imSetContrast, 3-110
- imSetControlKey, 3-112
- imSetDisplayMode, 3-113
- imSetFollowCursor, 3-119
- imSetInputMode, 3-120
- imSetKeyclick, 3-122
- imSetViewportLock, 3-123

Visual Basic functions *continued*

- imSetWarmBoot, 3-124
- imSound, 3-125
- imStandbyWait, 3-127
- imTransmitBuffer, 3-128
- imTransmitBufferNoprot, 3-132
- imTransmitBufferNoWait, 3-130
- imTransmitByte, 3-134
- imUnlinkComm, 3-136
- imViewportEnd, 3-137
- imViewportGetxy, 3-138
- imViewportHome, 3-139
- imViewportMove, 3-140
- imViewportPageDown, 3-142
- imViewportPageUp, 3-143
- imViewportSetxy, 3-144
- imViewportToCursor, 3-146

**W**

Warm boot

- imGetWarmBoot, 2-50, 3-54
- imSetWarmBoot, 2-118, 3-124

Warranty information, xiii

Wedge mode, 2-41, 2-114, 3-45, 3-120

Working with Visual Basic, 3-3