

**MICROSCAN<sup>®</sup>**

*MS-820  
Industrial  
Bar Code Scanner  
User's Manual*



P/N 83-000820 Rev G

Copyright © 2002  
by Microscan Systems, Inc.,  
1201 S.W. 7th Street, Renton, Washington, U.S.A. 98055  
(425) 226-5700 FAX: (425) 226-8682  
ISO 9001/Certification No. 00-1047

All rights reserved. The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Microscan manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Microscan.

Throughout this manual, trademarked names might be used. Rather than put a trademark (™) symbol in every occurrence of a trademarked name, we state herein that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

**Disclaimer**

The information and specifications described in this manual are subject to change without notice.

**Latest Manual Version**

For the latest version of this manual, see the Download page on our web site at [www.microscan.com](http://www.microscan.com). For technical support email [helpdesk@microscan.com](mailto:helpdesk@microscan.com).

## Microscan Limited Warranty Statement and Exclusions

### What is Covered?

Microscan Systems Inc. warrants to the original purchaser that products manufactured by it will be free from defects in material and workmanship under normal use and service for a period of one year from the date of shipment. This warranty is specifically limited to, at Microscan's sole option, repair or replacement with a functionally equivalent unit and return without charge for service or return freight.

### What is Excluded?

This limited warranty specifically excludes the following: (1) Any products or parts that have been subject to misuse, neglect, accident, unauthorized repair, improper installation, or abnormal conditions or operations; (2) Any products or parts that have been transferred by the original purchaser; (3) Customer mis-adjustment of settings contrary to the procedure described in the Microscan Systems Inc. owners manual; (4) Upgrading software versions at customer request unless required to meet specifications in effect at the time of purchase; (5) Units returned and found to have no failure will be excluded; (6) Claims for damage in transit are to be directed to the freight carrier upon receipt. Any use of the product is at purchaser's own risk. This limited warranty is the only warranty provided by Microscan Systems Inc. regarding the product. Except for the limited warranty above, the product is provided "as is." To the maximum extent permitted by law, this express warranty excludes all other warranties, express or implied, including but not limited to, implied warranties of merchantability and fitness for a particular purpose. Microscan Systems Inc. Does not warrant that the functions contained in the product will meet any requirements or needs purchaser may have, or that the product will operate error free, or in an uninterrupted fashion, or that any defects or errors in the product will be corrected, or that the product is compatible with any particular machinery.

### Limitation of Liability.

In no event shall Microscan Systems Inc. be liable to you or any third party for any special, incidental, or consequential damages (including, without limitation, indirect, special, punitive, or exemplary damages for loss of business, loss of profits, business interruption, or loss of business information), whether in contract, tort, or otherwise, even if Microscan Systems Inc. has been advised of the possibility of such damages. Microscan Systems Inc.'s aggregate liability with respect to its obligations under this warranty or otherwise with respect to the product and documentation or otherwise shall not exceed the amount paid by you for the product and documentation.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on an implied warranty, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

# Table of Contents

|           |  |      |
|-----------|--|------|
| Chapter 1 | Quick Start  |      |
|           | Step 1 Hardware Required.....                        | 1-2  |
|           | Step 2 Connect the System .....                      | 1-3  |
|           | Step 3 Install ESP-MP.....                           | 1-6  |
|           | Step 4 Select Scanner Model.....                     | 1-7  |
|           | Step 5 Select the Communications Ports.....          | 1-8  |
|           | Step 6 Connect with Auto Connect .....               | 1-9  |
|           | Step 7 Retrieve Scanner Settings .....               | 1-10 |
|           | Step 8 Compare Scanner Settings.....                 | 1-11 |
|           | Step 9 Position Scanner and Symbol.....              | 1-12 |
|           | Step 10 Autocalibrate Scanner .....                  | 1-13 |
|           | Step 11 Test Range for Bar Code Label.....           | 1-14 |
|           | Step 12 Make Changes to Configuration and Save ..... | 1-15 |
| Chapter 2 | Communications                                       |      |
|           | Communications Options .....                         | 2-2  |
|           | Host Port Parameters.....                            | 2-5  |
|           | RS422 Status .....                                   | 2-7  |
|           | Auxiliary Port.....                                  | 2-8  |
|           | Daisy Chain Autoconfigure.....                       | 2-16 |
|           | Daisy Chain Remote Scanner ID .....                  | 2-17 |
|           | IrDA Port .....                                      | 2-18 |
|           | Menu Mode .....                                      | 2-19 |
| Chapter 3 | Protocol   |      |
|           | Protocol.....  | 3-4  |
|           | LRC .....  | 3-9  |
|           | Response Timeout .....                               | 3-10 |
|           | Intercharacter Delay.....                            | 3-11 |
|           | Output Data Format .....                             | 3-12 |
|           | Auxiliary/Configuration System Data.....             | 3-14 |
|           | Network Client.....                                  | 3-15 |
| Chapter 4 | Read Cycle/Trigger                                   |      |
|           | Trigger Mode.....                                    | 4-4  |
|           | Serial Trigger.....                                  | 4-10 |
|           | External Trigger State .....                         | 4-12 |
|           | End of Read Cycle .....                              | 4-13 |
|           | Multilabel .....                                     | 4-16 |
| Chapter 5 | Codes  |      |
|           | Narrow Margins.....                                  | 5-5  |

|  |      |
|--|------|
| Symbology ID .....                           | 5-6  |
| Background Color .....                       | 5-7  |
| Code 39 .....                                | 5-8  |
| Codabar .....                                | 5-11 |
| Interleaved 2 of 5 .....                     | 5-14 |
| UPC/EAN .....                                | 5-17 |
| PDF417 .....                                 | 5-20 |
| Code 128 .....                               | 5-22 |
| UCC/EAN-128 .....                            | 5-23 |
| Code 93 .....                                | 5-26 |
| Pharma Code .....                            | 5-27 |
| Autodiscriminate .....                       | 5-29 |
| <b>Chapter 6      Autocalibration</b>        |      |
| Overview of Autocalibration .....            | 6-2  |
| Autocalibration by ESP .....                 | 6-4  |
| Autocalibration by Serial Command .....      | 6-7  |
| Autocalibration by Embedded Menu .....       | 6-8  |
| <b>Chapter 7      Calibration Database</b>   |      |
| Overview of Calibration Database .....       | 7-2  |
| Calibration Database by ESP .....            | 7-3  |
| Calibration Database by Serial Command ..... | 7-4  |
| Calibration Database by Embedded Menu .....  | 7-6  |
| <b>Chapter 8      Optoelectrics</b>          |      |
| Overview of Optoelectrics .....              | 8-4  |
| Optoelectric Database Modes .....            | 8-5  |
| <b>Chapter 9      Raster/LaserControl</b>    |      |
| Raster Setup .....                           | 9-3  |
| Laser Setup .....                            | 9-6  |
| Raster/Laser by Embedded Menu .....          | 9-9  |
| <b>Chapter 10     Scanner Setup</b>          |      |
| Scan Speed .....                             | 10-4 |
| Focus .....                                  | 10-5 |
| Gain Adjustment .....                        | 10-6 |
| Tracking .....                               | 10-6 |
| Transition Counter .....                     | 10-7 |
| Maximum Element .....                        | 10-8 |
| <b>Chapter 11     Matchcode</b>              |      |
| Overview of Matchcode .....                  | 11-4 |
| Matchcode Type .....                         | 11-5 |

|  |       |
|--|-------|
| Master Label Database .....                | 11-11 |
| New Master Pin .....                       | 11-16 |
| Chapter 12    Outputs                      |       |
| Noread Message .....                       | 12-4  |
| Bar Code Output .....                      | 12-5  |
| Serial Verification .....                  | 12-8  |
| Beeper Status .....                        | 12-10 |
| Quality Output .....                       | 12-11 |
| Chapter 13    Output Format and Filtering  |       |
| Overview of Output Format/Filtering .....  | 13-4  |
| Extraction Mode .....                      | 13-5  |
| Insertion Mode .....                       | 13-7  |
| Advanced Output Format by ESP .....        | 13-9  |
| Multilabel Output Format Assignment .....  | 13-10 |
| Ordered Output/Filtering .....             | 13-11 |
| Master Database in ESP .....               | 13-16 |
| Chapter 14    Discrete I/O                 |       |
| Input 1 .....                              | 14-4  |
| Output 1 .....                             | 14-5  |
| Output 2 .....                             | 14-10 |
| Output 3 .....                             | 14-10 |
| Diagnostic Outputs .....                   | 14-11 |
| Chapter 15    Diagnostics                  |       |
| Warning Messages .....                     | 15-4  |
| High Temperature Threshold .....           | 15-8  |
| Low Temperature Threshold .....            | 15-9  |
| Lifetime Hours .....                       | 15-10 |
| Present Ambient Temperature (deg. C) ..... | 15-11 |
| Counts .....                               | 15-12 |
| Time Since Last Reset .....                | 15-13 |
| Chapter 16    Wiring Box Option            |       |
| Wiring Box Description .....               | 16-2  |
| Installation Steps .....                   | 16-3  |
| Wiring Box Ports .....                     | 16-5  |
| Wiring Box PCB with Connectors .....       | 16-8  |
| Mounting Plate .....                       | 16-9  |
| Chapter 17    Utilities                    |       |
| File Transfer .....                        | 17-5  |
| Counters .....                             | 17-6  |

|   |       |
|---|-------|
| Part Number .....                               | 17-8  |
| Checksum.....                                   | 17-9  |
| Read Rate .....                                 | 17-10 |
| Device Control .....                            | 17-12 |
| Code Type .....                                 | 17-13 |
| Defaulting/Saving/Initializing.....             | 17-13 |
| <b>Appendices</b>                               |       |
| Appendix A General Specifications .....         | A-2   |
| Appendix B Electrical Specifications .....      | A-6   |
| Appendix C IrDA Configuration Port.....         | A-13  |
| Appendix D IrDA/Ir Comm for Palm Pilot.....     | A-15  |
| Appendix E Serial Configuration Commands .....  | A-16  |
| Appendix F Serial Command Format .....          | A-19  |
| Appendix G ASCII Table .....                    | A-21  |
| Appendix H Embedded Menus .....                 | A-23  |
| Appendix I Defaulting/Saving/Initializing.....  | A-24  |
| Appendix J Position Scanner and Bar Code .....  | A-28  |
| Appendix K Position Object Detector .....       | A-29  |
| Appendix L Test Decode Rate.....                | A-30  |
| Appendix M Formulas for Number of Decodes ..... | A-31  |
| Appendix N Operational Tips.....                | A-35  |
| Appendix O Interface Standards .....            | A-36  |
| Appendix P Multidrop Communications.....        | A-38  |
| Appendix Q Glossary of Terms .....              | A-43  |

## List of Figures

|   |      |
|---|------|
| Figure 1-1 Hardware Configuration .....                             | 1-2  |
| Figure 1-2 Side View of IB-131 showing Host 25-pin Connection ..... | 1-3  |
| Figure 1-3 Low Density Ranges .....                                 | 1-10 |
| Figure 1-4 High Density Ranges .....                                | 1-10 |
| Figure 1-5 Depth of Field .....                                     | 1-11 |
| Figure 4-1 Trigger Level .....                                      | 4-6  |
| Figure 4-2 Trigger Edge .....                                       | 4-7  |
| Figure 8-1 Output Message Flow .....                                | 8-4  |
| Figure 8-2 Read Cycle .....   | 8-10 |
| Figure 8-2 ESP Laser Framing Control .....                          | 8-11 |
| Figure 8-3 Laser Framing Pattern .....                              | 8-11 |
| Figure A-1 MS-820 Dimensions .....                                  | A-2  |
| Figure A-2 IB-131 Mechanical .....                                  | A-10 |
| Figure A-3 Scanner/IB-131 Typical Setup .....                       | A-10 |
| Figure A-4 IB-131 Multidrop Setup .....                             | A-11 |
| Figure A-5 Scanner/IB-131 Daisy Chain Setup .....                   | A-11 |
| Figure A-6 Scanner/Symbol Position .....                            | A-24 |
| Figure A-7 Object Detector .....                                    | A-25 |
| Figure A-8 Ladder .....   | A-27 |
| Figure A-9 Picket Fence .....                                       | A-28 |
| Figure A-10 Angled Picket Fence .....                               | A-28 |
| Figure A-11 Polling Sequence .....                                  | A-34 |
| Figure A-12 Polling Sequence .....                                  | A-35 |

## List of Tables

|  |       |
|--|-------|
| Table 5-1 Symbology Identifier Option Values .....               | 5-6   |
| Table 9-1 Maximum Sweep Rates at Selected Sweep Arcs .....       | 9-5   |
| Table 11-1 Maximum Characters for Master Label Database .....    | 11-13 |
| Table 17-1 Summary of Utility Serial Commands .....              | 17-3  |
| Table A-1 MS-880 FIS Options .....                               | A-3   |
| Table A-2 MS-880 Read Ranges .....                               | A-3   |
| Table A-3 MS-880 Status Lights (on the side of the MS-880) ..... | A-4   |
| Table A-4 Power Connector .....                                  | A-7   |
| Table A-5 Trigger Connector .....                                | A-7   |
| Table A-6 Host 9-pin Configuration Connector .....               | A-7   |
| Table A-7 Host 25-pin Connector .....                            | A-8   |
| Table A-8 Serial Configuration Commands in Numeric Order .....   | A-16  |
| Table A-9 ASCII Table with Control Characters .....              | A-21  |
| Table A-10 Communication Protocol Commands .....                 | A-22  |
| Table A-11 Multidrop Addresses .....                             | A-42  |

### *About the MS-820 Scanner*

The MS-820 scanner can decode high density bar code symbols from 3 to 30 inches. Its IP65 and heavy industrial rating makes it ideal for applications such as conveyors, assembly lines, or embedding within machinery.

Its application code resides in an onboard flash memory chip that can be easily updated by downloads.<sup>1</sup> A user interface program, the ESP-MP (Easy Setup Program–Multi-platform), can be downloaded from our web site ([www.microscan.com](http://www.microscan.com)) and runs on Microsoft Windows 95™, Windows 98™, Windows NT™ and Windows 2000™ operating systems. Alternately, configuration commands can be sent from an embedded, menu-driven terminal program, or directly by host serial command strings.

---

1. See your Microscan sales representative to access the latest application codes.

## About This Manual

This manual provides complete information on setting up, installing, and configuring the MS-820 scanner. The chapters are presented in the order in which a scanner might be setup and made ready for industrial operation.

[Chapter 1, "Quick Start"](#) provides overall step-by-step instructions for getting your scanner operational with specific "go to" references to other chapters and appendices.

The appendices include specifications, reference tables of serial commands, ASCII characters, multidrop setup and addresses, as well as other useful information relating to bar coding and electrical and mechanical setups for the scanner.

## Host Communications

There are three ways the scanner communicates with a host:

1. Microscan's Windows™ based **ESP-MP™** (Easy Setup Program—Multi-Platform), the preferred method which offers point-and-click ease of use and visual responses to user adjustments.
2. Serial commands such as <Kr1> can be sent from a terminal program. They can also be sent from the **Terminal** or **Utility** window within ESP-MP.
3. Embedded onboard menus are accessed from a terminal window with a **<D>** command. These menus lack some of the functionality of the ESP-MP, but may be more responsive in older, slower computers.

## Keystrokes

Serial commands, selections inside instructions, and menu defaults are highlighted in **red bold**. Cross-references are highlighted in **blue**. Web links and outside references are highlighted in **blue bold italics**. References to menu topics are highlighted in **Bold Initial Caps**. References to topic headings within this manual or other documents are enclosed in quotation marks.


## Approvals

This equipment is in compliance or approved by the following organizations:

- CDRH (Center for Devices & Radiological Health)
- UL (Underwriters Laboratories, Inc.)
- cUL (UL mark of Canada)
- TÜV (Technischer Überwachungs-Verein)
- FCC (Federal Communication Commission)
- CE Compliant
- BSMI (Bureau of Standards, Metrology and Inspection)

# Safety Labels

The following labels are located on the side and back of the MS-820 scanner:



# Warning and Caution Summary

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

For connection to a UL listed direct plug-in power unit marked Class II and rated 10 to 28 VDC at 2.7 watts or greater.

European models must use a similarly rated Class I or Class II power supply that is certified to comply with standard for safety EN 60950.



## **WARNING**

*Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous laser light radiation exposure.*



## **WARNING**

*There are no user serviceable parts in the scanner. Opening the scanner voids the Microscan Systems warranty and could expose the user to laser diode power of up to 7 mW.*



## **WARNING**

*The laser beam can be harmful to eyesight. Avoid eye contact with the laser beam. Never point the beam at other people, or in a direction where people may be passing.*

Chapter Contents

|   |      |
|---|------|
| Step 1 Hardware Required .....                      | 1-2  |
| Step 2 Connect the System .....                     | 1-3  |
| Step 3 Install ESP-MP .....                         | 1-4  |
| Step 4 Select Scanner Model .....                   | 1-5  |
| Step 5 Select the Communications Ports .....        | 1-6  |
| Step 6 Connect with Auto Connect.....               | 1-7  |
| Step 7 Retrieve Settings .....                      | 1-8  |
| Step 8 Position Scanner and Bar Code Label .....    | 1-9  |
| Step 9 Test Range for Bar Code Label.....           | 1-10 |
| Step 10 Make Changes to Configuration and Save..... | 1-11 |

This chapter is designed to get your scanner up and running quickly using Microscan's **ESP-MP™** so the user can get a sense of its capabilities and test bar code samples. Detailed setup information for installing the scanner into the actual application can be obtained in the subsequent chapters.

In addition to **ESP**, you can send commands to your scanner by serial commands and through the scanner's embedded menus.

## Step 1 — Hardware Required

(Refer to [figure 1-1](#).)

To get started you will need:

- An MS-820 scanner (**1**).
- A host computer (**2**) with either a terminal communications program or Microscan's ESP™ which runs under Windows™ operating system, Windows-95 or higher, including Windows NT™.
- A null modem configuration cable (**3**)  
(Use cable P/N 61-300026-01 if your computer uses a 25-pin serial port connector.)<sup>1</sup>
- A scanner to IB-131 interface cable (**4**), P/N 61-000011-01.
- An IB-131 interface module (**5**).
- A power supply (**6**), P/N 97-100004-1005 (120V) or P/N 97-100004-06 (240V).

**Caution:** If using your own power supply, be certain that it is wired correctly and supplies voltage within the +10 to 28 VDC limits. Incorrect wiring or voltage can cause software or equipment failures.

**Note:** An optional object detector (**7**) is shown here (P/N 99-440001-10).




Figure 1-1 Hardware Configuration

1. If using another host cable, make certain it does not have RTS/CTS connected to the host.

## Step 2 — Connect the System

1. Connect the scanner to the IB-131 interface box, using the supplied cable with kit P/N 98-000014-01. If making up your own cable, make certain that you connect transmit pins to receive pins.
2. Connect IB-131 Host to Computer.<sup>1</sup>  
(Refer to [table A-3](#) and [table A-8](#) for pin connections)
3. Use the host connector on the side of the IB-131 ([figure 1-2](#)) to connect with your host computer.




Figure 1-2 Side View of IB-131 showing Host 25-pin Connection

**Note:** When wiring the IB-131 host connector to a 25-pin host connector (typical desktop computer connection), cross pins 2 and 3. When wiring the IB-131 host connector to a 9-pin host connector (typical portable computer connection), do NOT cross pins 2 and 3. (See [figure 1-2](#).)

4. Connect power supply as shown in [Step 1](#), "Hardware Required."
5. Power up the scanner.

1. If using your own null modem RS232 host cable, be certain that the host's TxD connects to the scanner's RxD and the scanner's TxD connects to the host's RxD.

## Step 3 — Install ESP-MP<sup>1</sup>

(**ESP-MP** is short for *Easy Setup Program-Multi-Platform*.)

1. Insert your Microscan CD into your computer's CD drive.
2. Launch **Setup.exe** under **ESP\_Software\Multi\_Platform** and follow the prompts.<sup>2</sup>

*If downloading from the web:*

- a. Go to <http://www.microscan.com/esp>
  - b. Enter your user name and password.
  - c. Select **ESP-MP** and download to your computer hard drive.
  - d. Extract **ESP-MP WinZip** files to a directory of your choice.
3. Note where your ESP.exe file is stored on your hard drive.

At the end of the install process, you should see the following icon on your desktop:




4. Click the **ESP-MP** icon to start the program.

---

1. You can also access the scanner through its embedded menus. See [Appendix G — “Embedded Menus.”](#)  
2. Contact your sales representative


## Step 4 — Select Scanner Model

When you start the program, the following dialog box will appear:




**Note:** If you need to select another model later, you can find it under **Model Select** in the menu bar.

1. In the model dialog box, select your model.
2. Select the default name, **MS-820-1** or type in a new name of your choice.
3. Click **Yes** when the following dialog on the right appears.



## Step 5 — Select the Communications Ports

1. Select your communications port under **COM Port**.



**COM1** is typically used for laptops.


**COM1** and **COM2** are typically for desktop computers.

2. Click the **Start** button.

## Step 6 — Connect with Auto Connect

After clicking the **Start** button in the **Connecting to...** dialog, allow time for the auto connect routine to test all of the combinations. You will see a blue progress bar fill across the **Connecting to...** dialog.

When connected, the **CONNECTED** message will appear in a green box in the status bar on the bottom right of the dialog.



**Tip:** If you do not see either the CONNECTED or DISCONNECTED message at the bottom of your dialog, try expanding the ESP window horizontally.

**Tip:** If connection fails, enable a different Com port and try again.

## Step 7 — Retrieve Scanner Settings

Unless you have unchecked the default **Upload After Autoconnect** under **Options**, the communications values of the scanner will be loaded automatically and displayed under **Scanner Values**.


If **Upload After Autoconnect** is not checked, the scanner values will not be loaded and ESP communications values will remain displayed under the heading, **ESP Values**.

**Tip:** Before doing **Retrieve Scanner Settings**, you may want to preserve your current ESP settings to your computer as an ESP file by selecting **Save** or **Save As** in the **File** menu.

At any time you can retrieve **ALL** scanner values by:

1. **Right-clicking** anywhere in the configuration window, and
2. Selecting **Retrieve Scanner Settings**.

You can also retrieve settings by clicking on the **Send/Receive** button.



This is useful if you want to:

- Copy (upload) the scanner's settings and save them as a computer file for later retrieval.
- Ensure that whenever you save ESP settings to the scanner you are not saving any unwanted changes that you or someone else had made previously in ESP. By first doing **Retrieve Scanner Settings**, you eliminate that possibility.


# Step 8 — Compare Scanner Settings

If you want to compare settings in the current scanner side-by-side with those in ESP without changing the ESP values:

1. Under the pull down Options menu check **Show Comparison Column**.
2. **Right-click** anywhere in the configuration window.
3. Select **Retrieve as Comparison**.

After a short pause the scanner’s current settings will be displayed under the **Comparison** column. Compare those settings with the ESP values which are displayed under the **ESP Values** column.

For example, if you change **Background Color** to **Black**, but haven’t yet saved this to the scanner, you will see the dissimilar program and scanner values highlighted in blue.




| Parameters                      | ESP Values | Comparison |
|---------------------------------|------------|------------|
| [-] Code Type / Symbologies     |            |            |
| [-] Narrow Margins/Symbology ID |            |            |
| Narrow Margins                  | Disabled   | Disabled   |
| Symbology ID                    | Disabled   | Disabled   |
| Background Color                | Black      | White      |

## Step 9 — Position Scanner and Symbol

Set up a symbol at the scanning distance you will be using in your application. In positioning the scanner and symbols being scanned, consider the following:

- Avoid bright light or IR light from other sources, including other scanners.
- Pitch or skew label or scanner a minimum of  $\pm 15^\circ$  to avoid specular reflection, the return of direct, non-diffused light.


**Note:** For additional tips on positioning the scanner and bar code labels, see ["Position Scanner and Bar Code" on page A-24](#).



**Code 39** is the default code type enabled. If you are uncertain as to the symbology type, enable all codes, by clicking the **Utilities** menu and enabling **Autodiscriminate** under **Code Types**.

# Step 10 — Test Range for Bar Code Label

1. Position a label in front of an operational scanner.<sup>1</sup>



**20 mil Code 39 Test Symbol**  
 You can also find test symbols on the back of the Microscan Marketing CD jacket. The 20 mil refers to the width of the narrowest bar (e.g., 7.5 mil = .0075" or .1905 mm).

2. Click the **Utilities** button. 
3. Right-click **Read Rate** and select **Start**.
4. Observe rate in terminal window on the right of the **Utilities** screen.
5. Move your bar code label towards the scanner and away from the scanner until the decode rates drop off in each direction as shown in [figure 1-1](#).  
 This will give you a sense of the depth of field (inner and outer ranges) for your symbol's density and range.
6. To end test, right-click **Read Rate** and select the **Stop** button.





Figure 1-5 Depth of Field


**Note:** If the scanner is in the default **Continuous Read** mode, it will read and beep repeatedly as long as a readable label remains in the read range and the read cycle configuration has not changed.

1. If using an I 2/5 label, verify that the number of characters in the label being scanned matches the code length enabled for the I 2/5 code type (default is 10 and 6). See ["Interleaved 2 of 5" on page 5-14](#).

## Step 11 — Make Changes to Configuration and Save

To make changes to a configuration setting:

1. **Double-click** the setting (for example, **End of Read Cycle**).



2. Place your pointer in the selection box, scroll down to the setting of your choice and **left-click** on the setting.
3. **Left-click** again anywhere in the configuration window to complete the selection.
4. **Right-click** in the configuration window and select **Save to Scanner** to implement the command in the scanner. You have 3 choices:
  - a. **Send, No Save.** This initializes all changes in active memory. These changes will be lost if power to the scanner is cycled.
  - b. **Send and Save.** This will cause the scanner to beep, indicating that the change has been implemented and that all changes have been saved to the scanner's NOVRAM for power-on, except factory settings.<sup>1</sup>
  - c. **Advanced/Send and Save, Including Factory.** Same as above, except that changes to factory settings will also be saved for power-on.

**Note:** For Multidrop setup, see "[Multidrop Communications](#)" on page A-32.

1. Consult your model specific user's manual for a list of factory settings.

## Chapter Contents

|                            |     |
|----------------------------|-----|
| Host Port Parameters ..... | 2-4 |
| Auxiliary Port.....        | 2-5 |

This section tells how to setup communications parameters with the host and an auxiliary terminal.

In addition, the options for auxiliary port connections are fully explored.

With Microscan's ESP-MP™ (Easy Setup Program) configuration changes can be made in the ESP-MP menus, then sent and saved to your scanner. The user can also send serial commands to the scanner via the ESP's Terminal window.

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.


## Communications by ESP

2-Communications



Click this button to bring up the **Communications** menu.

To change a setting, **double-click** the setting and use your cursor to scroll through the options.



## Communications by Serial Command

| Command Title             | cmds       | Format   |
|---------------------------|------------|--|
| Host Port Parameters      | <b>Ka</b>  | < <b>Ka</b> baud,parity,stop bits,data bits>   |
| Auxiliary Port Parameters | <b>Ky</b>  | < <b>Ky</b> aux port mode,baud,parity,stop bits,data bits,daisy chain status,daisy chain ID> |
| Comm. Status Request      | <b>KT?</b> | < <b>KT?</b> >   |

## Communications by Embedded Menu

In addition to ESP-MP, Microscan's scanners have an embedded menu that can be accessed from the terminal window within ESP or a separate terminal program. See for instructions on using the embedded menus. For older, slower computers, the embedded menus might be a quicker method of communicating with your scanner. Send a **<D>** command from your terminal to bring up the main menu:

```

MICROSCAN SYSTEMS, INC.
CONFIGURATION PROGRAM
MAIN MENU
35-338201-14
-----
TOPICS                DESCRIPTIONS
1) COMMUNICATIONS    HOST PROTOCOL AND HOST PORT.
2) OPERATIONS        TRIGGERING, TIMEOUTS, ETC.
3) CODE TYPES 1      CODE 39, PDF417, I 2 OF 5, UPC, CODE 128.
4) CODE TYPES 2      CODE 93, CODABAR, ETC.
5) GLOBAL CODE PARAMETERS MARGINS, SYMB.ID., BACKGROUND, ATAG, ETC.
6) SCANNER OUTPUT    BARCODE, BEEPER, RELAYS, OUTPUT MODES, ETC.
7) SCANNER SETUP     GAIN, SCAN SPEED, TRANSITION COUNT, ETC.
8) DIAGNOSTICS SETUP WARNING MESSAGES, OPERATION TIME, ETC.
-----
ESC = MAIN MENU OR EXIT  N = NEXT ITEM
M  = PREVIOUS MENU      SP = NEXT ITEM
B  = PREVIOUS ITEM      CR = THIS ITEM
-----
MAIN--> COMMUNICATIONS_

```

Press the return key (**CR**) to see the communications menu:

```

CURRENT SETTINGS FOR COMMUNICATIONS
-----
HOST PROTOCOL          PARAMETER  HOST PORT  AUX PORT
-----
PROTOCOL = POINT TO POINT  BAUD RATE  9600      9600
PREAMBLE = DISABLED = <CR><LF><NUL><NUL>  PARITY     EVEN      EVEN
POSTAMBLE = ENABLED = <CR><LF><RS><SPC>  STOP BITS  ONE       ONE
ADDRESS =                  DATA BITS  SEVEN     SEVEN
RES = <NUL>                PORT MODE  RS232     N/A
REQ = <NUL>
EOT = <NUL>                AUX MODE   N/A       DISABLED
STX = <NUL>                DAISYCHAIN ID STATUS  DISABLED
ETX = <NUL>                DAISYCHAIN ID DEFINE  1/
ACK = <NUL>
NAK = <NUL>
LRC = DISABLED
RESPONSE TIMEOUT = 12 ms
INTERCHAR DELAY = 0 ms
-----
ESC = MAIN MENU OR EXIT  N = NEXT ITEM
M  = PREVIOUS MENU      SP = NEXT ITEM
B  = PREVIOUS ITEM      CR = THIS ITEM
-----
COMMUNICATIONS--> HOST PROTOCOL

```

For information on accessing the embedded menus, see ["Embedded Menus"](#) on page - 19.

---

*Host Port Parameters*

## Host Port Parameters

### Baud Rate, Host Port

---

*Definition:* The rate at which the scanner and host transfer data back and forth.

*Usage:* Can be used to transfer data faster or to match host port settings.

*Serial Cmd:* <**K** *baud rate*, *parity*, *stop bits*, *data bits*>

*Default:* **9600**

*Options:*

|          |           |           |
|----------|-----------|-----------|
| 0 = 600  | 3 = 4800  | 6 = 38.4K |
| 1 = 1200 | 4 = 9600  | 7 = 57.6K |
| 2 = 2400 | 5 = 19.2K | 8 = 300K  |

### Parity, Host Port

---

*Definition:* An error detection routine in which one data bit in each character is set to 1 or 0 so that the total number of 1 bits in the data field is even or odd.

*Usage:* Only changed if necessary to match host setting.

*Serial Cmd:* <**K** *baud rate*, ***parity***, *stop bits*, *data bits*>

*Default:* **Even**

*Options:* 0 = None          1 = Even          2 = Odd

### Stop Bits, Host Port

---

*Definition:* One or two bits added to the end of each character to indicate the end of the character.

*Usage:* Only changed if necessary to match host setting.

*Serial Cmd:* <**K** *baud rate*, *parity*, ***stop bits***, *data bits*>

*Default:* **One**

*Options:* 0 = One    1 = Two

### Data Bits, Host Port

---

*Definition:* One or two bits added to the end of each character to indicate the end of the character.

*Usage:* Only changed if necessary to match host setting.

*Serial Cmd:* <**K** *baud rate*, *parity*, ***stop bits***, *data bits*>

*Default:* **One**

*Options:* 0 = One    1 = Two

## RS422 Status

*Definition:* Enables RS422. When RS422 is enabled, RS232 is enabled.

*Usage:* Only changed if necessary to match host setting.

*Serial Cmd:* <**Kb**status>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Auxiliary Port

As with the host port parameters, the auxiliary terminal's settings (baud rate, parity, stop bits, and data bits) must be identical with those of the auxiliary device.

*Definition:* An auxiliary port connects the scanner to a remote display or to other scanners that can display or transfer data.

*Usage:* These commands set the communication parameters with the auxiliary port which can be used to configure menus, send data to the host, display data transmissions originating from the host of the scanner, and relay data from other scanners set in tandem (daisy chained).

*Serial Cmd:* **<Ky**aux port mode,baud rate,parity,stop bits,data bits,daisy chain ID status,daisy chain ID>

### Auxiliary Port Modes

*Definition:* Determines the flow of data between the auxiliary port device(s), the scanner, and the host.

*Serial Cmd:* **<Kyaux port mode**,baud rate,parity,stop bits,data bits,daisy chain ID status,daisy chain ID>

*Default:* **Disabled**


*Options:*

- 0 = Disabled
- 1 = Transparent
- 2 = Half duplex
- 3 = Full duplex
- 4 = Daisy chain

## Transparent Mode


**Definition:** In **Transparent** mode data is passed between the auxiliary port and the host. The scanner buffers data from the auxiliary port and echoes the keyed data on the auxiliary port.

- Auxiliary port data is passed through to the host whenever a return key is pressed at the auxiliary port or whenever bar code data is sent. If sent with bar code data, it is processed on a first-in/first-out basis.
- Auxiliary port data to the host is always sent with a preamble and a postamble.
- If the scanner is in a polled mode to the host, auxiliary port data will still pass through.
- **<D>** is the only command accepted by the scanner from the auxiliary port. All other commands will pass through to the host.




### Data initiated from the Scanner

- Transmission to the auxiliary port occurs immediately upon a good read.
- Scan data to the auxiliary port does not include a preamble or a postamble.
- Communications with the auxiliary port is always in Point-to-Point protocol, even if the host is in a polled protocol mode.



### Data initiated from the Host

- All host data is echoed to the auxiliary port in unpolled mode.



**Usage:** A common application, in conjunction with handheld scanners, is one that employs an auxiliary readout to detect mis-applied bar code labels.

**Serial Cmd:** **<Kyaux port mode, baud rate, parity, stop bits, data bits, daisy chain ID status, daisy chain ID>**

**1 = Transparent**


## Auxiliary Port

### Half Duplex Mode

**Definition:** In **Half Duplex** mode all auxiliary port data and bar code data is sent directly to the host. Bar code data is displayed on the auxiliary port screen at the same time the data is sent to the host.


#### Data initiated from the Auxiliary Port

- Auxiliary port data to the host is ignored if the scanner is in a polled mode.
- Auxiliary port data or scanned data is sent to the host whenever it is received.
- Auxiliary port data is not echoed.
- Auxiliary port data to the host is always sent without a preamble or a postamble.
- <D> is the only command that is accepted by the scanner from the auxiliary port. All other commands are passed through to the host.




#### Data initiated from the Scanner

- Scan data is transmitted to the auxiliary port at the same time it is transmitted to the host.
- Data transmission conforms with all parameters specified in the configuration menu (e.g., **Preamble, Postamble, End of Read Cycle**).



#### Data is initiated from the Host

- All host data is echoed to the auxiliary port in unpolled mode.



**Usage:** Useful when the user wants bar code data displayed on an auxiliary screen close to the scanner.

**Serial Cmd:** **<Kyaux port mode, baud rate, parity, stop bits, data bits, daisy chain ID status, daisy chain ID>**


**2 = Half Duplex**

## Full Duplex Mode

**Definition:** In **Full Duplex** mode all auxiliary port data and bar code data is sent directly to the host. Bar code data is not displayed on the auxiliary port screen.


### Data initiated from the Auxiliary Port

- Auxiliary port data to the host is ignored if the scanner is in a polled mode.
- Auxiliary port data or scanned data is sent to the host whenever it is received.
- Auxiliary port data is not echoed.
- Auxiliary port data to the host is always sent without a preamble or a postamble.
- <D> is the only command that is accepted by the scanner from the auxiliary port. All other commands are passed through to the host.




### Data initiated from the Scanner

- Scan data is not sent to the auxiliary port.



### Data initiated from the Host

- All host data is echoed to the auxiliary port in unpolled mode.



**Usage:** When communication to and from the auxiliary port is required.

**Serial Cmd:** <**Kyaux port mode**,baud rate,parity,stop bits,data bits,daisy chain ID status,daisy chain ID>

**3 = Full duplex**

---

## Auxiliary Port

### Daisy Chain Mode

**Note:** See also “Daisy Chain Autoconfigure” on page 2-27.

---

**Definition:** In a daisy chain application, scanners are connected in tandem or “daisy chain” and decoded data is relayed from one scanner to another on up to the host.

A master scanner has its host port linked to the host computer and its auxiliary port linked to the host port of the first “slave” scanner in the chain. Thereafter, each slave’s auxiliary port is linked to the host port of the slave that is further from the host in the daisy chain.

Each scanner in the daisy chain can be assigned an ID that accompanies any data that it sends.

**Usage:** Useful in applications where:

- A bar code label might be scanned in both ladder and picket fence directions.
- A bar code label may be present on multiple sides of a package.
- Bar code labels are presented at different depths.

**Serial Cmd:** **<Kaux port mode,baud rate,parity,stop bits,data bits,daisy chain ID status,daisy chain ID>**

**Options:** **4 = Daisy chain**

**Function:** Before the master scanner times out, it checks its auxiliary port for data. It should be set to wait at least **20** mS for each slave in the daisy chain. If no data is received within the read cycle timeout, the master sends a noread message to the host. Otherwise the complete data is sent.

If for example the master scanner is set to timeout in 120 ms, the first slave scanner downstream might be set to 100 ms, the next to 80 ms, and so forth, thus assuring that at least 20 mS elapses between transmissions.<sup>a</sup>


Daisy-chained scanners can send a series of labels by enabling **Multilabel** and a common multilabel separator. If the master scanner does not receive the expected number of labels, noread messages are appended to the data string to make up the difference between the number of labels enabled in **Multilabel** and the number of labels read.

For example, a master and two slave scanners have **Number of Labels** set to 3 and **Multilabel Separator** defined as %. If the master and the first slave scanner do not find labels, but the next slave scanner registers a good read, the transmitted results would be: label data % noread % noread.

a. The above example is based on the best case. Other factors such as baud rate, number of characters in a given symbol, and the number of slaves in the daisy chain can affect timing and may need to be included in your calculations for complete accuracy.

**Conditions:** The conditions for a daisy chain application are as follows:

1. The master scanner's trigger must be **Serial** or **External**; the slave scanners' triggers are configured for **Serial**.
2. All scanners are enabled to **Daisy Chain** mode.
3. Each scanner's auxiliary port must be connected to the Host port of its slave scanner.
4. Each slave scanner in the daisy chain must be set to send its data no less than **20** mS before its preceding scanner.
5. All but the master scanner must have **Postamble** enabled and set to **CR (^M)** only.
6. All but the master scanner must have their noread messages disabled.
7. If **Multilabel** is enabled, **Multilabel Separator** characters must match in all scanners and **Number of Labels** must be set to number large enough to include all the labels it may itself read plus the number of labels that it will be expected to relay to the host or the next scanner up the line.
8. **Symbology ID** enable/disable must be the same in all scanners.
9. All but the master scanner must have their diagnostic warning messages disabled.
10. **Daisy Chain ID Status** enable/disable and the number of characters in **Daisy Chain ID** must be the same in all scanners.



---

## Auxiliary Port

### Aux Port Communications Parameters

As with the host port parameters, the auxiliary terminal's settings (baud rate, parity, stop bits, and data bits) must be identical with those of the auxiliary device.

#### Baud Rate, Aux Port

*Definition:* The rate at which the scanner and host transfer data back and forth.

*Usage:* Can be used to transfer data faster or match an auxiliary device.

*Serial Cmd:* <**Ky**aux port mode,**baud rate**,parity,stop bits,data bits,daisy chain ID status,daisy chain ID>

*Default:* **9600**

*Options:*

|          |           |           |
|----------|-----------|-----------|
| 0 = 600  | 3 = 4800  | 6 = 38.4K |
| 1 = 1200 | 4 = 9600  | 7 = 57.6K |
| 2 = 2400 | 5 = 19.2K | 8 = 300   |

#### Parity, Aux Port

*Definition:* An error detection routine in which one data bit in each character is set to 1 or 0 so that the total number of 1 bits in the data field is even or odd.

*Usage:* Only changed if necessary to match host setting.

*Default:* **Even**

*Options:* <**Ky**aux port mode,baud rate,**parity**,stop bits,data bits,daisy chain ID status,daisy chain ID>

*Serial Cmd:* 0 = None            1 = Even            2 = Odd

#### Data Bits, Aux Port

*Definition:* Number of bits in each character.

*Usage:* Only changed if necessary to match host setting.

*Serial Cmd:* <**Ky**aux port mode,baud rate,parity,stop bits,**data bits**,daisy chain ID status,daisy chain ID>

*Default:* **Seven**

*Options:* 0 = Seven            1 = Eight

### Stop Bits, Aux Port

---

|                    |   |
|--------------------|---|
| <i>Definition:</i> | Allows the user to select the last one or two bits in each character to indicate the end of the character.    |
| <i>Usage:</i>      | Only changed if necessary to match host setting.  |
| <i>Serial Cmd:</i> | < <b>Ky</b> aux port mode,baud rate,parity, <b>stop bits</b> ,data bits,daisy chain ID status,daisy chain ID> |
| <i>Default:</i>    | <b>One</b>  |
| <i>Options:</i>    | 0 = One                      1 = Two  |

### Daisy Chain ID Status

---

|                    |  |
|--------------------|--|
| <i>Definition:</i> | Each scanner in a daisy chain can be assigned a one or two character ID that will appear in front of decoded data and identify its source. |
| <i>Usage:</i>      | Used in a daisy chain setup in cases where the host needs to know which scanner in a daisy chain setup sent the data.                      |
| <i>Serial Cmd:</i> | < <b>Ky</b> aux port mode,baud rate,parity,stop bits,data bits, <b>daisy chain ID status</b> ,daisy chain ID>                              |
| <i>Default:</i>    | <b>Disabled</b>  |
| <i>Options:</i>    | 0 = Disabled                      1 = Enabled  |

**Note:** Enable/disable and length must be the same in all scanners.

### Daisy Chain ID

---

|                    |  |
|--------------------|--|
| <i>Definition:</i> | A one or two character prefix which identifies the particular daisy chain scanner from which the data is being sent. |
| <i>Usage:</i>      | Used in a daisy chain setup in cases where the host needs to know which scanner sent the data.                       |
| <i>Serial Cmd:</i> | < <b>Ky</b> aux port mode,baud rate,parity,stop bits,data bits,daisy chain ID status, <b>daisy chain ID</b> >        |
| <i>Default:</i>    | <b>1/</b>  |
| <i>Options:</i>    | Any one or two ASCII characters.   |



# Chapter

# 3

# Protocol

## Chapter Contents

|                            |      |
|----------------------------|------|
| Protocol.....              | 3-4  |
| LRC.....                   | 3-9  |
| Response Timeout.....      | 3-10 |
| Intercharacter Delay ..... | 3-11 |
| Output Data Format.....    | 3-12 |

3-Protocol

Protocols are the rules by which devices pass data back and forth. This section includes the basic options available for data communication, including multidrop and user-defined options and output data formats.

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Protocol by ESP



Click this button to bring up the **Protocol** menu

To change a setting, **double-click** the setting and use your cursor to scroll through the options.

| Parameters               | Program Values |
|--------------------------|----------------|
| [-] Protocol Settings    |                |
| Protocol                 | Point-to-Point |
| LRC                      | Disabled       |
| Response Timeout         | 12             |
| Intercharacter Delay     | 0              |
| [-] Output Format        |                |
| [-] Preamble Characters  |                |
| Status                   | Disabled       |
| Characters               | CR             |
| [-] Postamble Characters |                |
| Status                   | Enabled        |
| Characters               | CR LF          |

## Protocol by Serial Command

| Command Title                 | cmds       | Format                            |
|-------------------------------|------------|-----------------------------------|
| Host Protocol                 | <b>Kf</b>  | < <b>Kf</b> protocol>             |
| LRC                           | <b>Kc</b>  | < <b>Kc</b> status>               |
| Response Timeout              | <b>KA</b>  | < <b>KA</b> response timeout>     |
| Intercharacter Delay          | <b>KB</b>  | < <b>KB</b> intercharacter delay> |
| Preamble                      | <b>Kd</b>  | < <b>Kd</b> status,preamble>      |
| Postamble                     | <b>Ke</b>  | < <b>Ke</b> status,postamble>     |
| Communications Status Request | <b>KT?</b> | < <b>KT?</b> >                    |

## Protocol by Embedded Menu

For information on accessing the embedded menus, see [“Embedded Menus”](#) on page A-19.

From the Main menu, scroll down through the options and select the following screen:

| CURRENT SETTINGS FOR COMMUNICATIONS       |                      |                |          |
|---|----------------------|----------------|----------|
| HOST PROTOCOL                             | PARAMETER            | HOST PORT      | AUX PORT |
| PROTOCOL = POINT TO POINT                 | BAUD RATE            | 9600           | 9600     |
| PREAMBLE = DISABLED = <CR><NUL><NUL><NUL> | PARITY               | EVEN           | EVEN     |
| POSTAMBLE = ENABLED = <CR><LF><NUL><NUL>  | STOP BITS            | ONE            | ONE      |
| ADDRESS = 1                               | DATA BITS            | SEVEN          | SEVEN    |
| RES = <NUL>                               | AUX MODE             | N/A            | DISABLED |
| REQ = <NUL>                               | DAISYCHAIN ID STATUS |                | DISABLED |
| EOT = <NUL>                               | DAISYCHAIN ID DEFINE |                | 1/       |
| STX = <NUL>                               |                      |                |          |
| ETX = <NUL>                               |                      |                |          |
| ACK = <NUL>                               |                      |                |          |
| NAK = <NUL>                               |                      |                |          |
| LRC = DISABLED                            |                      |                |          |
| RESPONSE TIMEOUT = 12 ms                  |                      |                |          |
| INTERCHAR DELAY = 0 ms                    |                      |                |          |
| ESC = MAIN MENU OR EXIT                   |                      | N = NEXT ITEM  |          |
| M = PREVIOUS MENU                         |                      | SP = NEXT ITEM |          |
| B = PREVIOUS ITEM                         |                      | CR = THIS ITEM |          |
| COMMUNICATIONS--> HOST PROTOCOL_          |                      |                |          |

# Protocol

*Definition:* Protocols define the sequence and format in which information is transferred between the scanner and the host, or in the case of **Multidrop**, between scanners and a concentrator.

*Usage:* In general, the point-to-point protocols will work well in most applications. They require no address and must use RS-232 or RS-422 communications standards.

*Default:* **Point-to-Point**

*Options:*

- 0 = Point-to-Point
- 1 = Point-to-Point with RTS/CTS
- 2 = Point-to-Point with XON/XOFF
- 3 = Point-to-Point with RTS/CTS & XON/XOFF
- 4 = Polling Mode D
- 5 = Multidrop
- 6 = User Defined
- 7 = User Defined Multidrop

If selecting one of the options from 0 to 4 (**Point-to-Point**, **Point-to-Point with RTS/CTS**, **Point-to-Point with XON/XOFF**, **Point-to-Point with RTS/CTS and XON/XOFF**, or **Polling Mode D**), use the **<Kfprotocol>** format.

Option 5 through 7 are special cases and discussed later in this section.

## *Point-to-Point (standard)*

*Definition:* Standard **Point-to-Point** requires no address and sends data to the host whenever it is available, without any request or handshake from the host.

*Usage:* Used only with RS-232 or RS-422.

*Serial Cmd:* **<Kf0>**

---

### Point-to-Point with XON/XOFF (Transmitter On/Off)

---

*Definition:* This option enables the host to send the XON and XOFF command as a single byte transmission command of start (^Q) or stop (^S).

*Usage:* If an XOFF has been received from the host, data will not be sent to the host until the host sends an XON. During the XOFF phase, the host is free to carry on other chores and accept data from other devices.  
Used only with RS-232.

*Serial Cmd:* <Kf1>

---

### Point-to-Point with RTS/CTS

---

*Definition:* **Point-to-Point with RTS/CTS** (request-to-send/clear-to-send) is a simple hardware handshaking protocol that allows a scanner to initiate data transfers to the host.

*Usage:* A scanner initiates a data transfer with an RTS (request-to-send) transmission. The host, when ready, responds with a CTS (clear-to-send) and the data is transmitted. CTS and RTS signals are transmitted over two dedicated wires as defined in the RS-232 standard.  
Used only with RS-232.

*Serial Cmd:* <Kf2>

---

### Point-to-Point with RTS/CTS & XON/XOFF

---

*Definition:* This option is a combination of **Point-to-Point with RTS/CTS** and **Point-to-Point with XON/XOFF**.

*Usage:* Used only with RS-232.

*Serial Cmd:* <Kf3>

---

### Polling Mode D

---

*Definition:* Like **Point-to-Point, Polling Mode D** requires a dedicated connection to the host; but unlike **Point-to-Point**, it requires an address and must wait for a poll from the host before sending data.

*Usage:* When in **Polling Mode D**, an address of 1 is automatically displayed on the configuration screen. However, during transmission, a 1C hex poll address (FS) and a 1D hex select address (GS) are substituted for the 1.

*Serial Cmd:* <Kf4>

---

## Protocol

### Multidrop

Note: See also “Multidrop Communications” on page A-32.

- 
- Definition:** **Multidrop** allows up to 50 devices to be connected to a single RS-485 host, with the scanner assigned an unique address (from 01 to 50).
- Usage:** The MS-5000 can be used as a concentrator to a single host port connection. When **Multidrop** is selected, the protocol characters for RES, REQ, etc. are assigned automatically.
- Multidrop Addresses:** Each address has its own separate poll and select address (from 1C to 7F hex).
- Options:** 01 through 50
- Serial Cmd:** If selecting **Multidrop** (Kf5) an address must be defined and appended to the command string.  
Format: <Kf5,address>

**Note:** Scanners linking up to a Microscan MS-5000 multidrop concentrator must be configured in standard multidrop protocol.

### User Defined Point-to-Point

- 
- Definition:** **User Defined Point-to-Point** allows the user to customize the point-to-point protocol.
- Usage:** Useful for developing custom protocols in polled or unpolled mode.
- Serial Cmd:** <Kf6,RES,address,REQ,EOT,STX,ETX,ACK,NAK,from host>

### User Defined Address

- 
- Definition:** **User Defined** is considered to be in a polled mode only if an address has been assigned.
- Serial Cmd:** <Kf6,RES,address,REQ,EOT,STX,ETX,ACK,NAK,from host>
- Default:** No address
- Options:** Any ASCII character except a null.

### User Defined Example

**Definition:** Example: ACK/NAK protocol can be configured using **User Defined**. The scanner will transmit data to the host, when an **ACK** is received, it will carry on with its business. If a **NAK** or response timeout occurs, the scanner will re-send the data to the host up to 3 more times before aborting.

**Tip:** To use **User Defined Point-to-Point**, first select **Point-to-Point <Kf0>** and then **User Defined <Kf6>**.

**Example:** To select an unpolled ACK/NAK **User Defined** protocol with LRC disabled, send **<Kf0><Kf6,,,,,,,,^F,^U><Kc0>**. ACK and NAK will be displayed in the menu.

**Serial Cmd:** **<Kf6,RES,address,REQ,EOT,STX,ETX,ACK,NAK,from host>**

**Default:** **No assignment**

**Options:** Any ASCII character except a null. Control characters can be used to define RES through NAK in serial commands.

### From Host

**Definition:** This option allows the handshaking protocol to be initiated from the host, if not configured in an unpolled mode. Messages sent to the host will include the scanner's defined protocol. The status of **From Host** determines if messages sent from the host to the scanner must include the defined protocol. If **From Host** is disabled, the defined protocol is not included. If **From Host** is enabled, the defined protocol must be included.

**Serial Cmd:** **<Kf6,RES,address,REQ,EOT,STX,ETX,ACK,NAK,from host>**

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

## User Defined Multidrop

- Definition:** **User Defined Multidrop** allows the user to customize the polling protocol.
- Usage:** This option is used when connecting to a concentrator or other device that does not match standard multidrop protocol.  
If selecting **User Defined Multidrop** (7), complete the format by either choosing new parameters or place commas where unchanged data fields occur.
- Serial Cmd:** **<Kf7,RES,address,REQ,EOT,STX,ETX,ACK,NAK>**  
For **User Defined Multidrop**, first select **Multidrop <KF5>**, then **User Defined Multidrop <KF7...>**.
- Address:** Any single character (02 hex to 7E hex) in the ASCII table can be assigned as the address character. The character chosen is used as the poll character and the subsequent ASCII character becomes the select character. For example, if a **^B** (02 hex) is selected as the address, **^C** (03 hex) becomes the select address that the host will use in sending host select commands.

**Note:** Any ASCII character except a null (00) and a ^A (01) can be assigned as an address. Control characters can be used to define RES through NAK in serial commands. (See "[Communication Protocol Commands](#)" on page A-18.)

**Note:** Definitions of commands in **User Defined** and **User Defined Multidrop** must be duplicated in host applications to enable poll and select sequences to execute correctly during transmission.

**Note:** Typically, parameters in **User Defined Multidrop** are defined by first enabling **Multidrop**, then enabling **User Defined Multidrop**. This pre-loads multidrop characters into the parameters. Then changes are made to individual characters to match the host or other requirements.

# LRC

(Longitudinal Redundancy Check)

*Definition:* An error-checking routine that verifies the accuracy of transmissions. It is the exclusive OR of all characters following the **STX** (start of text) up to and including the **ETX** (end of text). What this means is that the binary representation of all the characters in a transmissions are cumulatively added in a column and each resulting odd integer is assigned a 1 and each even integer a 0 (two 1s = 0, two 0s = 0, a 1 and a 0 = 1). The extra **LRC** character is then appended to the transmission and the receiver (usually the host) performs the same addition and compares the results.

*Usage:* Used when extra data integrity is required.

*Serial Cmd:* <**Kcstatus**>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Response Timeout

*Definition:* Time the scanner will wait before timing out if **ACK**, **NAK**, and **ETX** are enabled, and a host response is expected.

*Usage:* Only used when a response is required from the host. While in **Multi-drop**, if the scanner does not receive an **ACK** or **NAK** from the host after sending polled data, it will act on a fault. The scanner can be set to wait indefinitely by setting **Response Timeout** to zero.

*Serial Cmd:* <**KA**response timeout>

*Default:* **12**mS

*Options:* 0 to 255 (A zero (0) setting causes an indefinite wait.)

## Intercharacter Delay

- Definition:* The time interval in milliseconds between individual characters transmitted from the scanner to the host.
- Usage:* **Intercharacter Delay** is only used where a host cannot receive data quickly enough and there is enough time between labels to allow data to be completely transferred. It is rarely used since any setting other than zero will slow down communications. For example, a 200 setting will result in a 1/5 second delay between each character that is transmitted.
- Serial Cmd:* **<KBintercharacter delay>**  
Example: To change **Intercharacter Delay** to 30 ms, send **<KB30>**.
- Default:* **0**
- Options:* 0 to 255 (in milliseconds). Zero (0) causes no delay between characters.

# Output Data Format

Up to four user defined ASCII characters, including control characters can be defined and added to the front or end of the data string that is sent from the scanner to the host.

## Preamble Characters

### Preamble Status

*Definition:* Define a one to four character data string that can be added to the front of the decoded data.

*Usage:* Useful for identifying and controlling incoming data. For example, defining the **preamble** as a carriage return and a line feed causes each decoded message to be displayed on its own line.

*Serial Cmd:* **<Kdstatus,preamble character(s)>**

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled (within any protocol)

### Preamble Character(s)

*Serial Cmd:* **<Kdstatus,preamble character(s)>**

*Default:* **^M** corresponding to: **carriage return/null/null/null.**

*Options:* **Within a Serial Command**

To enter control characters within a serial command, hold down the control key while typing the desired character.

Example: **<Kd1,CNTL-m>** to enter **^M**

**Within an Embedded Menu**

Control characters entered on the command line are displayed in the menu as mnemonic characters, such as: **<CR><NUL><NUL><NUL>**.

To enter a control character from within an embedded menu, first type in a space (with the space key). This has the effect of allowing the control key to be recognized as a part of the control character. Next hold down the control key while typing the desired character.

Example: **Space CNTL-m** to enter **^M**.

## Postamble Characters

### Postamble Status

---

|                    |   |
|--------------------|---|
| <i>Definition:</i> | Allows the user to enable or disable up to four postamble character(s) that can be added to the end of the decoded data.  |
| <i>Usage:</i>      | Useful for identifying and controlling incoming data. For example, defining the postamble as a carriage return and a line feed causes each decoded message to be displayed on its own line. |
| <i>Serial Cmd:</i> | < <b>Ke</b> status,postamble character(s)>  |
| <i>Default:</i>    | <b>Enabled</b>  |
| <i>Options:</i>    | 0 = Disabled      1 = Enabled (within any protocol)   |

### Postamble Character(s)

---

|                    |  |
|--------------------|--|
| <i>Serial Cmd:</i> | < <b>Ke</b> status, <b>postamble character(s)</b> >  |
| <i>Default:</i>    | <b>^M^J</b> . Corresponds to carriage return/line feed/null/null, as displayed in the menu.  |
| <i>Options:</i>    | Up to four user-defined ASCII character, including control characters.   |
|                    | <i>Within a Serial Command</i>   |
|                    | To enter control characters within a serial command, hold down the control key while typing the desired character.   |
|                    | Example: < <b>Ke</b> 1, <b>CNTL-m CNTL-j</b> > to enter ^M^J.  |
|                    | <i>Within an Embedded Menu</i>   |
|                    | Control characters entered on the command line are displayed in the menu as mnemonic characters, such as: <CR><LF><NUL><NUL>   |
|                    | To enter a control character from within an embedded menu, first type in a space (with the space key). This has the effect of allowing the control key to be recognized as a part of the control character. Next hold down the control key while typing the desired character. |
|                    | Example: <b>Space CNTL-m Space CNTL-j</b> to enter ^M^J.   |



*Chapter*

4

# Read Cycle/Trigger


## Chapter Contents

|                              |      |
|------------------------------|------|
| Trigger Mode .....           | 4-4  |
| External Trigger State ..... | 4-10 |
| End of Read Cycle .....      | 4-11 |
| Multilabel.....              | 4-14 |

Read cycles and triggering modes are at the heart of bar code scanning. After you've established communications and completed basic read rate testing, you will need to address the spatial and timing parameters associated with your application. In a typical operation a bar-coded item moves along a line past a scanner. A sensor or timer activates a read cycle during which the scanner actively searches for bar code symbols. You will need to decide how to initiate the read cycle and how and when to end it. This section addresses these issues.

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Read Cycle/Trigger by ESP



Click this Button to bring up the **Read Cycle/Triggering** menu

To change a setting, **double-click** the setting and use your cursor to scroll through the options.

| Parameters                          | Program Values  |
|-------------------------------------|-----------------|
| [-] Read Cycle / Triggering         |                 |
| [-] Triggering                      |                 |
| Mode                                | Continuous Read |
| Filter Time                         | 78              |
| [+] End of Read Cycle Mode          |                 |
| External Trigger                    | Positive        |
| Serial Trigger                      | G5              |
| Good Decode Reads                   | 1               |
| [-] Multilabel                      |                 |
| Number of Labels                    | 1               |
| Separator                           | ,               |
| [+] Scanner Setup (Factory Setti... |                 |

## Read Cycle/Trigger by Serial Command

4-Read Cycle/Trig-

| Command Title            | Cmd       | Format  |
|--------------------------|-----------|---|
| Triggering Mode          | <b>Kg</b> | < <b>Kg</b> trigger mode, filter time>              |
| End of Read Cycle        | <b>Kh</b> | < <b>Kh</b> mode, timeout>                          |
| Serial Trigger Character | <b>Ki</b> | < <b>Ki</b> character>                              |
| External Trigger State   | <b>Kj</b> | < <b>Kj</b> external trigger state>                 |
| Decodes Before Output    | <b>Km</b> | < <b>Km</b> decodes before output>                  |
| Multilabel               | <b>KL</b> | < <b>KL</b> number of labels, multilabel separator> |

### Read Cycle/Trigger by Embedded Menu

For information on accessing the embedded menus, see “Embedded Menus” on page A-19.

```

                                CURRENT SETTINGS FOR OPERATIONS
-----
TRIGGERING MODE      = CONTINUOUS READ  || MATCHCODE TYPE      = DISABLED
END OF READ CYCLE   = TIMEOUT          || SEQUENTIAL MATCHING = INCREMENT
TIMEOUT in 10ms incs = 1000 ms         || MATCH START POSITION = 0
TRIGGER CHARACTER    = N/A              || MATCH LENGTH        = 1
EXTERNAL TRIGGER     = N/A              || WILD CARD CHARACTER = *
TRIGGER FILTER       = 9984 us          || SEQUENCE ON NOREAD  = ENABLED
GOOD DECODE READS   = 1                 || SEQUENCE ON MISMATCH = DISABLED
NEW MASTER PIN      = DISABLED          || MATCH DATABASE SIZE = 1
NUMBER OF LABELS    = 1
MULTILABEL SEPARATOR = ,

-----
ESC = MAIN MENU OR EXIT  N = NEXT ITEM
M  = PREVIOUS MENU      SP = NEXT ITEM
B  = PREVIOUS ITEM      CR = THIS ITEM
-----
OPERATIONS--> TRIGGERING MODE      = CONTINUOUS READ_

```

From the Main menu, scroll down through the options until you reach the following screen:

## Trigger Mode

*Definition:* The type of trigger event that will initiate the read cycle.

*Serial Cmd:* <Kg**trigger mode**,trigger filter duration>

*Default:* **Continuous Read**

*Options:*

|                              |                                 |
|------------------------------|---------------------------------|
| 0 = Continuous Read          | 4 = Serial Data                 |
| 1 = Continuous Read 1 Output | 5 = Serial Data & External Edge |
| 2 = External Level           |                                 |
| 3 = External Edge            |                                 |

### Continuous Read

*Definition:* In **Continuous Read**, trigger input options are disabled, the scanner is always in the read cycle, and it will attempt to decode and transmit every scan crossing a label.

**When To Output** and **Noread** options have no affect on **Continuous Read**.

*Usage:* **Continuous Read** is useful in testing bar code label readability or scanner functions. It is not recommended for normal operations.

*Serial Cmd:* <Kg**0**>

## Continuous Read 1 Output

- Definition:* In **Continuous Read 1 Output** the scanner self-triggers whenever it decodes a new bar code label or a timeout occurs.
- If **End Of Read Cycle** is set to **Timeout** and the label doesn't change, the scanner will repeat the output at the end of each timeout period. For example, if **Timeout** is set to one second, the scanner sends the label data immediately and repeats the output at intervals of one second for as long as the label continues to be scanned.
- If **End Of Read Cycle** is set to **New Trigger**, the scanner will send the current label data immediately, but send it only once. A new label appearing in the scanner's range will be read and sent immediately provided it is not identical to the previous label read.
- Usage:* **Continuous Read 1 Output** can be useful in applications where it is not feasible to use a trigger and all succeeding labels contain different information. It is also effective in applications where the objects are hand presented.
- Serial Cmd:* **<Kg1>**

**Caution:** In automated environments, **Continuous Read 1 Output** is not recommended because there is no one to verify that a label was missed.

**Note:** If **Trigger** is set to **Continuous Read 1 Output**, **Number of Labels** will default back to **1** (if set to any number greater than 1).

## External Trigger Level

**Definition:** **External Trigger Level** allows the read cycle (active state) to begin when a trigger (change of state) from an external sensing device is received. The read cycle endures until the object moves out of the sensor range and the active trigger state changes again.

**Usage:** This mode is effective in an application where the speeds of the conveying apparatus are variable and the time the scanner spends scanning each object is not predictable. It also allows the user to determine if a noread has occurred.




Figure 4-1 Trigger Level

Serial Cmd: **<Kg2>**

**Important:** **Level** and **Edge** apply to the active logic state (Active Off ( $I_{OFF}$ ) or Active On ( $I_{ON}$ )) that exists while the object is in a read cycle, between the rising edge and falling edge. *Rising edge* is the trigger signal associated with the appearance of an object. *Falling edge* is the trigger signal associated with the subsequent disappearance of the object.

## External Trigger Edge

**Definition:** **External Trigger Edge**, as with Level, allows the read cycle (active state) to begin when a trigger (change of state) from an external sensing device is received. However, the passing of an object out of sensor range does not end the read cycle. The read cycle ends with a good read output or, depending on **End of Read Cycle** setting, a timeout or new trigger occurs.

**Usage:** This mode is highly recommended in any application where conveying speed is constant or if spacing, object size, or timeouts are consistent.




Figure 4-2 Trigger Edge

**Serial Cmd:** <Kg3>

**Important:** **Level** and **Edge** apply to the active logic state (**Active Off** ( $I_{OFF}$ ) or **Active On** ( $I_{ON}$ )) that exists while the object is in a read cycle, between the rising edge and falling edge. *Rising edge* is the trigger signal associated with the appearance of an object. *Falling edge* is the trigger signal associated with the subsequent disappearance of the object.

---

## Trigger Mode

### Serial Data

---

*Definition:* In **Serial Data**, the scanner accepts an ASCII character from the host or controlling device as a trigger to start a read cycle. A **Serial Data** trigger behaves the same as an **External Edge** trigger.

Serial commands are entered inside corner brackets, such as **<t>**.

*Usage:* **Serial Data** is effective in a highly controlled environment where the host knows precisely when the object is in the scan zone. It is also useful in determining if a noread has occurred.

*Serial Cmd:* **<Kg4>**

### Serial Data or External Edge

---

*Definition:* In this mode the scanner accepts either a serial ASCII character or an external trigger pulse to start the read cycle.

*Usage:* **Serial Data or External Edge** is seldom used but can be useful in an application that primarily uses an external sensing device but occasionally needs to be manually triggered.

An auxiliary terminal can be connected to the aux port so the user can send the serial trigger character through the scanner to the host.

*Serial Cmd:* **<Kg5>**

## Trigger Filter Duration

- Definition:** **Trigger Filter Duration** can prevent trigger bounce from falsely triggering the scanner by limiting the time in which trigger pulses can be received.
- Usage:** **Trigger Filter Duration** is useful where trigger bounce could cause false triggers.
- Serial Cmd:** **<Kg trigger mode,trigger filter duration>**
- Default:** **78** (x 128 $\mu$ s = 9984 $\mu$ s)
- Options:** **0 to 65535** (corresponding to 0 to 2.048s in 31.25 $\mu$ s steps)

## Good Decode Reads

- Definition:** The number of decodes (from 1 to 31) required per label before a label's decoded data is sent. It requires the scanner to successfully decode a label a designated number of times (not necessarily consecutively) before it is sent. If it doesn't achieve the number of good reads during the read cycle, then a noread will be sent.
- Note:** Higher settings will decrease throughput speed.
- Usage:** This is a very useful feature to increase reliability of reads for symbologies that do not have internal error checking such as Pharmacode.
- Serial Cmd:** **<Km decodes before output>**
- Default:** **1**
- Options:** 1 to 31

**Note:** When setting up, be sure to determine if the scanner's scan rate is capable of scanning your longest label the required number of times.

## External Trigger State

*Definition:* When enabled for **Active On (I<sub>ON</sub>)** (Positive) the triggering device imposes a current on the optoisolator to activate the read cycle. When enabled for **Active Off (I<sub>OFF</sub>)** (Negative) the triggering device interrupts the current to the optoisolator to activate the read cycle.

*Usage:* Allows users to select the trigger state that will operate with their systems.

(If using the Microscan object detector, use **Active Off.**)

*Serial Cmd:* **<Kjexternal trigger state>**

*Default:* **Active On** (Positive)

*Options:* 0 = Active Off (Negative)

1 = Active On (Positive)

**Note:** **External Level**, **External Edge**, or **Serial Data or Edge** trigger mode must be enabled for **External Trigger** to take effect.

## End of Read Cycle


**Definition:** The read cycle is the time during which the scanner will attempt to read and decode a bar code symbol.

**Serial Cmd:** <**Khend of read cycle status,timeout**>

### End of Read Cycle Status

**Definition:** A read cycle can be terminated by a new trigger, a timeout, or a combination of both.

**ESP:** Double-click on **End of Read Cycle Mode** and make a selection.



**Serial Cmd:** <**Khend of read cycle status,timeout**>

**Default:** **Timeout**

**Options:**  
 0 = Timeout  
 1 = New Trigger  
 2 = Timeout & New Trigger

**Note:** When operating in **Continuous Read** or **Continuous Read 1 Output**, the scanner is always in the read cycle.

---

## End of Read Cycle

### Timeout

---

**Definition:** **Timeout** ends the read cycle, causing the scanner to stop reading labels and send the label data or noread message when the time set in **Timeout** elapses (times out), if **When to Output** is set to **End of Read Cycle**.

If in **Continuous Read 1 Output**, a timeout initiates a new read cycle and allows the same label to be read again.

With either **External Edge**, **Serial Data**, or **Serial Data & Edge** enabled, a timeout ends the read cycle and label data or a noread message is sent to the host.

With **External Level** enabled, the read cycle does not end until the falling edge trigger or a timeout occurs. The next read cycle does not begin until the next rising edge trigger.

**Usage:** Typically used with Serial or **Edge** and **Continuous One**.

It is effective in highly controlled applications when the maximum length of time between objects can be predicted. It assures that a read cycle ends before the next bar-coded object appears, giving the system extra time to decode and transmit the data to the host.

## New Trigger

**Definition:** **New Trigger** ends the current read cycle and initiates a new one when a new trigger occurs. **New Trigger** refers only to a “rising edge” trigger.

With either **External Edge**, **Serial**, or **Serial** or **Edge** enabled, an edge or serial trigger ends a read cycle and initiates the next read cycle.

In the case of **External Level**, a falling edge trigger ends the read cycle but the next read cycle does not begin until the occurrence of the next rising edge trigger.

(See [figure 4-1 on page 4-6](#) and [figure 4-2 on page 4-7](#).)

**Usage:** **New Trigger** is an effective way to end a read cycle when objects move past the scanner at irregular intervals (not timing dependent).

**Note:** When **New Trigger** is enabled, **Laser On/Off** will have no effect. When no reads occur, the laser will remain on.

## Timeout or New Trigger

**Definition:** **Timeout or New Trigger** is identical to **Timeout**, except that a timeout or a new trigger (whichever occurs first) ends the read cycle.

**Usage:** Useful in applications that require an alternative way to end the read cycle. For example, if an assembly line should stop completely or the intervals between objects are highly irregular.

## Timeout Duration

**Definition:** **Timeout Duration** is the time span of the read cycle and is represented in 10 mS increments. It is used in conjunction with **External Edge** or **Serial Trigger**.

**Usage:** It is useful in many tightly controlled applications which require a read cycle to end before the next object appears and therefore need the flexibility of a timeout adjustment.

**Serial Cmd:** `<Kh end of read cycle status, timeout>`

**Default:** **100** (Corresponds to one second or 1000 ms.)

**Options:** 0 to 65535. (Divide any positive number entered by 100 to determine the time in seconds.)

**Note:** A minimum setting of **2** is recommended.

**Note:** **Timeout** or **Timeout or New Trigger** under **End of Read Cycle** must be enabled for **Timeout Duration** to take effect.

# Multilabel

- Definition:** **Multilabel** allows the user to define up to 12 bar code labels that can be read in a single read cycle.
- Usage:** **Multilabel** is commonly used in shipping applications where a shipping label contains individual bar codes for part number, quantity, etc. This feature allows one trigger to pick up all the labels. AIAG and UCC/EAN-128 are two application standards that address this need.
- Conditions** Allows you to choose the number of different labels that can be read in a single trigger event. The following conditions apply:
1. All noread messages are posted at the end of the data string.
  2. If more than one label is within the scan beam at the same time, label data may not be displayed in the order of appearance.
  3. If **Matchcode Type** is set to **Sequential** or if **Trigger** is set to **Continuous Read 1 Output, Number of Labels** will default to **1** (if set to any number greater than 1).
  4. The maximum number of characters in any one bar code (other than PDF417) is **64**. For PDF417 it's **2710**.
  5. The maximum number of characters in a single scan line is **102** (Code 39).
  6. The maximum number of characters for all labels is **788**, including preamble, separators, and LRC.

Table 4-1 Maximum Number of Characters per Numbers of Labels

| Number of labels | Non-PDF Labels Cumulative Maximum | PDF Labels        |                    |
|------------------|-----------------------------------|-------------------|--------------------|
|                  |                                   | Maximum per label | Cumulative Maximum |
| 1-5              | 333                               | 2710              | 13563              |
| 6                | 398                               | 2320              | 13961              |
| 7                | 463                               | 2030              | 14225              |
| 8                | 528                               | 1804              | 14448              |
| 9                | 593                               | 1622              | 14615              |
| 10               | 658                               | 1474              | 14758              |
| 11               | 723                               | 1350              | 14869              |
| 12               | 788                               | 1246              | 14972              |

4-Read Cycle/Trig-

## Number of Labels

*Definition:* **Number of Labels** is the number of different labels that can be read in a single read cycle.

*Serial Cmd:* <**KL***number of labels*,multilabel separator>


*Default:* **1**

*Options:* 1 to 12

## Multilabel

### Multilabel Separator

- Definition:** The character that's inserted between each label scanned when **Multi-label** is set to any number greater than **1**.
- Usage:** Used to delimit or separate data fields with a user defined character.
- ESP:** Double-click on **Separator** and select a character in the popup window.



**Serial Cmd:** <KL number of labels, **multilabel separator**>

**Note:** If **Multilabel Separator** has been changed to any other character than the default comma and you wish to re-define the separator as a comma, use ESP (as shown below) or the embedded menu.

**Default:** , (comma)

**Options:** Any available ASCII character, except < > **NUL**.

## Chapter Contents

|                          |      |
|--------------------------|------|
| Narrow Margins .....     | 5-5  |
| Symbology ID .....       | 5-6  |
| Background Color .....   | 5-7  |
| Code 39 .....            | 5-8  |
| Codabar .....            | 5-11 |
| Interleaved 2 of 5 ..... | 5-14 |
| UPC/EAN .....            | 5-16 |
| PDF417 .....             | 5-19 |
| Code 128 .....           | 5-21 |
| UCC/EAN-128 .....        | 5-22 |
| Code 93 .....            | 5-25 |
| AIAG .....               | 5-26 |
| Autodiscriminate .....   | 5-29 |

This section describes the various bar code symbol types that can be read and decoded by the scanner.


**Code 39** is enabled by default. To enable all codes, right-click **Autodiscrimination** under Code Type in the Utilities menu and select **Enable**, or send a **<P>** serial command to the scanner from the Terminal window.<sup>1</sup>

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

See [www.aimusa.org/standards](http://www.aimusa.org/standards) for additional information about codes.

1. If using an I 2/5 label, verify that the number of characters in the label being scanned matches the code length enabled for the I 2/5 code type (default is 10 and 6).

## Code Types by ESP



Click this button to bring up the **Code Types** menu.

To change a setting, **double-click** the setting and use your cursor to scroll through the options.

| Parameters                      | Program Values |
|---------------------------------|----------------|
| [-] Code Type / Symbologies     |                |
| [-] Narrow Margins/Symbology ID |                |
| [-] Narrow Margins              | Disabled       |
| [-] Symbology ID                | Disabled       |
| [-] Background Color            | White          |
| [+] Code 39                     |                |
| [+] Interleaved 2 of 5          |                |
| [+] PDF417                      |                |
| [+] UPC/EAN                     |                |
| [+] Code 128                    |                |
| [+] Codabar                     |                |
| [+] Code 93                     |                |
| [+] AIAG                        |                |

## Code Types by Serial Command

| Command Title                       | cmds       | Format  |
|-------------------------------------|------------|---|
| Narrow Margins/Symbology ID         | <b>Ko</b>  | < <b>Ko</b> narrow margins status,symbology ID status>  |
| Background Color                    | <b>Kx</b>  | < <b>Kx</b> background color>   |
| Code 39                             | <b>Kp</b>  | < <b>Kp</b> status,check digit status,check digit output status,large intercharacter gap,fixed code length status,fixed code length,full ASCII>   |
| Codabar                             | <b>Kq</b>  | < <b>Kq</b> status,start & stop match status,start & stop output status,large intercharacter gap,fixed code length status,fixed code length,check digit type,check digit output>                                  |
| Interleaved 2 of 5                  | <b>Kr</b>  | < <b>Kr</b> status,check digit,check digit output,length 1,length 2>  |
| UPC/EAN                             | <b>Ks</b>  | < <b>Ks</b> status,EAN status,supplementals status,separator char.>   |
| PDF417                              | <b>K[</b>  | < <b>K[</b> status,[unused],fixed code length status,fixed code length>   |
| Code 128                            | <b>Kt</b>  | < <b>Kt</b> status,fixed length,length>   |
| EAN-128                             | <b>Kt</b>  | < <b>Kt</b> ,,EAN-128 status,output format,separator status,separator character,application identifier parentheses,record padding>  |
| UCC/EAN-128<br>(subset of Code 128) | <b>Kt</b>  | < <b>Kt</b> ,,UCC/EAN-128 status,output format,application record separator status,application record separator character,application record brackets,application record padding>                                 |
| Code 93                             | <b>K!</b>  | < <b>K!</b> status,fixed code length status,fixed code length>  |
| AIAG                                | <b>KZ</b>  | < <b>KZ</b> AIAG status, ID1, status1, ID2, status2, ID3, status3, ID4, status4, *ID5a,ID5b,ID5c, status5, ID6, status6, ID7, status7, ID8, status8, ID9, status9, ID9, status10, ID11, status11, ID12, status12> |
| Code Type Status Request            | <b>KW?</b> | < <b>KW?</b> >  |

## Code Types by Embedded Menu

For information on accessing the embedded menus, see ["Embedded Menus" on page A-19](#).

From the Main menu, scroll down through the options until you reach the following screens:

| CURRENT SETTINGS FOR CODE TYPES 1 |          |          |          |          |          |
|-----------------------------------|----------|----------|----------|----------|----------|
|                                   | CODE 39  | PDF417   | I 2 OF 5 | UPC      | CODE 128 |
| CODE TYPE                         | ENABLED  | DISABLED | DISABLED | DISABLED | DISABLED |
| FIXED LENGTH                      | DISABLED | DISABLED | N/A      | N/A      | DISABLED |
| CODE LENGTH 1,2                   | 10, N/A  | 10, N/A  | 10, 6    | N/A      | 10, N/A  |
| CHECK DIGIT                       | DISABLED | N/A      | DISABLED | N/A      | N/A      |
| C/D OUTPUT                        | DISABLED | N/A      | DISABLED | N/A      | N/A      |
| INTERCHAR GAP                     | DISABLED | N/A      | N/A      | N/A      | N/A      |
| FULL ASCII                        | DISABLED | N/A      | N/A      | N/A      | N/A      |
| SUPPLEMENTALS                     | N/A      | N/A      | N/A      | DISABLED | N/A      |
| EAN                               | N/A      | N/A      | N/A      | DISABLED | DISABLED |
| UCC/EAN FORMAT                    | N/A      | N/A      | N/A      | N/A      | STANDARD |
| SEPARATOR STATUS                  | N/A      | N/A      | N/A      | DISABLED | DISABLED |
| SEPARATOR DEFINE                  | N/A      | N/A      | N/A      | N/A      | N/A      |
| AP.REC.BRACKETS                   | N/A      | N/A      | N/A      | N/A      | DISABLED |
| AP.REC.PADDING                    | N/A      | N/A      | N/A      | N/A      | ENABLED  |

| CURRENT SETTINGS FOR CODE TYPES 2 |          |          |  |  |  |
|-----------------------------------|----------|----------|--|--|--|
|                                   | CODE 93  | CODABAR  |  |  |  |
| CODE TYPE                         | DISABLED | DISABLED |  |  |  |
| FIXED LENGTH                      | DISABLED | DISABLED |  |  |  |
| CODE LENGTH #1                    | 10       | 10       |  |  |  |
| CODE LENGTH #2                    | N/A      | N/A      |  |  |  |
| CHECK DIGIT                       | N/A      | DISABLED |  |  |  |
| C/D OUTPUT                        | N/A      | DISABLED |  |  |  |
| INTERCHAR GAP                     | N/A      | DISABLED |  |  |  |
| S/S MATCH                         | N/A      | ENABLED  |  |  |  |
| S/S OUTPUT                        | N/A      | ENABLED  |  |  |  |

| CURRENT SETTINGS FOR GLOBAL CODE PARAMETERS |   |          |          |          |          |
|---|---|----------|----------|----------|----------|
| NARROW MARGINS                              | = | DISABLED |          |          |          |
| SYMBOLGY ID                                 | = | DISABLED |          |          |          |
| BACKGROUND COLOR                            | = | WHITE    |          |          |          |
| AIAG  | = | DISABLED |          |          |          |
| ID1   | = | N        |          |          |          |
| ID2   | = | P        |          |          |          |
| ID3   | = | Q        |          |          |          |
| ID4   | = | V        |          |          |          |
| ID5   | = | DISABLED | ID5a = S | ID5b = M | ID5c = G |
| ID6   | = | H        |          |          |          |
| ID7   | = | EZ       |          |          |          |
| ID8   | = | EB       |          |          |          |
| ID9   | = | ED       |          |          |          |
| ID10  | = | EC       |          |          |          |
| ID11  | = | EL       |          |          |          |
| ID12  | = | EX       |          |          |          |

## Narrow Margins

*Definition:* Allows the scanner to read symbols with quiet zones less than 8 times the width of the narrow bar element. "Quiet zone" is the space at the leading and trailing ends of a symbol. Each quiet zone can be as narrow as only five times the width of the narrow bar element when **Narrow Margins** is enabled.

*Usage:* Used when the leading and trailing edges of the symbols are smaller than the standard margin or other objects encroach into the margins.

*Serial Cmd:* <**Konarrow margins status**,symbology identifier>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

**Note:** Do not use **Narrow Margins** with **Large Intercharacter Gap** enabled in Code 39 or Codabar.

# Symbology ID

**Definition:** Symbology ID is an AIM standard prefix character that identifies the bar code type.

When enabled, the scanner analyzes and identifies the bar code symbology and adds a three character identifying prefix to the data:

1. **]** (close bracket character) indicating the presence of a symbology ID
2. **A, C, E, F, G, I, L, Q**  
A = Code 39; C = Code 128 or UCC/EAN-128; E = UPC/EAN; F = Codabar; G = Code 93; I = I-2 of 5; L = PDF417; Q = Pharma Code
3. **Modifier**, a single number indicating the status of the check digit character:

If **Check Digit** is not enabled, the output is 0 (Col. 1). If **Check Digit** and **Check Digit Output** are enabled, the output is as shown in Column 2. If **Check Digit** is enabled, but **Check Digit Output** is disabled (Col. 3), the output is as shown in Col. 4, which is the sum of Col. 2 and Col. 3.

**Usage:** Used when host needs to know the symbology type and how it's decoded.

**Serial Cmd:** `<K narrow margins status, symbology identifier>`

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

**Example:** For **Code 39**, if **Check Digit** and **Check Digit Output** are both enabled, a 1 will be sent; if **Check Digit Output** is disabled, a 3 (sum of column 1 and column 2) will be sent.

Table 5-1 Symbology Identifier Option Values

| Symbology I.D. | Symbology   | Column 1<br>No check character | Column 2<br>Check digit Output enabled | Column 3<br>Check digit Output disabled | Column 4<br>Sum of Column 2 and 3 | FNC 1 Character in first position |
|----------------|-------------|--------------------------------|--|---|-----------------------------------|-----------------------------------|
| <b>A</b>       | Code 39     | 0                              | 1                                      | 2                                       | 3                                 |                                   |
| <b>C</b>       | Code 128    | 0                              | 0                                      | 0                                       | 0                                 |                                   |
| <b>C</b>       | UCC/EAN-128 | 0                              | 0                                      | 0                                       | 0                                 | 1                                 |
| <b>E</b>       | UPC/EAN     | 0                              | 0                                      | 0                                       | 0                                 |                                   |
| <b>F</b>       | Codabar     | 0                              | 1                                      | 2                                       | 3                                 |                                   |
| <b>G</b>       | Code 93     | 0                              | 0                                      | 0                                       | 0                                 |                                   |
| <b>I</b>       | I-2 of 5    | 0                              | 1                                      | 2                                       | 3                                 |                                   |
| <b>L</b>       | PDF417      | 0                              | 0                                      | 0                                       | 0                                 |                                   |
| <b>Q</b>       | Pharma Code | 0                              | 0                                      | 0                                       | 0                                 |                                   |

# Background Color

**Definition:** Allows the user to choose which symbol background (white or black) the scanner can read.

**Usage:** If the background is darker than the symbol, then enable black background.

Typically the background is white; but on PCBs for example, they can be black.

**ESP:**



**Serial Cmd:** <**Kxbackground color**>

**Default:** **White**

**Options:**  
 0 = White  
 1 = Black

## Code 39

*Definition:* An alphanumeric code with unique start/stop code patterns, composed of 9 black and white elements per character, of which 3 are wide.

*Usage:* **Code 39** is considered the standard for non-retail symbology.

### Code 39 Status

*Serial Cmd:* <**Kpstatus**,check digit status,check digit output status,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>

*Default:* **Enabled**

Note: This is the only code type enabled by default.

*Options:* 0 = Disabled      1 = Enabled

### Check Digit Status (Code 39)

*Serial Cmd:* <**Kpstatus**,**check digit status**,check digit output,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

### Check Digit Output (Code 39)

*Definition:* When enabled, the check digit character is read and compared along with the label data. When disabled, label data is sent without the check digit.

**Note:** With **Check Digit Output** and an **External** or **Serial** trigger option enabled, an invalid check digit calculation will cause a noread message to be transmitted at the end of the read cycle.

*Usage:* **Check digit Output**, added to the bar code symbol, provides additional security.

*Serial Cmd:* <**Kpstatus**,check digit status,**check digit output**,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Large Intercharacter Gap (Code 39)

- Definition:** When enabled, the scanner can read symbols with gaps between bar code characters that exceed three times (3x) the narrow element width.
- Usage:** **Large Intercharacter Gap** is helpful for reading symbols that are printed out of specification.
- Caution:** Do not use **Large Intercharacter Gap** with **Narrow Margins** enabled since a large intercharacter gap (over 3x) could cause a narrow margins (5x) to be interpreted as an intercharacter gap.
- Serial Cmd:** `<Kp status,check digit status,check digit output,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>`
- Default:** **Disabled**
- Options:** 0 = Disabled      1 = Enabled

## Fixed Code Length Status (Code 39)

- Definition:** When enabled the scanner will check the label length against the code length field. If disabled any length would be considered a valid label.
- Serial Cmd:** `<Kp status,check digit status,check digit output,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>`
- Default:** **Disabled**
- Options:** 0 = Disabled      1 = Enabled

## Fixed Code Length (Code 39)

- Definition:** Specifies the exact number of characters that the scanner will recognize (this does not include start and stop and check digit characters). The scanner ignores any code not having the specified length.
- Usage:** **Fixed Code Length** helps prevent truncations and increases data integrity by ensuring that only one label length will be accepted.
- Serial Cmd:** `<Kp status,check digit status,check digit output,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>`
- Default:** **10**
- Options:** 1 to 128

---

## Code 39

### Full ASCII Set (Code 39)

**Definition:** Standard Code 39 encodes 43 characters; zero through nine, capital "A" through capital "Z", minus symbol, plus symbol, forward slash, space, decimal point, dollar sign and percent symbol. When **Full ASCII Set** is enabled, the scanner can read the full ASCII character set, from 0 to 255.

**Usage:** Must be enabled when reading characters outside the standard character set (0-9, A-Z, etc.)

User must know in advance whether or not to use **Full ASCII Set** option. Since **Full ASCII Set** requires two code words to encode one character, it is less efficient.

**Serial Cmd:** *<Kp status,check digit status,check digit output,large intercharacter gap,fixed code length status,fixed code length,full ASCII set>*

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

# Codabar

*Definition:* Codabar is a 16-character set (0 through 9, and the characters \$, :, /, ., +, and -) with start/stop codes and at least two distinctly different bar widths.

*Usage:* Used in photo-finishing and library applications. Formerly used in some medical applications but not typically used in newer applications.

## Codabar Status

*Serial Cmd:* <**Kqstatus**,start & stop match,start & stop match output,large inter-character gap,fixed code length status,fixed code length,check digit type,check digit output>

*Default:* **Disabled**

*Options:* 0 = Disable      1 = Enabled

## Start & Stop Match (Codabar)

*Definition:* Requires the Codabar start and stop characters (a, b, c, or d) to match before a valid read can occur.

*Usage:* Used to increase security of symbology.

*Serial Cmd:* <**Kqstatus**,**start & stop match**,start & stop match output,large inter-character gap,fixed code length status,fixed code length,check digit type,check digit output>

*Default:* **Enabled**

*Options:* 0 = Disabled      1 = Enabled

## Start & Stop Output (Codabar)

*Definition:* Causes the start and stop characters to be transmitted with bar code data.

*Usage:* Used to verify matching.

*Serial Cmd:* <**Kqstatus**,start & stop match,**start & stop match output**,large inter-character gap,fixed code length status,fixed code length,check digit type,check digit output>

*Default:* **Enabled**

*Options:* 0 = Disabled      1 = Enabled

## Large Intercharacter Gap (Codabar)

- Definition:** Instructs the scanner to read symbols with gaps between characters exceeding three times the narrow element width.
- Usage:** It is helpful for reading symbols that are printed out of specification.
- Caution:** Do not use **Large Intercharacter Gap** with **Narrow Margins** enabled since enabling **Large Intercharacter Gap** (over 3x) could cause a narrow margins (5x) to be interpreted as an intercharacter gap.
- Serial Cmd:** `<Kqstatus,start & stop match,start & stop output match,large inter-character gap,fixed code length status,fixed fixed code length,check digit type,check digit output>`
- Default:** **Disabled**
- Options:** 0 = Disabled      1 = Enabled

## Fixed Code Length Status (Codabar)

- Definition:** When enabled, the scanner will check the label length against the fixed code length field. If disabled any length would be considered a valid label.
- Serial Cmd:** `<Kqstatus,start & stop match,start & stop match output,large inter-character gap,fixed code length status,fixed code length,check digit type,check digit output>`
- Default:** **Disabled**
- Options:** 0 = Disabled      1 = Enabled

## Fixed Code Length (Codabar)

- Definition:** Specifies the exact number of characters that the scanner will recognize (this does not include start and stop and check digit characters). The scanner ignores any code not having the specified length.
- Usage:** **Fixed Code Length** helps prevent truncations and increases data integrity by ensuring that only one symbol length will be accepted.
- Serial Cmd:** `<Kqstatus,start & stop match,start & stop match output,large inter-character gap,fixed code length status,fixed code length,check digit type,check digit output>`
- Default:** **10**
- Options:** 1 to 128

**Note:** **Fixed Code Length Status** must be enabled for **Fixed Code Length** to take effect.

**Note:** Because of symbology limitations, setting **Code Length** to any number less than four will produce undetermined results.



## Interleaved 2 of 5

**Definition:** A dense, continuous, self-checking, numeric symbology. Characters are paired together so that each character has five elements, two wide and three narrow, representing numbers 0 through 9, with the bars representing the first character and the interleaved spaces representing the second character. (A check digit is highly recommended.)

**Important:** You must set **Code Length** in order to decode I 2/5 symbols.

**Usage:** It has been popular because it is the most dense code for printing numeric characters less than 10 characters in length; however Microscan does not recommend this symbology for any new applications because of inherent problems such as truncation.

### Interleaved 2 of 5 Status

**Serial Cmd:** <K**r**status,check digit status,check digit output status,code length #1,code length #2,guard bar>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

### Check Digit Status (Interleaved 2 of 5)

**Definition:** An error correcting routine in which the check digit character is added.

**Usage:** It is typically not used but can be enabled for additional security in applications where the host requires redundant check digit verification.

**Serial Cmd:** <K**r**status,**check digit status**,check digit output status,code length #1,code length #2>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

### Check Digit Output (Interleaved 2 of 5)

**Definition:** When enabled, a check digit character is sent along with the bar code data for added data security.

**Serial Cmd:** <K**r**status,check digit status,**check digit output**,code length #1,code length #2,guard bar>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

## Code Length #1 (Interleaved 2 of 5)

- Definition:** Allows user to define the symbol length. Because I 2/5 is a continuous code, it is prone to substitution errors. Hence, a code length must be defined and a bar code symbol must contain an even number of digits.
- Note:** If a start, stop or check digits are used, they are not included in the code length count.
- Usage:** With I 2/5, two code lengths can be defined. When using only one symbol length in an application, setting **Code Length #2** to 0 (zero) to ensure data integrity is recommended.
- Serial Cmd:** <Kr status,check digit status,check digit output status,**code length #1**,code length #2,guard bar>
- Default:** **10**
- Options:** 2 to 128, even.
- Since I 2/5 characters are paired, code length must be set to an even number. If **Check Digit** is enabled, add 2 to your code length. For example, if your symbol is 10 characters plus a check digit, then enable **Code Length** for 12.
- Note: Typically, when printing an I 2/5 label with an odd number of digits, a 0 will be added as the first character.

## Code Length #2 (Interleaved 2 of 5)

- Definition:** Allows user to define a second code length for I-2 of 5.
- Usage:** If using a second symbol, a zero or any even code length from 2 to 64 may be specified. If not using a second symbol, set Code Length #2 to 0 to ensure data integrity.
- Serial Cmd:** <Kr status,check digit status,check digit output status,code length #1,**code length #2**,guard bar>
- Default:** **6**
- Options:** 2 to 128, even.
- Since I 2/5 characters are paired, code length must be set to an even number. If **Check Digit** is enabled, add 2 to your code length. For example, if your symbol is 10 characters plus a check digit, then enable **Code Length** for 12.
- Note: Typically, when printing an I 2/5 label with an odd number of digits, a 0 will be added as the first character.

## UPC/EAN

**Definition:** UPC (Universal Product Code) is a fixed length numeric, continuous symbology. UPC can have two or five digit supplemental bar code data following the normal code. The U.P.C., Version A (U.P.C., A) symbol is used to encode a 12 digit number. The first digit is the number system character, the next five are the manufacturer number, the next five are the product number, and the last digit is the checksum character.

When enabled, the scanner will read UPC version A and UPC version E only.

**Usage:** Used primarily in POS application in the retail industry. It is commonly used with Microscan scanners in applications in combination with **Matchcode** when there is a need to verify that the right product is being placed in the right packaging.

### UPC Status

**Serial Cmd:** <**KsUPC status**,EAN status,supplementals status,separator status,separator character>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

### EAN Status

**Definition:** EAN is a subset of UPC. When enabled, the scanner will read UPC version A, UPC version E, EAN 13, and EAN 8. It also appends a leading zero to UPC version A symbol information and transmits 13 digits. If transmitting 13 digits when reading UPC version A symbols is not desired, disable **EAN**.

**Note:** The extra character identifies the country of origin.

**Usage:** **EAN** is the European version of the UPC symbology and is used in European market applications.

**Note:** **UPC** must be enabled for **EAN** to take effect.

**Serial Cmd:** <**KsUPC status**,**EAN status**,supplementals status, separator status, separator character>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

## Supplementals Status (UPC/EAN)

- Definition:** A supplemental is a 2 or 5 digit symbol appended to the main label. When set to **Enabled** or **Required**, the scanner reads supplemental bar code data that has been appended to the standard UPC or EAN codes.
- Usage:** Reads **Supplementals** typically used in publications and documentation.
- Serial Cmd:** <**Ks**UPC status,EAN status,**supplementals status**,separator status,separator character,>
- Default:** **Disabled**
- Options:** 0 = Disabled      1 = Enabled      2 = Required
- Disabled:** UPC **Supplementals** will not be decoded.
- Enabled:** When enabled, the scanner will try to decode a main and a supplemental. However, if a supplemental is not decoded, at the end of the read cycle, the main will be sent by itself. The UPC main and supplemental symbols are considered to be one symbol and will be treated as such.
- Required:** When set to **Required** and either the main or supplemental symbol is not read, a single noread condition results. The UPC main and supplemental symbols are treated as one symbol.
- For example, if **Supplementals** is set to **Required**, **Separator** is enabled, and an asterisk is defined as the UPC separator character, then the data will be displayed as: MAIN \* SUPPLEMENTAL.

**Note:** Under no circumstances will supplemental symbol data be sent without a main symbol.

**Note:** If additional symbols—other than the main or supplemental—will be read in the same read cycle, **Number of Labels** should be set accordingly.

## Separator Status (UPC/EAN)

- Definition:** Allows the user to insert a character between the standard UPC or EAN code and the supplemental code when **Supplementals** is set to **Enabled** or **Required**.
- Usage:** Allows user to distinguish between the main and **Supplemental** symbols.
- Serial Cmd:** <**Ks**UPC status,EAN status,supplementals status,**separator status**,separator character>
- Default:** **Disabled**
- Options:** 0 = Disabled      1 = Enabled

### Separator Character (UPC/EAN)

- Definition:* Allows the user to change the separator character from a comma to a new character.
- Usage:* As required by the application.
- Serial Cmd:* **<Ks**UPC status,EAN status,supplementals status,separator status,**separator character**>
- Default:* **, (comma)**
- Options:* Any ASCII character

**Note:** If **Separator Character** has been changed to any other character and you wish to re-define the separator as a comma, you will need to use ESP or the embedded menu.

**Note:** Whenever **Separator Character** is defined as a comma (,) sending a **<Ks?>** command will return the current definitions including the separator character comma which will appear between two serial separator commas.

### Supplementals Type (UPC/EAN)

- Definition:* Allows the user to select 2 character or 5 character supplements, or both.
- Usage:* As required by symbology used in application.
- Serial Cmd:* **<Ks**UPC status,EAN status,supplementals status,separator status,**separator character,supplemental type**>
- Default:* **Both**
- Options:*  
0 = Both  
1 = 2 char only  
2 = 5 char only
- Both:* Either 2 character or 5 character supplementals will be considered valid.
- 2 Char Only:* Only two character supplementals will be considered valid.
- 5 Char Only:* Only five character supplementals will be considered valid.

## PDF417

*Definition:* A two-dimensional, multi-row (3 to 90), continuous, variable length symbology that has high data capacity for storing up to 2700 numeric characters, 1800 printable ASCII characters, or 1100 binary character per symbol. Each symbol character consists of 4 bars and 4 spaces in a 17-module structure.

*Usage:* Used in applications where a large amount of information (over 32 characters) needs to be encoded within a symbol, typically where the symbol is transported from one facility to another. For example, an automobile assembly line might use a single label with multiple fields of information that will be read at several stations along the way, without reference to a database.

*Serial Cmd:* **<K[status],[unused],fixed code length status,fixed code length>**

### PDF417 Status

*Serial Cmd:* **<K[status],[unused],fixed code length status,fixed code length>**

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

### Fixed Code Length (PDF417)

*Definition:* When enabled, the PDF label must contain the same number of characters as the code length setting before it can be considered a good decode. The scanner will ignore any code not having the specified length.

*Usage:* Used to increase data integrity by ensuring that only one label length will be accepted.

### Fixed Code Length Status (PDF417)

*Serial Cmd:* <K[status,[unused]][unused],**fixed code length status**,fixed code length>

*Default:* **Disabled**

*Options:* 0 = Disabled 1 = Enabled

### Fixed Code Length (PDF417)

*Definition:* Specifies the exact number of characters the scanner will recognize.

*Serial Cmd:* <K[status,[unused]][unused],fixed code length status,**fixed code length**>

*Default:* **10**

*Options:* 1 to 2710

**Note:** **Fixed Code Length Status** must be enabled for **Fixed Code Length** to take effect.

## Code 128

**Definition:** A very dense alphanumeric symbology. It encodes all 128 ASCII characters, it is continuous, has variable length, and uses multiple element widths measured edge to edge.

**Usage:** **Code 128** is a smaller code useful in applications with tight spots and high security needs.

### Code 128 Status

**Serial Cmd:** <**Kt status**,fixed code length status,fixed code length>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

### Fixed Code Length Status (Code 128)

**Definition:** When enabled the scanner will check the label length against the code length field. If disabled any length would be considered a valid label.

**Serial Cmd:** <**Kt status**,fixed code length status,fixed code length>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

### Fixed Code Length (Code 128)

**Definition:** It specifies the exact number of characters that the scanner will recognize (this does not include start and stop and check digit characters). The scanner ignores any code not having the specified length.

**Usage:** **Fixed Code Length** helps prevent truncations and increases data integrity by ensuring that only one symbol length will be accepted.

**Serial Cmd:** <**Kt status**,fixed code length status,fixed code length>

**Default:** **10**

**Options:** 1 to 128

**Note:** **Fixed Code Length Status** must be enabled for **Fixed Code Length** to take effect.

## UCC/EAN-128

**Definition:** A subset of Code 128, with extended features.  
See the Uniform Code Council, Inc. at [www.uc-council.org](http://www.uc-council.org).

**Usage:** Used as a standard for shipping labels.

**Note:** Code 128 must be **Enabled** for UCC/EAN-128 to function.

### UCC/EAN-128 Status

**Serial Cmd:** *<Kt,,,UCC/EAN-128 status,output format,application record separator status,application record separator character,application record brackets,application record padding>*

**Note:** Code 128 serial command fields for K precede UCC/EAN-128.

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled      2 = Required

**Enabled:** If **Enabled**, the scanner can read labels with or without a function 1 character in the first position.

**Required:** If set to **Required**, the label must have a function 1 in the first position and conform to EAN format in order to decode the bar code symbol.

### Output Data Format (UCC/EAN-128)

**Definition:** Offers an option between **Standard UCC/EAN-128** and **Application Record** format.

**Usage:** **Application Record** is useful in applications in which the software can utilize application record formatting to help automate the processing of its UCC/EAN-128 data.

**Serial Cmd:** *<Kt,,,UCC/EAN-128 status,output format,application record separator status,application record separator character,application record brackets,application record padding>*

**Default:** **Standard**

**Options:** 0 = Standard      1 = Application Record

**Standard:** In **Standard** UCC/EAN-128 application identifiers and data fields are sent, but none of the formatting (separators, parentheses, padding) will be included.

**Application Record:** **Application Record** is a variation of UCC/EAN-128 that allows the user to define separators between data fields, enclose application identifiers in parentheses, and enable padding (zeros) for variable length fields.

**Note:** If an illegal **Application Record** format is detected, the scanner will process it as a noread and output a noread message (if enabled).

### Application Record Separator Status (UCC/EAN-128)

**Definition:** When enabled, a separator character is inserted between application records.

**Serial Cmd:** <Kt,,UCC/EAN-128 status,output format,**application record separator status**,application record separator character,application record brackets,application record padding>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enable

**Note: Output Format** must be set to **Application Record** before this parameter can take effect.

### Application Record Separator Character (UCC/EAN-128)

**Definition:** Allows the user to define an ASCII character as an application record separator.

**Serial Cmd:** <Kt,,UCC/EAN-128 status,output format,application record separator status,**application record separator character**,application record brackets,application record padding>

**Default:** **, (comma)**

**Options:** User Defined ASCII character

**Note: Output Format** must be set to **Application Record** before this parameter can take effect.

### Application Record Brackets (UCC/EAN-128)

**Definition:** When enabled, parentheses ( ) are added to enclose application identifiers.

**Serial Cmd:** <Kt,,UCC/EAN-128 status,output format,application record separator status,application record separator character,**application record brackets**,application record padding>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

**Note: Output Format** must be set to **Application Record** before this parameter can take effect.

## Application Record Padding (UCC/EAN-128)

**Definition:** Padding is the insertion of zeros to make up the maximum length of a variable application record data field, except for the last field which does not require padding.

When enabled, padding is included. When disabled, padding is omitted.

**Note:** Padding is never added to fixed length fields or to the last data field of a label. Enabling or disabling **Record Padding** will have no effect on these.

**Serial Cmd:** `<Kt,,,UCC/EAN-128 status,output format,application record separator status,application record separator character,application record brackets,application record padding>`

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

**Note: Output Format** must be set to **Application Record** before this parameter can take effect.

## Code 93

*Definition:* Code 93 is a variable length, continuous symbology employing four element widths. Each Code 93 character has nine modules that may be either black or white. Each character contains three bars and three spaces.

*Usage:* Used occasionally in clinical industry.

### Code 93 Status

*Serial Cmd:* <**K!status**,fixed code length status,fixed code length>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

### Fixed Code Length Status (Code 93)

*Definition:* When enabled the scanner will check the label length against the code length field. If disabled any length would be considered a valid label.

*Serial Cmd:* <**K!status**,fixed code length status,fixed code length>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

### Fixed Code Length (Code 93)

*Definition:* Specifies the exact number of characters that the scanner will recognize (this does not include start and stop and check digit characters). The scanner ignores any code not having the specified length.

*Usage:* **Fixed Code Length** helps prevent truncations and increases data integrity by ensuring that only one symbol length will be accepted.

*Serial Cmd:* <**K!status**,fixed code length status,fixed code length>

*Default:* **10**

*Options:* 1 to 128

# AIAG

**Definition:** **AIAG** is not a bar code symbology, but rather a standard that enables a user to add information to symbols and to filter data according to user-defined identifiers (up to 12).

AIAG is the Automotive Industry Action Group standard and **is applicable to all symbologies**. If when **AIAG** is enabled a decoded symbol has an AIAG ID, it will be counted. Otherwise, the symbol will be rejected.

**Usage:** Originally created for identifying and sorting automotive parts and processes, **AIAG** is now used in a wide variety of industries for everything from quality control to data processing.

**ESP:** From the **Code Type** menu, scroll to **AIAG**.

| AIAG     | Status   | Disabled | Disabled |
|----------|----------|----------|----------|
| ID1      | N        | N        | N        |
| Status1  | Enabled  | Enabled  | Enabled  |
| ID2      | P        | P        | P        |
| Status2  | Disabled | Disabled | Disabled |
| ID3      | Q        | Q        | Q        |
| Status3  | Disabled | Disabled | Disabled |
| ID4      | V        | V        | V        |
| Status4  | Disabled | Disabled | Disabled |
| ID5a     | S        | S        | S        |
| ID5b     | M        | M        | M        |
| ID5c     | G        | G        | G        |
| Status5  | Disabled | Disabled | Disabled |
| ID6      | H        | H        | H        |
| Status6  | Disabled | Disabled | Disabled |
| ID7      | E Z      | E Z      | E Z      |
| Status7  | Disabled | Disabled | Disabled |
| ID8      | E B      | E B      | E B      |
| Status8  | Disabled | Disabled | Disabled |
| ID9      | E D      | E D      | E D      |
| Status9  | Disabled | Disabled | Disabled |
| ID10     | E C      | E C      | E C      |
| Status10 | Disabled | Disabled | Disabled |
| ID11     | E L      | E L      | E L      |
| Status11 | Disabled | Disabled | Disabled |
| ID12     | E X      | E X      | E X      |
| Status12 | Disabled | Disabled | Disabled |

## AIAG Status

**Serial Cmd:** <**KZAIAG status**, ID1, status1, ID2, status2, ID3, status3, ID4, status4, \*ID5a,ID5b,ID5c, status5, ID6, status6, ID7, status7, ID8, status8, ID9, status9, ID9, status10, ID11, status11, ID12, status12>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

## AIAG Identifiers

**Definition:** AIAG has 12 Identifiers, each of which allows you to enter up to 4 ASCII characters with the exception of ID #5 which allows you enter 3 sub-identifiers of 4 characters each.

**Serial Cmd:** <**KZAIAG status**, ID1, status1, ID2, status2, ID3, status3, ID4, status4, \*ID5a,ID5b,ID5c, status5, ID6, status6, ID7, status7, ID8, status8, ID9, status9, ID9, status10, ID11, status11, ID12, status12>

**ESP:** Each Identifier can be individually changed.

1. **Double-click** on the individual identifier to bring up the screen shown on the right.
2. Select a character and click anywhere in the **Code Type** ESP window.

| AIAG    |          |
|---------|----------|
| Status  | Disabled |
| ID1     | N        |
| Status1 | Enabled  |
| ID2     | P        |
| Status2 | Disabled |
| ID3     | Q        |
| Status3 | Disabled |

**Default:** **Status1** is **Enabled** by default. Status 2 through 12 are **Disabled**.

**Options:** 1 to 12 status settings; 1 to 12 user-defined identifiers.

Default identifiers for ID1 through ID12 are as follows:

| ID1 | ID2 | ID3 | ID4 | ID5a | ID5b | ID5c | ID6 | ID7 | ID8 | ID9 | ID10 | ID11 | ID12 |
|-----|-----|-----|-----|------|------|------|-----|-----|-----|-----|------|------|------|
| N   | P   | Q   | V   | S    | M    | G    | H   | EZ  | EB  | ED  | EC   | EL   | EX   |

The following rules apply:

1. **Number of Labels** <**KZnumber**> must be set to the number of **AIAG** symbols required per read cycle. (The number of AIAG IDs enabled has no effect.)
2. Any noread messages will be added to the end of the output with no ID prefix. For example, the following symbols—S123, N456, P678, and Q987—are scanned in order but the third symbol P678 fails to be decoded. The noread output will appear at the end of the data array, as follows: S123,N456,Q987,**NOREAD**.
3. Symbol output is not sorted.
4. Allows any number of symbols with same ID if the data field is different.

# Autodiscriminate

Although **Autodiscriminate** is not a configuration command, but it is included here as a convenient tool for enabling most code types.


**Definition:** Enables all available symbology types except PDF417, and UCC/EAN 128. The user may also individually disable/enable each symbology type.

**Usage:** Commonly used for quick setup mode to detect bar code type. This is particularly useful for users who might be unfamiliar with their application's symbology.

**Note:** It does not alter individual fields such as **Start/Stop, Fixed Length**, etc. These need to be setup individually.

**ESP:** In the **Utilities** menu, right-click on **Autodiscriminate** and select **Enable**.

**Note:** There will be a few seconds delay while the scanner values are retrieved.



**Serial Cmd:** **<P>**

**Default:** **Code 39** (only)

**Options:** <P> Enables all codes except noted above.

<Q> Enable Code 36 only

<R> Enable Codabar only

<S> Enable I 2/5 only

**Note:** If using an I 2/5 label, verify that the number of characters in the label being scanned matches the code length enabled for the I 2/5 code type (default is 10 and 6).


## Chapter Contents

|                                 |     |
|---------------------------------|-----|
| Scanner Type .....              | 6-4 |
| Scan Speed .....                | 6-5 |
| Gain Adjustment .....           | 6-6 |
| AGC Sampling .....              | 6-7 |
| Transition Sample Counter ..... | 6-9 |

This section includes AGC and factory settings such as **Focus**, **Gain**, **Tracking**, and **Scan Speed**.

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Scanner Setup by ESP



Click on this button to bring up the **Scanner Setup** menu.

To change a setting, **double-click** on the setting and use your cursor to scroll through the options.

|                                  |                    |
|----------------------------------|--------------------|
| Scanner Setup (Factory Settings) |                    |
| Scan Speed                       | 80                 |
| Analog Gain Adjustment (AGC)     |                    |
| Gain Adjustment                  | 45                 |
| AGC Sampling                     | Continuous         |
| AGC Minimum                      |                    |
| AGC Maximum                      |                    |
| Scanner Type                     | Low/Medium Density |
| Transition Counter               |                    |
| Status                           | Disabled           |
| Minimum Label Transitions        | 14                 |

## Scanner Setup by Serial Command

| Command Title                | comds      | Format  |
|------------------------------|------------|---|
| Scanner Type (factory)       | <b>KP</b>  | < <b>KP</b> density>  |
| Scan Speed (factory)         | <b>KE</b>  | < <b>KE</b> scan speed>   |
| Gain                         | <b>KD</b>  | < <b>KD</b> gain,AGC mode,AGC min,AGC max>                          |
| Transition Counter           | <b>KH</b>  | < <b>KH</b> transition counter status,transition counter threshold> |
| Scanner Setup Status Request | <b>KU?</b> | < <b>KU?</b> >  |

**Note:** To save **Factory Settings** changes to NOVRAM, send **<Zp>**, or if in ESP, select **Save to Scanner/Advanced/Send and Save, Including Factory**. (See ["Save Active Settings including Factory for Power-on"](#) on page -22.)

## Scanner Setup by Embedded Menu

For information on accessing the embedded menus, see ["Embedded Menus" on page - 19.](#)

From the Main menu, scroll down through the options and select the following screen:

```
-----
                          CURRENT SETTINGS FOR SCANNER SETUP
-----
GAIN ADJUSTMENT (factory) = 45
-----
AGC SAMPLING           = CONTINUOUS
SCANS PER SECOND       = 800
TRANSITION COUNTER     = DISABLED
MIN LABEL TRANSITIONS  = 14
BAD BARCODE OUTPUT     = DISABLED
BAD BARCODE MESSAGE    = BADCODE
NO BARCODE OUTPUT     = DISABLED
NO BARCODE MESSAGE     = NOLABEL
-----

          ESC = MAIN MENU OR EXIT   N = NEXT ITEM
           M = PREVIOUS MENU        SP = NEXT ITEM
           B = PREVIOUS ITEM        CR = THIS ITEM
-----
SCANNER SETUP--> SCANNER TYPE (factory) = STANDARD/LOW
```



---

*Scan Speed*

## Scan Speed

(factory setting)

---

*Definition:* Allows the user to set the number of scans per second by controlling the spinning mirror motor speed.

*Usage:* Typically, to ensure a minimum number of scans, faster scan speeds are used for fast moving labels and/or longer labels with larger bar widths. See "**Formulas for Number of Decodes**" on page A-27.

**Note:** Scan beams will be moving faster across labels further out in the scan range since the moving beam is being projected from a spinning mirror.

*Serial Cmd:* <**KEscan speed**>

*Default:* **80** (x 10 scans per second)

*Options:* 35 to 110 (x 10 scans per second)

# Gain Adjustment

(factory setting)

- 
- Definition:* Sets a voltage amplitude value for the analog circuitry.
- Usage:* Can be useful for fine-tuning gain or when portions of analog signals spike as in the case of specular reflection or extraneous noise.
- Caution:** Changes to **Gain** are typically done by qualified technicians i.
- Serial Cmd:* <**KDgain**,AGC sampling,AGC min,AGC max>
- Default:* Default is **45** (nominal). **Gain** is optimized at the factory before shipment; the default value may not be 45.
- Options:* 10 to 255

---

## AGC Sampling

---

*Definition:* AGC is the acronym for Automatic Gain Control. AGC increases the depth of field by attempting to maintain signal strength at a constant level regardless of the range of the bar code label.

**AGC Sampling** allows you to specify how automatic gain control sampling will be done.

*Serial Cmd:* <KD gain,**AGC sampling**,AGC min,AGC max>

*Default:* **Continuous**

*Options:* 0 = Disabled      1 = Leading Edge      2 = Continuous

### Disabled

---

*Definition:* When **AGC Sampling** is set to **Disabled**, gain levels can only be manually controlled by the **Gain** command.

*Usage:* **Disabled** is not recommended, but can be useful in certain applications in which labels do not require a large depth of field.

### Leading Edge

---

*Definition:* Finds the leading edge of a symbol by looking for a 40  $\mu$ s quiet zone followed by the number of transitions, stores the highest value of the samples, and adjusts the AGC accordingly at the end of the scan.

*Usage:* **Leading Edge** is rarely used, but in some cases can improve scan rates when labels are skewed and the leading edge of a label is difficult to locate.

### Continuous

---

*Definition:* Samples AGC throughout the scan at the rate averages the sample values, and adjusts the AGC value at the end of the scan.

*Usage:* **Continuous** is the default and the preferred mode for sampling analog signal amplitude.

---

## AGC Minimum

(Read Only)

---

*Definition:* Limits the hardware gain available to the software for the usable range.

*Serial Cmd:* <**KD** gain,AGC sampling,**AGC min**,AGC max>

## AGC Maximum

(Read Only)

---

*Definition:* Limits the hardware gain available to the software for the usable range.

*Serial Cmd:* <**KD** gain,AGC sampling,AGC min,**AGC max**>

---

## Transition Counter

# Transition Counter

Used for both AGC and label detection routines (see [Chapter 8, "Outputs"](#)).

---

**Definition:** During the read cycle, the scanner counts the number of bar and space transitions defined in the **Transition Counter**. If the count matches or exceeds the threshold, the scanner will perform AGC routines. The results of this test are also made known in output messages. See ["Bar Code Output," on page 8-8](#) and ["Bar Code Output," on page 8-8](#).

## Transition Counter Status

---

**Serial Cmd:** <**KH transition counter status**, transition counter threshold>

**Default:** **Disabled**

**Options:** 0 = Disabled      1 = Enabled

## Transition Counter Threshold

---

**Definition:** Determines the number of bar/space transitions that must be read before a label is considered present and AGC can be resolved.

**Usage:** Can be useful in certain application where extraneous objects in the field of view might require a higher threshold.

**Serial Cmd:** <**KH transition counter status**, **transition counter threshold**>

**Default:** **14**

**Options:** 1 to 255

# Chapter

# 7

# Matchcode

## Chapter Contents

|                             |      |
|-----------------------------|------|
| Overview of Matchcode ..... | 7-4  |
| Matchcode Type .....        | 7-5  |
| Master Label Database ..... | 7-10 |
| New Master Pin .....        | 7-15 |

This section explains the matchcode output functions and the master label database setup.


**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Matchcode by ESP



Click this button to bring up the **Matchcode** menu.

To change a setting, **double-click** the setting and use your cursor to scroll through the options.



7-Matchcode

## Matchcode by Serial Command

| Command Title                                      | cmds      | Format  |
|--|-----------|---|
| Master Label Database Size                         | <b>KM</b> | < <b>KM</b> number of master labels>  |
| Matchcode Type                                     | <b>Kn</b> | < <b>Kn</b> type,sequential matching,match start position,match length,wild card character,sequence on noread,sequence on mismatch> |
| New Master Pin                                     | <b>Kz</b> | < <b>Kz</b> status>   |
| Store next label scanned to database. <sup>a</sup> | <b>G</b>  | < <b>G</b> >  |
| Enter data to database                             | <b>M</b>  | < <b>M</b> master label number,data>  |
| Request Master Label information                   | <b>M?</b> | < <b>M?</b> >   |
| Delete Master Label                                | <b>M</b>  | < <b>M</b> master label number,>  |

a. If no number is included, the label will be saved to database number 1.

### Matchcode by Embedded Menu

For information on accessing the embedded menus, see ["Embedded Menus" on page A-19](#).

From the Main menu, scroll down through the options and select the following screen:

```
-----
                          CURRENT SETTINGS FOR OPERATIONS
-----
TRIGGERING MODE      = CONTINUOUS READ      MATCHCODE TYPE      = DISABLED
END OF READ CYCLE   = TIMEOUT              SEQUENTIAL MATCHING = INCREMENT
TIMEOUT in 10ms incs = 1000 ms             MATCH START POSITION = 0
TRIGGER CHARACTER    = N/A                 MATCH LENGTH        = 1
EXTERNAL TRIGGER     = N/A                 WILD CARD CHARACTER = *
TRIGGER FILTER       = 9984 us             SEQUENCE ON NOREAD  = ENABLED
GOOD DECODE READS   = 1                   SEQUENCE ON MISMATCH = DISABLED
NEW MASTER PIN       = DISABLED            MATCH DATABASE SIZE = 1
NUMBER OF LABELS    = 1
MULTILABEL SEPARATOR = .

-----
ESC = MAIN MENU OR EXIT  N = NEXT ITEM
M  = PREVIOUS MENU      SP = NEXT ITEM
B  = PREVIOUS ITEM      CR = THIS ITEM
-----
OPERATIONS--> TRIGGERING MODE      = CONTINUOUS READ
```

7-Matchcode

# Overview of Matchcode

- Definition:** With **Matchcode** you can store master label data in the scanner's memory, compare this data against the scanned bar codes, and define how label data and/or discrete signal output will be directed. A master label database can be setup for up to 10 master labels. See ["Master Label Database" on page 7-10](#).
- Note:** **Matchcode** will function with multiple labels (see ["Multilabel" on page 4-14](#)); however if **Matchcode Type** is set to **Sequential** or if **Triggering Mode** is set to **Continuous Read 1 Output**, **Number of Labels** will default back to **1** (if set to any number greater than 1).
- Usage:** **Matchcode** is used in applications to sort, route, or verify data based on matching the specific bar code label in a variety of ways as defined in this section. For example, a manufacturer might sort a product based on dates that are embedded in the bar code.

## Steps for entering and using master labels


1. Set **Triggering Mode** to **External** or **Serial** (["Trigger Mode" on page 4-4](#)).
2. Chose the method of label comparison that fits your application (["Matchcode Type" on page 7-5](#)).
3. Define the output you want to achieve with your matchcode setup:
  - a. Barcode output (["Bar Code Output" on page 8-8](#)).
  - b. Discrete output (["Output 1" on page 9-4](#), ["Output 2" on page 9-6](#), and ["Output 3" on page 9-6](#)).
3. Select the number of master labels you want to create (["Master Label Database Size" on page 7-10](#)).
4. Decide which of 4 ways you want enter your master label(s):
  - a. Use **ESP** to type in master label data directly (["Enter Master Label Data" on page 7-11](#)).
  - b. Send a serial command with label data in the form of **<Mmaster label#,data>**.
  - c. Send a **<G>** (Scan Next Label as Master Label) command.
  - d. Enable the **New Master Pin** command (["New Master Pin" on page 7-15](#)) and activate a discrete input to store the in the next label scanned as master label.
5. Enter master label data using the method determined in step 4.

# Matchcode Type

**Definition:** Allows the user to choose the way that master labels will be compared with subsequently scanned labels.

**Note:** First set **Triggering Mode** to **External** or **Serial**.

**ESP:**



7-Matchcode

**Serial Cmd:** <**Knmatchcode type**, sequential matching, match start position, match length, wild card character, sequence on noread, sequence on mismatch>

**Default:** **Disabled**

**Options:**  
0 = Disabled  
1 = Enabled  
2 = Sequential  
3 = Wild Card

**Disabled:** Has no effect on operations.

**Enabled:** Instructs the scanner to compare labels or portions of labels with the master label.

**Wild Card:** Allows the user to enter user defined wild card characters in the master label.

**Sequential Matching:** Instructs the scanner to sequence after each match (numeric only) and compare labels or portions of labels for sequential numbers.

**Note:** If **Matchcode Type** is set to **Sequential**, **Number of Labels** will default back to **1** (if set to any number greater than 1).

---

## Matchcode Type

### Sequential Matching

- Definition:** With **Sequential** enabled, **Sequential Matching** determines if a count is in ascending (incremental) or descending (decremental) order.
- Usage:** Useful in tracking product serial numbers that increment or decrement sequentially.
- Serial Cmd:** *<Knmatchcode type,sequential matching,match start position,match length,wild card character,sequence on noread,sequence on mismatch>*
- Default:** **Increment**
- Options:** 0 = Increment  
1 = Decrement

---

### Match Start Position

- Definition:** **Match Start Position** determines the portions of labels that will be matched by defining the first character in the label (from left to right) that will be compared with those of the master label, when **Matchcode Type** is set to **Enabled** or **Sequential**.
- Function:** For example, if **Match Start Position** is set to 3, the first 2 characters read in the symbol will be ignored and only the 3rd and subsequent characters to the right will be compared, up to the number of characters specified by **Match Length**.
- Usage:** **Match Start Position** is useful in defining specific portions of a symbol for comparisons. For example, if a symbol contains a part number, manufacturing date, and lot code info but the user is only interested in the part number information. With **Match Start Position** the scanner can be set to only sort on the part number and ignore the rest of the characters.
- Serial Cmd:** *<Knmatchcode type,sequential matching,match start position,match length,wild card character,sequence on noread,sequence on mismatch>*
- Default:** **0**
- Options:** 0 to 50

**Note:** **Match Start Position** must be set to **1** or greater to enable this feature. A **0** setting will disable this feature.

## Match Length

- Definition:* Defines the length of the character string that will be compared with that of the master label when **Match Start Position** is set to **1** or greater. when **Match Start Position** is set to **0**, no comparison will occur.
- Usage:* For example, if **Match Length** is set to **6** in a 10 character symbol, and **Match Start Position** is set for **2**, only the 2nd through 7th characters (from left to right) will be compared.
- Serial Cmd:* **<Knmatchcode type,sequential matching,match start position, match length,wild card character,sequence on noread,sequence on mismatch>**
- Default:* **1**
- Options:* 1 to 5050

## Wild Card Character

- Definition:* **Wild Card Character** allows a user to define a wild card character as part of the master label.
- Usage:* For example, with **Wild Card Character** defined as the default asterisk, defining **CR\*34** as the master label will result in matches for **CR134**, **CR234**, but not **CR2345**. Entering the wild card at the end of the master label as in **CR\*** will result in matches for variable label lengths such as **CR1**, **CR23**, **CR358**, etc.
- Serial Cmd:* **<Knmatchcode type,sequential matching,match start position, match length,wild card character,sequence on noread,sequence on mismatch>**
- Default:* **\*** (asterisk)
- Options:* Any valid ASCII character

7-Matchcode

---

## Matchcode Type

### Sequence On Noread

---

**Definition:** When **Sequence On Noread** is **Enabled** and **Matchcode** is set to **Sequential**, the scanner sequences the master label on every match or noread. When disabled, it does not sequence on a noread.

**Usage:** **Sequence On Noread** is useful when the scanner needs to stay in sequence even if no decode occurs.

**Serial Cmd:** *<Knmatchcode type,sequential matching,match start position, match length,wild card character,sequence on noread,sequence on mismatch>*

**Default:** **Enabled**

**Options:** 0 = Disabled    1 = Enabled

As an example of **Sequence on Noread Enabled**, consider the following series of decodes:

| Master label | Decoded label | Master label after decode |
|--------------|---------------|---------------------------|
| 001          | 001           | 002                       |
| 002          | 002           | 003                       |
| 003          | noread        | 004 (sequenced on noread) |
| 004          | 004           | 005                       |
| 005          | noread        | 006 (sequenced on noread) |
| 006          | noread        | 007 (sequenced on noread) |
| 007          | 007           | 008                       |

As an example of **Sequence on Noread Disabled**, consider the following series of decodes:

| Master label | Decoded label | Master label after decode |
|--------------|---------------|---------------------------|
| 001          | 001           | 002                       |
| 002          | 002           | 003                       |
| 003          | noread        | 003 (not sequenced)       |
| 003          | 003           | 004                       |
| 004          | noread        | 004 (not sequenced)       |
| 004          | noread        | 004 (not sequenced)       |
| 004          | 004           | 005                       |

### Sequence On Mismatch

**Note:** Matchcode must be set to **Sequential** for this command to function.

**Definition:** When set to **Enabled**, the master label sequences on every decode, match or mismatch.

When set to **Disabled**, the master label will not sequence whenever consecutive mismatches occur.

**Usage:** Enable this parameter if every trigger event should have a decode and more than one consecutive mismatch may occur.

Disable this parameter if every trigger event should have a decode but no more than one consecutive mismatch may occur.

**Serial Cmd:** <**Kn** matchcode type, sequential matching, match start position, match length, wild card character, sequence on noread, **sequence on mismatch**>

**Default:** **Disabled**

**Options:** 0 = Disabled, 1 = Enabled

The scanner will sequence the master to one more/less than the decoded symbol. As an example of **Sequence On Mismatch Enabled**, consider the following decodes:

| Master label | Decoded label | Master label after decode   |
|--------------|---------------|-----------------------------|
| 001          | 001           | 002                         |
| 002          | 002           | 003                         |
| 003          | abc           | 004 (sequenced on mismatch) |
| 004          | 004           | 005                         |
| 005          | def           | 006 (sequenced on mismatch) |
| 006          | ghi           | 007 (sequenced on mismatch) |
| 007          | 007           | 008                         |

As an example of **Sequence On Mismatch Disabled**, consider the following decodes:

| Master label | Decoded label | Master label after decode                        |
|--------------|---------------|--|
| 001          | 001           | 002  |
| 002          | 002           | 003  |
| 003          | abc           | 004 (sequenced because of previous match)        |
| 004          | 004           | 005  |
| 005          | def           | 006 (sequenced because of previous match)        |
| 006          | ghi           | 006 (not sequenced because of previous mismatch) |
| 006          | 006           | 007  |

7-Matchcode

# Master Label Database

**Important: Master Label Database** is used only for comparing entire bar codes, when **Sequential** and **Wild Card** are NOT enabled, and **Start Position** is equal to **0**.

## Master Label Database Overview

**Definition:** Allows you to define up to 10 master labels as the master label database, which can be entered by keyboard, scanned-in, displayed, or deleted by serial or ESP commands.


**Usage:** Useful where more than one master label is required, as in a Multilabel setup, for matching and other matchcode operations.

## Master Label Database Size

**Definition:** **Master Label Data Base Size** allows you to select 1 to 10 master labels for the master label database.

**ESP:** Click the **Utilities** button  to access the master label:

First set the number of master labels you want to include by double-clicking **Database Size** and entering the number.



**Serial Cmd:** **<Mmaster label data base size>**

**Note:** You must follow this command with a save command **<A>** or **<Z>**.


**Default:** **1**

**Options:** 1 to 10

## Enter Master Label Data

**Definition:** Allows you to enter master label data for a specific master label index number (1 to 10), provided the index number is not larger than the number of labels enabled by the **Master Label Database Size** (see [page 7-10](#)). For example, if **Master Label Database Size** is set to 2, you will not be able to enter data for labels 3 through 10.

- ESP:**
1. Open the **Utilities** menu.
  2. Set the number of master labels you want to create in **Database Size**.
  3. **Double-click** on each label number you want to setup and copy or type in your data.
  4. With your cursor in the label row you have just edited, right-click and choose **Send** or **Send Save**.



7-Matchcode

**Serial Cmd:** <**M**master label number, master label data>

**Default:** **1, blank**

**Options:** 1 to 10, data (any combination of ASCII text up to the maximum indicated in ["Maximum Characters for Master Label Database"](#) on [page 7-12](#)). For example, to enter data for master label 9, after making certain that master label database size is enabled for 9 or more labels (see ["Master Label Database Size"](#) on [page 7-10](#)), send <**M9, data**>.

**Caution:** Since the total number of characters available for the master label data base is **2045**, changes to the **Master Label Data Base Size** will re-allocate the number of characters available for each master label and could cause existing master labels to be deleted (except master label #1 unless it also exceeds the size limitation).

The table below specifies the maximum number of characters available to each label according to the number of master labels defined, from 1 through 10. See ["Master Label Database Size"](#) on [page 7-10](#).

---

## Master Label Database

Table 7-1 Maximum Characters for Master Label Database

| Master Label Number | Maximum Characters |
|---------------------|--------------------|
| #1                  | 2045               |
| #2                  | 1022               |
| #3                  | 681                |
| #4                  | 510                |
| #5                  | 408                |
| #6                  | 340                |
| #7                  | 291                |
| #8                  | 254                |
| #9                  | 226                |
| #10                 | 203                |

7-Matchcode

### Request Master Label Data Request All Master Label Data

---

*Serial Cmd:* **<Mmaster label number?>**

This will display data in the master label number you indicated. For example, to request master label #5, enter **<M5?>**. The scanner transmits master label #5 data in brackets in the following format: <KM5/.....>. If no master label data available, the output will be: <KM5,>.

---

*Serial Cmd:* **<M?>**

This command will return master label data for all labels enabled (up to 10).

*ESP:* Access the same as ["Enter Master Label Data" on page 7-11.](#)

## Delete Master Label Data

- Definition:** You can directly delete the master label data by serial command or ESP.
- ESP:**
1. Open the **Utilities** menu.
  2. Select a label # under **Edit Labels** in **Master Label Database**.
  3. **Double-click** on each label number you want to delete.
  4. Delete text in the text block.
  5. Change **Database Size** accordingly.
- Serial Cmd:** **<Mmaster label number,>**
- To delete a master label, enter the database number and a comma, but leave the data field empty. For example, to delete master label #5, send the following **<M5,>**. The command is entered with a blank master label data field which tells the scanner to delete the selected master label from the database.
- Default:** **(no data)**
- Options:** Any combination of ASCII text up to the maximum indicated in ["Maximum Characters for Master Label Database" on page 7-12.](#)

7-Matchcode

## Store Next Label Scanned as Master Label<sup>1</sup>

---

**Definition:** After you've set the size in the database ("[Master Label Database Size](#)" on [page 7-10](#)), you can order the scanner to scan-in the next label as the master label for any given master label number.

**Serial Cmd:** **<G master label number>**

To store the next label scanned as master label #1, send: **<G>** or **<G1>**.

To store next label scanned as the master label for any other master label database number, send: **<Gmaster label number [1-10]>**.

For example, **<G5>** will cause the next label scanned to be entered as master label #5.

**Default:** (no data)

---

1. While not strictly a configuration command, <G> is included here because it is so closely related to other master label commands.

# New Master Pin


**Definition:** After **New Master Pin** is enabled, a pulse can be received on the new master pin which will cause the scanner to record the next decoded bar code label(s) as the new master label(s).

It is important to note that the enabling **New Master Pin** does not in itself cause a master label to be recorded. The master pin must then be activated momentarily (for a minimum of 10 ms) before a master label can be scanned into memory. (See .)

**Usage:** Some applications require the line worker to change the master label. This can be done by installing a switch at the location of the scanner. It is very common to have a keyed switch so that accidental switching does not occur.

**ESP:** In the **Matchcode** menu, select **New Master Pin**, double-click on **Disabled** and select **Enabled**.

7-Matchcode



**Serial Cmd:** <Kzstatus>

**Default:** Disabled

**Options:** 0 = Disabled      1 = Enabled

After **New Master Pin** has been enabled and the pin activated, decodes will be saved in the master database beginning with master label #1. If the scanner is configured for a multilabel read cycle (**Number of Labels** is greater than 1), the remaining decodes will be saved in each consecutive master label location. For example, if **Number of Labels** is set to **3** and **New Master Pin** is then activated, at the end of the next read cycle, the decoded bar code labels will be saved as master labels 1, 2, and 3.

---

*New Master Pin*

**7-Matchcode**

*Chapter*

8

# Outputs

## Chapter Contents

|                                    |      |
|------------------------------------|------|
| Output Data by Embedded Menu ..... | 8-3  |
| Bar Code Output .....              | 8-5  |
| Partial Output .....               | 8-8  |
| Noread Message .....               | 8-9  |
| Bad Bar Code Message .....         | 8-10 |
| No Bar Code Message .....          | 8-11 |
| Beeper Status .....                | 8-12 |
| Serial Verification .....          | 8-13 |
| Operation Command Output .....     | 8-15 |

This section explains the commands for controlling data and beeper outputs.

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Outputs by Serial Command

| Command Title            | cmds                  | Format  |
|--------------------------|-----------------------|---|
| Noread Message           | <b>Kk</b>             | <Kkstatus,message>  |
| Bar Code Output          | <b>KI<sup>a</sup></b> | <KIstatus,when to output>   |
| Laser                    | <b>KC</b>             | <KClaser on/off status,laser framing status,laser off percentage,laser on percentage> |
| Serial Verification      | <b>KS</b>             | <KSserial command echo status,serial command beep status,control/hex output>          |
| Beeper                   | <b>Ku</b>             | <Kustatus>  |
| Partial Output           | <b>KY</b>             | <KYstatus,start position,length>  |
| No Bar Code              | <b>KN</b>             | <KNstatus,message>  |
| Bad Bar Code             | <b>K'</b>             | <K'status,message>  |
| Operation Command Output | <b>K/</b>             | <K/status>  |

a. Lower case L


## Outputs by Embedded Menu

For information on accessing the embedded menus, see ["Embedded Menus" on page A-19](#).

From the Main menu, scroll down through the options and select the following screen:

| CURRENT SETTINGS FOR SCANNER OUTPUT |                 |                              |                 |
|-------------------------------------|-----------------|------------------------------|-----------------|
|                                     | OUTPUT-1        | OUTPUT-2                     | OUTPUT-3        |
| OUTPUT ON                           | MISMATCH/NOREAD | MISMATCH/NOREAD              | MISMATCH/NOREAD |
| POLARITY                            | NEGATIVE        | NEGATIVE                     | NEGATIVE        |
| PULSE WIDTH                         | 50 ms           | 50 ms                        | 50 ms           |
| # BEFORE OUTPUT                     | 1               | 1                            | 1               |
| BARCODE OUTPUT = GOOD READ          |                 | ECHO K COMMAND = DISABLED    |                 |
| WHEN TO OUTPUT = ASAP               |                 | BEEP ON K COMMAND = DISABLED |                 |
| NOREAD MESSAGE = NOREAD             |                 | CTRL CHAR OUTPUT = CTRL      |                 |
| NOREAD OUTPUT = ENABLED             |                 | PARTIAL OUTPUT = DISABLED    |                 |
| BEEPER STATUS = ON GOOD             |                 | START POSITION = 1           |                 |
| BEEPER VOLUME = LEVEL 4             |                 | PARTIAL LENGTH = 63          |                 |
| FULL SCREENS = ENABLED              |                 | RESPONSE FORMAT = FORMATTED  |                 |
| LASER ON/OFF = DISABLED             |                 |                              |                 |
| ESC = MAIN MENU OR EXIT             |                 | N = NEXT ITEM                |                 |
| M = PREVIOUS MENU                   |                 | SP = NEXT ITEM               |                 |
| B = PREVIOUS ITEM                   |                 | CR = THIS ITEM               |                 |
| SCANNER OUTPUT--> OUTPUT-1          |                 |                              |                 |

### Output Data by ESP Menu



Click this button to bring up the **Outputs** menu.

To change a setting, **double-click** the setting and use your cursor to scroll through the options.

| Parameters                                    | Program Values      |
|---|---------------------|
| <input type="checkbox"/> Outputs              |                     |
| <input type="checkbox"/> Noread Message       |                     |
| Status  | Enabled             |
| Message Output                                | NOREAD              |
| <input type="checkbox"/> Bar Code Output      |                     |
| Status  | Good Read           |
| When to Output                                | As Soon As Possible |
| <input type="checkbox"/> Laser Control        |                     |
| <input type="checkbox"/> Serial Verification  |                     |
| Command Echo Status                           | Disabled            |
| Command Beep Status                           | Disabled            |
| Control/Hex Output                            | Control             |
| <input type="checkbox"/> Beeper               |                     |
| <input type="checkbox"/> Partial Output       |                     |
| Status  | Disabled            |
| Start Position                                | 1                   |
| Length  | 63                  |
| <input type="checkbox"/> No Bar Code Message  |                     |
| <input type="checkbox"/> Bad Bar Code Message |                     |
| Operation Command Output                      | Enabled             |
| <input type="checkbox"/> Outputs              |                     |

8-Outputs

## Message Output

The following flow chart explains the logic paths taken for **Noread**, **Bad Bar Code** and **No Bar Code** outputs.




Figure 8-1 Output Message Flow

## Noread Message

*Definition:* When enabled, and if no bar code label has been decoded before time-out or the end of the read cycle, the noread message will be transmitted to the host.

*Usage:* Used in applications where the host needs serial verification that a label has not been read and especially useful in new print verification.

### Noread Status

*Serial Cmd:* <**Kkstatus**,message>

*Default:* **Enabled**

*Options:* 0 = Disabled      1 = Enabled

### Noread Message

*Definition:* Any combination of ASCII characters can be defined as the noread message.

*Serial Cmd:* <**Kkstatus**,**message**>

*Default:* **NOREAD**

*Options:* 0 to 7 ASCII characters.

**Note: Noread Message** will only be transmitted if **Bar Code Output** is set to **Match**, **Mismatch** or **Good Read**.

**Noread Message** can be set to any ASCII characters except **NULL <>** and **,** (comma).

## Bad Bar Code Message

*Definition:* When enabled, a message is sent to the host when a label is detected but not decoded. See ["Transition Counter Threshold" on page 6-10](#).

The **Bad Bar Code** output is tied to the transition counter. If during a read cycle no symbol is decoded and the required setting for the **Transition Sample Threshold** is met, a **Bad Bar Code** message will be sent to the host. See ["Output Message Flow" on page 8-4](#).

*Usage:* Useful in verifying the presence of a bar code label that has not been decoded.

### Bad Bar Code Status

*Serial Cmd:* <**K'***status,message*>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

### Bad Bar Code Message

*Serial Cmd:* <**K'***status,message*>

*Default:* **BADCODE**

*Options:* Up to seven ASCII characters (except NUL)

The **Bad Bar Code** output is tied to the transition counter. If during a read cycle no symbol is decoded and the required setting for the **Transition Sample Threshold** is met, a **Bad Bar Code** message will be sent to the host.

## No Bar Code Message

*Definition:* When enabled, sends a message to the host whenever an object is detected but no bar code label is detected. See ["Transition Counter Threshold" on page 6-10](#).

The **No Bar Code** output is tied to the transition counter. If during a read cycle no symbol is decoded and the required setting for the **Transition Sample Threshold** is NOT met, a **No Bar Code** message will be sent to the host. See ["Output Message Flow" on page 8-4](#).

*Usage:* Useful in determining if an object has an attached bar code label.

### No Bar Code Status

*Serial Cmd:* <**KNstatus**,message>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

### No Bar Code Message

*Serial Cmd:* <**KNstatus**,message>

*Default:* **NOLABLE**

*Options:* Up to seven ASCII characters (except NUL)

## Bar Code Output

**Note:** **Bar Code Output** relates to data and should not to be confused with **Outputs 1, 2, and 3** listed in the **Outputs Parameters** which describe output states and functions.

### Bar Code Output Status

*Definition:* Defines the conditions under which decoded bar code labels are transmitted to the host.

*Usage:* Useful when the host needs bar code data only under certain conditions.

*Serial Cmd:* <**Kloutput status**,when to output>

*Default:* **Good Read**

*Options:*  
0 = Disabled  
1 = Match  
2 = Mismatch  
3 = Good Read

**Note:** **Bar Code Output Status** if set to **Match** or **Mismatch** will not take effect unless **Matchcode Type** is enabled and a master label is loaded into memory.

#### Disabled

*Definition:* When set to **Disabled**, the scanner will not transmit any data that is generated during a read cycle (bar codes, noreads, etc.).

*Usage:* It is useful when an application only needs to use the discrete outputs and can allow the scanner to do the decision-making. When **Disabled**, the host does not need the bar code data and the communication lines are used only for setup and status checks.

#### Match

*Definition:* When set to **Match**, the scanner transmits bar code data whenever a bar code matches a master label. However, if **Matchcode Type** is **Disabled**, it transmits on any good read.

**Note:** A noread can still be transmitted if **Enabled**.

*Usage:* **Match** is used in an application that requires specific bar code information and needs to sort, route or verify based on matching the specific bar code data.

**Mismatch**

*Definition:* With **Mismatch** enabled, the scanner transmits bar code data whenever the bar code data information does NOT match the master label.

**Note:** A noread can still be transmitted if enabled.

*Usage:* **Mismatch** is typically used as a flag within the host system to prevent an item from being routed in the wrong container.

**Good Read**

*Definition:* With **Good Read** enabled, the scanner transmits bar code data on any good read regardless of **Matchcode Type** setting.

**Note:** A noread can still be transmitted if enabled.

*Usage:* **Good Read** is used when an application requires all bar code data to be transmitted. It's typically used in tracking applications in which each object is uniquely identified.

**When to Output Bar Code Data**

*Definition:* This command allows the user to choose when bar code data can be sent to the host.

*Serial Cmd:* <**KI**output status,**when to output**>

*Default:* **As Soon As Possible**

*Options:* 0 = As Soon As Possible  
1 = End of Read Cycle

**As Soon As Possible**

*Definition:* Enabling **As Soon As Possible** causes bar code data to be sent to the host immediately after a bar code has been successfully decoded.

**Note:** More than one decode might in fact be required to qualify as a good decode, depending on how **Decodes Before Output** is set.

*Usage:* **As Soon As Possible** is useful in applications in which bar code data needs to be moved quickly to the host, typically when the host is making decisions based on bar code data.

## Bar Code Output

### End of Read Cycle

*Definition:* Enabling **End of Read Cycle** means that bar code data does not get sent to the host until the read cycle ends with a timeout or new trigger.




Figure 8-2 Read Cycle

*Usage:* **End of Read Cycle** is useful in timing-based systems in which the host is not ready to accept data at the time it is decoded.

# Laser Control


## Laser On/Off Status

- Definition:** When enabled, the laser is ON only during the read cycle. When disabled, the laser operates continuously.
- Usage:** **Laser On/Off** extends the life of the laser. It is useful where there are significant time gaps between symbols. It also provides visual confirmation of a read cycle duration and minimizes laser exposure to people.
- Serial Cmd:** **<KClaser on/off status,laser framing status,laser off percentage,laser on percentage>**
- Default:** **Disabled**
- Options:** 0 = Disabled, 1 = Enabled

## Laser Framing Status

- Definition:** Sets the percentage of time the laser is ON during each scan so that only a selected portion of the scan width is effectively scanned.
- Usage:** This is useful to avoid highly reflective objects, for filtering out unwanted signals and avoiding the wrong symbols.
- Serial Cmd:** **<KClaser on/off status,laser framing status,laser off percentage>**
- Default:** **Disabled**
- Options:** 0 = Disabled, 1 = Enabled

To adjust laser framing, click the **Laser Control** button, and **Laser On/Off** arrows up or down as shown here.



ESP Laser Framing Control




Figure 8-3 Laser Framing Pattern

8-Outputs

## Laser Control

**Note:** Because scan widths are not always perfectly symmetrical, the most effective way to setup laser framing is to experiment with the **Laser On Percentage** and **Laser Off Percentage** commands until you get the best results.

### Laser Off Percentage

**Definition:** Percentage of time that the laser is OFF during the scan width sweep. When **Laser Framing** is disabled, the laser is ON during the full scan. When **Laser Framing** is enabled, the laser remains OFF from the start of the scan and remains OFF for the specified percentage of the scan.

**Important:** The combined values of **Laser Off Percentage** and **Laser On Percentage** cannot exceed 100 which is the duration of one scan.

**Serial Cmd:** `<KClaser on/off status,laser framing status,laser off percentage,laser on percentage>`

**Default:** 20

**Options:** 1 to 80

When setting up **Laser Framing** in ESP-MP, use the **Laser Off Percentage** and **Laser Framing On Percentage** arrows to constrain or expand the laser framing area.

**Laser On Percentage** When setting up **Laser Framing** in ESP-MP, use the

**Definition:** Percentage of time that the laser is ON during the scan width sweep. Whenever the **Laser Off Percentage** of the laser beam has expired, the **Laser On Percentage** begins and remains ON for the specified percentage of the scan.

Duration of laser on time, in increments of 1/100th of the total scan width sweep.

**Important:** The combined values of **Laser Off Percentage** and **Laser On Percentage** cannot exceed 100 which is the duration of one scan.

**Serial Cmd:** `<KClaser on/off status,laser framing status,laser off percentage,laser on percentage>`

**Default:** 80

**Options:** 20 to 100

**Laser Off Percentage** and **Laser Framing On Percentage** arrows to constrain or expand the laser framing area.

# Serial Verification

Allows the user to verify configuration command status.

## Serial Command Echo Status

*Definition:* When enabled, a configuration command received from the host is echoed back to the host with the resultant settings.

*Function:* If a command with multiple fields is processed, some of the fields may have been processed properly while others were not. The changes will appear in the string echoed back so that the user will know which fields did or did not change.

*Usage:* This command is useful in removing any doubt about the scanner's interpretation of any configuration command.

For example, if the current **preamble** is "SOM" and <Kd1, START> is entered, the scanner will echo back <Kd1, SOM> since the attempted entry "START" exceeds the four character limit for that command. Therefore it is rejected and the existing "SOM" message is echoed back and remains the preamble message.

*Serial Cmd:* <**KSserial command echo status**,serial command beep status,control/hex output>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Serial Command Beep Status

*Definition:* Causes the scanner to beep once whenever a K command is entered to indicate that the command was accepted and processed.

*Function:* If an invalid command is entered, the scanner beeps 5 times to indicate an invalid entry. However, this does not necessarily mean that all data fields have been entered incorrectly. Only one bad field needs to be found in order to activate the 5 beep response.

*Usage:* Used to audibly verify the acceptance and validity of a command.

*Serial Cmd:* <**KSserial command echo status**,**serial command beep status**,control/hex output>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Control/Hex Output

- Definition:** Determines the response to an **Serial Command Echo** or status request command.
- When set to **Control**, two characters are transmitted to represent a non-displayable character. For example, a carriage return will be shown as the two characters: **^M**.
- When set to **Hex**, the output is the hex character.
- Usage:** Useful for viewing settings with binary characters when using serial command on a terminal.
- Serial Cmd:** **<KS serial command echo status, serial command beep status, control/hex output>**
- Default:** **Control**
- Options:** 0 = Control      1 = Hex

# Beeper Status

*Definition:* A beep is emitted either after each good read of a bar code label or after each noread.

**Note:** Beeper will also sound if any of the following occur:

- the scanner is defaulted
- a send/save command from **ESP** or an **Exit** command from any embedded menu
- a **<Z>**, **<Zp>**, **<Zd>**, or **<KS,1>** command is sent

*Usage:* Can be used as an audible verification that either a good read or a noread has occurred.

## Status

*Serial Cmd:* **<Kustatus,volume>**

*Default:* **On Good**

*Options:*  
 0 = Disabled  
 1 = On Good  
 2 = On Noread

## Volume

*Serial Cmd:* **<Kstatus,volume>**

*Default:* **Level 4**

*Options:*  
 0 = Off  
 1 = Level 1  
 2 = Level 2  
 3 = Level 3  
 4 = Level 4  
 5 = Level 5

# Partial Output

*Definition:* When enabled, allows you to pre-select portions of labels to be transmitted by the scanner.

*Usage:* In **Multilabel** mode, partial output is performed on each separate label. For example, if **Start Position** is set to 3 and **Partial Length** is set to 5, the following labels are transmitted as follows:

1234567890 as 34567

1234 as 34

123456789,abcde as "34567,cde" (two labels with separator)

12 as [blank]

## Status

*Serial Cmd:* <**KY status**,start position,length>

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Start Position

*Definition:* Allows you to determine the first character from the beginning of a label to transmit.

*Serial Cmd:* <**KY status**,**start position**,length>

*Default:* **1**

*Options:* 1 to 2710

## Partial Length

*Definition:* Allows you to determine the number of characters to be transmitted.

*Serial Cmd:* <**KY status**,start position,**length**>

*Default:* **63**

*Options:* 1 to 2710

## Operation Command Output

*Definition:* Directs the scanner to bracket non-bar code scanner data outputs such as counters with command start and stop characters and echo the command to the screen.

*Usage:* Useful when brackets are required to delineate certain scanner outputs such as counters.

*Serial Cmd:* **<K/ status>**

*Default:* **Enabled**

*Options:* 0 = Disabled      1 = Enabled



*Chapter*

**9**

# Discrete I/O


## Chapter Contents

|                |      |
|----------------|------|
| Output 1 ..... | 14-4 |
| Output 2 ..... | 14-6 |
| Output 3 ..... | 14-6 |

This section includes instructions for setting up conditions for changing input/output electrical transitions for control of internal and external devices. A discrete I/O (in/out) signal is an electrical transition from one voltage level to another so that digital switching can occur.


**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Discrete I/O by ESP Menu



Click this button to bring up the **Outputs** menu.

To change a setting, **double-click** the setting and use your cursor to scroll through the options.



## Discrete I/O by Serial Command

| Command Title              | cmds       | Format   |
|----------------------------|------------|--|
| Output 1                   | <b>Kv</b>  | < <b>Kv</b> output on,active state,pulse width,number before output> |
| Output 2                   | <b>Kw</b>  | < <b>Kw</b> output on,active state,pulse width,number before output> |
| Output 3                   | <b>K'</b>  | < <b>K'</b> output on,active state,pulse width,number before output> |
| Scanner I/O Status Request | <b>KX?</b> | < <b>KX?</b> >   |

### Discrete I/O by Embedded Menus

For information on accessing the embedded menus, see ["Embedded Menu"](#) on page A-19.

From the Main menu, scroll down through the options and select the following screen:

| CURRENT SETTINGS FOR SCANNER OUTPUT |                 |                              |                 |
|-------------------------------------|-----------------|------------------------------|-----------------|
|                                     | OUTPUT-1        | OUTPUT-2                     | OUTPUT-3        |
| OUTPUT ON                           | MISMATCH/NOREAD | MISMATCH/NOREAD              | MISMATCH/NOREAD |
| POLARITY                            | NEGATIVE        | NEGATIVE                     | NEGATIVE        |
| PULSE WIDTH                         | 50 ms           | 50 ms                        | 50 ms           |
| # BEFORE OUTPUT                     | 1               | 1                            | 1               |
| BARCODE OUTPUT = GOOD READ          |                 | ECHO K COMMAND = DISABLED    |                 |
| WHEN TO OUTPUT = ASAP               |                 | BEEP ON K COMMAND = DISABLED |                 |
| NOREAD MESSAGE = NOREAD             |                 | CTRL CHAR OUTPUT = CTRL      |                 |
| NOREAD OUTPUT = ENABLED             |                 | PARTIAL OUTPUT = DISABLED    |                 |
| BEEPER STATUS = ON GOOD             |                 | START POSITION = 1           |                 |
| BEEPER VOLUME = LEVEL 4             |                 | PARTIAL LENGTH = 63          |                 |
| FULL SCREENS = ENABLED              |                 | RESPONSE FORMAT = FORMATTED  |                 |
| LASER ON/OFF = DISABLED             |                 |                              |                 |
| ESC = MAIN MENU OR EXIT             |                 | N = NEXT ITEM                |                 |
| H = PREVIOUS MENU                   |                 | SP = NEXT ITEM               |                 |
| B = PREVIOUS ITEM                   |                 | CR = THIS ITEM               |                 |
| SCANNER OUTPUT--> OUTPUT-1          |                 |                              |                 |

# Output 1

*Definition:* Sets the discrete output functions for specific user-selected conditions.  
*Usage:* This option provides switching to host software to control external devices such as PLCs and relays. It is useful for routing and sorting and to prevent mis-packaging and mis-routing.

## Output On

*Definition:* Allows the user to set the conditions under which an output (or outputs) will be activated.  
*Serial Cmd:* **<Kvoutput on,active state,pulse width,number before output>**  
*Default:* **Noread**  
*Options:* 0 = Mismatch Or Noread  
1 = Match (or good read)  
2 = Mismatch  
3 = Noread

**Note:** If **Output On** is set to **Mismatch Or Noread**, **Match**, or **Mismatch**, a transition (switching) will not occur unless **Matchcode Type** is enabled and a master label is loaded into memory.

### Mismatch or Noread

*Definition:* Activates discrete output when the bar code data does not match that of the master label or the bar code has not been decoded before the end of the read cycle.

### Match

*Definition:* Activates a discrete output when the bar code data matches the master label.  
**Note:** If you want to output for a good read and **Matchcode** is not enabled, you can enable any output for **Match**.

### Mismatch

*Definition:* Activates a discrete output whenever the bar code data does not match that of the master label.

### Noread

*Definition:* Activates a discrete output whenever the bar code data is not decoded before the end of the read cycle.

## Active State

*Definition:* Sets the active state of the discrete output.  
*Serial Cmd:* <**Kv**output on,**active state**,pulse width,number before output>  
*Default:* **Normally Open**  
*Options:* 0 = Normally Closed  
 1 = Normally Open

## Pulse Width

*Definition:* Sets the time in 10 mS increments that the discrete output remains active.  
*Serial Cmd:* <**Kv**output on,active state,**pulse width**,number before output>  
*Default:* **5** (.05 seconds). Corresponds to 50 mS displayed in the menu.  
*Options:* 1 to 255 (0.01 to 2.55 seconds). Divide the number entered on the command line by 100 for time in seconds.

## Number Before Output

*Definition:* Sets the number of events (matches, mismatches, or noreads as configured by **Output On**) that must occur before activating the associated output.  
*Usage:* For example, if **Number to Output On** is set to 3 and **Output 1** is set to **Noread**, then **Output 1** will not be activated until 3 noreads have occurred.  
*Serial Cmd:* <**Kv**output on,active state,pulse width,**number before output**>  
*Default:* **0**  
*Options:* 0 to 255

---

*Output 2*

## Output 2

*Serial Cmd: <Kwoutput on,active state,pulse width,number before output>*

**Output 2** has the same parameters and default settings as **Output 1**.

## Output 3

*Serial Cmd: <Koutput on,active state,pulse width,number before output>*

**Output 3** has the same parameters and default settings as **Output 1**.

# Chapter

# 10

# Diagnostics


## Chapter Contents

|                                   |       |
|-----------------------------------|-------|
| Warning Messages .....            | 10-4  |
| Warning Message Status.....       | 10-5  |
| Laser High Warning .....          | 10-6  |
| Laser Low Warning.....            | 10-7  |
| NOVRAM Reset Warning Status ..... | 10-8  |
| High Temperature Threshold .....  | 10-9  |
| Low Temperature Threshold.....    | 10-10 |
| Lifetime Hours.....               | 10-11 |

**Important:** Since **Warning Messages** and **NOVRAM Messages** are not enabled by default, these messages will not be displayed. However, if you suspect that erroneous defaults are occurring, enable **Warning Messages** and **NOVRAM Messages** by sending **<K"1,,,1>**.


**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.

## Diagnostics by ESP Menu



Click this button to bring up the **Diagnostics** menu.

To change a setting, **double-click** the setting and use your cursor to scroll through the options.



## Diagnostics by Serial Command

| Command Title                 | Cmnds      | Format  |
|-------------------------------|------------|---|
| Warning Message Status        | <b>K"</b>  | <K"warning message status,laser high status,laser low status,novram/reset warning status> |
| Lifetime Hours                | <b>K\$</b> | <K\$hours10,message>  |
| Over-temperature              | <b>K+</b>  | <K+degrees,message>   |
| Under-temperature             | <b>K-</b>  | <K-degrees,message>   |
| Laser Overcurrent             | <b>K;</b>  | <K;message>   |
| Laser Undercurrent            | <b>K:</b>  | <K:message>   |
| Power On/Resets Counts        | <b>K_</b>  | <K_powerups,resets>   |
| Time Since Last Reset         | <b>K@?</b> | <K@?hours,minutes> (read only)  |
| Present Operating Temperature | <b>K%?</b> | <K%?deg> (read only)  |

### Diagnostics by Embedded Menu

For information on accessing the embedded menus, see "Embedded Menus" on page A-19.

From the Main menu, scroll down through the options and select the following screen:

```

                                CURRENT SETTINGS FOR DIAGNOSTICS SETUP
-----
WARNING MESSAGES                = DISABLED
NVRAM WARNING MESSAGES         = ENABLED
LIFE WARNING MESSAGE           = SERVICE
LIFE WARNING THRESHOLD         = 25000 HOURS
POWERUP RESET COUNT            = 3
OTHER RESETS COUNT             = 2
HOURS:MINUTES SINCE RESET      = 0: 2
-----
                                CURRENT SETTINGS FOR LASER AND TEMPERATURE
-----
LASER LOW MESSAGE              = LO-LASR  || PRESENT TEMPERATURE (C) = 21C
LASER LOW WARNING              = ENABLED  || TEMPERATURE LOW MESSAGE = LO-TEMP
LASER HIGH MESSAGE             = HI-LASR  || TEMPERATURE LOW THRESHOLD = 1C
LASER HIGH WARNING             = ENABLED  || TEMPERATURE HIGH MESSAGE = HI-TEMP
                                || TEMPERATURE HIGH THRESHOLD = 50C
-----
                                ESC = MAIN MENU OR EXIT  N = NEXT ITEM
                                M = PREVIOUS MENU        SP = NEXT ITEM
                                B = PREVIOUS ITEM         CR = THIS ITEM
-----
DIAGNOSTICS SETUP--> WARNING MESSAGES = DISABLED_

```

## Warning Messages

**Important Note: Warning Message Status** must be enabled before any warnings in this menu can be displayed.

*Definition:* Warning messages that relate to the environment and condition of the scanner can be defined and set to activate specific outputs.

**Note:** When enabled, the error condition will override all other operational modes configured for the output.

When enabled, laser current and NOVRAM warning messages will be transmitted to the host or any active port whenever the pre-defined conditions are met.

*Usage:* These messages serve as a flag to service a scanner or as an early warning that potential problems could arise. They are particularly useful in factories that run 24/7 and can't afford down time.

*Serial Cmd:* **<K"warning message status,laser high status,laser low status, novram/reset warning status>**

### Warning Message Status

*Function:* When enabled, warning messages will be transmitted to the host or any active port.

**Note:** This option must be enabled before any other warning messages can be transmitted.

*Usage:* Alerts the user to impending failures or conditions that may soon cause failures.

*Serial Cmd:* **<K"warning message status,laser high status,laser low status, novram/reset warning status>**

*Default:* **Disabled**

*Options:* 0 = Disabled      1 = Enabled

## Laser High Warning

Transmits a message whenever the laser current exceeds a factory-calibrated reference value which cannot be altered. The message repeats once every 30 minutes until the condition is corrected.

### Laser High Status

*Definition:* Enables the **Laser High** message.

*Usage:* Alerts the user to impending laser failure. (Contact Microscan Service.)

*Serial Cmd:* <**K**"warning message status,**laser high status**,laser low status,  
novram/reset warning status>

*Default:* **Enabled**

*Options:* 0 = Disabled      1 = Enabled

### Laser High Message

*Definition:* Defines the **Laser High** message.

*Serial Cmd:* <**K**;**laser high message**>

*Default:* **HI-LASER**

*Options:* Any 1 to 10 character ASCII string except NUL, <, or >.

---

## Warning Messages

### Laser Low Warning

When enabled a message up to 10-characters is transmitted whenever the laser current falls below a factory-calibrated reference value which cannot be altered. The message repeats once every 30 minutes until the condition is corrected.

#### Laser Low Status

*Definition:* Enables the **Laser Low** message.

*Usage:* Alerts the user to impending laser failure. (Contact Microscan Service.)

*Serial Cmd:* <**K**" warning message status,laser high status,**laser low status**, novram/reset warning status>

*Default:* **Enabled**

*Options:* 0 = Disabled      1 = Enabled

#### Laser Low Message

*Definition:* When enabled a message up to 10-characters is transmitted whenever the laser current falls below a factory-calibrated reference value which cannot be altered. The message repeats once every 30 minutes until the condition is corrected.

Defines the **Laser Low** message.

*Serial Cmd:* <**K:laser low message**>

*Default:* **LO-LASER**

*Options:* Any 1 to 10 character ASCII string except NUL, <, or >.

## NOVRAM Corrupt Warning Status

When enabled, a 7 character message is sent whenever the system detects a warning condition.

**Important Note: Warning Corrupt Message Status** must be enabled before the **NOVRAM** message in this menu can be transmitted.

- Function:* When enabled, a 7 character message is sent whenever the system detects a warning condition.  
However, if you suspect that erroneous defaults are occurring, enable **NOVRAM Messages** by sending **<K1,,,1>**. This will allow the **NOVRAM** messages, if present, to be viewed.
- Usage:* Alerts the user to NOVRAM failure. (Contact Microscan Service.)
- Serial Cmd:* **<Kwarning message status,laser high status,laser low status, novram reset warning status>**
- Default:* **Disabled**
- Options:* 0 = Disabled  
1 = Enabled

*Warning messages for NOVRAM can appear in one of five formats:*

### **<NVRAM-C>**

This message indicates an error in user settings. The message repeats once every 30 minutes. If this message is received, restore customer settings and send a **<Z>** command.

If the condition persists, call customer service.

### **<NVBAD-D>**

Indicates that diagnostic lifetime hours, power-on counts, and reset counts have been lost. The message repeats once every 30 minutes. (Contact Microscan Service.)

### **<NVBAD-L>**

Indicates a problem with laser current factory reference. The message repeats once every 30 minutes. (Contact Microscan Service.)

### **<DFALT-C>**

Indicates that the customer NOVRAM settings have been defaulted either by a customer initiated default or by a problem with the scanner. This message is sent ONLY ONCE.

### **<DFALT-F>**

Indicates that the factory NOVRAM settings have been defaulted. This message is sent ONLY ONCE upon reset. (Contact Microscan Service.)

## High Temperature Threshold

A message can be defined that will display when a user-set **High Temperature Threshold** has been reached. The message repeats once every 30 minutes until the condition is corrected. This value is a reference to the external ambient temperature in the environment around the scanner.

### High Temperature Degrees

*Definition:* A user can set a temperature value that when exceeded will cause a high temperature message to be displayed. If **High Temperature Threshold** is set to zero, then the warning message will be disabled

*Usage:* Helps ensure that the scanner is being used within its temperature specification. Also, since hotter environments tend to shorten the life of electronics components, a user may want to set the temperature threshold closer to the nominal temperature of 25°.

*Serial Cmd:* <K+degrees,message>

*Default:* **50° Celsius**

*Options:* 0° to 50°, zero disables.

### High Temperature Message

*Definition:* The user can enter a 10-character message that will be displayed whenever **High Temperature Threshold** is exceeded.

*Serial Cmd:* <K+degrees,message>

*Default:* **HI\_TEMP**

*Options:* Any 1 to 10 character ASCII string except **NUL, <, or >**.

## Low Temperature Threshold

A message can be defined that will display when a user-set **Low Temperature Threshold** has been reached. The message repeats once every 30 minutes until the condition is corrected. This value is a reference to the external ambient temperature in the environment around the scanner.

### Low Temperature Degrees

*Definition:* The user can set a low temperature value that whenever the ambient temperature falls below it causes a low temperature message to be displayed. If **Low Temperature Threshold** is set to zero, the warning message will be disabled.

*Usage:* Helps ensure that the scanner is being used within its temperature specification.

*Serial Cmd:* <**K-degrees**,message>

*Default:* **1°** Celsius

*Options:* 0° to 50°, zero disables.

### Low Temperature Message

*Definition:* The user can enter a 10-character message that will be displayed whenever the ambient temperature falls below the **Low Temperature Threshold**.

*Serial Cmd:* <**K-degrees**,message>

*Default:* **LO\_TEMP**

*Options:* Any 1 to 10 character ASCII string except NUL, <, or >.

## Lifetime Hours

A message can be defined that will be transmitted whenever the scanner's elapsed time clock exceeds the set hours threshold. The message repeats one time every 30 minutes.

### Hours Threshold

*Definition:* A user can set a time in hours that will cause a message to be sent whenever the scanner's run time exceeds this value.

The elapsed time is the time the scanner is powered up.

*Usage:* Useful for setting up a preventive maintenance program.

*Serial Cmd:* **<K\$hours10,message>**

*Default:* **2500** (actually 25,000 hours)

*Options:* 0 to 65534

Note: Hours entered are 1/10 of the actual hours.

### Message

*Definition:* A user can define message up to 10-characters that will be displayed whenever the hours threshold is reached or exceeded.

*Serial Cmd:* **<K\$hours10,message>**

*Default:* SERVICE

*Options:* Any 1 to 10 character ASCII string except NUL, <, or >.

## Present Ambient Temperature (deg. C)

(This command is READ ONLY.)

- Definition:* Close estimation of external temperature.  
A thermal sensor on the main PCB measures the internal temperature of the scanner. From this a case-differential constant is subtracted to yield an estimated external temperature.
- Usage:* Indicates temperature of the environment immediately outside of the scanner. Useful for setting **Over Temperature Threshold** and **Under Temperature Threshold**.
- Serial Cmd:* Send: **<K%?>**  
Returns **<K% degrees Celsius>**.

**Note:** When viewing the **Present Operating Temperature**, allow at least 20 minutes after startup for the scanner's inside and outside temperatures to stabilize.

# Counts

(These commands are READ ONLY.)

## Powerups

*Definition* Returns the number of times the scanner has been re-powered or a watchdog reset occurs.

*Usage:* Useful for detecting unwanted resets caused by power supply problems or ESD transients.

*Serial Cmd:* Send **<K\_>**  
Returns **<K\_ powerups, resets>**

*Read Only Ranges:* 0 to 65,535 powerups, 0 to 65,535 resets.

## Resets

*Definition* Resets include watchdog reset, **<A>**, **<Z>**, **<Zd>**, and hardware defaults. A watchdog reset is a reset that is forced whenever the software locks-up.

*Usage:* Useful for detecting unwanted resets caused by power supply problems or ESD transients.

*Serial Cmd:* Send **<K\_>**  
Returns **<K\_ powerups, resets>**

*Read Only Ranges:* 0 to 65,535 powerups, 0 to 65,535 resets.

## Time Since Last Reset

(This command is READ ONLY.)

*Definition:* Records the number of hours and minutes of operation since the last system reset.

*Usage:* Useful as a troubleshooting tool that can help pinpoint the cause of a reset.

*Serial Cmd:* Send **<K@?>**  
Returns **<K@ hours,minutes>**

*Read Only Ranges:* 0 to 23 hours, 0 to 59 minutes.

---

*Time Since Last Reset*

## Chapter Contents

|                                     |       |
|-------------------------------------|-------|
| File Transfer.....                  | 11-5  |
| Counters .....                      | 11-6  |
| Part Number .....                   | 11-8  |
| Checksum .....                      | 11-9  |
| Read Rate.....                      | 11-10 |
| Device Control .....                | 11-12 |
| Code Types .....                    | 11-13 |
| Defaulting/Saving/Initializing..... | 11-13 |
| Master Label .....                  | 11-13 |

Utility commands are generally commands that are performed during scanner operations to check read rates, determine read rates or perform miscellaneous operations on scanner hardware. Serial utility commands are not prefaced with a "K". Nor do they require an initialization command (<A> and <Z>). They can be entered from within any terminal program or from within ESP-MP in the **Terminal** window or the window adjacent to the **Utilities** menu.

**Note:** The characters **NULL <>** and **,** can only be entered through embedded menus, not through ESP or serial commands.


## Utilities by ESP Menu

11-Utilities



Click this button to bring up the **Utilities** menu

To change a setting, **right-click** the setting and use your cursor to scroll through the options.



**Note:** Utility commands are not accessible by embedded menus.

## Utilities by Serial Command

Table 11-1 Summary of Utility Serial Commands

| Command Type              | Command | Name  |
|---------------------------|---------|---|
| Counter Request and Clear | <N>     | Noread Counter                              |
|                           | <O>     | Noread Counter Reset                        |
|                           | <T>     | Trigger Counter                             |
|                           | <U>     | Trigger Counter Reset                       |
|                           | <V>     | Good Read/Match Counter                     |
|                           | <W>     | Good Read/Match Counter Reset               |
|                           | <X>     | Mismatch Counter                            |
|                           | <Y>     | Mismatch Counter Reset                      |
| Part Number Checksum/     | <I>     | Display all three Checksums of Flash memory |
|                           | <!b>    | Display Checksum for Boot Code              |
|                           | <!a>    | Display Checksum for Application Code       |
|                           | <#>     | Display both Part Numbers                   |
|                           | <#b>    | Display Boot Code Part Number               |
|                           | <#a>    | Display Application Code Part Number        |
| Read Rate                 | <Cp>    | Enter Single Label Percent Rate Test        |
|                           | <C>     | Enter Single Label Decode Rate Test         |
|                           | <Cm>    | Enter Multilabel Percentage Rate Test       |
|                           | <Cs>    | Enter Multilabel Decode Rate Test           |
|                           | <a1>    | PDF Information                             |
|                           | <J>     | Exit Decode Rate and Percent Rate Test      |
| Device Control            | <H>     | Enable Laser Scanning                       |
|                           | <I>     | Disable Laser Scanning                      |
|                           | <KE>    | Motor On                                    |
|                           | <KF>    | Motor Off                                   |
|                           | <L1>    | Programmable Output 1                       |
|                           | <L2>    | Programmable Output 2                       |
|                           | <L3>    | Programmable Output 3                       |
| Code Types Commands       | <P>     | Autodiscriminate All Codes                  |
|                           | <Q>     | Enable Code 39 Only                         |
|                           | <R>     | Enable Codabar Only                         |
|                           | <S>     | Enable I 2/5 Only                           |
| Trigger                   | <char>  | Serial Trigger Character                    |
| Default/Reset/Save        | <A>     | Reset (does not save for power-on)          |
|                           | <Ad>    | Default                                     |
|                           | <An>    | Restore Saved Settings                      |
|                           | <Z>     | Reset/Save (for power-on)                   |
|                           | <Zp>    | Save Factory Settings                       |
|                           | <Zd>    | Save/Restore Factory Defaults               |

|                 |                                      |  |
|-----------------|--------------------------------------|--|
| Master Label    | <E>                                  | Enable Master Label *                              |
|                 | <F>                                  | Disable Master Label*                              |
|                 | <G>                                  | Store next label scanned to database. <sup>a</sup> |
|                 | <M <i>master label number,data</i> > | Enter data to database for specified label*        |
|                 | <M?>                                 | Request master label information*                  |
|                 | <M <i>master label number,&gt;</i> > | Delete Master Label*                               |
| Status Commands | <->                                  | Input Status                                       |
|                 | <?>                                  | Scanner Status                                     |
|                 | <?1>                                 | Extended Scanner Status                            |
|                 | <K?>                                 | Configuration Status                               |

a. If no number is included, the label will be saved to database number 1.

\*Can also be set in the configuration menu or with a serial configuration command. (See [Chapter 7](#), "Matchcode.")

# File Transfer

File transfer is used to download application code to the scanner.

Application code versions are specific to your scanner. Consult with your sales representative before downloading application code. If needed, an application code will be sent to you in the form of a **\*.mot** file.

To download application code:

1. First make sure the host is connected to your scanner.
2. Apply power to the scanner.
3. In the **Utilities** window, right-click on **File Transfer** and select **Download/App Code**.

This will open a file dialog box.

4. Navigate to the appropriate file (a **\*.mot** file) and open the file.

As application code begins to download to the scanner, the scanner will go silent, the scanner's RDY and GD/RD LEDs will flash intermittently, and a progress indicator at the bottom of the ESP window will let you know when the download is complete.

**Caution:** Do not interrupt power or disconnect the host cable while download is in progress.

# Counters


Counter commands can be a numeric value from 00000 to 65,535. After reaching the maximum numeric limit of 65,535, an error message will be displayed and the counter will automatically roll-over and start counting again at 00000. To obtain the cumulative total of counts after the roll-over has occurred, add 65,536 per each roll-over (the scanner does not keep track of the number of roll-overs) to the current count.

**Note:** All counter values will be lost if power is recycled to the scanner or the scanner receives a reset or save command.

## By ESP

You can access **Counters** from the **Utilities** menu.

**Right-click** the appropriate counter option and select **Request** to display count or **Clear** to set counter to zero.



## By Serial Command

### Noread Counter

Sending **<N>** displays the total number of noreads that have occurred since the last reset.

### Noread Counter Reset

Sending **<O>** sets Noread Counter to 00000.

### Trigger Counter

Sending **<T>** displays the total number of triggers since the last reset.

### Trigger Counter Reset

Sending **<U>** sets the trigger counter to 00000.

### Good Read/Match Counter (or Good Read Counter)

Sending **<V>** displays the total number of good reads matching the master label or, if Master Label is not enabled, the number of good reads since the last reset. This counter is always enabled, but will only work as a match count when Master Label is enabled. If Master Label is not enabled, this counter records the number of good reads. This count can be requested at any time.

*Good Read/Match Counter Reset*

Sending **<W>** sets the Match Counter to 00000.

*Mismatch Counter*

Sending **<X>** displays the number of decoded labels since the last reset that do not match the master label.

*Mismatch Counter Reset*

Sending **<Y>** sets the Mismatch Counter to zero.

# Part Number

You can send a request to the scanner for part numbers, checksums, boot code and application code.

## By ESP

You can access **Part Number** from the **Utilities** menu.

**Right-click** the appropriate option and select **Request** to see the associated part number or check sum number.



## By Serial Command

Upon sending **<#>** the scanner returns software part numbers for application code **<#a/>** and boot code **<#b/>**.

Individual part numbers for **Application Code** and **Boot Code** are returned when their respective commands **<#a>** and **<#b>** are sent.

# Checksum

You can send a request to the scanner for part numbers, checksums, boot code and application code.

## By ESP

You can access **Checksum** from the **Utilities** menu.

**Right-click** the appropriate option and select **Request** to see the associated part number or check sum number.



## By Serial Command

Upon sending **<!>** the scanner returns three 4-digit hex numbers that are displayed under **Check Sum**. Checksums verify a scanner's flash memory.

Individual checksums for **Boot Code** and **Application Code** are returned when their respective commands **<!b>** and **<!a>** are sent.

# Read Rate

You can do a read rate test for decode rate or percent by ESP or serial command.


## By ESP

You can access **Read Rate** from the **Utilities** menu.

To start or end a read rate test, right-click **Read Rate** and select **Start** or **Stop**.

To change from percent read rate to decodes per second, right-click **Read Rate** and make the selection.

11-Utilities



## By Serial Command

### *Enter Single Label Decodes/Second Test*

Sending **<C>** instructs the scanner to transmit the decodes per second and label data (if any). The decode rate can vary dramatically due to the angle and location of the label in relation to the scan line. This test is very useful in aligning and positioning the scanning device during installation.

### *Enter Single Label Percent Test*

Sending **<Cp>** instructs the scanner to transmit the percentage of decodes and any scanned label data.

### *Enter Multilabel Percent Test*

Sending **<Cm>** instructs the scanner to transmit the percentage of scans decoded and label data (if any) for multiple labels.

### *Enter Multilabel Decode Rate Test*

Sending **<Cs>** instructs the scanner to transmit the decode rate and label data (if any) for multiple labels.

### *Enter Percent PDF Read Rate Test*

Sending **<CPDF>** instructs the scanner to transmit the number of decodes per second on the full PDF label. This test includes both capture and decode and translation time. Note that the output format of the data is done as a running average of 750 mS windows. This means that you can remove the label from the view of the scanner and it will continue to transmit some history of the label for a few outputs.

### *End Read Rate Test*

Sending **<J>** ends both the **Percent** test and the **Decodes/Second** test for both single and multi-label.

### *Enable PDF Information*

Sending the **<a1>** check box will cause PDF417 symbology data to be prefaced with information consisting of error correction level, number of rows, number of columns, number of informative code words and the number of data characters.

Explanation of above PDF Info sample of a PDF417:

Level = 5 tells you that the error correction level is level 5. There are 13 rows and 6 columns. There are 14 info code words, and 16 characters in the data.

This feature can be disabled by using the exit read rate command **<J>**.

# Device Control

You can control laser scanning by ESP or serial command.

## By ESP

You can access **Device Control** from the **Utilities** menu.

For any of the **Device Control** commands, **right-click** on the command and make your selection.

11-Utilities



## By Serial Command

### Enable Laser Scanning

Sending **<H>** will turn the laser on continuously.

**Note: Enable Laser Scanning** does not relate to **Laser On/Off** command.

### Disable Laser Scanning

Sending **<I>** will turn the laser off. This feature is useful during extended periods of time when no bar code labels are being scanned or the scanner is being configured. Disabling laser scanning will not affect any downloaded commands to the scanner.

**Note: Disable Laser Scanning** does not relate to **Laser On/Off**, which when enabled also turns off the laser but only between read cycles.

### Motor On

Sending **<KE>** turns the spinning mirror on (if not already running).

**Note:** the spinning mirror reaches full speed after a short time delay.

### Motor Off

Sending **<KF>** turns the spinning mirror motor off. This command is useful for long idle periods.

**Note:** Laser turns off whenever motor is off.

**Output #1**

Sending **<L1>** activates the link between Output 1(+) and Output 1(-) of the 25-pin host connector (regardless of Master Label or Output 1 status).

**Output #2**

Sending **<L2>** activates the link between Output 2(+) and Output 2(-) of the 25-pin host connector (regardless of Master Label or Output 2 status).

**Output #3**

Sending **<L3>** activates the link between Output 3(+) and Output 3(-) of the 25-pin host connector (regardless of Master Label or Output 3 status).

## Code Type

See also ["Autodiscriminate" on page 5-28](#) for a discussion of **Utility** commands for **Code Types** and **Autodiscrimination**.

**Default:**       **Code 39 (only)**  
**Options:**       **<P>** Enables most code types.  
                  **<Q>** Enable Code 39 only  
                  **<R>** Enable Codabar only  
                  **<S>** Enable I 2/5 only

## Master Label Database

See ["Master Label Database" on page 7-10](#).

## Defaulting/Saving/Initializing

See [Appendix H — "Defaulting/Saving/Initializing" on page A-20](#).



# Appendices

## Chapter Contents

|   |      |
|---|------|
| Appendix A General Specifications .....         | A-2  |
| Appendix B Electrical Specifications .....      | A-5  |
| Appendix C Serial Configuration Commands .....  | A-11 |
| Appendix D Serial Command Format.....           | A-14 |
| Appendix E ASCII Table.....                     | A-16 |
| Appendix F Embedded Menus .....                 | A-18 |
| Appendix G Defaulting/Saving/Initializing.....  | A-19 |
| Appendix H Position Scanner and Bar Code .....  | A-23 |
| Appendix I Test Decode Rate .....               | A-24 |
| Appendix J Formulas for Number of Decodes ..... | A-25 |
| Appendix K Operational Tips.....                | A-29 |
| Appendix L Interface Standards .....            | A-30 |
| Appendix M Multidrop Communications.....        | A-31 |
| Appendix N Glossary of Terms .....              | A-36 |

Appendices

# Appendix A — General Specifications

## Key Features

- Multiple label and symbology reading
- Industrial IP65 rated enclosures

## Mechanical

Depth: 2.59" (65.8mm)  
 Width: 3.47" (88.1mm)  
 Height: 1.38" (35.0mm)  
 Weight: 7.5 oz. (212g)

## Environmental

Ambient Light Immunity:  
 450 foot candles (indoor: fluorescent, incandescent, mercury vapor, sodium vapor); 1800 foot candles (soft outdoors)  
 Enclosure rating: IP65  
 Operating temperature: 0° to 50°C  
 Storage Temperature: -29° to 70°C  
 Operating temperature:  
 Humidity: Up to 90% (non-condensing)

## Emissions and Immunity

General immunity for ITE equipment:  
 EN 55024:98  
 General immunity for heavy industry:  
 EN 61000-6-2:98  
 Radiated and conducted emissions  
 of ITE equipment: EN 55022:98, Class A

## Laser Light

Semiconductor visible laser diode: 650nm nominal; 780nm nominal (optional)  
 Safety class:  
 Visible laser: CDRH Class II, 650nm  
 Infrared laser: CDRH Class 1, 780nm  
 Operating Life: 50,000 hours @25°C

Appendices




Figure A-1 MS-820 Dimensions

### Scanning Parameters

Scanning mirror type:

Rotating, 10-faceted

Options: Single line/raster

Scan width angle: Typically 60°; Pitch: ±50° max.; Skew: ±40° max.

Label contrast: 25% min. absolute dark to light differential at 650nm wavelength

### Communication

RS-232, RS-422/485, Daisy Chain , DeviceNet and Ethernet (Modicon) can be used with an accessory IB-131 Interface.

### Code Types

Standard offering: Code 128, Code 39, Code 93, Codabar, Interleaved 2 of 5, UPC/EAN, PDF417

Application standards: AIAG, UCC/EAN-128

### FIS Options

| FIS # | Light   | Density      | Line        |
|-------|---------|--------------|-------------|
| 001   | Visible | Low Density  | Single Line |
| 002   | Visible | High Density | Single Line |
| 003   | Visible | Low Density  | Raster      |
| 004   | Visible | High Density | Raster      |

### Read Ranges

Table A-1 MS-820 Read Ranges<sup>a</sup>

| Narrow-bar-width | High Density                | Low Density               |
|------------------|-----------------------------|---------------------------|
| .0033" (.084mm)  | Call Microscan              | -                         |
| .005" (.127mm)   | 4" to 5.5" (102 to 140mm)   | -                         |
| .0075" (.190mm)  | 3.5" to 6.75" (89 to 171mm) | 10" to 12" (254 to 305mm) |
| .010" (.254mm)   | 3.25" to 8" (82 to 203mm)   | 7" to 16" (178 to 406mm)  |
| .015" (.381mm)   | 3" to 9" (76 to 229mm)      | 6" to 19" (152 to 483mm)  |
| .020" (.508mm)   | -                           | 5" to 22" (127 to 558mm)  |
| .040" (1.020mm)  | -                           | 4" to 30" (102 to 762mm)  |

a. Range data is based on a grade A Code 39 label.

---

## Appendix A

### Beeper

Beeps on output (good read, noread, on/off).

### LED Indicators

*Table A-2 MS-820 Status Lights*

| LED   | State    | Status                     |
|-------|----------|----------------------------|
| PWR   | Red-On   | Scanner has power          |
| RDY   | Green-On | Scanner is ready to read   |
| GD/RD | Green-On | Label is qualified as good |

### Safety Certifications

FCC, CDRH, CE, UL/cUL, TÜV, BSMI

Product specifications are given for typical performance at 25°C (77°F) using grade A labels. Some performance characteristics may vary at high temperatures or other environmental extremes.

© Microscan Systems, Inc., Specifications subject to change

**Note:** Specifications subject to change.


# Appendix B — Electrical Specifications

Maximum Operating Power: 3.6 Watts  
 Power Input: 10 to 28VDC, 200mV p-p max. ripple, 120 mA @ 24VDC (typical)  
 Trigger, New Master: 4.5 to 28 VDC (optoisolated)  
 Outputs (1,2,3): 1 to 28VDC (optoisolated) rated  
 ( $I_{CE} < 100\text{mA}$  @24VDC, current limited by user)

### Pin Assignments

Table A-3 MS-820 Host Connector, 15-pin

| Pin | Host RS232                         | Host & Aux RS232 | Host RS422/485 | In/Out |
|-----|------------------------------------|------------------|----------------|--------|
| 1   | Power +10 to 28 VDC                |                  |                | In     |
| 2   | Host TxD                           | Host TxD         | TxD (-)        | Out    |
| 3   | Host RxD                           | Host RxD         | RxD (-)        | In     |
| 4   | Power/Signal ground                |                  |                |        |
| 5   | Trigger (-)                        |                  |                | In     |
| 6   | RTS                                | Aux TxD          | TxD (+)        | Out    |
| 7   | Output 1 (+)                       |                  |                | Out    |
| 8   | Default configuration <sup>a</sup> |                  |                | In     |
| 9   | Trigger (+)                        |                  |                | In     |
| 10  | CTS                                | Aux RxD          | RxD (+)        | In     |
| 11  | Output 3 (+)                       |                  |                | Out    |
| 12  | New master pin                     |                  |                | In     |
| 13  | Chassis ground <sup>b</sup>        |                  |                |        |
| 14  | Output 2 (+)                       |                  |                | Out    |
| 15  | Outputs 1, 2, 3 (-)                |                  |                | Out    |



Appendices

a. The default is activated by connecting pin 8 to ground pin 4. See "By Hardware Default" on page A-21.  
 b. Chassis ground: Used to connect chassis body to earth ground only. Not to be used as power or signal return.


**Caution:** If using your own power supply, verify correct connection of power and ground lines. Incorrect connections or use of "Chassis ground," "Power ground," and "Signal ground" lines could cause equipment and/or software failure.

## Optoisolator Outputs

Optoisolator circuits can transfer pulses between the scanner and peripherals with no direct connection with the scanner's internal circuitry. However, not every optoisolator configuration provides complete isolation. The following diagrams show both fully optoisolated and non-optoisolated circuits. They are only examples and do not represent all the possible wiring configurations.

Generic Output Waveform Characteristics

|               | $I_{load} = 5\text{ mA}$ | $I_{load} = 50\text{ mA}$ | $I_{load} = 100\text{ mA}$ |
|---------------|--------------------------|---------------------------|----------------------------|
| $V_{Out-On}$  | 0.5V                     | 0.5V                      | 1.0V                       |
| $t_{On-Typ}$  | 5mS                      | 0.7mS                     | 0.8mS                      |
| $t_{Off-Typ}$ | 5 $\mu$ S                | 5 $\mu$ S                 | 5 $\mu$ S                  |




### Output Circuit Examples

#### Fully Optoisolated

This circuit is fully optoisolated and the recommended configuration. It allows the user to apply 1 to 28 VDC to the circuit.


**Caution:** The maximum current that can pass through the optoisolator is 100mA.




#### Not Optoisolated, Scanner Grounded

In this diagram, power is applied externally, but the scanner's power ground is used to complete the circuit. This setup involves some risk to the optoisolator if excessive voltages are applied.

**Caution:** The maximum current that can pass through the optoisolator is 100mA.



Additional Isolated Output Circuit Examples



Appendices

Appendix B


### Optoisolator Inputs

All discrete inputs can be fully isolated pulses as PNP or NPN circuits. Inputs include trigger and new master.

Generic Waveform Characteristics<sup>a</sup>

|                            | Minimum      | Maximum    |
|----------------------------|--------------|------------|
| $V_{IN-HIGH}/I_{IN-HIGH}$  | 4.5 V/3.0 mA | 28 V/23 mA |
| $V_{IN-LOW}/I_{IN-LOW}$    | 0 V/0 mA     | 2.0 V/1 mA |
| Pulse Width <sub>min</sub> | 48 $\mu$ S   |            |


a. New Master is activated by applying a voltage of 5 to 28 VDC between New Master (+) and internal ground.




New master pin input (-) is internally grounded.

### Input Examples

#### Fully Optoisolated



#### Not Optoisolated



Appendices

## Appendix C — IB-131 Interface Module

The IB-131 interface module simplifies connecting to the scanner by providing separate ports for the host, power supply, trigger and network. The network port is used for multidrop or daisy chain configurations. See the following pages for configuration diagrams and a list of cables offered by Microscan for ease of connectivity when using the IB-131.

*Table A-4 Host 25-pin Connector*

| Pin | Function                 |
|-----|--------------------------|
| 1   | External ground          |
| 2   | Transmit data (RS-232)   |
| 3   | Receive data (RS-232)    |
| 4   | RTS                      |
| 5   | CTS                      |
| 6   | Output 2 (+)             |
| 7   | Signal ground            |
| 8   | Output 1 (+)             |
| 9   | Trigger (-)              |
| 10  | Trigger (+)              |
| 11  | Default configuration    |
| 13  | Receive data RS-422 (+)  |
| 14  | Transmit data RS-422 (-) |
| 15  | Output 3 (+)             |
| 16  | Receive data RS-422 (-)  |
| 17  | Output 1/2/3 (-)         |
| 19  | Transmit data RS-422 (+) |
| 25  | New master/OMR (in)      |

*Table A-5 Trigger 4-pin Connector*

| Pin | Function                  |
|-----|---------------------------|
| 1   | Power + 10 to 28VDC (out) |
| 2   | Trigger (-) (in)          |
| 3   | Power Ground              |
| 4   | Trigger (+) (in)          |

*Table A-6 Power 3-pin Connector*

| Pin | Function                 |
|-----|--------------------------|
| 1   | Power Ground             |
| 3   | Power + 10 to 28VDC (in) |

*Table A-7 Scanner 15-pin Connector*

| Pin | Function                           |
|-----|------------------------------------|
| 1   | Power + 10 to 28 VDC (out)         |
| 2   | Transmit RS-232/RS-422 (-)         |
| 3   | Receive RS-232/RS-422 (-)          |
| 4   | Power/Signal Ground                |
| 5   | Trigger (-) (out)                  |
| 6   | RTS/Aux Transmit/RS-232/RS-422 (+) |
| 7   | Output 1 (+)                       |
| 8   | Default configuration              |
| 9   | Trigger (+) (out)                  |
| 10  | CTS/Aux Receive RS-232/RS-422 (+)  |
| 11  | Output 3 (+)                       |
| 12  | New master/OMR (out)               |
| 13  | External ground                    |
| 14  | Output 2 (+)                       |
| 15  | Output 1/2/3 (-)                   |

*Table A-8 Network 25-pin Connector*

| Pin | Function                 |
|-----|--------------------------|
| 1   | Ground                   |
| 2   | Aux Receive RS-232       |
| 3   | Aux Transmit RS-232      |
| 6   | Output 2 (+)             |
| 7   | Signal ground            |
| 8   | Output 3 (+)             |
| 13  | Receive data/RS-422 (+)  |
| 14  | Transmit data/RS-422 (-) |
| 15  | Output 3 (+)             |
| 16  | Receive data/RS-422 (-)  |
| 17  | Output 1/2/3 (-)         |
| 19  | Transmit data (RS-422+)  |

Appendices

## Appendix C

### Electrical:

Voltage Input: Regulated +10 to 28VDC

### Cabling:

RS-232 Cable: 61-300026

Multidrop Cable: 61-100030

Daisy Chain Cable: 61-100029

### Mechanical:

Length: 3.2 in. (8.13 cm)

Width: 3.15 in. (8 cm)

Height: 0.75 in. (1.9 cm)




Figure A-2 IB-131 Mechanical

## Scanner to IB-131

With this configuration the scanner communicates directly with the host through the IB-131.

**IB-131:** 99-400005-02  
(1 per MS-820)

**Host RS-232 Serial Cable:**  
61-300026 (for PC)

**Power Supply:** 97-10004-05 (for each scanner)

**Trigger:** 99-440001-10  
(for each scanner)




Figure A-3 Scanner/IB-131 Typical Setup

### Multidrop

This setup allows the user to link multiple scanners together, using only one host.

**IB-131:** 99-400005-02  
(1 per MS-820)

**Multidrop Cable:** 61-100030  
(connects multiple IB-131s)

**Power Supply:** 97-10004-05  
(for each scanner)

**Trigger:** 99-440001-10 (for each scanner)




Figure A-4 IB-131 Multidrop Setup

### Daisy Chain

This setup allows the user to link multiple scanners together, using only one host.

**IB-131:** 99-400005-02  
(1 per MS-820)

**Daisy Chain Cable:** 61-100029  
(connects multiple IB-131s)

**Power Supply:** 97-10004-05  
(for each scanner)

**Trigger:** 99-440001-10  
(for each scanner)




Figure A-5 Scanner/IB-131 Daisy Chain Setup

Appendices

## Appendix D — Serial Configuration Commands

The following table is a list of all the available serial configuration commands alphabetical. These commands are also listed at the beginning of each applicable chapter. For utility (operational) commands see [Table 11-1, "Summary of Utility Serial Commands," on page 11-3.](#)

Table A-9 Complete List of Serial Configuration Commands

| Command Title                    | Cmd        | Format   |
|----------------------------------|------------|--|
| Host Port Parameters             | <b>Ka</b>  | < <b>Ka</b> baud,parity,stop bits,data bits>   |
| Auxiliary Port Parameters        | <b>Ky</b>  | < <b>Ky</b> aux port mode,baud,parity,stop bits,data bits,daisy chain status,daisy chain ID>   |
| Host Protocol                    | <b>Kf</b>  | < <b>Kf</b> protocol>  |
| LRC                              | <b>Kc</b>  | < <b>Kc</b> status>  |
| Response Timeout                 | <b>KA</b>  | < <b>KA</b> response timeout>  |
| Intercharacter Delay             | <b>KB</b>  | < <b>KB</b> intercharacter delay>  |
| Preamble                         | <b>Kd</b>  | < <b>Kd</b> status,preamble>   |
| Postamble                        | <b>Ke</b>  | < <b>Ke</b> status,postamble>  |
| Comm. Status Request             | <b>KT?</b> | < <b>KT?</b> >   |
| Triggering Mode                  | <b>Kg</b>  | < <b>Kg</b> trigger mode,filter time>  |
| End of Read Cycle                | <b>Kh</b>  | < <b>Kh</b> mode,timeout>  |
| Serial Trigger Character         | <b>Ki</b>  | < <b>Ki</b> character>   |
| External Trigger State           | <b>Kj</b>  | < <b>Kj</b> external trigger state>  |
| Decodes Before Output            | <b>Km</b>  | < <b>Km</b> decodes before output>   |
| Multilabel                       | <b>KL</b>  | < <b>KL</b> number of labels,multilabel separator>   |
| Narrow Margins/Symbology ID      | <b>Ko</b>  | < <b>Ko</b> narrow margins status,symbology ID status>   |
| Background Color                 | <b>Kx</b>  | < <b>Kx</b> background color>  |
| Code 39                          | <b>Kp</b>  | < <b>Kp</b> status,check digit status,check digit output status,large intercharacter gap,fixed code length status,fixed code length,full ASCII>                                    |
| Interleaved 2 of 5               | <b>Kr</b>  | < <b>Kr</b> status,check digit,check digit output,length 1,length 2>   |
| UPC/EAN                          | <b>Ks</b>  | < <b>Ks</b> status,EAN status,supplementals status,separator char>   |
| PDF417                           | <b>K[</b>  | < <b>K[</b> status,,fixed code length status,fixed code length>  |
| Code 128                         | <b>Kt</b>  | < <b>Kt</b> status,fixed length,length,,,,,>   |
| UCC/EAN-128 (subset of Code 128) | <b>Kt</b>  | < <b>Kt</b> ,,,UCC/EAN-128 status,output format,application record separator status,application record separator character,application record brackets,application record padding> |
| Codabar                          | <b>Kq</b>  | < <b>Kq</b> status,start & stop match status,start & stop output status,large intercharacter gap,fixed code length status,fixed code length,check digit type,check digit output>   |
| Code 93                          | <b>K!</b>  | < <b>K!</b> status,fixed code length status,fixed code length>   |

## Serial Configuration Commands

| Command Title                     | Cmd        | Format  |
|-----------------------------------|------------|---|
| AIAG                              | <b>KZ</b>  | < <b>KZ</b> AIAG status, ID1, status1, ID2, status2, ID3, status3, ID4, status4, *ID5a,ID5b,ID5c, status5, ID6, status6, ID7, status7, ID8, status8, ID9, status9, ID9, status10, ID11, status11, ID12, status12> |
| Code Type Status Request          | <b>KW?</b> | < <b>KW?</b> >  |
| Match Code Type                   | <b>Kn</b>  | < <b>Kn</b> type,sequential matching,match start position,match length,wild card character,sequence on noread,sequence on every mismatch>   |
| Master Label Data Base Size       | <b>KM</b>  | < <b>KM</b> number of master labels>  |
| New Master Pin                    | <b>Kz</b>  | < <b>Kz</b> status>   |
| Operations Status Request         | <b>KV?</b> | < <b>KV?</b> >  |
| Background Color                  | <b>Kx</b>  | < <b>Kx</b> background color>   |
| Code Type Status Request          | <b>KW?</b> | < <b>KW?</b> >  |
| Noread Message                    | <b>Kk</b>  | < <b>Kk</b> status,output>  |
| Laser On/Off                      | <b>KC</b>  | < <b>KC</b> status,laser on/off status,laser framing status,laser off time,laser on time>   |
| Serial Verification               | <b>KS</b>  | < <b>KS</b> serial command status,serial command beep status,control/hex output>  |
| Beeper                            | <b>Ku</b>  | < <b>Ku</b> status,volume>  |
| Output 2                          | <b>Kw</b>  | < <b>Kw</b> output on,active state,pulse width,number before output>  |
| Output 3                          | <b>K'</b>  | < <b>K'</b> output on,active state,pulse width,number before output>  |
| Output 1                          | <b>Kv</b>  | < <b>Kv</b> output on,active state,pulse width,number before output>  |
| Output 2                          | <b>Kw</b>  | < <b>Kw</b> output on,polarity,pulse width,# before output>   |
| Output 3                          | <b>K'</b>  | < <b>K'</b> output on,polarity,pulse width,# before output>   |
| Bar Code Output                   | <b>KI</b>  | < <b>KI</b> status,when to output>  |
| Partial Output                    | <b>KY</b>  | < <b>KY</b> status,start position,length>   |
| Operational Command Output Format | <b>K/</b>  | < <b>K/</b> status>   |
| Scanner Output Status Request     | <b>KX?</b> | < <b>KX?</b> >  |
| Scanner Type (factory)            | <b>KP</b>  | < <b>KP</b> density>  |
| Scan Speed (factory)              | <b>KE</b>  | < <b>KE</b> scan speed>   |
| Gain/Tracking (factory)           | <b>KD</b>  | < <b>KD</b> gain,tracking>  |
| Transition Trigger Sampling Rate  | <b>KH</b>  | < <b>KH</b> transition sample status,transition sample rate threshold>  |
| No Barcode Output                 | <b>KN</b>  | < <b>KN</b> status,message>   |

Appendices

## Appendix D

| Command Title                 | Cmd        | Format  |
|-------------------------------|------------|---|
| Bad Barcode Output            | <b>K'</b>  | < <b>K'</b> status,message>   |
| Scanner Setup Status Request  | <b>KU?</b> | < <b>KU?</b> >  |
| Raster Setup                  | <b>KR</b>  | < <b>KR</b> status,top offset,bottom offset,sweep rate,read cycle on/off> |
| Warning Message Status        | <b>K"</b>  | < <b>K"</b> status1,laserhi,laserlo,novram corrupt>                       |
| Laser Overcurrent             | <b>K;</b>  | < <b>K;</b> message>  |
| Laser Undercurrent            | <b>K:</b>  | < <b>K:</b> message>  |
| Over-temperature              | <b>K+</b>  | < <b>K+</b> deg,message>  |
| Under-temperature             | <b>K-</b>  | < <b>K-</b> deg,message>  |
| Lifetime Hours                | <b>K\$</b> | < <b>K\$</b> hours10,message>   |
| Present Operating Temperature | <b>K%</b>  | < <b>K%</b> deg> (read only)  |
| Counts                        | <b>K_</b>  | < <b>K_</b> powerups,resets> (read only)                                  |
| Time Since Last Reset         | <b>K@</b>  | < <b>K@</b> hours,minutes> (read only)                                    |
| All Status Request            | <b>K?</b>  | < <b>K?</b> >   |

## Appendix E — Serial Command Format

Serial commands are of two types: utility and configuration.

### Rules that apply to both utility and configuration commands

- A less than < and greater than > characters enclose the commands.
- Commands and data are “case sensitive.” That is, characters must be entered as upper or lower case, as specified.

### Serial Utility Commands

These are sent during operations and are not followed by a <A> or <Z>. See [Table 11-1, “Summary of Utility Serial Commands,” on page 11-3.](#)

### Serial Configuration “K” Commands

See [Appendix E — “Serial Command Format” on page A-15.](#)

These begin with a single **K** character followed by a single character, data fields, and an initializing command, as follows:

*<Kparameterdata,data,...etc.><initializing command>*

An initializing command <A> or <Z> always follows the command. A <Z> initializes the scanner’s memory and saves for power-on; an <A> initializes the scanner’s memory but does not save for power-on.

For example, to enable **UPC** and save the change for power-on, send <K1><Z>.

To change **Baud Rate** and reset without saving changes for power-on, send <Ka3><A>.

### Serial Configuration Command Conventions

- All data fields (except the last) must be followed by a comma (without a space).
- The following characters cannot be used: , < > **NUL**.
- All fields preceding a modified field must be included.
- If there is no change in preceding fields, then commas alone can be entered in these fields. For example, if only the last field in the following command is changing, <Ka4,1,0,0> can be entered as <Ka,,,0>.
- All fields *following* a modified field can be omitted. For example, to change **Baud Rate**, send <Ka3>.

### Concatenating Configuration Commands

Commands can be concatenated (added together) in a single string or data block.

### Serial Command Status Request

To ensure that any command was received and accepted, you can send the **Show Scanner Status** command: **<?>**.

The status of a specific serial command can be requested by entering the command followed by a question mark.

### Entering Special Characters in Serial Commands

To enter control characters within a serial command, hold down the control key while typing the desired character.

### Entering Special Characters in Embedded Menus

#### *Control Characters*

Control characters entered on the command line are displayed in the menu as mnemonic characters, such as: <CR><LF><NUL><NUL>.

Press **SP** (the space bar) once, then enter the control character by holding down the control key and simultaneously pressing the desired character. For example to define a line feed, press **SP**, then **Control** and **J** simultaneously. It is displayed as ^J on the command line and as <LF> in the menu when the screen is refreshed.

#### *To Define a Carriage Return as a Character*

Press **SP**, then **CR**. It is displayed as ^M on the command line and as <CR> in the menu when the screen is refreshed.

#### *To Define a Space as a Character*

Press **SP** twice. It is displayed as a blank space in the menu when the screen is refreshed. While it appears that nothing has been assigned, the hex value 20 will be sent during data transmission.

#### *To Select NUL as the Character*

Press **SP**, then a **0** (zero). It is displayed as <NUL> in the menu when the screen is refreshed.

# Appendix F — ASCII Table

Table A-10 ASCII Table with Control Characters

| Dec | Hex | Mne | Ctrl | Dec | Hex | Ch | Dec | Hex | Ch | Dec | Hex | Ch |
|-----|-----|-----|------|-----|-----|----|-----|-----|----|-----|-----|----|
| 00  | 00  | NUL | ^    | 32  | 20  | SP | 64  | 40  | @  | 96  | 60  | `  |
| 01  | 01  | SOH | ^A   | 33  | 21  | !  | 65  | 41  | A  | 97  | 61  | a  |
| 02  | 02  | STX | ^B   | 34  | 22  | "  | 66  | 42  | B  | 98  | 62  | b  |
| 03  | 03  | ETX | ^C   | 35  | 23  | #  | 67  | 43  | C  | 99  | 63  | c  |
| 04  | 04  | EOT | ^D   | 36  | 24  | \$ | 68  | 44  | D  | 100 | 64  | d  |
| 05  | 05  | ENQ | ^E   | 37  | 25  | %  | 69  | 45  | E  | 101 | 65  | e  |
| 06  | 06  | ACK | ^F   | 38  | 26  | &  | 70  | 46  | F  | 102 | 66  | f  |
| 07  | 07  | BEL | ^G   | 39  | 27  | '  | 71  | 47  | G  | 103 | 67  | g  |
| 08  | 08  | BS  | ^H   | 40  | 28  | (  | 72  | 48  | H  | 104 | 68  | h  |
| 09  | 09  | HT  | ^I   | 41  | 29  | )  | 73  | 49  | I  | 105 | 69  | i  |
| 10  | 0A  | LF  | ^J   | 42  | 2A  | *  | 74  | 4A  | J  | 106 | 6A  | j  |
| 11  | 0B  | VT  | ^K   | 43  | 2B  | +  | 75  | 4B  | K  | 107 | 6B  | k  |
| 12  | 0C  | FF  | ^L   | 44  | 2C  | ,  | 76  | 4C  | L  | 108 | 6C  | l  |
| 13  | 0D  | CR  | ^M   | 45  | 2D  | -  | 77  | 4D  | M  | 109 | 6D  | m  |
| 14  | 0E  | SO  | ^N   | 46  | 2E  | .  | 78  | 4E  | N  | 110 | 6E  | n  |
| 15  | 0F  | SI  | ^O   | 47  | 2F  | /  | 79  | 4F  | O  | 111 | 6F  | o  |
| 16  | 10  | DLE | ^P   | 48  | 30  | 0  | 80  | 50  | P  | 112 | 70  | p  |
| 17  | 11  | DC1 | ^Q   | 49  | 31  | 1  | 81  | 51  | Q  | 113 | 71  | q  |
| 18  | 12  | DC2 | ^R   | 50  | 32  | 2  | 82  | 52  | R  | 114 | 72  | r  |
| 19  | 13  | DC3 | ^S   | 51  | 33  | 3  | 83  | 53  | S  | 115 | 73  | s  |
| 20  | 14  | DC4 | ^T   | 52  | 34  | 4  | 84  | 54  | T  | 116 | 74  | t  |
| 21  | 15  | NAK | ^U   | 53  | 35  | 5  | 85  | 55  | U  | 117 | 75  | u  |
| 22  | 16  | SYN | ^V   | 54  | 36  | 6  | 86  | 56  | V  | 118 | 76  | v  |
| 23  | 17  | ETB | ^W   | 55  | 37  | 7  | 87  | 57  | W  | 119 | 77  | w  |
| 24  | 18  | CAN | ^X   | 56  | 38  | 8  | 88  | 58  | X  | 120 | 78  | x  |
| 25  | 19  | EM  | ^Y   | 57  | 39  | 9  | 89  | 59  | Y  | 121 | 79  | y  |
| 26  | 1A  | SUB | ^Z   | 58  | 3A  | :  | 90  | 5A  | Z  | 122 | 7A  | z  |
| 27  | 1B  | ESC | ^[   | 59  | 3B  | ;  | 91  | 5B  | [  | 123 | 7B  | {  |
| 28  | 1C  | FS  | ^\   | 60  | 3C  | <  | 92  | 5C  | \  | 124 | 7C  |    |
| 29  | 1D  | GS  | ^]   | 61  | 3D  | =  | 93  | 5D  | ]  | 125 | 7D  | }  |
| 30  | 1E  | RS  | ^^   | 62  | 3E  | >  | 94  | 5E  | ^  | 126 | 7E  | ~  |
| 31  | 1F  | US  | ^_   | 63  | 3F  | ?  | 95  | 5F  | _  | 127 | 7F  | D  |

Appendices

Table A-11 Communication Protocol Commands

| <i>Protocol Command<br/>(Mnemonic displayed<br/>on Microscan menu)</i> | <i>Control Characters<br/>(Entered in menu or<br/>serial command)</i> | <i>Hex<br/>Code</i> | <i>Effect of Command</i>    |
|--|---|---------------------|-----------------------------|
| <i>RES</i>   | <i>^D</i>   | <i>04</i>           | <i>Reset</i>                |
| <i>REQ</i>   | <i>^E</i>   | <i>05</i>           | <i>Request</i>              |
| <i>EOT</i>   | <i>^D</i>   | <i>04</i>           | <i>Reset</i>                |
| <i>STX</i>   | <i>^B</i>   | <i>02</i>           | <i>Start of Text</i>        |
| <i>ETX</i>   | <i>^C</i>   | <i>03</i>           | <i>End of Text</i>          |
| <i>ACK</i>   | <i>^F</i>   | <i>06</i>           | <i>Acknowledge</i>          |
| <i>NAK</i>   | <i>^U</i>   | <i>15</i>           | <i>Negative Acknowledge</i> |
| <i>XON</i>   | <i>^Q</i>   | <i>11</i>           | <i>Begin Transmission</i>   |
| <i>XOFF</i>  | <i>^S</i>   | <i>13</i>           | <i>Stop Transmission</i>    |

## Appendix G — Embedded Menus

In addition to **ESP-MP**, you can also use a communications menu such as Microsoft's HyperTerminal™ to establish communication with Microscan's embedded menus.<sup>1</sup>

1. With your host connected to the configuration port, set your host communications settings as follows: **9600**, **7**, **1**, and **Even**.
2. Set **Flow Control** to **None**.
3. Make the communications port selection. (Usually **COM 1** or **COM 2** for desktops and **COM 1** for laptops.)
4. Upon connection, send a **<D>** command to bring up the main menu.

```

MICROSCAN SYSTEMS, INC.
CONFIGURATION PROGRAM
MAIN MENU
35-338201-14
-----
TOPICS                DESCRIPTIONS
1) COMMUNICATIONS     HOST PROTOCOL AND HOST PORT.
2) OPERATIONS         TRIGGERING, TIMEOUTS, ETC.
3) CODE TYPES 1       CODE 39, PDF417, I 2 OF 5, UPC, CODE 128.
4) CODE TYPES 2       CODE 93, CODABAR, ETC.
5) GLOBAL CODE PARAMETERS MARGINS, SYMB.ID., BACKGROUND, AIAG, ETC.
6) SCANNER OUTPUT    BARCODE, BEEPER, RELAYS, OUTPUT MODES, ETC.
7) SCANNER SETUP     GAIN, SCAN SPEED, TRANSITION COUNT, ETC.
8) DIAGNOSTICS SETUP WARNING MESSAGES, OPERATION TIME, ETC.
-----
ESC = MAIN MENU OR EXIT  N = NEXT ITEM
M  = PREVIOUS MENU      SP = NEXT ITEM
B  = PREVIOUS ITEM      CR = THIS ITEM
-----
MAIN--> COMMUNICATIONS

```

Appendices

Menu navigation commands are case sensitive. Use the **space bar** or **N** to advance to the next item, **CR** (return key) to select a highlighted item, **B** to return to the previous item, **M** to return to the previous menu, and **ESC** to return to the Main menu or to exit the program. When exiting the program, you will be prompted to save your active settings for power up (**Y** or **N**). Typing **Y** will be equivalent to saving with a **<Z>** command.

1. If you are using Microsoft's HyperTerminal program, you may find that the initial screen is unviewable when you call up the program with the **<D>** command. If this occurs, simply exit the embedded menu with a **ESC**, **E**, and **N** sequence and repeat the **<D>** command.

## Appendix H — Defaulting/Saving/Initializing

**Defaults** are original or saved settings. **Defaulting** occurs when default settings (from flash or user-saved NOVRAM) are restored. Defaulting might be necessary if you have made temporary changes, communications between the scanner and another device are lost or interrupted, or you are using incompatible equipment (for example, a terminal that is set at 9600 baud communicating with a scanner that is set at 38.4K baud).

**Initializing** occurs whenever any command or set of commands is implemented.

**Active Memory** (SRAM) is where the scanner's active settings are stored during use. These are not available on power-up.

**User-saved NOVRAM** (*non-volatile random access memory*) is where the scanner's operating parameters are stored for power-on. It can be changed by user command.

**Flash Defaults** is where the scanner's default download/boot programs are stored. It can only be changed by downloading application/boot codes.<sup>1</sup>

### Defaulting

#### Restore NOVRAM Defaults to Active Memory

- Restores user-defined NOVRAM settings to active memory.
- Initializes serial configuration commands in active memory and resets counters to zero.

##### By Serial Command

Send **<An>** command to the scanner.

By ESP (There is no equivalent ESP command.)

#### Restore Flash Defaults to Active Memory

- Restores flash defaults to memory.
- Initializes serial configuration commands in active memory and resets counters to zero.
- Does not save settings to NOVRAM for power-on.



##### By Serial Command

Send **<Ad>** command to the scanner.

##### By ESP

- Right-click** in the configuration window and select **Default All ESP Settings**.
- Right-click** and select **Save to Scanner, Send and Save**.


1. See your Microscan sales representative to access the latest application codes.



## Restore Flash Defaults to Active Memory and for Power-on

**Caution:** Defaulting the scanner to flash default settings will overwrite user-saved NOVRAM settings.

- Restores flash defaults to memory.
- Restores flash defaults to user-saved NOVRAM for power-on.
- Initializes serial configuration commands in active memory and resets counters to zero.



### By Serial Command

Send **<Zd>** command to the scanner.

### By ESP

1. **Right-click** in the configuration window and select **Default All ESP Settings**.
2. **Right-click** and select **Save to Scanner, Send and Save**.

### By Hardware Default

If a software default reset is not possible, it may be necessary to reset the scanner by shorting (connecting) specific pins. This procedure has the same effect as the **<Zd>** software command.

1. Apply power to the scanner.
2. Locate pins or wires that have continuity to pins4 and8 on the back of the scanner (see [figure A-8 on page A-27](#)). If using an IB-131, locate pins 7 and 11 on the host connector (see [Table A-3 on page A-5](#)).

**Caution:** Be certain that the correct pins are located. Connecting the wrong pins could cause serious damage to the unit.

3. Momentarily connect these wires (or pins) and listen for a series of short beeps.
4. Within 3 seconds, connect them again. A longer beep should be heard. If not, repeat the process.

## Saving

### Save Active Settings except Factory for Power-on


- Initializes serial configuration commands in active memory and resets counters to zero.
- Saves all active settings except factory settings to NOVRAM for power-on.

#### By Software Command

Send **<Z>** command to the scanner.

#### By ESP

**Right-click** in the configuration window and select **Save to Scanner, Send and Save**.



### Save Active Settings including Factory for Power-on


- Initializes serial configuration commands in active memory and resets counters to zero.
- Saves all active settings including factory settings to NOVRAM for power-on (factory settings include but are not limited to **Focus, Gain, Tracking, and Scan Speed**).

#### By Serial Command

Send **<Zp>** command to the scanner.

#### By ESP

**Right-click** in the configuration window and select **Advanced, Send and Save, Including Factory**.



## Initializing

Initializing is a part of all save and default functions. It is also used as a follow-on to implement serial configuration commands into active memory.

- Initializes serial configuration commands in active memory and resets counters to zero.
- Does not save settings to NOVRAM.


### By Serial Command

Send **<A>** after a serial configuration command or a string of serial configuration commands, for example, **<Kd1><A>**.

### By ESP

**Right-click** in the configuration window and select **Save to Scanner, Send No Save**.

This will initialize all serial configuration changes that have been made in the current ESP session.



## Loss of Communications

Making changes to communications with the host such as **Baud Rate, Parity, Stop Bits, LRC**, etc. without corresponding changes in linked device(s) can result in the loss of menu access through. If this should occur, you should restore the scanner's defaults.

## Appendix I — Position Scanner and Bar Code

In positioning the scanner in relation to the bar codes being scanned, consider the following:

- Position the scanner in a place devoid of sunlight, bright lights, or laser light from other sources.
- Avoid excessive tilt, skew, or pitch. Maximum tilt is determined by label characteristics and the number of decodes required. Maximum skew is  $\pm 40^\circ$ ; maximum pitch is  $\pm 50^\circ$ .<sup>1</sup>
- Pitch or skew label or scanner a minimum of  $\pm 15^\circ$  to avoid specular reflection, the return of direct, non-diffused light.<sup>2</sup>




Figure A-6 Scanner/Symbol Position

1. Maximum tilt is determined by label characteristics and number of decodes required.  
2. The specular reflection zone is a narrow zone straight out from the scanner in which direct reflected light from a label can distort the scanner's ability to distinguish bars from spaces.

## Appendix J — Position Object Detector

In a typical operation, a scanner will wait for bar code data only during a triggered read cycle. A read cycle is initiated by a “trigger” and can be in the form of a serial command from the host (internal trigger) or a signal from an object detector (external trigger).

When an object detector (also called a sensor, package detector, etc.) is used, it is set up so that its beam will bounce off the approaching object and the resulting pulse will be sent to the scanner to begin the read cycle. Typically, a detector is positioned so that it will detect the presence of an object before its label can be scanned.

An object detector is mounted in almost any position relative to the object as long as (1) the object passes within range of the detector and (2) direct or reflected light from the detector does not interfere with the scanner’s reception.

As the item continues to move down the line, its label moves into the scanner beam and is read by the scanner.

The drawing below shows a label in the picket fence direction with the object detector positioned so as not to cause interference.




Figure A-7 Object Detector

## Appendix K — Test Decode Rate

### With a Static Label

1. Position a stationary bar code in front of a functioning scanner at the scan distance used in your application.

2. Enter a **<C>** command to see the decodes per second.

The decode rate is the number of decoded scans per total number of scan. It will appear at the beginning of the data strings.

**Note:** You can also enter a **<Cp>** command to see the percentage of decodes per scans.

3. Make a note of the decode rate. You will need this when calculating the number of decodes (see [Appendix L — “Formulas for Number of Decodes” on page A-27](#)).

4. End the test by sending the **<J>** command.

### Number of Decodes

To ensure reliable scanning, you need to apply a minimum of five decodes to each bar code. This means that all variables, label speed, read range, etc. are significant.

**Note:** Variations between labels are common. For this reason, the greater number of sample bar codes tested, the more likely you are to achieve optimum decode rates.

In general, the number of decodes of a given bar code can be increased by:

- Increasing label height
- Decreasing label length
- Increasing scan rate (spinning mirror speed)
- Slowing label speed

### With a Moving Label

Before testing with a moving label, it is highly recommended that you calculate the expected number of decodes by using the formulas in [Appendix L — “Formulas for Number of Decodes” on page A-27](#).

Once you’ve mounted the scanner, established a good read rate with a stationary label, and calculated the number of decodes for your label speed, you can begin decoding with moving labels.

## Appendix L — Formulas for Number of Decodes

To ensure reliable scanning, apply a minimum of *five* decodes to each bar code. Use the formulas below to calculate the number of decodes that your label will receive.

If the number of decodes you derive from one of these calculations is less than the minimum for your application, plug in the minimum number of decodes (5) and solve for another parameter that might be changed, such as label speed or scans per second.

**Note:** While the formulas given here solve for the predicted number of decodes, you may also use the formulas to solve for other parameters that might be changed, such as label speed, label length, etc.

### Single Line Ladder Calculation

For single scan line ladder scanning, use the following formula:

$$\left(\frac{LH}{LS} \times DR\right) - 3 = NS \text{ (number of decodes)}^1$$

**LH** (Label Height) (ladder formula only) is a measurement of the height of individual bars.

**LS** (Label Speed) is the distance per second that a bar code moves through the scan.

**DR** (Decode Rate) is the number of decodes per second that a given bar code receives (as derived from a stationary scan test in [Appendix K — "Test Decode Rate" on page A-26](#)).

Example 1:

LH = 1 inch

LS = 100 inches per second

DR = 900 scans per second

$$ND = \left(\frac{1}{100} \times 900\right) - 3 = 6 \text{ complete decodes}$$




Figure A-8 Ladder

1. The -3 component in the formula is included to allow for AGC acquisition, an incomplete first scan, and an incomplete last scan. This applies only if the number inside the parentheses equals 4 or more. If the number equals 3, then only subtract 2 to derive 1 good scan.

## Single Scan Line Picket Fence Calculation

For single scan line picket fence scanning use the following formula:

$$\left( \frac{(SW - LL)}{LS} \times DR \right) - 3 = \text{number of complete decodes}^1$$

**Example:**

LL = 2 inches (including quiet zones)

LS = 100 inches per second

SW = 4 inches

DR = 1000 decodes per second

$$\left( \frac{(4 - 2)}{100} \times 1000 \right) - 3 = 17 \text{ complete decodes}$$




Figure A-9 Picket Fence

## Angled Picket Fence Calculation

The number of complete scans for angled picket fence is calculated the same as that for picket fence, with the exception that the scan width is shortened in proportion to scan tilt.




Figure A-10 Angled Picket Fence

## Improving the Number of Decodes

After changing any of the parameters described in this section, recalculate the number of decodes.

### Scan Rate

Scan rate is a function of motor speed and is adjustable. A slower scan rate may allow greater label range and/or higher decode rates, but at the cost of fewer scans per label.

### Range

Adjusting the label's range, if possible, is one of the quickest and most effective ways to improve decode rates. However, in some applications you may need to select a less than optimum range, or one that is beyond the fringes of the ranges.

### Scan Width

Increasing scan width will increase the number of scans in a picket fence oriented application. Scan width is linked with scan range and changing one will usually require a change in the other.

***Label Speed***

Applies to both picket fence and ladder oriented labels. If your application allows it, slowing label speed (the time in seconds that a label is fully within the scan width of the scanner) is an effective way to increase the number of decodes.

***Label Dimensions, Label Density, and Label Ratio***

Not usually an option in most applications, but changes to label parameters can affect number of decodes calculations and possibly decode rates.

If your application allows it, shortening the length of a picket fence label means the label will be in the scan range longer and hence receive a greater number of scans. Increasing the height of a ladder label means it will receive more scans. Changing label density and/or bar code ratio is another way ranges, decode rates, etc. can be altered.

***Gain and Tracking***

These adjustments, typically made by qualified technicians, are referenced in the Scanner Setup menu (see ["Save Active Settings including Factory for Power-on" on page A-22](#)). Changes to tracking will generally have a limited affect on decode rates.

## Appendix M — Operational Tips

### Do:

- Check inputs (label speed, length, height, etc.) to ensure the desired number of decodes per label.
- For optimum decodes, mount scanner so that your labels pass through the center of the depth-of-field (minimum/maximum range). You find the center by moving your label in and out during a read rate test.
- Avoid excessive tilt, pitch, and skew of the bar code label.
- Check the bar code label for readability by doing a decode rate test. If there is any question about the label's readability, contact your Microscan representative at [helpdesk@microscan.com](mailto:helpdesk@microscan.com).
- After changing any parameter that might affect decode rate, repeat decode rate test.
- Clean the scanner window with a clean, dry Q-tip or cotton cloth on a regular basis.

### Do Not:

- Aim the scanner into direct light or sunlight.
- Aim the scanner into an external object detector or other light-emitting device.
- Obstruct the scanner window with mounting hardware or other objects.
- Connect chassis of scanner and host to different ground potentials.
- Operate the scanner in excessive temperature environments.

## Appendix N — Interface Standards

Interface Standards, established by the Electronic Industries Association (EIA), specify such things as the signaling voltage levels, maximum cable lengths, and number of drivers. With Microscan devices, selection of interface is made by pin assignment and, in the case of the host communications, by software switching between RS-232 and RS-422. Microscan devices use RS-232, RS-422, and RS-485 multidrop.

### RS-232

RS-232 defines an interface between two devices such as, for example, the scanner and host. It differs from the other interfaces by dedicating individual pins to specific functions and by requiring both devices to share a common ground line. Since both device chassis are connected to a common ground, a ground loop potential and the possibility of noise interference exists. Therefore cable lengths are limited to a maximum of 50 feet (19.7m). Despite being the most limited, this interface is used frequently because of the large installed base of RS-232 equipment.

### RS-422

RS-422, unlike RS-232, measures signals differentially; that is, the receiver looks at the potentials between the two receive (or transmit) wires rather than the potential between signal and ground. As a result, cables, if shielded, can be up to 4000 feet (1219m) in length. Like RS-232, RS-422 communication is designed for only two devices on a single line and must have a common ground. It can be used wherever RS-232 is used.


### RS-485

RS-485, like RS-422, can transmit up to 4000 feet (1219 m) using differential voltages but unlike RS-422, its transmitters are turned off until a request for data is received from the host. RS-485 is used exclusively in multidrop protocol.

## Appendix O — Multidrop Communications

This appendix describes the rules for setting up a concentrator or controller to communicate with a scanner in standard Multidrop protocol.

The diagram to the right shows a typical Multidrop network in which 1 to 50 scanners can communicate with a host via an intermediary device, a concentrator or a controller.



### Configure Your Scanner for Multidrop

1. With the scanner connected to the host, do **Retrieve Scanner Settings** as in [Step 5 —“Retrieve Scanner Settings” on page 2-6](#).


2. Select **Multidrop** in the **Protocol** configuration menu.

You will see the following message:

**Warning.** You must change your preamble and postamble characters so that they are not CR or NULL.

This allows data to move through the concentrator without interference.

3. Click **OK**.
4. Next, go to **Preamble Characters** (still in the **Protocol** menu) and double-click on **Characters**.
5. This will open up an ASCII character table. Select any character other than **CR**. For example, select **LF**.
6. Repeat the above for **Postamble**.
7. Check the multidrop address. Enter a number from **01** to **50**.
8. Right-click in the window and select **Save to Scanner** and **Send and Save**.
9. Your scanner is now in multidrop. From here on, you will need to use the concentrator to relay commands and data between the scanner or scanners and the host.
10. Next, go to [“Connect to Scanner via the Concentrator” on page A-33](#).



## Connect to Scanner via the Concentrator

You will need a multidrop concentrator and the required power supplies and cabling to communicate with your scanner(s).

1. From the **Communications** drop down menu, select **Configure Multidrop** to bring up the **Multidrop Settings** dialog.
2. If necessary, change the default address to match the address of your multidropped scanner and click **OK**.

If the host serial port is not connected in ESP, you will see the following popup message:

*ESP is not currently connected to the multidrop concentrator. Do you wish to establish a connection now?*

3. Click **Yes**.

You will see a **Serial Communication Parameters** dialog as shown on the next page.

Notice that the **Force Connection** option is checked. Do not change this.

4. Select the concentrator's host port communications settings.

When you click **Connect**, you will be connecting to your concentrator, which can then relay commands to the scanner whose address was set in the **Multidrop Settings** dialog.

5. Click **Connect**.



6. You should see the **CONNECTED** message in green at the bottom of the window along with the scanner's **Multidrop** address.



7. Do **Retrieve Scanner Settings** to upload scanner's configuration (**Step 5**). If upload fails, return to the **Serial Communication Parameters** dialog and make the corrections.

8. Follow the same procedure for connecting other scanners to your multidrop network.

**Note:** For more information, see your scanner user's manual or Microscan's **MS-5000 Multidrop Concentrator User's Manual, 83-005000**.



## Polling Sequence

Data that is transmitted to the host (bar code data, noread messages, counters, etc.) via concentrators is solicited by poll requests from the host.

The polling sequence example by poll address 1E (ASCII hex value for Scanner 02) and a REQ (request). The scanner responds by first transmitting its own address, 1E, followed by a STX (start of text) character, and then the data. Next it transmits an ETX (end of text) character and an LRC (longitudinal redundancy check) character.

If the concentrator (or controller) receives the data from the scanner and is able to validate it with an LRC calculation, it responds with an ACK (acknowledgment). If the scanner in turn receives the ACK, the scanner ends this exchange with a RES (reset).




Figure A-11 Polling Sequence

### Polling Reset

- If the scanner has no information, it responds to a poll request by transmitting a RES (reset).
- If the scanner receives a NAK instead of the ACK after transmitting its data string, it will re-attempt to send the data string up to three times. If the scanner still does not receive an ACK, it will send a RES (reset) and discard the data in its buffers.
- If the scanner transmits data to the concentrator and the concentrator responds with an ACK or NAK, but the scanner doesn't receive the concentrator's response, the scanner will timeout and send a REQ to the concentrator and request another response. If after three retries (the number of times it transmits a REQ to the concentrator) the scanner receives no response, it ends the transmission with a RES (reset).

### Select Sequence

Unlike poll requests, select commands always originate from the host and consist of serial configuration or operation commands to devices that are configured in Multi-drop. The scanner complies with the command when it is polled during the cycle.




Figure A-12 Polling Sequence

A RES (reset) is the first command in the select sequence. The 1F hex is the select address associated with Scanner 02 address. It is followed by a REQ (request). The scanner responds with its own select address, 1F hex, and an ACK (acknowledge). The concentrator then transmits an STX (start of text), the data (in this case a <T>), an ETX (end of text), and an LRC character.

The scanner replies by transmitting its own address, followed by an ACK, acknowledging receipt of the command. Upon receipt of an ACK, the concentrator concludes the successful exchange with a RES.

In the example above, the scanner only acknowledges a trigger counter request from the concentrator. It does not respond to the trigger counter request until a subsequent poll. For example, if the scanner's trigger count was 12 at the time the trigger counter request was received, on a subsequent poll it would send 02T/00012. (The 02 at the beginning of the string is the scanner's address.)

#### Select Reset

If the scanner receives bad data from the concentrator, it transmits a SEL (its select address) and a NAK to the concentrator. The concentrator re-transmits the data up to three times. The concentrator will end the sequence with a RES (reset) if no ACK is received.

Table A-12 Multidrop Addresses

| Multidrop Address | Poll Character |     | Select Character |     | Multidrop Address | Poll Character |     | Select Character |     |
|-------------------|----------------|-----|------------------|-----|-------------------|----------------|-----|------------------|-----|
|                   | ASCII          | HEX | ASCII            | HEX |                   | ASCII          | HEX | ASCII            | HEX |
| 01                | ^\             | 1C  | ^]               | 1D  | 26                | N              | 4E  | O                | 4F  |
| 02                | ^^             | 1E  | ^-               | 1F  | 27                | P              | 50  | Q                | 51  |
| 03                | SP             | 20  | !                | 21  | 28                | R              | 52  | S                | 53  |
| 04                | "              | 22  | #                | 23  | 29                | T              | 54  | U                | 55  |
| 05                | \$             | 24  | %                | 25  | 30                | V              | 56  | W                | 57  |
| 06                | &              | 26  | '                | 27  | 31                | X              | 58  | Y                | 59  |
| 07                | (              | 28  | )                | 29  | 32                | Z              | 5A  | [                | 5B  |
| 08                | *              | 2A  | +                | 2B  | 33                | \              | 5C  | ]                | 5D  |
| 09                | ,              | 2C  | -                | 2D  | 34                | ^              | 5E  | _                | 5F  |
| 10                | .              | 2E  | /                | 2F  | 35                | `              | 60  | a                | 61  |
| 11                | 0              | 30  | 1                | 31  | 36                | b              | 62  | c                | 63  |
| 12                | 2              | 32  | 3                | 33  | 37                | d              | 64  | e                | 65  |
| 13                | 4              | 34  | 5                | 35  | 38                | f              | 66  | g                | 67  |
| 14                | 6              | 36  | 7                | 37  | 39                | h              | 68  | i                | 69  |
| 15                | 8              | 38  | 9                | 39  | 40                | j              | 6A  | k                | 6B  |
| 16                | :              | 3A  | ;                | 3B  | 41                | l              | 6C  | m                | 6D  |
| 17                | <              | 3C  | =                | 3D  | 42                | n              | 6E  | o                | 6F  |
| 18                | >              | 3E  | ?                | 3F  | 43                | p              | 70  | q                | 71  |
| 19                | @              | 40  | A                | 41  | 44                | r              | 72  | s                | 73  |
| 20                | B              | 42  | C                | 43  | 45                | t              | 74  | u                | 75  |
| 21                | D              | 44  | E                | 45  | 46                | v              | 76  | w                | 77  |
| 22                | F              | 46  | G                | 47  | 47                | x              | 78  | y                | 79  |
| 23                | H              | 48  | I                | 49  | 48                | z              | 7A  | {                | 7B  |
| 24                | J              | 4A  | K                | 4B  | 49                |                | 7C  | }                | 7D  |
| 25                | L              | 4C  | M                | 4D  | 50                | ~              | 7E  | D                | 7F  |

Appendices

## Appendix P — Glossary of Terms

**Active On ( $I_{ON}$ ).** An optoisolated input that's logically "on" when current flows through the connection points.

**Active Off ( $I_{OFF}$ ).** An optoisolated input that's logically "on" when *no* current flows through the connection points.

**Analog Gain Adjustment (AGC).** Adjustment to signal strength that seeks to maintain a constant level regardless of the range of the bar code label.

**Application Record.** A variation of UCC/EAN-128 which adds an application identifier to label data, including user-definable separators, brackets, and padding.

**Autocalibration.** A routine that cycles through various optical settings and selects the combination that produce the best read rate.

**Autodiscriminate.** The ability to decode several different bar code symbologies without changing configuration.

**Auto Range.** Outward focus of the scanner until an object is sensed by signal strength. The scanner then begins searching for a decodable label.

**Auxiliary Port.** RS-232 connections to an auxiliary terminal or device for remote viewing, the transfer of data to and from the host, and under certain conditions a configuration port.

**Bar Code.** The symbol used for recognition by a bar code scanner. An array of parallel bars and spaces of varying widths that conform to recognized standards and can be decoded and displayed as serial data.

**Bar Code Data.** The information that is transmitted from a decoded bar code symbol.

**Bar Code Label.** The physical media on which a bar code symbol is presented.

**Bar Code Density.** Number of characters per inch or other unit of measure.

**Baud Rate.** The number of discrete signal events per second. Bits per second.

**Capture.** The act of grabbing or recording a frame by an sensor. A frame or succession of frames that are captured.

**Channel.** A high-speed pathway between the computer and the control units of the peripheral devices.

**Check Digit.** A Modulus 43 or Modulus 10 digit that is added to the bar code message for additional data integrity.

**Command Processing.** Allows the user to enter the ESP program from the auxiliary port or send serial string commands from the auxiliary port.

**Configuration.** A setup or process of changing a scanner's settings to conform to a specific application.

**Concentrator.** Intermediary device that relays data from scanners to a host and commands from the host to the scanner or other devices.

**Connector.** Physical device (plug or socket) on a device or cable to provide in/out connectivity for various circuits and pins.

**Counter.** Memory space provided to keep track of scanner events.

**Daisy Chain.** Linkage of master and slave scanners to allow data to be relayed up to the host via auxiliary port connections.

**Decode.** A good read. The successful scanning and decoding of the information encoded in a bar code label.

**Default.** Restores ROM or Flash settings, initializes serial commands and resets all counters.

**Delimited.** A command or field that is bracketed by pre-defined characters.

**Decode Rate.** The number of good reads per second decoded by the scanner.

**Depth of Field.** The distance between the minimum and maximum range in which a scanner can read bar code labels.

**Discrete I/O.** Inputs and outputs characterized by discrete signal transitions from one voltage level to another so that digital switching can occur.

**EPROM.** Erasable, programmable, read only memory.

**Embedded Memory.** Onboard memory device such as EPROM or flash.

**End of Read Cycle.** The time or condition at which the scanner stops expecting label information to decode.

**External Edge.** Allows a read cycle to be initiated by a trigger signal from an object detector when it detects the appearance of an object (rising edge). The read cycle ends with a good read, a timeout, or a new trigger.

**External Level.** Allows a read cycle to be initiated by a trigger signal from an object detector. The read cycle ends when the object moves out of the detector's range.

**Falling Edge.** A change of state (to inactive) associated with a level trigger in which the scanner stops searching for bar code symbols. (See **Rising Edge**.)

**Fixed Code Length.** Increases data integrity by ensuring that only one label length will be accepted.

**Flash Memory.** Memory that can be changed by downloading new code.

**Focal Length.** The distance measured from the scanner to the center of the depth of field, or *focal* point.

**Focus.** The point at which the tip of the scan beam is at its narrowest.

**Frame.** The total area scanned in an image sensor.

**Full Duplex.** Auxiliary port data is sent directly to the host but not displayed on the auxiliary port screen.

**Gain.** Optimal signal strength.

**Good Read.** A decode. The successful scanning and decoding of the information encoded in a bar code label.

**Half Duplex.** Auxiliary port data is sent directly to the host and displayed on the auxiliary port screen.

- Host.** A computer, PLC, or other device that is used to execute commands and process data and discrete signals.
- Host Port.** The pins or connections on a scanner or other device that physically connect with a host and—using the RS-232, RS-422, or RS-485 standards—pass data and serial commands from one device to another.
- Initialize.** Implement serial configuration commands into the scanner's active memory.
- Input.** A channel or communications line. Decoded data or a discrete signal that is received by a device. See **Output**.
- Intercharacter Delay.** The time interval in milliseconds between individual characters transmitted from the scanner to the host.
- Intercharacter Gap.** The extra space between the last element of one character and the first element of the adjacent character of a specific bar code symbol.
- IrDA.** Infrared Data Association which promotes interoperable, infrared data interconnection standards.
- Label Height.** Regardless of orientation, the measurement taken along the length of a label's individual bars.
- Label Length.** Regardless of orientation, the measurement taken across the label's bars from one end to the other, including the quiet zone.
- Label Speed (LS)** is the distance per second that a label moves as it travels through the scan lines.
- Label Transitions.** The transition of bars and spaces on a label, used to detect the presence of a label on an object.
- Ladder Label Orientation.** A bar code label in which the bars are parallel to the label's direction of travel.
- Large Intercharacter Gap.** Allows the scanner to read symbols with gaps between bar code characters that exceed three times (3x) the narrow element width.
- Laser Framing.** Setting scan width size by adjusting the on/off duration of the laser beam.
- Laser On/Off.** When enabled, the laser is ON only during the read cycle, provided the scanner is enabled for a Serial or External trigger.
- LED.** Light emitting diode.
- Longitudinal Redundancy Check (LRC).** An error-checking routine that verifies the accuracy of transmissions.
- Master Scanner.** First scanner in a daisy chain mode and linked directly to the host and in tandem to slave scanners.
- Matchcode.** The ability to compare bar code labels being scanned against a master label that is stored in the memory of the scanner.
- Embedded Menu.** Configuration options embedded in the scanner's erasable memory.
- ESP-MP Menu.** Easy Setup Program—Multiple Platform. Configuration program that runs in Windows-based operating systems 95 and above.

**Mil.** One thousandths of an inch or 0.0254 mm. In bar-coding, a measurement standard that identifies a bar code label by the width of its narrowest element.

**Mismatch.** An event that occurs when the scanned bar code label does not match the master label that is stored in the memory of the scanner.

**Multilabel.** A scanner mode which allows a scanner to read more than one bar code label in a single read cycle.

**Multidrop.** A communications protocol for networking two or more scanners or other devices with a concentrator (or controller) and characterized by the use of individual device addresses and the RS-485 standard.

**Narrow-bar-width.** The width of the narrowest bar of a given label, expressed in thousands of an inch (or mils).

**Narrow Margins.** Allows the scanner to read symbols with quiet zones less than 8 times the width of the narrow bar element.

**Non-delimited.** A command that is not bracketed by pre-defined characters.

**Non-volatile RAM (NOVRAM).** Random Access Memory that is available on power-on; that is, after power to the unit has been recycled.

**Noread.** A non-read. A condition that occurs when the scanner is set up to decode labels but no label is scanned during the read cycle.

**Normally Closed.** A discrete output state that is only active when open.

**Normally Open.** A discrete output state that is only active when closed.

**NOVRAM.** Non-volatile random access memory. Data that is saved for "power-on" is saved to NOVRAM.

**Number of Decodes.** The number of times a bar code label is scanned by the scanner during one pass through the laser beam.

**Object Detector.** A photo electric device used to sense the presence or absence of an object (also referred to as a package detector).

**Output.** A channel or communications line. Data or discrete signals that are transmitted or displayed by a device.

**Output Format.** The modification of data output according to a user-defined index of **Extraction** and **Insertion** commands.

**Parity.** An error detection routine in which one data bit in each character is set to 1 or 0 (zero) so that the total number of 1 bits in the data field is even or odd.

**Picket Fence Label Orientation.** A bar code label in which the bars are perpendicular to the label's direction of travel.

**Pitch.** Label (or scanner) rotation around the center of a line perpendicular to the label's bars.

**Point-to-Point.** A protocol consisting of a single communications event, typically used to connect a bar code scanner to a terminal or host computer.

**Port.** Logical circuit for data entry and exit. (One or more ports may be included within a single connector.)

**Protocol.** The rules for communication between devices, providing a means to control the orderly flow of information between linked devices.

**Quiet Zones.** Specified "clear" (non printed) areas immediately before and after the bar code symbol. The area is usually white (for black and white bar code) and at least 10 times the width of the narrowest bar, as measured in thousands of an inch. The zones can be other than white as long as their densities remain consistent and they have the required contrast relative to the bars.

**RAM.** (Random Access Memory) Memory that is lost after power is recycled to the unit.

**Raster.** Multiple, stacked scans produced by a separate oscillating mirror or by a spinning mirror with varying facet angles.

**Read Cycle.** A programmed period of time or condition during which the scanner will accept bar code label input.

**Read Range.** The distances in which a label can be reliably read, as measured from the front of the scanner. See "Depth of Field."

**Relay.** An electrical switch that allows a low power to control a higher one.

**Reset.** Sets all counters to zero.

**Rising Edge.** A change of state (to active) that initiates (and in some cases ends) a read cycle with a new trigger, an edge trigger, or the leading edge of a level trigger. (See **Falling Edge.**)

**ROM.** (Read Only Memory) Memory that cannot be changed.

**Scanner.** A scanning device that is comprised of a scan head and a decoder integrated in one package.

**Scan Rate (SR)** The number of decodes per second that a given scanner is capable of casting.

**Scan Width (SW)** is the width across the scan beam at a given distance from the scanner in which a label can be read.

**Send.** Transmit data from one device to another.

**Separator.** A character that separates data fields.

**Serial Commands.** Online data strings such as <D> or <P> sent from a host or auxiliary terminal to a scanner or other device.

**Serial Configuration (Host Configuration).** Serial command specifically for changing configuration and distinguished from operational command by the fact that they modify the non-volatile for power up configuration.

**Skew.** Label (or scanner) rotation around the center of the skew axis.

**Slave Scanner.** Linked to the master or preceding scanner in a daisy chain and relays bar code data to the host. See "Daisy Chain."

**Specular Reflection Zone.** The narrow zone straight out from the scanner in which direct reflected light from a label can distort the scanner's ability to distinguish bars from spaces.

**Supplemental.** A character or data string that is appended to the main bar code symbol.

---

## Appendix P

**Symbol.** A bar code. A decodable unit of information that is recognized by a bar code scanner.

**Symbology.** A code type, such as Code 39 or Code 128, with special rules to define the widths and positions of bars and spaces to represent specific numeric or alphanumeric information.

**Symbology ID.** An AIM standard prefix character that identifies the bar code type.

**Tilt.** Label (or scanner) rotation around the centerline of the scan beam.

**Timeout.** A user-selected period of time that ends a scanner's read cycle.

**Tracking.** Adjustment of the precision of analog-to-digital conversion.

**Transmission.** The transfer of data over a communications channel.

**Transmit.** Send or convey signals or information from one device to another.

**Transparent.** Data is passed between the auxiliary port and the host with keyed data echoed to the auxiliary port

**Trigger.** A signal, transition, or character string that initiates a read cycle.

**Watchdog Timer.** A security device that detects system crashes and attempts to reset the scanner.

**Watchdog Reset.** A reset that is forced whenever the software locks up.

**Wild Card.** User-defined character entered into a master label to permit matches with variable characters.

# Index

## A

- About This Manual i-ix
- Active State, discrete outputs 9-5
- AGC Gain Adjustment 6-7
- AGC Mode 6-7
- AGC Sampling 6-9
- AGC Transition Sample Rate Threshold 6-9
- AGC Transitions Sample Counter 6-9
- Application Record Brackets, EAN-128 5-22
- Application Record Padding, EAN-128 5-23
- Application Record Separator, EAN-128 5-22
- Application Record, EAN-128 5-21
- Approvals i-xi
- As Soon As Possible 8-5
- ASCII Table, including control characters A-14
- Auto Connect 1-7
- Autodiscrimination, Code Types 5-27
- Aux Port 2-5
- Auxiliary Port Parameters 2-5

## B

- Background Color 5-7
- Bar Code Symbolologies A-3
- Baud Rate
  - aux port 2-11
  - host port 2-4
- Beeper Status 8-12
- BSMI i-xi

## C

- Caution Summary i-xiii
- CDRH i-xi
- CE Compliance i-xi
- Check Digit
  - Codabar 5-13
  - Code 39 5-8
  - 1 2 of 5 5-14
- Code 39 5-8

- Code 93 5-24
- Code Length
  - 1 2 of 5 5-15
- Code Types
  - by embedded menu 5-4
  - by ESP 5-2
  - by serial command 5-3
- COM1 1-6
- Communication Protocol Commands A-15
- Communications
  - by Embedded Menu 2-3
  - by ESP 2-2
  - by serial command 2-2
- Communications Port 1-6
- Communications, loss of A-20
- Communications, Specifications A-3
- Continuous 6-7
- Continuous Read 1-11, 4-4
- Continuous Read 1 Output 4-5
- Control Characters A-13
- Control/Hex Output 8-14
- Counters 11-6
- Counts 10-13
- cUL i-xi

## D

- Daisy Chain ID 2-12
- Daisy Chain Mode 2-9
- Daisy Chain, IB-131 A-9
- Data Bits
  - aux port 2-11
  - host port 2-4
- Decode Rate A-23, A-24
- Decodes/Second Test 11-10
- Default Commands A-17
- Default Flash Defaults to Active Memory and for Power-on A-18
- Default NOVRAM Defaults to Active Memory A-17

Index

## Index

Defaulting/Saving/Initializing A-17  
Device Control 11-12  
DFALT-C 10-7  
DFALT-F 10-7  
Diagnostics  
    by embedded menu 10-3  
    by ESP Menu 10-2  
    by serial command 10-2  
Disclaimer i-ii  
Discrete I/O  
    by Embedded Menus 9-2  
    by ESP Menu 9-2  
    by serial command 9-2

## E

EAN-128 5-21  
Easy Setup Program i-ix  
Easy Setup Program - Multiple Platform 1-4  
Electrical Specifications A-5  
Electrical, IB-131 A-8  
Emissions, Specifications A-2  
End of Read Cycle 4-11, 8-6  
End Read Rate Test 11-11  
Enter Master Label Data 5-26, 7-11  
Environmental, Specifications A-2  
ESP (Easy Setup Program) i-ix  
External Trigger 4-10  
External Trigger Edge 4-7, 4-8  
External Trigger Level 4-6

## F

FCC i-xi  
File Transfer 11-5  
Fixed Code Length  
    Codabar 5-12  
    Code 128 5-20  
    Code 39 5-9  
    Code 93 5-24  
    PDF417 5-19  
Flash memory i-ix  
Focus 6-4  
Formulas for Number of Decodes A-24  
From Host 3-7

Full ASCII Set 5-10  
Full Duplex Mode 2-8

## G

Gain 6-6, A-26  
General Specifications A-2  
Glossary of Terms A-32  
Good Decode Reads 4-9  
Good Read/Match Counter 11-7  
Good Read/Match Counter Reset 11-7

## H

Half Duplex Mode 2-7  
Hardware Required 1-2  
Hex Output 8-14  
High Temperature Threshold 10-8  
Host Commands i-x  
Host Connector (25-pin) A-7  
Host Connector, 25-pin A-5  
Host Port Parameters 2-4  
Hours Threshold 10-10

## I

IB-131 Interface Module A-7  
Immunity A-2  
Initializing (resetting) Commands A-20  
Install ESP-MP 1-4  
Intercharacter Delay 3-11  
Interface A-3  
Interface Standards A-28  
Interleaved 2 of 5 5-14  
IrDA Port 2-12

## K

K Commands A-12  
Keystrokes i-x

## L

Label Density A-26  
Label Dimensions A-26  
Label Height A-24  
Label Ratio A-26

Label Speed A-24, A-26  
Ladder Calculation, single line A-24  
Large Intercharacter Gap 5-9  
    Codabar 5-12  
laser beam i-xiii  
Laser High Message 10-5  
Laser High Warning 10-5  
Laser Light, Specifications A-2  
Laser Low Message 10-6  
Laser Low Warning 10-6  
Laser Scanning 11-12  
Laser Scanning, disable 11-12  
Leading Edge 6-7  
Lifetime Hours 10-10  
Lifetime Threshold 10-10  
Longitudinal Redundancy Check 3-9  
Low Temperature Threshold 10-9  
LRC 3-9

## **M**

Master Label  
    by ESP 7-10  
Master Label Data  
    Delete 7-13  
    Enter 5-26, 7-11  
    Request 7-12  
    Request All 7-12  
    Store Next Label Scanned 7-14  
Master Label Database 7-10  
Master Label Database Size 7-10  
Match Counter 11-7  
Match Length 7-7  
Match Start Position 7-6  
Match, discrete outputs 9-4  
Matchcode  
    by Embedded Menu 7-3  
    by ESP 7-2  
    by serial command 7-2  
Matchcode Setup 7-5  
Menu Mode 2-12  
Mirror Type A-3  
Mismatch Counter 11-7  
Mismatch Counter Reset 11-7

Mismatch or Noread, discrete outputs 9-4  
Mismatch, discrete outputs 9-4  
Model Selection 1-5  
Motor Off 11-12  
Motor On 11-12  
Multidrop 3-6  
Multidrop Addresses A-31  
Multidrop Communications A-29  
Multidrop, IB-131 A-9  
Multilabel 4-14  
Multilabel Decode Rate Test 11-10  
Multilabel Percent Test 11-10  
Multilabel Separator 4-15

## **N**

Network Connector (25-pin) A-7  
New Master Pin 7-15  
New Trigger 4-13  
Noise Interference A-28  
Noread Counter 11-6  
Noread Counter Reset 11-6  
Noread Message 8-8  
Noread, discrete outputs 9-4  
NOVRAM Reset Warning Status 10-7  
NOVRAM/Default Warnings 10-4  
Null Modem Cable 1-2  
NULs, defining A-13  
Number of Decodes A-23  
Number of Labels 4-15  
Number to Output On 9-5  
NVRAM-C 10-7  
NVRAM-D 10-7

## **O**

Object Detector A-22  
Operating Life A-2  
Operating Temperature 10-8  
Operational Serial Commands 11-3  
Operational Tips A-27  
Output 1 9-4  
Output 2 9-6  
Output 3 9-6  
Output Data

## Index

- by Embedded Menu 8-3
- by ESP Menu 8-2
- by serial command 8-3
- Output Data Format 3-12
- Output Format, EAN-128 5-21
- Output On, discrete outputs 9-4
- Output-1 11-12
- Output-2 11-13
- Output-3 11-13

**P**

- Package detector A-22
- Padding 5-23
- Parity
  - aux port 2-11
  - host port 2-4
- Part Number 11-8
- Partial Length 8-10
- PDF Information 11-11
- PDF417 5-19
- Percent PDF Read Rate Test 11-11
- Percent Test 11-10
- Picket Fence Calculation
  - Angled A-25
  - Single Scan Line A-25
- Pitch A-21
- Point-to-Point
  - standard 3-4
  - with RTS/CTS 3-5
  - with RTS/CTS & XON/XOFF 3-5
  - with XON/XOFF 3-5
- Polling Mode D 3-5
- Polling Sequence A-29
- Position Scanner and Symbol A-21
- Postamble 3-13
- Power Connector (3-pin) A-7
- Power Supply 1-2, 1-3
- Powerups 10-13
- Preamble Status 3-12
- Present Operating Temperature 10-12
- Program Values 1-8
- Protocol 3-4
  - by embedded menu 3-3

- by ESP 3-2
- by Serial Command 3-2
- Protocol Commands A-15
- Pulse Width, discrete outputs 9-5

**R**

- Range 1-11, A-25
- Raster Mirror A-3
- Raster Sweeps Before Decode Attempt, PDF417 5-19
- Read Cycle 4-11
  - by ESP 4-2
- Read Cycle/Trigger
  - by embedded menu 4-3
  - by serial command 4-2
- Read Rate 11-9, 11-10
- Reset A-20
- Reset Flash Defaults to Active Memory A-17
- Resets 10-13
- Response Timeout 3-10
- Restore Commands A-17
- Restore Flash Defaults to Active Memory A-17
- Restore Flash Defaults to Active Memory and for Power-on A-18
- Restore NOVRAM Defaults to Active Memory A-17
- Retrieve as Program 1-8
- Retrieve Scanner Settings 1-8
- Retrieve Settings 1-8
- RS-232 A-28
- RS-422 A-28
- RS-485 A-28

**S**

- Safety Certifications A-4
- Safety Class A-2
- Safety Labels i-xii
- Save Active Settings except Factory for Power-on A-19
- Save Active Settings including Factory for Power-on A-19
- Save Commands A-17

- Scan Range 1-11
- Scan Rate A-3, A-25
- Scan Width A-25
- Scanner Connector (15-pin) A-7
- Scanner Range
  - Range 1-10
- Scanner Setup
  - by Embedded Menu 6-3
  - by ESP 6-2
  - by serial command 6-2
- Scanner Values 1-8
- Scanning Parameters A-3
- Select Sequence A-30
- Sensor A-22
- Separator
  - EAN-128 5-22
  - UPC/EAN 5-18
- Sequence On Every Mismatch 7-9
- Sequence On Noread 7-8
- Sequential Direction 7-6
- Serial Command Beep 8-13
- Serial Command Echo 8-13
- Serial Command Format A-12
- Serial Command Status Request A-13
- Serial Commands
  - Code Types 5-3
  - Diagnostics 10-2
  - Matchcode 7-2
  - Output Data 8-3
  - Read Cycle-Trigger Mode 4-2
  - Utilities 11-3
- Serial Commands, concatenating A-13
- Serial Configuration Commands A-12
- Serial Configuration Commands, summary A-10
- Serial Data 4-8
- Serial Utility Commands A-12
- Serial Verification 8-13
- Skew A-21
- Special Characters in Embedded Menus A-13
- Special Characters in Serial Commands A-13
- Specular reflection A-21
- Stand Alone, IB-131 A-8
- Stop Bits
  - aux port 2-12
  - host port 2-4
- Supplementals 5-17
- Supplementals Type 5-18
- Symbology ID 5-6

**T**

- Test Range 1-11
- Tilt A-21
- Time Since Last Reset 10-11
- Timeout
  - read cycle 4-12
- Timeout Duration, Read Cycle 4-13
- Timeout or New Trigger 4-13
- Tracking A-26
- Transition Counter 6-9
- Transition Sample Counter 6-9
- Transition Sample Rate Threshold 6-9
- Transparent Mode 2-6
- Trigger Connector (4-pin) A-7
- Trigger Counter 11-6
- Trigger Counter Reset 11-6
- Trigger Filter Duration 4-9
- Trigger Mode 4-4
- TüV i-xi

**U**

- UCC/EAN-128 5-21
- UL i-xi
- UPC/EAN 5-16
- User Defined Multidrop 3-8
- User Defined Point-to-Point 3-6
- Utilities
  - by ESP 11-2
  - by serial command 11-3
- Utility Commands A-12
- Utility Serial Commands, summary 11-3

**W**

- Warning Message Status 10-4
- Warning Messages, diagnostics 10-4
- Warning Summary i-xii

## ***Index***

When to Output Bar Code Data 8-5

Wild Card Character 7-7

Windows NT i-ix

## **Z**

Zero Position 6-4