

Contents

Warranty Statement

One-Year Limited Warranty	i
Exclusions	i
Obtaining Warranty Service	i
Warranty Limitations	ii
Exclusive Remedies	ii
Obtaining Service or Customer Support:	ii
Before you call for service... ..	iii
Symbol Support Center	iv

Chapter 1. User's Guide

Scanning Made Easy	1-1
Set Up	1-2
Unpacking	1-2
Accessories	1-2
Software Companies	1-3
Connecting Your Scanner	1-4
LS 2080 Configuration: IBM AT/XT:	1-5
LS 2080 Configuration: IBM PS/2 & COMPAQ 386:	1-5
External Power Connection	1-6
Internal Power Connection	1-6
Ready, Test, Scan, Program	1-9
Aiming	1-10
Problems	1-10
Beeper Definitions	1-10
What If... ..	1-11
Maintenance	1-11
Technical Specifications	1-12
Scanner Labeling - Class 2	1-14
Scanner Labeling - Class 1	1-15
Gas Tank Operation (Europe)	1-16

Chapter 2. Programmer's Guide

Programming Your LS 2080 Scanner	2-1
Scanning Sequences	2-1
Scanning Sequence Examples	2-1
Errors While Scanning	2-2
Scanning Sequence Flowchart	2-3
Parameter Descriptions	2-4

Set Parameter Defaults	2-4
Keyboard Type	2-4
National Type (Europe)	2-4
Numeric Key Pad Emulation (Europe)	2-4
Break Key Code Transmission (Europe)	2-4
Code Types	2-5
Fixed Lengths for Code 2 of 5	2-5
Decode Options	2-5
Prefix	2-7
Suffix	2-7
Communications Delays and Timeouts (Intercharacter Delay)	2-7
Prefix/Suffix Transmit Delay	2-8
UPC A and E Preamble(s)	2-8
Scan and Store (Code 39 Buffering)	2-8
Transmit "No Decode" Message	2-9
Scan Data Transmission Format	2-9
Laser On Time	2-9
Parameter Selections	2-10
Beeper Definitions	2-12
Standard Use	2-12
Parameter Menu Scanning	2-12
Code 39 Scan and Store	2-12
Full ASCII Code 39	2-13
Code 39 Full ASCII	2-13
Standard Code 39	2-13
Prefixes and Suffixes	2-14
Selecting a Prefix and Suffix	2-14
Code 39 Buffering (Scan and Store)	2-15
Buffer Data	2-15
Clear Transmission Buffer	2-15
Transmit Buffer	2-16
Overfilling Transmission Buffer	2-16
Attempt to Transmit an Empty Buffer	2-16
Parameter Menus	2-17
Set Default Parameter	2-18
Keyboard Type	2-19
National Type (Europe)	2-21
Numeric Key Pad Emulation (Europe)	2-23
Break Key Code Transmission (Europe)	2-24
Code Types	2-25
Fixed Lengths For A Code 2 of 5	2-27
Decode Options	2-29
Prefix/Suffix	2-31
Communications Delays and Timeouts	2-33

Prefix/Suffix Transmit Delay	2-35
UPC-E/UPC-A Preamble	2-37
Code 39 Scan and Store	2-39
Transmit “No Decode” Message	2-40
Scan Data Transmission Format	2-41
Laser On Time	2-42
Test Symbols	2-44

Appendix A.

LS 2080 Decode Zone.	A-1
Encoded Full ASCII Code 39 Characters and their Keyboard Output	A-2
Prefix and Suffix Keystroke Identifiers.	A-3
ASCII Character Set.	A-4
Keyboard Identifier Maps.	A-5

Glossary