

# Contents

## Chapter 1. User's Guide

Scanning Made Easy .....	1-1
Set Up .....	1-2
Unpacking .....	1-2
Connecting the Cable to the Scanner.....	1-2
LS 2050MX .....	1-2
LS 3050MX .....	1-2
Connecting the Scanner to a Portable Data Terminal. ....	1-3
Programming the System .....	1-3
Ready, Test, Scan .....	1-4
Aiming .....	1-5
Hold at an Angle .....	1-5
Scan the Entire Symbol .....	1-5
What If... ..	1-6
50MX Decode Zone .....	1-7
Maintenance .....	1-8
Factory Service .....	1-9
Symbol Support Center.....	1-10
Accessories .....	1-11
Required Accessories.....	1-11
Optional Accessories.....	1-11
Technical Specifications .....	1-12
Glossary.....	1-14

## Chapter 2. Programmer's Guide

Programming .....	2-1
Scanning Sequences.....	2-2
Errors While Scanning.....	2-2
Scanning Sequence Flow Chart .....	2-3
Set Parameter Defaults .....	2-4
POS Terminal Type .....	2-4
Code Types .....	2-4
Fixed Lengths For Code I 2 of 5 .....	2-5
Decode Options .....	2-5
Transmit UPC-E/UPC-A Check Digit .....	2-5
Decode UPC Only (Not EAN) .....	2-5
ITF-14/EAN-13 Conversion .....	2-5
Convert UPC-E to UPC-A.....	2-5
Beeper Enable/Disable .....	2-6
EAN Zero Extend.....	2-6

UPC A And E Preamble(s) . . . . .	2-6
Decode UPC/EAN Supplemental. . . . .	2-7
Scanstand/IntelliStand Time-out . . . . .	2-7
Laser On Time . . . . .	2-7
Beeper Definitions . . . . .	2-8
Standard Use. . . . .	2-8
Parameter Menu Scanning . . . . .	2-8
Default Table. . . . .	2-9
Parameter Menus. . . . .	2-10
Set Defaults . . . . .	2-11
POS Terminal Type . . . . .	2-12
Nixdorf 8812-200 . . . . .	2-12
ICL 9505/9507/9516/9518 . . . . .	2-13
NCR255/1255/2126-1120/2152/2154/2155/2157/2257/7000/7050/7051/7052/7820 . . . . .	2-13
NCR 7052. . . . .	2-14
Nixdorf 8812-200 . . . . .	2-15
Code Types . . . . .	2-16
Fixed Lengths For Code I 2 OF 5 . . . . .	2-18
Decode Options . . . . .	2-20
UPC-E/UPC-A Preamble . . . . .	2-22
UPC/EAN Supplementals Option . . . . .	2-24
Scanstand/IntelliStand Time-out . . . . .	2-25
Laser On Time . . . . .	2-27