

Contents

About This Manual

Notational Conventions	About-i
Related Publications	About-i
Service Information	About-i
Symbol Support Center.....	About-ii
Canada.....	About-ii
Europe	About-ii
Asia.....	About-ii

Chapter 1. Setting Up the LT 1810

Overview.....	1-1
Set Up.....	1-2
Unpacking.....	1-2
Connecting Your LT 1810.....	1-2
External Power Supply	1-3
Battery Operation.....	1-3
Changing the Battery.....	1-4
Recharging a Nickel-Cadmium Battery	1-4

Chapter 2. Scanning with the LT 1810

Scanning	2-1
LT 1810 Decode Zone	2-2

Chapter 3. Maintenance and Specifications

Maintenance	3-1
What If... ..	3-1
Accessories	3-2
Standard Accessories.....	3-2
Technical Specifications	3-4
LT 1810 Dimensions.....	3-5
LT 1810 Signal Descriptions	3-6

Chapter 4. Programming the LT 1810

Scanning Sequences.....	4-1
Errors While Scanning.....	4-2
Scanning Sequence Flowchart	4-3
Parameter Descriptions.....	4-4
Set Parameter Defaults	4-4

Code Type Selection	4-4
Fixed Lengths for Code 2 of 5	4-4
Decode UPC Only	4-4
Decode UPC/EAN Supplementals	4-5
Beep After Good Decode	4-5
Beeper Volume	4-5
Trigger Mode (for triggered models only)	4-5
Decode Redundancy	4-6
Variable Leading Margin	4-6
Controller Type	4-6
Wand Emulator	4-6
Convert All to Code 39	4-6
Parameter Selections	4-7
Beeper Definitions	4-8

Chapter 5. Parameter Menus

Set Default	5-1
Code Types	5-2
Fixed Lengths For Code 2 of 5	5-5
Decode UPC Only	5-9
UPC/EAN Supplementals Option	5-11
Beep After Good Decode	5-13
Beeper Volume	5-15
Trigger Mode (for triggered models only)	5-17
Decode Redundancy	5-19
Variable Leading Margin	5-21
Controller Type	5-25
Wand Emulator	5-27
Convert All to Code 39	5-29

Glossary