



Chapter 2

Scanning with the LT 1810

Scanning

- Make sure the scanner is connected to the controller or portable data terminal before you turn on the system.
- Make sure the symbol you want to scan is within the LT 1810 scanning range. (See *LT 1810 Decode Zone* on page 2-2.)
- If the scanner is in triggerless mode, simply bring the scanner to the bar code. The scan beam is in a constant blinking state which becomes steady when the scanner is decoding a bar code.
- If the scanner is in triggered mode, bring the scanner to the bar code and press the trigger. The scan beam (and red LED on the top of the scanner) illuminates for approximately 1 second, or until a successful decode.
- The scan beam must cross every bar and space on the symbol.

RIGHT



WRONG



- When the symbol has been decoded, you will hear a short, high-tone beep, and the green decode LED will light.

LT 1810 Decode Zone

