



Chapter 2

Scanning with the LT 1850

Scanning

- Make sure connections are secure and the symbol you want to scan is within the scanning range. (See *LT 1850 Decode Zone* on page 2-2.)
- Simply bring the scanner to the bar code. The scan beam is in a constant blinking state, which becomes steady when the scanner is decoding a bar code.
- The scan beam must cross every bar and space on the symbol.

RIGHT



WRONG



- When the scanner has read the symbol, you will hear a short high tone beep, and the green decode LED will light.

LT 1850 Decode Zone

