

Contents

About This Manual

Notational Conventions	About-i
Related Publications	About-i
Service Information	About-i
Symbol Support Center.....	About-ii
Canada.....	About-ii
Europe	About-ii
Asia.....	About-ii

Chapter 1. Setting Up the LT 1850

Overview.....	1-1
Set Up.....	1-2
Unpacking.....	1-2
Connecting Your LS 1850	1-2

Chapter 2. Scanning with the LT 1850

Scanning	2-1
LT 1850 Decode Zone	2-2

Chapter 3. Maintenance and Specifications

Maintenance	3-1
What If... ..	3-1
Accessories	3-2
Technical Specifications	3-4
LT 1850 Dimensions.....	3-5
LT 1850 Signal Descriptions.....	3-6

Chapter 4. Programming the LT 1850

Scanning Sequences.....	4-1
Scanning Sequence Flowchart	4-2
Parameter Descriptions.....	4-3
Set Parameter Defaults	4-3
POS Terminal Type	4-3
Code Types	4-3
Fixed Lengths for Code I 2 of 5	4-4
Decode Options	4-4
UPC A and E Preamble(s).....	4-5
Decode UPC/EAN Supplementals.....	4-5

Beep After Good Decode	4-6
Beeper Volume	4-6
Trigger Mode (for triggered models only)	4-6
Decode Redundancy	4-6
Parameter Selections	4-7
Beeper Definitions	4-8

Chapter 5. Parameter Menus

Set Default	5-1
POS Terminal Type	5-2
Terminal: Nixdorf 8812-200	5-3
Terminal: ICL 9505/9507/9516/9518	5-3
Terminal: NCR255/1255/2126-1120/2152/2154/2155/2157/2257/7000/7050/7051/7052/ 7820	5-4
Terminal: NCR 7052	5-4
Terminal: Nixdorf 8812-200	5-5
Code Types	5-6
Fixed Lengths For Code I 2 of 5	5-9
Decode Options	5-13
UPC-E/UPC-A Preamble	5-16
UPC/EAN Supplementals Option	5-18
Beep After Good Decode	5-20
Beeper Volume	5-22
Trigger Mode (for triggered models only)	5-24
Decode Redundancy	5-26

Glossary