

# Index

---

## A

AC Adapter. . . . . 6-4, 9-3  
Accessories . . . . . 1-4  
    Antenna . . . . . 1-4  
    Battery Packs. . . . . 1-4  
    Cradles. . . . . 1-4  
    Keyboard Interface Cable . . . . . 1-5  
    PCMCIA cards . . . . . 1-5  
    Pen . . . . . 1-5  
    Power Supplies. . . . . 1-4  
    RS-232 Cable . . . . . 1-5  
Adjusting the Backlight. . . . . 9-6  
Adjusting the Display . . . . . 9-5  
API for extended memory management 11-7  
API for memory management . . . . . 11-7  
API supported by EMS . . . . . 11-10  
API, for XMS . . . . . 11-7  
application programming interface (API) 11-7  
AUTOEXEC.BAT 5-5, 6-2, 7-1, 7-4, 8-1, 8-10  
    DOS settings . . . . . 5-5

## B

Backlight Brightness . . . . . 8-8, 8-9  
Backlight Timer . . . . . 8-7, 8-9  
Base Memory . . . . . 8-5  
Battery  
    Charging Outside the Terminal. . . 10-4  
    Charging the Backup. . . . . 10-6  
    Charging using the Terminal. . . . 10-3  
    Cleaning. . . . . 10-8  
    Removing from the Terminal. . . . 10-4  
Battery Charge Lights . . . . . 3-13  
Binary Compressed . . . . . 6-9

Booting the Terminal . . . . . 8-10, 9-4  
Burning ROM Disk Image . . . . . 6-1  
Buzzer Volume . . . . . 8-8, 8-9

## C

Cables  
    Keyboard Interface . . . . . 1-5  
    RS-232 . . . . . 1-5, 6-1  
    Subminiature . . . . . 9-11  
Calibration . . . . . 8-2  
call . . . . . 8-9  
Card Services . . . . . 4-10  
    client driver . . . . . 4-10  
    system resources . . . . . 4-10  
Card Services (PCMCS.EXE) . . . . . 4-10  
Card Services, PCM Plus . . . . . 4-6  
Charging the battery in terminal . . . . 10-3  
Charging the Battery outside the terminal 10-4  
CIC's Handwriter Recognition System . B-1  
Cleaning the Battery . . . . . 10-8  
Client driver . . . . . 4-10  
Clients, PCM Plus . . . . . 4-6  
COM Interrupts (/MIRQ=n,...) . . . . 4-12  
COM Ports (/COM=n,...) . . . . . 4-12  
COM1ON . . . . . 11-5  
COM1ON.COM. . . . . 11-4  
Comm Light . . . . . 3-13  
command line parameters, PCCEMM. 11-8  
Compressed Hex . . . . . 6-9  
CONFIG.SYS . . . . . 5-1  
    DOS settings. . . . . 5-2  
CONFIG.SYS file . . . . . 11-7  
CPU Speed . . . . . 8-5

Cradle.....	6-9
Connecting Power .....	3-5
Getting Started .....	3-1
Host Communications.....	3-12
Indicator Lights .....	3-13
Inserting the Terminal.....	3-9
Interconnecting.....	3-7
Locking Mechanism.....	3-10
Operating .....	3-7
Parts of.....	3-2, 3-3
recharging terminal's battery .....	10-1
removing the terminal.....	3-11
Terminator Plug.....	3-7, 3-8
Unpacking.....	3-1
Wall and Desk Mounting .....	3-4
Cradle Problems.....	12-4

<b>D</b>	
Default ROM Disk .....	6-2
DISKCFG.....	6-1, 6-3
DISKCFG.EXE .....	6-7
Diskette .....	8-5
Diskette A .....	8-5
DOS Configuration Files	
PCCEMM.SYS.....	5-1
DOS configuration files	
AUTOEXEC.BAT.....	5-5
CONFIG.SYS.....	5-1
edits .....	5-1
HIMEM.SYS .....	5-1
DOS device drivers	
ANSISYS.....	5-4
DISPLAY.SYS .....	5-4
RAMDRIVE.SYS.....	5-4
SETVER.EXE.....	5-4
SMARTDRV.EXE.....	5-4
DOS settings .....	5-5
DOS=HIGHused to load MS-DOS into high memory	
11-11	
DSKACHK.COM .....	11-3
DSKBCHK.COM .....	11-3


<b>E</b>	
editing DOS settings.....	5-2
EMS memory .....	11-11
Extended Memory.....	8-5
extended memory manager (XMM) . . .	11-7
eXtended Memory Specification (XMS), ver. 2.0	
11-7	

<b>F</b>	
F8680 PC/CHIP.....	11-8
Floppy Drive Emulator (PCMFDD.EXE)4-14	

<b>H</b>	
HEX2TERM .....	6-1, 6-4, 6-5, 6-6
HEX2TERM.EXE .....	6-8
HIDOS.SYS.....	11-7
HIDOS.SYS , installation .....	11-7
high memory area (HMA).....	11-7
HIMEM.SYS device driver.....	5-1
HMA (high memory area) .....	11-7
Host Communications .....	3-12

<b>I</b>	
IC card.....	4-1
Idle and Suspend.....	8-6
Indicator Lights .....	3-13
Battery Charge.....	3-13
Terminal Charge .....	3-13
Information Utility, PCM Plus .....	4-6
Initial Program Loader (IPL).....	6-9
Installing PCMCIA Cards on the PPT 41xx4-2	
Intel Hex.....	6-9
Interrupt 0x67 .....	11-10
Inverse Video.....	8-6
IPL .....	6-1, 6-5, 6-9, 6-10

<b>K</b>	
Keyboard .....	7-1, 9-11
attaching to terminal.....	9-11



# Index

---

- L**
- LCD Contrast ..... 8-8, 8-9, 9-5
  - LEFTSW.COM ..... 11-2
  - LIM XMS 2.00 ..... 11-7
  - Lithium Back-up Battery ..... 10-6
  - Locking Mechanism. .... 3-10
  - Lotus-Intel-Microsoft Extended Memory Specification  
11-7
- M**
- Manual Structure ..... ix
  - Memory Management. .... 4-14, 4-18
  - Modem Point Enabled  
    invoking the TSR ..... 4-16
  - Modem Point Enabler (MODEMPE.EXE) 4-15
  - MPE (Modem Point Enabler) ..... 4-15
  - MS-DOS 5.0. .... 11-7
  - MS-DOS device drivers. .... 5-4
- N**
- NET.CFG ..... 5-9
  - Non-Card-Services PCMCIA Utilities .. 4-7
  - NOSYS ..... 11-6
  - Null Modem Cable ..... 6-6
- P**
- PC card ..... 4-1
  - PC Card Configuration Address (/ADDR=xx)  
4-11
  - PC Card Events (/POLL) ..... 4-11
  - PC/CHIP Advanced Features ..... 8-5
  - PCCEMM command line parameters .. 11-8
  - PCCEMM.SYS ..... 11-7
  - PCCEMM.SYS , installation alternatives 11-11
  - PCCEMM.SYS , installed without HIDOS.SYS  
11-11
  - PCCEMM.SYS device driver ..... 5-1
  - PCCEMM.SYS, installation ..... 11-8
  - PCCEMM.SYS, installed with HIDOS.SYS 11-11
  - PCM Plus Files and SDK directories ... 4-7
  - PCM Plus Information Utility (PCMINFO.EXE)  
4-8
  - PCM Plus Services. .... 4-5
  - PCM Plus software ..... 4-6
  - PCM Plus software components ..... 4-8
  - PCMATA.SYS ..... 4-13
  - PCMCIA ..... 7-1, 7-4, 8-5, 12-2
    - Hot Removal and Insertion ..... 4-5
    - Installing ..... 4-2
    - Removing ..... 4-4
  - PCMCIA (Personal Computer Card International Assn.) ..... 4-1
  - PCMCIA ATA Fixed-Disk Support Driver 4-13
  - PCMCIA Card Utilities, non-card-services 4-7
  - PCMCIA Cards ..... 1-5
  - PCMCIA Cards supported on the PPT 4100/4110  
4-6
  - PCMCIA cards, Type II socket on PPT 4100/4110  
4-1
  - PCMCS DEVICE Statement Options .. 4-10
  - PCMCS.EXE (Card Services) .... 4-10, 4-17
  - PCMINFO screen ..... 4-8
  - PCMINFO Switch Options ..... 4-8
  - PCMINFO, PCM Plus information utility 4-6

PCMINFO.EXE.....	4-8
PCMSCD (Phoenix Super Client Driver) 4-6	
PCMSCD DEVICE Statement Options .4-12	
PCPLUS.....	11-5
Pen .....	9-8
replacing in port.....	9-10
using to select.....	9-9
using to write .....	9-10
PENMS46T.EXE.....	5-7
Personal Computer Memory Card International Association (PCMCIA) .....	4-1
Phoenix Super Client Driver (PCMSCD) 4-6	
Phoenix Super Client Driver (PCMSCD.EXE)4-11	
PhoenixCARD Manager Plus (PCM Plus)4-5	
Power	
Adapter .....	9-3
terminal .....	9-2
Power Management.....	8-6
Disabled.....	8-6
Idle and Suspend .....	8-6
PPT 4100 Advanced Feature Controls ..	8-7
PPT 4100/4110	
Accessories .....	1-1
Parts of.....	1-2, 1-3
power.....	9-2
Printing .....	3-12
Publications	
Related.....	x


## R

RAD2NCU.EXE .....	11-2
Rebooting .....	7-4
Recharging the battery .....	10-1, 10-2
Related Publications .....	x
Resetting the Terminal .....	9-4
RIGHTSW.COM.....	11-2
ROM Disk .....	6-7, 7-1, 7-5
Default image .....	6-2
Requirements for burning .....	6-1
Set-up.....	6-2

Transferring .....	6-4
--------------------	-----

## S

Scanning .....	9-7
SCN1D46T.EXE.....	5-7
SDK .....	1-6
for DOS .....	2-1
Serial Cable Pinouts .....	A-1
SETUP.COM	
Backlight Brightness .....	8-8
Backlight Timer .....	8-7
Base Memory .....	8-5
Boot Sequence .....	8-8
Buzzer Volume .....	8-8
CPU Speed .....	8-5
Exit Menu .....	8-3
Extended Memory.....	8-5
Fields.....	8-3
Inverse Video.....	8-6
LCD Contrast.....	8-8
Next Page .....	8-3
Next Value .....	8-4
options .....	8-3
PC/CHIP Advanced Feature Controls8-5	
Power Management .....	8-6
PPT 4100 Advanced Feature Controls8-7	
Prev. Value.....	8-4
running .....	8-1
Socket 1 .....	8-5
Socket 2 .....	8-5
Suspend Timeout .....	8-7
System Date .....	8-5
System Time.....	8-5
Video Card.....	8-5
SLEEPOFF .....	11-5
SLEEPOFF.COM .....	11-4
Socket Services.....	4-10
Socket Services, PCM Plus.....	4-6
Software Developer's Kit .....	6-3, 11-1
Software Development Kit.....	4-7
software development kit .....	1-6



# Index

---

Software Development Kit (SDK) . . . . . 4-5  
software installation  
    DOS . . . . . 2-2  
Spectrum24  
    configuration file edits . . . . . 5-9  
    ODI installation . . . . . 5-10  
Spectrum24 Radio Terminals . . . . . 1-6  
SRAM Card . . 6-10, 7-5, 7-6, 9-11, 11-3, 11-4  
    booting from . . . . . 8-5  
    Copying Files . . . . . 7-4  
    Formatting on PC . . . . . 7-2  
    Formatting on Terminal . . . . . 7-1  
    Loading software using . . . . . 7-1  
    Running Applications . . . . . 7-4  
SRAM Cards . . . . . 8-10  
SRAMFORM.EXE . . . . . 7-5  
Standard Intel Hex . . . . . 6-9  
Standard System Parameters . . . . . 8-2  
Start Address, PCMCIA card configuration 4-11  
stylus . . . . . 9-8  
Stylus(Pen . . . . . 1-5  
Subminiature Cable . . . . . 9-11  
SunDisk AT Attachment driver (SDATA41.SYS)  
    4-17  
Super Client Driver (PCMSCD.EXE) . . 4-11  
Suspend Timeout . . . . . 8-7  
Suspend Timer . . . . . 8-9  
Suspending and Resuming Terminal . . 9-1  
SUSPOFF . . . . . 11-5  
SUSPOFF.COM . . . . . 11-4  
Symbol TSRs  
    CRADL46T.EXE . . . . . 5-6

PENMS46T.EXE . . . . . 5-7  
SCN2D46T.EXE . . . . . 5-7  
Symbol-Supplied Network Configuration Files  
    5-9  
    NET.CFG . . . . . 5-9  
System Date . . . . . 8-5  
System Time . . . . . 8-5

## T

### Terminal

Adjusting the Backlight . . . . . 9-6  
Adjusting the Display . . . . . 9-5  
Booting . . . . . 8-10, 9-4  
Charging the Battery in . . . . . 10-3  
Cleaning . . . . . 10-7  
Environment . . . . . 10-7  
Parts of . . . . . 1-2, 1-3  
Power . . . . . 9-2, 9-3  
rebooting . . . . . 6-6  
Resetting . . . . . 9-4  
Resume . . . . . 9-11  
Scanning . . . . . 9-7  
Set-Up . . . . . 8-1  
Storage . . . . . 10-8  
Suspend . . . . . 9-11  
Suspending and Resuming . . . . . 9-1  
terminal  
    before you use it for the first time . . 1-7  
Terminal Charge Light . . . . . 3-13  
Terminal Problems . . . . . 12-2  
Terminator Plug . . . . . 3-7, 3-8  
Transparent Mode Hex . . . . . 6-9  
Troubleshooting

Cradle Problems.....	12-4
Terminal Problems.....	12-2
TSR, Symbol Supplied.....	5-5

## U

UMB (upper memory block) .....	11-7
upper memory block (UMB) .....	11-7

### Utilities

COMION.COM .....	11-4
DISKCFG.....	6-1, 6-3
DISKCFG.EXE .....	6-7
DSKACHK.COM .....	11-3
DSKBCHK.....	11-3
HEX2TERM.....	6-1, 6-4, 6-5, 6-6
HEX2TERM.EXE .....	6-8
IPL .....	6-1, 6-9, 6-10
LEFTSW.COM .....	11-2
NOSYS.....	11-6
RIGHTSW.COM.....	11-2
SLEEPOFF.COM .....	11-4
SRAMFORM.EXE .....	7-5
SUSPOFF.COM .....	11-4
XSYMRST .....	11-5

## V

Video Card .....	8-5
------------------	-----

## X

XMM (extended memory manager) ...	11-7
XSYMBIOS .....	8-9, 11-4, 11-5
Backlight Timer .....	8-9
Buzzer Volume.....	8-9
LCD Contrast .....	8-9
Suspend Timer .....	8-9
XSYMRST .....	11-5
XSYMRST.COM.....	11-5