

Contents

About This Manual

- Introduction
- Manual Structure
- Related Publications

Chapter 1. Getting Started

- Introduction
- Unpacking the Terminal
- The Parts of the PPT 41xx
- Accessories
 - Battery Packs
 - Cradles
 - Power Supplies
 - Antenna
 - Keyboard Interface Cable
 - RS-232 Cable
 - Stylus (Pen)
 - LCD Overlay
 - PCMCIA Cards
 - PPT 4140 Spectrum24 Radio Terminals
 - SDK
- Before You Use the Terminal
 - Install and Charge Battery
 - Configure the Terminal

Chapter 2. Software Installation on the Development PC

- Introduction
- Installing the SDK
- Network Development Kit (NDK)
- DOS

Chapter 3. Cradle Hardware Installation

- Introduction
- Getting Started
 - Unpacking the CRD 4100-101X
 - The Parts of the CRD 4100-101X
 - Wall and Desk Mounting the CRD 4100-101X
- Operating the CRD 4100-101X
 - Connecting to Other Cradles
 - Connecting to Other Devices

- Placing the Terminal in Cradle
- Using the Locking Mechanism
- Printing or Sending Data to the Host Computer
- Indicator Lights

Chapter 4. Configuring the Terminal: PCMCIA Card Services

- Introduction

 - PCMCIA Cards

- Installing PCMCIA Cards on the PPT 41xx

- Removing PCMCIA Cards

 - Notes on PCMCIA Card Removal and Insertion

- PCM Plus Services on the PPT 41xx

 - PCMCIA Card Utilities That Do Not Use Card Services

- PCM Plus Software Components/Drivers

 - Installation

 - PCM Plus Software Components

 - Memory Management

- Non-Card Services PCMCIA Utilities

 - Installation

 - Modem Point Enabler

 - Memory Management

Chapter 5. Configuring the Terminal: Edit the Configuration Files

- Introduction

 - CONFIG.SYS

 - AUTOEXEC.BAT

 - Symbol-Supplied TSRs

 - Symbol-Supplied Network Configuration Files

 - Spectrum24 Software: Edit & Installation Summary

Chapter 6. Configuring the Terminal: Build and Send the Hex Image

- Introduction

- Burning a ROM Image Via RS-232 Cable Connection

 - Requirements for Burning the ROM Disk Image

 - Utilities

 - Setting Up the ROM Image

 - Transferring the ROM Disk Image Hex File to the PPT 41xx

- DISKCFG.EXE

- HEX2TERM.EXE

- Initial Program Loader (IPL)

Chapter 7. Configuring the Terminal: Setting Up PCMCIA Cards

- Introduction

- Loading Software into the Terminal via an SRAM Card

- Formatting an SRAM Card on the PPT 41xx Terminal
- Formatting a PCMCIA Card using a PC
- Copying Files to an SRAM Card
- Running an Application on the Terminal from an SRAM Card
- SRAMFORM.EXE

Chapter 8. Configuring the Terminal: Terminal Setup

- Introduction
- Terminal Set-Up
 - Running SETUP.COM
 - Overriding Default Parameters in XSYMBIOS
- Booting the Terminal

Chapter 9. Operating the PPT 41xx

- Introduction
- Suspending and Resuming the Terminal
 - Suspending and Resuming While Maintaining the Network Connection
- Providing Power to the Terminal
- Booting the Terminal
- Adjusting the Display
 - Adjusting the Backlight
- Scanning
- Using the Pen
 - Using the Pen to Select an Item
 - Using the Pen to Perform Handwriting
 - Replacing the Pen
 - LCD Overlay
 - Using a Keyboard

Chapter 10. Maintenance

- Introduction
- Recharging the Terminal's Battery in the Cradle
- Recharging the Battery Pack
- Charging the Battery in the Terminal
- Charging the Spare Battery and Terminal in the Cradle
 - Charging the Battery Outside of the Terminal
 - The Lithium Back-up Battery
- Environment
- Cleaning the Terminal
- Cleaning the Battery
- Storage

Chapter 11. Utilities

- Introduction

RIGHTSW.COM
LEFTSW.COM
DSKACHK.COM
DSKBCHK.COM
COMION.COM
SLEEPOFF.COM
SUSPOFF.COM
XSYMRST.COM
NOSYS.COM
HIDOS.SYS XMS
PCCEMM.SYS EMS

Chapter 12. Error Messages and Troubleshooting

Introduction

Error Messages

Troubleshooting

Terminal Problems

Cradle Problems

SRAM Card Problems

Appendix A. Serial Cable Pin Outs, Memory Map, I/O Ports, & IRQ Usage

Appendix B. Handwriter Recognition System

Introduction

PPT 41xx Glossary of Terms

Index.