Contents

Chapter 1. User's Guide

Scanning Made Easy 1-1
Unpacking 1-2
Connecting Your LS 5300 1-3
Accessories 1-3
Mounting 1-4
Turning the Scanner On 1-5
LS 5300 Indicators 1-6
    LEDs 1-6
    Beeper 1-6
Programming 1-7
    Scanning Sequence Examples 1-7
    Errors While Scanning 1-7
Setting Parameters 1-8
    Host Types and Options 1-8
    Code Types & Options 1-8
    Custom Tailoring 1-8
    Decode Options 1-9
    Data Transmission Formats 1-10
    RS-232 Port Auxiliary Options 1-10
    Programming Utilities 1-10
Beeper Definitions 1-11
    Standard Use 1-11
    Parameter Menu Scanning 1-12
    Serial Communication 1-12
What If... 1-13
Maintenance 1-14
Factory Service 1-15
Symbol Support Center 1-16
Technical Specifications 1-17

Chapter 2. Parameter Menus

Set Default Parameter 2-4
Default Table. 2-5
Host Types & Options 2-11
Single Port RS-232C Host Options. 2-13
Baud Rate. 2-17
Parity 2-25
Check Parity 2-30
Hardware Handshaking 2-32
Software Handshaking 2-39
Serial Response Time-out 2-44
Stop Bit Select 2-45
ASCII Format 2-47
Serial Host RTS Line State. 2-49
Beep on <BEL> 2-51
Code Types & Options 2-53
Enable UPC-A. 2-53
Enable UPC-E 2-55
Enable EAN-8 2-57
Enable EAN-13 2-59
Decode UPC/EAN Supplementals 2-61
Enable Code 128 2-64
Enable UCC/EAN-128 2-66
Lengths for Code 128. 2-68
Enable Code 39 2-69
Enable/Disable Code 39 Full ASCII 2-71
Set Lengths for Code 39. 2-74
Code 39 Check Digit Verification. 2-78
Enable Interleaved 2 of 5. 2-80
Set Lengths for Interleaved 2 of 5 2-82
Enable Codabar 2-86
Set Lengths for Codabar 2-88
Enable CLSI Editing. 2-92
Enable NOTIS Editing 2-94

Custom Tailoring 2-97
Scanning Range 2-97
Enable Internal Beeper. 2-100
Enable Host Port External Beeper 2-102
Enable RS-232 Port External Beeper 2-104
Beeper Volume 2-106
Beeper Frequency. 2-109
Time-out Between Decodes, Same Symbol 2-112
Time-out Between Decodes, Different Symbols . 2-113
Enable Decode Buffering. 2-114
Time Delay to Sleep Mode 2-116
Primary Decode Session Time 2-120
Decode Options 2-121
UPC/EAN Predecode Block. 2-121
UPC/EAN Security Level. 2-123
Enable Linear UPC/EAN Decode 2-127
Decode Redundancy for UPC/EAN 2-129
Enable UPC/EAN Decode Performance 2-130
Linear Code Type Security 2-135
Enable Code 128 Decode Performance 2-139
Enable Code 39 Decode Performance 2-144
Data Transmission Format 2-149
Transmit UPC-A Check Digit. 2-149
Transmit UPC-E Check Digit 2-151
UPC-A Preamble 2-153
UPC-E Preamble. 2-156
Convert UPC-E to UPC-A. 2-159
EAN Zero Extend. 2-161
Beep After Good Decode. 2-163
Intercharacter Delay. 2-165
Transmit Code ID Character. 2-166
Transmit AIM Code ID Character 2-167
Transmit No Code ID Character 2-168
Pause Duration 2-169

Prefix / Suffix Values 2-170
Scan Data Transmission Format 2-174
Serial Data Transmission Format. 2-179
Ignore Unknown Characters 2-184
Data Format Cancel 2-186
RS-232 Port Auxiliary Options. 2-187
Baud Rate. 2-188
Parity 2-196
Check Parity 2-201
Hardware Handshaking 2-203
Software Handshaking 2-207
Serial Response Time-out 2-209
Stop Bit Select 2-210
ASCII Format 2-212
Auxiliary RTS Line State 2-214
Programming Utilities. 2-217
Numeric Bar Codes 2-217
Cancel. 2-227
Enter 2-228
Applications Items 2-229

Appendix.

UCC / EAN-128 . . . . . A-1
AIM Code Identifiers. A-4