

# CPT-7xx Keyboard Wedge Cable Connection Guide

1. This package includes the following:
  - (1) a keyboard wedge(KB) cable
  - (2) a terminator
  
2. Connection Guide
  - (1) Connect the KB cable between your host and keyboard. (Plug the male din connector into the keyboard port of the host and the female din connector into the male connector of keyboard cable.)
  - (2) Plug the black male connector into the terminator for normal keyboard entry.



<Fig.1>

- (3) If you need to upload/download the data from/to the CPT-7xx terminal, just pull out the black male connector from the terminator and then plug it into the CPT-7xx terminal.<Fig.2>



<Fig.2>