Zebex Z-1070 & Z-1071 Portable Data Terminal User Manual

OVERVIEW



Installing and charging battery



Figure 2: Inserting Batteries

Press the battery cover lock to remove the cover.

Insert batteries according to the orientation in the picture

Replace the cover and lock it back.

Charging Batteries

M W

Warning!

Use the Power Adapter with NiMH batteries ONLY! Connecting the Power Adapter with any other type of batteries in the PDC voids the warranty, ruins batteries, can burn up the Personal Data Collector, and could possibly cause harm to persons or property! You may use regular disposable alkaline cells to operate the PDC, but never mix NiMH with alkaline batteries, and never connect the Power Adapter when there are disposable (alkaline) batteries in the unit.

To charge NiMH batteries:

1. With NiMH rechargeable batteries (ONLY!) in the PDC unit, connect PDC with the Communication Cable.

2. Plug the Power Adapter connector into the socket on the side of the large end connector of the Communication Cable.

3. Plug the Power Adapter into an outlet. While charging, the LED on the PDC lights up red. The LED turns off when the batteries are fully charged. Charging takes 3 to 5 hours.



Figure 3: Connecting the Power Adapter

It is normal that the Power Adapter and the NiMH battery cells become warm during charging.

Note:

If needed, when NiMH batteries are low, the PDC may be operated with the Power Adapter connected. Never use the Power Adapter with other types of batteries inside the PDC unit!

Store Data



Show Barcode (View barcode in memory)



Check Barcode (Only display Barcode, will not save into memory)



Clear Data (Delete ALL data in memory)



Upload Data to Computer

SCANNER

1. Press **FN** several time until returns to Memory Screen.



2. Connect cradle and adapter as figure bellow.

Computer

- 1. Download WintaskGen & Install in http://www.manicon.com/download/driver.htm#terminal
- 2. If usage USB-Serial Converter Cable, Download Drivers http://www.manicon.com/download/driver/Zebex CP210x VCP Win2K XP S2K3 v5 1.zip

After Install Driver, go to Device Manger Check Usage com port



3. Start \rightarrow Programs \rightarrow WinTaskGen \rightarrow WinTaskGen

📲 WinTasl	kGen		
	7 1 1	In X 1mm 🤣	
	Reo Nr Setti	ng	
G Communication S	etting	Beep Volume	Loud 💌
Com Port	COM3 🗸	Power Up Scan	On
Baud rate	9600 💌	Communication Device Date Format	IR • MM/DD/YY •
Parity	None 👻	AUX Scaner	
Data bit	8 💌	AUX. Device	
Stop bit	1 🔽	Date 2008 10 09 Time 10 10 02	Auto Set
<u>0</u> K	Cancel		Set

Com Port Default Setting: Com1,9600,None,8,1 Change setting of Data Terminal

4. Select Upload Data

📲 WinTaskGen			
V 📬 🀴	📸 🎻 🕅 📶	<i></i>	
	-		

5.		
WinTaskGen - [Upload Da		
*		_ & ×
🕑 🧊 🀴 👬	A 🕆 📶 🧇	
Form Name		
DATAFORM Records 3 00003 Fields 3	DV00007,100908,100540 EP00003,100908,100541 EP00005,100908,100543	
File Header		
🗖 Upload & Delete Data	Communication Uti	
Show Data		
Field Delimiter ,(2CH) -	Upload Finished!	
Rec. Delimiter CR/LF 💌		
Upload	確定	
Connect		
Stop		
Save		
Upload Data COM	3, 9600,N, 8,1	<i>5</i> .

- 5.1 Click Connect
- 5.2 Select DATAFORM in the list box
- 5.3 Chick Upload
- 5.4 After Upload finish, chick **Save** to save as a Text (.TXT) file

