


16 cm

Introduction

Front View




- 1. Port Selection Switches**
 - Press a switch to access the computer attached to the corresponding port.
 - Pressing Buttons 1 and 2 simultaneously for 3 seconds performs a Keyboard and Mouse reset
 - Pressing Buttons 7 and 8 simultaneously starts Auto Scan Mode. To exit Auto Scan, simply press the Spacebar
- 2. Ports LEDs**
 - On Line: Lights ORANGE to indicate that the computer attached to the corresponding port is up and running.
 - Selected: Lights Green to indicate the current selected port. The LED is steady under normal conditions, but flashes when its port is accessed under Auto Scan mode.
- 3. Reset Switch**

To reset the KVM, use a thin object to press this recessed switch in to initiate a warm reset. If the switch is kept in for longer than three seconds, a cold reset takes place.
- 4. Power LED**

Lights to indicate that the KVM is receiving power.

Back View



- 1. Console ports**

Connect the cables from your VGA monitor, and PS/2 keyboard and mouse to these ports.
- 2. CPU ports**

Plug in the KVM cables into these ports and the other end of the cable to your computers. The IOGEAR part number for the cables are:

 - G2L5002P for 6' cables
 - G2L5003P for 10' cables
- 3. Power Jack**

The power adapter plugs into this jack.

Set up & Installation


Step. 1

- Power On the KVM Switch**
- Plug in the power adapter into a power outlet and the other end to the power jack on your KVM switch

- Console Connection (located on the rear of the GCS78)**
- Connect your monitor VGA cable into the video port of console section.
 - Plug your PS/2 mouse and PS/2 keyboard into their designated ports on the console side.

Installation

- CPU Port Connection**
- Plug in the PS/2 mouse and keyboard connectors to the PS/2 ports on your computer. Typically, your PS/2 ports on the computer will be color-coded to identify keyboard (purple) and mouse (green) port.
 - Plug in the Video connector to the VGA port on your computer.



Step. 2

Basic Operation

- Port Switching
There are two ways to access the computers in your KVM setup:
- Manual switching – pressing the push-buttons on the unit's front panel
 - Hotkey switching – entering commands from the keyboard

Manual Switching

- Press and release a port selection switch to bring the KVM focus to the computer attached to its corresponding port.
- Press button switches 7, 8 simultaneously to initiate Auto Scanning the ports on the KVM. To quit Auto Scan, simply press the Spacebar.
- Press button switches 1, 2 simultaneously to perform a soft reset of the KVM.

Hotkey Operation

The GCS78 provides an easy-to-use hotkey function that makes it convenient to control your KVM installation from the keyboard.

Port Switching:

- Press [Ctrl] + [Shift] + [Alt] to invoke the hotkey function.
- Key in the desired Port ID number then press [Enter].

The Port ID number refers to the ports on the KVM and can be from 1 to 8.

For example, [Ctrl] + [Shift] + [Alt] + [4] + [Enter], will switch the KVM to port number 4.

**MiniView®
8-port PS/2 KVM Switch**
Quick Start Guide (GCS78)

IOGEAR
23 Hubble Drive
Irvine, CA 92618

866.946.4327
949.453.8785
Web-site: www.iogear.com
E-mail: info@iogear.com

Entire contents copyright © 2005 IOGEAR
All rights reserved. Reproduction in whole or in part without permission is prohibited. MiniView™ is a trademark of IOGEAR. All other trade marks are the property of their respective owners.
PKG-M0141/QS



Auto Scanning

- Press [Ctrl] + [Shift] + [Alt] to invoke hotkey function
- Key in [0] (zero) and then press [Enter]. This will invoke Auto Scanning. To quit Auto Scan, simply press the Spacebar.

NOTE:

- Press the keys in sequence - one key at a time. First [Ctrl], then [Shift], then [Alt].
- After invoking the hotkey function with the [Ctrl]+[Shift]+[Alt] combination, you must key in the Port ID and press [Enter] within 1 second for each key press; otherwise, Hotkey function will not work.

Congratulations!



Congratulations! You have completed installing the IOGEAR® KVM Switch.

MiniView® 8-port PS/2 KVM Switch

Quick Start Guide (GCS78)

