

N i C a d B a t t e r y P a c k

QRG

**NiCad Battery Pack
for
LS3064 Memory and LS3070 Cordless
Scanners**

symbol[®]

N i C a d B a t t e r y P a c k



© 1994 - 1998 **SYMBOL TECHNOLOGIES, INC.** All rights reserved.

Symbol reserves the right to make changes to any product to improve reliability, function, or design.

Symbol does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any patent right or patent, covering or relating to any combination, system, apparatus, machine, material, method, or process in which Symbol products might be used. An implied license only exists for equipment, circuits, and subsystems contained in Symbol products.

Symbol is a registered trademark of Symbol Technologies, Inc. Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Symbol Technologies, Inc.

One Symbol Plaza


Holtsville, N.Y. 11742-1300

<http://www.symbol.com>

Rechargeable Battery Pack Accessory for LS 3064 and LS 3070

Both the LS 3064 and LS 3070 have a rechargeable NiCad battery pack in the handle of the scanner. This provides all power to the scanner during normal operation. It provides 360 mA hours, which accommodates 12,000 1/2 second scans.

When fully depleted, the battery pack can be recharged on the Universal Four-Slot Charger/Recharger within 8 hours. However, the battery pack in the LS 3070 inserted into the RL 470 base/charger unit can be fully charged within 2 hours.



Rechargeable Battery Packs: LS 3064 and LS 3070



Battery Pack Removal / Installation

Removing Battery Pack from Scanner

Using a probe, press in the release button on the handle past the inside handle plastic (see the illustration on page 2). With the button pressed in, slide the battery pack down and out from the handle.

Refer to the ***Universal Four-Slot Battery Charger Quick Reference Guide*** (60116-00-82) for more information on the charger.

N i C a d B a t t e r y P a c k



Release Button on LS 3064 and LS 3070 Battery Packs

Installing Charged Battery Pack in Handle

With the release button down, slide the charged battery pack up into the handle until it locks into place and the release button pops up.

Battery Pack Assembly Numbers

Scanner (Color)	Assembly Number
LS 3070 (Dark Gray)	KT-11211-01
LS 3070 (Light Gray)	KT-11211-02
LS 3064 (Dark Gray)	KT-11212-01
LS 3064 (Light Gray)	KT-11212-02

I n s t a l l a t i o n I n s t r u c t i o n s

Service Information

Before you use a terminal, it must be configured to operate in your facility's network and run your applications.

If you have a problem with running your terminal or using your equipment, contact your facility's Technical or Systems Support. If there is a problem with the equipment, they will contact the Symbol Support Center:

1-800-653-5350

Outside North America, contact your local Symbol representative.

Warranty

Symbol products are warranted against defects in workmanship and materials for a period of one year from the date of shipment, provided that the product remains unmodified and is operated under normal and proper conditions.

This warranty is limited to repair or replacement at Symbol's option, with reasonable promptness after being returned to Symbol by a carrier selected and paid for by the customer. These provisions do not prolong the original warranty term for any product which has been repaired or replaced by Symbol.

This warranty applies to the original owner and does not extend to any product which has been subject to misuse, neglect, accidental damage, unauthorized repair or tampering. Preventive maintenance activities are not covered by warranty.

Patents

This product is covered by one or more of the following U.S. and foreign Patents:

U.S. Patent No. 4,360,798; 4,369,361; 4,387,297; 4,460,120; 4,496,831; 4,593,186; 4,603,262; 4,607,156; 4,652,750; 4,673,805; 4,736,095; 4,758,717; 4,816,660; 4,845,350; 4,896,026; 4,897,532; 4,923,281; 4,933,538; 4,992,717; 5,015,833; 5,017,765; 5,021,641; 5,029,183; 5,047,617; 5,103,461; 5,113,445; 5,130,520 5,140,144; 5,142,550; 5,149,950; 5,157,687; 5,168,148; 5,168,149; 5,180,904; 5,229,591; 5,230,088; 5,235,167; 5,243,655; 5,247,162; 5,250,791; 5,250,792; 5,262,627; 5,262,628; 5,266,787; 5,278,398; 5,280,162; 5,280,163; 5,280,164; 5,280,498; 5,304,786; 5,304,788; 5,306,900; 5,321,246; 5,324,924; 5,337,361; 5,367,151; 5,373,148; 5,378,882; 5,396,053; 5,396,055; 5,399,846; 5,408,081; 5,410,139; 5,410,140; 5,412,198; 5,418,812; 5,420,411; 5,436,440; 5,444,231; 5,449,891; 5,449,893; 5,468,949; 5,471,042; 5,478,998; 5,479,000; 5,479,002; 5,479,441; 5,504,322; 5,519,577; 5,528,621; 5,532,469; 5,543,610; 5,545,889; 5,552,592; 5,578,810; 5,581,070; 5,589,679; 5,589,680; 5,608,202; 5,612,531; 5,619,028; 5,664,229; 5,668,803; 5,675,139; 5,693,929; 5,698,835; 5,705,800; 5,714,746; 5,723,851; 5,734,152; 5,734,153; 5,745,794; 5,754,587; 5,762,516; 5,763,863; 5,767,500; 5,789,728; 5,808,287; 5,811,785; 5,811,787; 5,815,811; 5,821,519; 5,821,520; 5,823,812; 5,828,050; 5,850,078; 5,861,615; 5,874,720; 5,875,415; D305,885; D341,584; D344,501; D359,483; D362,453; D363,700; D363,918; D370,478; D383,124; D391,250; D405,077; D406,581.

Invention No. 55,358; 62,539; 69,060; 69,187 (Taiwan); No. 1,601,796; 1,907,875; 1,955,269 (Japan).

European Patent 367,299; 414,281; 367,300; 367,298; UK 2,072,832; France 81/03938; Italy 1,138,713.

rev. 4/99



70-11217-01
Revision C — May 1999